



Ruckus Wireless™ FlexMaster™ Release 9.8

SNMP Reference Guide

Part Number 800-70595-001 Rev A
Published July 2014

www.ruckuswireless.com

Copyright Notice and Proprietary Information

Copyright 2014. Ruckus Wireless, Inc. All rights reserved.

No part of this documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Ruckus Wireless, Inc. ("Ruckus"), or as expressly provided by under license from Ruckus.

Destination Control Statement

Technical data contained in this publication may be subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

THIS DOCUMENTATION AND ALL INFORMATION CONTAINED HEREIN ("MATERIAL") IS PROVIDED FOR GENERAL INFORMATION PURPOSES ONLY. RUCKUS AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THE MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE MATERIAL IS ERROR-FREE, ACCURATE OR RELIABLE. RUCKUS RESERVES THE RIGHT TO MAKE CHANGES OR UPDATES TO THE MATERIAL AT ANY TIME.

Limitation of Liability

IN NO EVENT SHALL RUCKUS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR DAMAGES FOR LOSS OF PROFITS, REVENUE, DATA OR USE, INCURRED BY YOU OR ANY THIRD PARTY, WHETHER IN AN ACTION IN CONTRACT OR TORT, ARISING FROM YOUR ACCESS TO, OR USE OF, THE MATERIAL.

Trademarks

Ruckus Wireless, Ruckus, the bark logo, ZoneFlex, FlexMaster, ZoneDirector, SmartMesh, ChannelFly, SmartCell, Dynamic PSK, and Simply Better Wireless are trademarks of Ruckus Wireless, Inc. in the United States and other countries. All other product or company names may be trademarks of their respective owners.

Contents

About This Guide

Related Documentation	4
Document Conventions	5
Documentation Feedback	6

1 Event MIBs

ruckusDeviceConnectivityProblemTrap	8
ruckusFMCPUUsageTrap	9
ruckusFMEventZDAdminUpgradeTrap	10
ruckusFMEventZDAdminRestartedTrap	11
ruckusFMEventZDAdminShutdownTrap	12
ruckusFMEventZDAPDeleteTrap	13
ruckusFMEventZDAPJoinTrap	14
ruckusFMEventZDAPLostTrap	15
ruckusFMEventZDAPLostHeartbeatTrap	16
ruckusFMEventZDSystemFailureRecovered	17
ruckusFMEventZDSystemStartupTrap	18
ruckusFMMiscEventTrap	19
ruckusStandaloneAPRebootTrap	20
ruckusStandaloneAPTransferCompleteTrap	21
ruckusStandaloneAPReconnectTrap	22
ruckusZDCPUUsageTrap	23
ruckusZDAPTrafficTrap	24
ruckusZDAPofclientsTrap	25
ruckusZDAPLostConnectionTrap	26
ruckusZDAPChannelChangeTrap	27
ruckusZDAPRebootTrap	28

Index

About This Guide

This *FlexMaster 9.8 SNMP Reference Guide* contains information about configuring and monitoring FlexMaster Release 9.8 devices and supported ZoneFlex devices using Simple Network Management Protocol (SNMP).

NOTE Refer to the *FlexMaster 9.8 User Guide* for SNMP server configuration instructions.

This guide is written for service operators and system administrators who are responsible for managing, configuring, and troubleshooting Ruckus Wireless devices. Consequently, it assumes a basic working knowledge of local area networks, wireless networking, and wireless devices. Prior knowledge and experience with SNMP would be helpful.

NOTE If release notes are shipped with your product and the information there differs from the information in this guide, then follow the instructions in the release notes.

Most user guides and release notes are available in Adobe Acrobat Reader Portable Document Format (PDF) or HTML on the Ruckus Wireless Support Web site at <https://support.ruckuswireless.com/documents>.

Related Documentation

In addition to this *Reference Guide*, each FlexMaster documentation set includes the following:

- *User Guide*: Provides detailed information on how to use FlexMaster. The FlexMaster User Guide is available for download on the Ruckus Wireless Support Web site at <http://support.ruckuswireless.com>.
- *Online Help*: Provides instructions for performing tasks using the FlexMaster Web interface. The online help is accessible from the Web interface and is searchable.
- *Release Notes*: Provide information about the current software release, including new features, enhancements, and known issues.

Document Conventions

Table 1 and Table 2 list the text and notice conventions that are used throughout this guide.

Table 1. Text conventions

Convention	Description	Example
monospace	Represents information as it appears on screen	[Device name]>
monospace bold	Represents information that you enter	[Device name]> set ipaddr 10.0.0.12
default font bold	Keyboard keys, software buttons, and field names	On the Start menu, click All Programs .
<i>italics</i>	Screen or page names	Click Advanced Settings . The <i>Advanced Settings</i> page appears.

Table 2. Notice conventions

Notice Type	Description
NOTE	Information that describes important features or instructions
CAUTION!	Information that alerts you to potential loss of data or potential damage to an application, system, or device
WARNING!	Information that alerts you to potential personal injury

Documentation Feedback

Ruckus Wireless is interested in improving its documentation and welcomes your comments and suggestions. You can email your comments to Ruckus Wireless at:

docs@ruckuswireless.com

When contacting us, please include the following information:

- Document title
- Document part number (on the cover page)
- Page number (if appropriate)

For example:

- FlexMaster 9.8 SNMP Reference Guide
- Part number: 800-70595-001 Revision A
- Page 11

Event MIBs

1

Use the FlexMaster Event MIBs to retrieve information about events that have occurred on FlexMaster.

- [ruckusDeviceConnectivityProblemTrap](#)
- [ruckusFMCPUsageTrap](#)
- [ruckusFMEventZDAdminUpgradeTrap](#)
- [ruckusFMEventZDAdminRestartedTrap](#)
- [ruckusFMEventZDAdminShutdownTrap](#)
- [ruckusFMEventZDAPDeleteTrap](#)
- [ruckusFMEventZDAPJoinTrap](#)
- [ruckusFMEventZDAPLostTrap](#)
- [ruckusFMEventZDAPLostHeartbeatTrap](#)
- [ruckusFMEventZDSystemFailureRecovered](#)
- [ruckusFMEventZDSystemStartupTrap](#)
- [ruckusFMMiscEventTrap](#)
- [ruckusStandaloneAPRebootTrap](#)
- [ruckusStandaloneAPTransferCompleteTrap](#)
- [ruckusStandaloneAPReconnectTrap](#)
- [ruckusZDCPUUsageTrap](#)
- [ruckusZDAPTrafficTrap](#)
- [ruckusZDAPofclientsTrap](#)
- [ruckusZDAPLostConnectionTrap](#)
- [ruckusZDAPChannelChangeTrap](#)
- [ruckusZDAPRebootTrap](#)

ruckusDeviceConnectivityProblemTrap

MIB Name

ruckusDeviceConnectivityProblemTrap

Events

device connection problem

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.52

Status

current

Objects

ruckusFMEventAPIAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName

ruckusFMEventAPSerialNumber

ruckusFMEventAPDeviceName

Description

Triggered when there is a device connection problem event. The device's IP address, MAC address, Serial number, Device name and Model name are enclosed.

Recommended actions

No action required.

ruckusFMCPUsageTrap

MIB Name

ruckusFMCPUsageTrap

Events

FM CPU usage exceeds the threshold value

Severity

(enclosed)

OID

1.3.6.1.4.1.25053.2.3.1.54

Status

current

Objects

ruckusFMAlarmDefinitionCode

ruckusFMAlarmDeviceName

ruckusFMAlarmSeverity

ruckusFMAlarmDeviceMac

ruckusFMAlarmCategory

ruckusFMAlarmTypeText

ruckusFMAlarmMessage

ruckusFMAlarmDatetime

Description

Triggered when FM CPU usage exceeds the threshold value. The Definition Code, Device Name, and Alarm Severity are enclosed.

Recommended actions

No action required.

ruckusFMEventZDAdminUpgradeTrap

MIB Name

ruckusFMEventZDAdminUpgradeTrap

Events

Admin upgrade

Severity

low

OID

1.3.6.1.4.1.25053.2.3.1.41

Status

current

Objects

ruckusFMEventZDFirmwareVersion

ruckusFMEventZDIPAddr

ruckusFMEventZDModelName

ruckusFMEventZDSerialNumber

Description

Triggered when there is a ZD upgrade event. The ZD's Firmware version and IP address and Model name and Serial number are enclosed.

Recommended actions

No action required.

ruckusFMEventZDAdminRestartedTrap

MIB Name

ruckusFMEventZDAdminRestartedTrap

Events

Admin restart

Severity

low

OID

1.3.6.1.4.1.25053.2.3.1.42

Status

current

Objects

ruckusFMEventZDIPAddr
ruckusFMEventZDModelName
ruckusFMEventZDSerialNumber

Description

Triggered when there is a ZD restart event. The ZD's IP address and Model name and Serial number are enclosed.

Recommended actions

No action required.

ruckusFMEventZDAdminShutdownTrap

MIB Name

ruckusFMEventZDAdminShutdownTrap

Events

event.admin.shutdown

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.43

Status

current

Objects

ruckusFMEventZDIPAddr
ruckusFMEventZDModelName
ruckusFMEventZDSerialNumber

Description

Triggered when there is a ZD shutdown event. The ZD's IP address and Model name and Serial number are enclosed.

Recommended actions

No action required.

ruckusFMEventZDAPDeleteTrap

MIB Name

ruckusFMEventZDAPDeleteTrap

Events

AP delete

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.44

Status

current

Objects

ruckusFMEventAPIPAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName

ruckusFMEventZDIPAddr

ruckusFMEventZDModelName

ruckusFMEventZDSerialNumber

Description

Triggered when there is a AP delete event. The AP's IP address and Mac address and Model name, ZD's IP address and Model name and Serial number are enclosed.

Recommended actions

No action required.

ruckusFMEventZDAPJoinTrap

MIB Name

ruckusFMEventZDAPJoinTrap

Events

AP joined with reason

AP joined

Severity

medium

OID

1.3.6.1.4.1.25053.2.3.1.45

Status

current

Objects

ruckusFMEventAPIPAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName,

ruckusFMEventZDIPAddr

ruckusFMEventZDModelName

ruckusFMEventZDSerialNumber

Description

Triggered when there is an AP join event. The AP's IP address and Mac address and Model name, ZD's IP address and Model name and Serial number are enclosed.

Recommended actions

No action required.

ruckusFMEventZDAPLostTrap

MIB Name

ruckusFMEventZDAPLostTrap

Events

AP lost

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.46

Status

current

Objects

ruckusFMEventAPIPAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName

ruckusFMEventZDIPAddr

ruckusFMEventZDModelName

ruckusFMEventZDSerialNumber

Description

Triggered when AP lost contact for 20 minutes or more. The AP's IP address and Mac address and Model name, ZD's IP address and Model name and Serial number are enclosed.

Recommended actions

Check connection stability between ZD and AP. If customer knows that this AP will never be used, this AP can be removed from the ZD database.

ruckusFMEventZDAPLostHeartbeatTrap

MIB Name

ruckusFMEventZDAPLostHeartbeatTrap

Events

AP lost heartbeat

Severity

medium

OID

1.3.6.1.4.1.25053.2.3.1.47

Status

current

Objects

ruckusFMEventAPIPAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName

ruckusFMEventZDIPAddr

ruckusFMEventZDModelName

ruckusFMEventZDSerialNumber

Description

Triggered when AP loses 30-second heartbeats for 80 seconds or more. The AP's IP address and MAC address and Model name, ZD's IP address and Model name and Serial number are enclosed.

Recommended actions

Check connection stability between ZD and AP.

ruckusFMEventZDSystemFailureRecovered

MIB Name

ruckusFMEventZDSystemFailureRecovered

Events

ZD System Failure Recovered

Severity

medium

OID

1.3.6.1.4.1.25053.2.3.1.48

Status

current

Objects

ruckusFMEventZDIPAddr

ruckusFMEventZDSerialNumber

ruckusFMEventZDModelName

Description

Triggered upon ZD System Failure Recovery. The ZD's IP address and Serial number and Model name are enclosed.

Recommended actions

Verify ZD status in ZD user interface.

ruckusFMEventZDSystemStartupTrap

MIB Name

ruckusFMEventZDSystemStartupTrap

Events

System cold restarted

System warm restarted

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.49

Status

current

Objects

ruckusFMEventZDIPAddr

ruckusFMEventZDSerialNumber

ruckusFMEventZDModelName

Description

Triggered when there is a ZD cold restart or warm restart event. The ZD's IP address and Serial number and Model name are enclosed.

Recommended actions

No action required.

ruckusFMMiscEventTrap

NOTE The *ruckusFMMiscEventTrap* requires that the ZoneDirector and AP devices support the same set of traps.

This does not mean that ZD requires the same version as FM. Rather, it means that when ZD has an event, that FM needs to have the ZD assigned in *Configure > Event Configuration*.

By default, FM enables all event types, so customers should not have a customized configuration to not support any event type in FM. (If a customer creates an event configuration, it replaces the default rule for the assigned ZDs.)

Name

ruckusFMMiscEventTrap

Events

(various messages)

Severity

low

OID

1.3.6.1.4.1.25053.2.3.1.1

Status

current

Objects

ruckusFMEventDescription

Description

Generic trap triggered by admin specified miscellaneous event. The Event Description is enclosed.

Recommended actions

No action required.

ruckusStandaloneAPRebootTrap

MIB Name

ruckusStandaloneAPRebootTrap

Events

standalone AP reboot

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.50

Status

current

Objects

ruckusFMEventAPIPAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName

ruckusFMEventAPSerialNumber

ruckusFMEventAPDeviceName

Description

Triggered when there is a standalone AP reboot event. The AP's IP address, MAC address, Serial number, Device name, and Model name are enclosed.

Recommended actions

No action required.

ruckusStandaloneAPTransferCompleteTrap

MIB Name

ruckusStandaloneAPTransferCompleteTrap

Events

standalone AP transfer complete

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.51

Status

current

Objects

ruckusFMEventAPIPAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName

ruckusFMEventAPSerialNumber

ruckusFMEventAPDeviceName

ruckusFMEventAPFirmwareVersion

Description

Triggered when there is a standalone AP transfer complete event. The AP's IP address, MAC address, Serial number, Device name, Model name and Firmware Version are enclosed.

Recommended actions

No action required.

ruckusStandaloneAPReconnectTrap

MIB Name

ruckusStandaloneAPReconnectTrap

Events

standalone AP connection problem

Severity

minor

OID

1.3.6.1.4.1.25053.2.3.1.53

Status

current

Objects

ruckusFMEventAPIPAddr

ruckusFMEventAPMacAddr

ruckusFMEventAPModelName

ruckusFMEventAPSerialNumber

ruckusFMEventAPDeviceName

Description

Triggered when there is a standalone AP reconnect event. The AP's IP address, MAC address, Serial number, Device name and Model name are enclosed.

Recommended actions

No action required.

ruckusZDCPUUsageTrap

MIB Name

ruckusZDCPUUsageTrap

Events

ZD CPU usage exceeds the threshold value

Severity

(enclosed)

OID

1.3.6.1.4.1.25053.2.3.1.55

Status

current

Objects

ruckusFMAlarmDefinitionCode

ruckusFMAlarmDeviceName

ruckusFMAlarmSeverity

ruckusFMAlarmDeviceMac

ruckusFMAlarmCategory

ruckusFMAlarmTypeText

ruckusFMAlarmMessage

ruckusFMAlarmDatetime

Description

Triggered when ZD CPU usage exceeds the threshold value. The Definition Code, Device Name, and Alarm Severity are enclosed.

Recommended actions

No action required.

ruckusZDAPTrafficTrap

MIB Name

ruckusZDAPTrafficTrap

Events

AP count exceeds the threshold value

Severity

(enclosed)

OID

1.3.6.1.4.1.25053.2.3.1.56

Status

current

Objects

ruckusFMAlarmDefinitionCode

ruckusFMAlarmDeviceName

ruckusFMAlarmSeverity

ruckusFMAlarmDeviceMac

ruckusFMAlarmCategory

ruckusFMAlarmTypeText

ruckusFMAlarmMessage

ruckusFMAlarmDatetime

Description

Triggered when the AP count exceeds the threshold value. The Definition Code, Device Name, and Alarm Severity are enclosed.

Recommended actions

No action required.

ruckusZDAPofclientsTrap

MIB Name

ruckusZDAPofclientsTrap

Events

number of AP clients exceeds the threshold value

Severity

(enclosed)

OID

1.3.6.1.4.1.25053.2.3.1.57

Status

current

Objects

ruckusFMAlarmDefinitionCode

ruckusFMAlarmDeviceName

ruckusFMAlarmSeverity

ruckusFMAlarmDeviceMac

ruckusFMAlarmCategory

ruckusFMAlarmTypeText

ruckusFMAlarmMessage

ruckusFMAlarmDatetime

Description

Triggered when the number of AP clients exceeds the threshold value. The Definition Code, Device Name, and Alarm Severity are enclosed.

Recommended actions

No action required.

ruckusZDAPLostConnectionTrap

MIB Name

ruckusZDAPLostConnectionTrap

Events

ZD and AP lost their connection

Severity

(enclosed)

OID

1.3.6.1.4.1.25053.2.3.1.58

Status

current

Objects

ruckusFMAlarmDefinitionCode

ruckusFMAlarmDeviceName

ruckusFMAlarmSeverity

ruckusFMAlarmDeviceMac

ruckusFMAlarmCategory

ruckusFMAlarmTypeText

ruckusFMAlarmMessage

ruckusFMAlarmDatetime

Description

Triggered when the ZD and AP lost their connection. The Definition Code, Device Name, and Alarm Severity are enclosed.

Recommended actions

No action required.

ruckusZDAPChannelChangeTrap

MIB Name

ruckusZDAPChannelChangeTrap

Events

AP channel changes

Severity

(enclosed)

OID

1.3.6.1.4.1.25053.2.3.1.59

Status

current

Objects

ruckusFMAlarmDefinitionCode

ruckusFMAlarmDeviceName

ruckusFMAlarmSeverity

ruckusFMAlarmDeviceMac

ruckusFMAlarmCategory

ruckusFMAlarmTypeText

ruckusFMAlarmMessage

ruckusFMAlarmDatetime

Description

Triggered when the AP channel changes. The Definition Code, Device Name, and Alarm Severity are enclosed.

Recommended actions

No action required.

ruckusZDAPRebootTrap

MIB Name

ruckusZDAPRebootTrap

Events

ZD-controlled AP reboot

Severity

(enclosed)

OID

1.3.6.1.4.1.25053.2.3.1.60

Status

current

Objects

ruckusFMAlarmDefinitionCode

ruckusFMAlarmDeviceName

ruckusFMAlarmSeverity

ruckusFMAlarmDeviceMac

ruckusFMAlarmCategory

ruckusFMAlarmTypeText

ruckusFMAlarmMessage

ruckusFMAlarmDatetime

Description

Triggered when a ZD-controlled AP reboots. The Definition Code, Device Name, and Alarm Severity are enclosed.

Recommended actions

No action required.

Index

R

ruckusDeviceConnectivityProblemTrap 8
ruckusFMCPUUsageTrap 9
ruckusFMEventZDAdminRestartedTrap
11
ruckusFMEventZDAdminShutdownTrap
12
ruckusFMEventZDAdminUpgradeTrap 10
ruckusFMEventZDAPDeleteTrap 13
ruckusFMEventZDAPJoinTrap 14
ruckusFMEventZDAPLostHeartbeatTrap
16
ruckusFMEventZDAPLostTrap 15
ruckusFMEventZDSystemFailureRecov-
ered 17
ruckusFMEventZDSystemStartupTrap 18
ruckusFMMiscEventTrap 19
ruckusStandaloneAPRebootTrap 20
ruckusStandaloneAPReconnectTrap 22
ruckusStandaloneAPTransferCompleteT-
rap 21
ruckusZDAPChannelChangeTrap 27
ruckusZDAPLostConnectionTrap 26
ruckusZDAPofclientsTrap 25
ruckusZDAPRebootTrap 28
ruckusZDAPTrafficTrap 24
ruckusZDCPUUsageTrap 23



Copyright © 2006-2014. Ruckus Wireless, Inc.
350 West Java Dr. Sunnyvale, CA 94089. USA
www.ruckuswireless.com