

RUCKUS IoT Controller Configuration Guide, 1.8.1.0 MR

Supporting IoT Controller Release 1.8.1.0

Copyright, Trademark and Proprietary Rights Information

© 2021 CommScope, Inc. All rights reserved.

No part of this content may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from CommScope, Inc. and/or its affiliates ("CommScope"). CommScope reserves the right to revise or change this content from time to time without obligation on the part of CommScope to provide notification of such revision or change.

Export Restrictions

These products and associated technical data (in print or electronic form) may be subject to export control laws of the United States of America. It is your responsibility to determine the applicable regulations and to comply with them. The following notice is applicable for all products or technology subject to export control:

These items are controlled by the U.S. Government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations.

Disclaimer

THIS CONTENT AND ASSOCIATED PRODUCTS OR SERVICES ("MATERIALS"), ARE PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, COMMSCOPE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, NON-INFRINGEMENT, FREEDOM FROM COMPUTER VIRUS, AND WARRANTIES ARISING FROM COURSE OF DEALING OR COURSE OF PERFORMANCE. CommScope does not represent or warrant that the functions described or contained in the Materials will be uninterrupted or error-free, that defects will be corrected, or are free of viruses or other harmful components. CommScope does not make any warranties or representations regarding the use of the Materials in terms of their completeness, correctness, accuracy, adequacy, usefulness, timeliness, reliability or otherwise. As a condition of your use of the Materials, you warrant to CommScope that you will not make use thereof for any purpose that is unlawful or prohibited by their associated terms of use.

Limitation of Liability

IN NO EVENT SHALL COMMSCOPE, COMMSCOPE AFFILIATES, OR THEIR OFFICERS, DIRECTORS, EMPLOYEES, AGENTS, SUPPLIERS, LICENSORS AND THIRD PARTY PARTNERS, BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER, EVEN IF COMMSCOPE HAS BEEN PREVIOUSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, WHETHER IN AN ACTION UNDER CONTRACT, TORT, OR ANY OTHER THEORY ARISING FROM YOUR ACCESS TO, OR USE OF, THE MATERIALS. Because some jurisdictions do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of liability for consequential or incidental damages, some of the above limitations may not apply to you.

Trademarks

ARRIS, the ARRIS logo, COMMSCOPE, RUCKUS, RUCKUS WIRELESS, the Ruckus logo, the Big Dog design, BEAMFLEX, CHANNELFLY, FASTIRON, ICX, SMARTCELL and UNLEASHED are trademarks of CommScope, Inc. and/or its affiliates. Wi-Fi Alliance, Wi-Fi, the Wi-Fi logo, Wi-Fi Certified, the Wi-Fi CERTIFIED logo, Wi-Fi Protected Access, the Wi-Fi Protected Setup logo, Wi-Fi Protected Setup, Wi-Fi Multimedia and WPA2 and WMM are trademarks or registered trademarks of Wi-Fi Alliance. All other trademarks are the property of their respective owners.

Contents

Preface	5
Contacting RUCKUS Customer Services and Support.....	5
What Support Do I Need?.....	5
Open a Case.....	5
Self-Service Resources.....	6
Document Feedback.....	6
RUCKUS Product Documentation Resources.....	6
Online Training Resources.....	6
Document Conventions.....	7
Notes, Cautions, and Safety Warnings.....	7
Command Syntax Conventions.....	7
About This Guide	9
Introduction to RUCKUS IoT Controller.....	9
What's New in This Document.....	9
Getting Started	11
Before You Begin.....	11
Supported Web Browsers.....	11
Logging In to RUCKUS IoT Controller.....	11
Getting to Know the Dashboard.....	15
Configuring N+1	17
Configuring Static Addresses for Primary and Secondary Controllers.....	17
Configuring the N+1 Feature.....	17
Disabling N+1	31
Managing IoT Controller System Configuration	33
Managing Services.....	33
Enabling Samsung SmartThings.....	34
Activating and Editing the Plugins.....	42
Activating and Editing the Kontakt.io Beacons Plugin.....	42
Activating and Editing the Assa Abloy Plugin.....	45
Activating and Editing the Eddystone Plugin.....	46
Activating and Editing the iBeacon Plugin.....	50
Activating and Editing the Beacon as a Service Plugin (iBeacon, Eddystone and Custom).....	53
Activating and Editing the Beacon as a Service Plugin (React Mobile).....	58
Activating and Editing the BLE Scan Plugin.....	59
Activating and Editing the Controller Data Stream Plugin.....	62
Activating and Editing the Dormakaba Plugin.....	64
Activating and Editing the Telkonet Plugin.....	66
Activating and Editing the Soter Plugin.....	69
Changing the Password.....	71
Configuring Virtual Machines.....	71
Uploading Versions and Patches.....	72
Uploading an Image.....	72
Uploading a Patch.....	73
Backing Up Files.....	73

Backing up Rules.....	74
Uploading the RUCKUS IoT Controller License.....	75
Change the Settings.....	77
Rebooting RUCKUS IoT Controller.....	79
Resetting RUCKUS IoT Controller.....	79
Managing IoT Access Points.....	81
IoT AP Overview.....	81
DHCP Option 43.....	81
RUCKUS Command Line Interface.....	82
USB Power.....	82
Adding an IoT AP.....	84
Editing an IoT AP.....	86
Single IoT Access Point Mode.....	87
Adding Tags to an AP.....	88
Approval of IoT APs.....	90
Exporting IoT APs to CSV.....	90
Managing Devices.....	91
Devices Overview.....	91
Managing OSRAM Light Bulbs.....	94
Managing an Assa Abloy Lock.....	95
Managing the Dormakaba Locks.....	96
Discovering Dormakaba Lock.....	97
Blocking and Unblocking Dormakaba Lock.....	98
Blocking the Key Remotely.....	102
Unblocking the Key Remotely.....	105
Rules Engine.....	109
Rules Engine Overview.....	110
Configuring Rules.....	110
Rules-Dashboard.....	111
LoRaWAN.....	113
LoRaWAN Overview.....	113
Logging In to the LoRa Network	113
LoRaWAN Dashboard.....	114
Configuring LoRa Devices	115
Configuring LoRaWAN Routers.....	117
Preparing the Semtech LoRa Picocell Gateway.....	117
Configuring the Semtech LoRa Picocell Gateway as a Router in the LNS.....	119
Events.....	121
Viewing Events.....	121
Viewing SmartThings Event.....	122

Preface

- [Contacting RUCKUS Customer Services and Support](#)..... 5
- [Document Feedback](#)..... 6
- [RUCKUS Product Documentation Resources](#)..... 6
- [Online Training Resources](#)..... 6
- [Document Conventions](#)..... 7
- [Command Syntax Conventions](#)..... 7

Contacting RUCKUS Customer Services and Support

The Customer Services and Support (CSS) organization is available to provide assistance to customers with active warranties on their RUCKUS products, and customers and partners with active support contracts.

For product support information and details on contacting the Support Team, go directly to the RUCKUS Support Portal using <https://support.ruckuswireless.com>, or go to <https://www.ruckuswireless.com> and select **Support**.

What Support Do I Need?

Technical issues are usually described in terms of priority (or severity). To determine if you need to call and open a case or access the self-service resources, use the following criteria:

- Priority 1 (P1)—Critical. Network or service is down and business is impacted. No known workaround. Go to the **Open a Case** section.
- Priority 2 (P2)—High. Network or service is impacted, but not down. Business impact may be high. Workaround may be available. Go to the **Open a Case** section.
- Priority 3 (P3)—Medium. Network or service is moderately impacted, but most business remains functional. Go to the **Self-Service Resources** section.
- Priority 4 (P4)—Low. Requests for information, product documentation, or product enhancements. Go to the **Self-Service Resources** section.

Open a Case

When your entire network is down (P1), or severely impacted (P2), call the appropriate telephone number listed below to get help:

- Continental United States: 1-855-782-5871
- Canada: 1-855-782-5871
- Europe, Middle East, Africa, Central and South America, and Asia Pacific, toll-free numbers are available at <https://support.ruckuswireless.com/contact-us> and Live Chat is also available.
- Worldwide toll number for our support organization. Phone charges will apply: +1-650-265-0903

We suggest that you keep a physical note of the appropriate support number in case you have an entire network outage.

Self-Service Resources

The RUCKUS Support Portal at <https://support.ruckuswireless.com> offers a number of tools to help you to research and resolve problems with your RUCKUS products, including:

- Technical Documentation—<https://support.ruckuswireless.com/documents>
- Community Forums—<https://forums.ruckuswireless.com/ruckuswireless/categories>
- Knowledge Base Articles—<https://support.ruckuswireless.com/answers>
- Software Downloads and Release Notes—https://support.ruckuswireless.com/#products_grid
- Security Bulletins—<https://support.ruckuswireless.com/security>

Using these resources will help you to resolve some issues, and will provide TAC with additional data from your troubleshooting analysis if you still require assistance through a support case or RMA. If you still require help, open and manage your case at https://support.ruckuswireless.com/case_management.

Document Feedback

RUCKUS is interested in improving its documentation and welcomes your comments and suggestions.

You can email your comments to RUCKUS at #Ruckus-Docs@commscope.com.

When contacting us, include the following information:

- Document title and release number
- Document part number (on the cover page)
- Page number (if appropriate)

For example:

- RUCKUS SmartZone Upgrade Guide, Release 5.0
- Part number: 800-71850-001 Rev A
- Page 7

RUCKUS Product Documentation Resources

Visit the RUCKUS website to locate related documentation for your product and additional RUCKUS resources.

Release Notes and other user documentation are available at <https://support.ruckuswireless.com/documents>. You can locate the documentation by product or perform a text search. Access to Release Notes requires an active support contract and a RUCKUS Support Portal user account. Other technical documentation content is available without logging in to the RUCKUS Support Portal.

White papers, data sheets, and other product documentation are available at <https://www.ruckuswireless.com>.

Online Training Resources

To access a variety of online RUCKUS training modules, including free introductory courses to wireless networking essentials, site surveys, and products, visit the RUCKUS Training Portal at <https://training.ruckuswireless.com>.

Document Conventions

The following table lists the text conventions that are used throughout this guide.

TABLE 1 Text Conventions

Convention	Description	Example
monospace	Identifies command syntax examples	<code>device(config)# interface ethernet 1/1/6</code>
bold	User interface (UI) components such as screen or page names, keyboard keys, software buttons, and field names	On the Start menu, click All Programs .
<i>italics</i>	Publication titles	Refer to the <i>RUCKUS Small Cell Release Notes</i> for more information.

Notes, Cautions, and Safety Warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

NOTE

A NOTE provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

ATTENTION

An ATTENTION statement indicates some information that you must read before continuing with the current action or task.



CAUTION

A CAUTION statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



DANGER

A DANGER statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

Command Syntax Conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
bold text	Identifies command names, keywords, and command options.
<i>italic text</i>	Identifies a variable.
[]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{x y z}	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member[member...]</i> .
\	Indicates a "soft" line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

About This Guide

- [Introduction to RUCKUS IoT Controller..... 9](#)

Introduction to RUCKUS IoT Controller

This document describes the configuration required for setting up the RUCKUS IoT Controller on the network.

This guide is intended for service operators and system administrators who are responsible for managing, configuring, and troubleshooting RUCKUS devices. Consequently, it assumes a basic working knowledge of local area networks, wireless networking, and wireless devices.

NOTE

If release notes are shipped with your product and the information there differs from the information in this guide, follow the instructions in the release notes.

What's New in This Document

TABLE 2 Summary of New Features in RUCKUS IoT Controller Release 1.8.1.0 MR

Feature	Description	Location
No new features for this release.	Minor content update	Refer to topics - Backing up Files and Getting to know the Dashboard.

Getting Started

- Before You Begin..... 11
- Logging In to RUCKUS IoT Controller..... 11
- Getting to Know the Dashboard..... 15

Before You Begin

The RUCKUS IoT Controller must be installed on a hypervisor.

Supported Web Browsers

The RUCKUS IoT Controller is primarily accessible using a web browser.

TABLE 3 Supported Web Browser Versions

Browser	Version
Google Chrome	63.0 and later
Apple Safari	60.0 and later
Mozilla Firefox	10.1.2 and later

Logging In to RUCKUS IoT Controller

To manage IoT APs and devices, you must first log in to the RUCKUS IoT Controller.

1. Log in to the console of the RUCKUS IoT Controller using the username "admin" and password "admin".

Getting Started

Logging In to RUCKUS IoT Controller

2. Enter **1** in the **Enter Choice** field to get the IP address.

FIGURE 1 RUCKUS IoT Controller Main Menu

```
1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 1

-----
Network info :
-----
IP (eth0)      : 10.174.112.79/23
Gateway       : 10.174.112.1
Hostname      : vriot
DNS domain    :
FQDN         : vriot
DNS          : 10.42.50.240 10.0.248.1
N+1 Status   : Disabled
-----

Set Network(1) or Exit(x). Select [1/x]: █
```

3. Open a web browser, enter the IP address in the address bar, and press **Enter**.

The **Initialization** page is displayed.

FIGURE 2 Initialization Page

The screenshot shows the 'Initialization' page of the RUCKUS IoT Controller. The page is titled 'Initialization' and includes a sub-header 'Click on next button to continue'. It is divided into three main sections: 'VM Configurations', 'IP Configurations', and 'Optional Services'. The 'VM Configurations' section contains fields for 'Hostname' (with 'vriot' entered), 'Time Zone' (set to 'America/Santiago'), and two radio buttons for 'Set Time Automatically using NTP' (selected) and 'Set Time Manually' (with a date/time field showing 'May 20, 2021 4:13 PM'). The 'IP Configurations' section has two radio buttons for 'DHCP' (selected) and 'Static'. The 'Optional Services' section lists three services: 'Rules Engine', 'Track Central', and 'Samsung SmartThings', each with an unchecked checkbox. A 'Next' button is located in the bottom right corner.

The following optional services are listed on the **Initialization** page.

- Rules Engine
 - Track Central
 - Samsung SmartThings
4. Enter the **Hostname**, **Time Zone**, and select the **IP Configuration (DHCP or Static)**, and click **Next** to start all the services in the RUCKUS IoT Controller.


The RUCKUS IoT Controller services are sensitive to time synchronization. If the **Set Time Automatically using NTP** option is not available (such as in an isolated setup), you can select the **Set Time Manually** option to disable NTP sync.

Getting Started

Logging In to RUCKUS IoT Controller

5. Enter the RUCKUS IoT Controller password in the **New Password** field. Re-enter the password in the **Confirm Password** field. The password must be a least eight characters in length and contain one uppercase letter, one lowercase letter, one digit, and one special character. Click **Start**.


FIGURE 3 Confirming the Password



The screenshot shows the 'Initialization' page of the RUCKUS IoT Controller. The page title is 'Initialization' and the subtitle is 'Enter new password to continue'. There are two password input fields: 'New Password' and 'Confirm Password'. Each field has a 'Show' button next to it. At the bottom left is a 'Back' button and at the bottom right is a 'Start' button. The top navigation bar includes the RUCKUS logo, 'IoT Controller', and 'IoT API'. The top right corner displays version information: '1.5.0.0.19 Version', '16 December 2019 4:27:28', and 'America/Los_Angeles'.

6. On the **End-user License Agreement** page, click **Accept** to accept the RUCKUS IoT Controller license.

FIGURE 4 End-user License Agreement



The screenshot shows the 'End-user License Agreement' dialog box. The title is 'End-user License Agreement' and the subtitle is 'Ruckus IoT Controller (RIoT Controller) Software License'. The main text reads: 'PLEASE READ THIS SOFTWARE LICENSE CAREFULLY. RUCKUS WIRELESS, INC. ("RUCKUS") IS WILLING TO LICENSE THE SOFTWARE TO YOU ("LICENSEE") ONLY ON THE CONDITION THAT THE LICENSEE ACCEPTS ALL OF THE FOLLOWING TERMS AND CONDITIONS. IF A USER ACCEPTS THIS LICENSE, OR DOWNLOADS, USES OR INSTALLS THE SOFTWARE, AS AN EMPLOYEE OF, OR AS AN AGENT OR CONTRACTOR FOR THE BENEFIT OF, A COMPANY, THAT COMPANY SHALL BE DEEMED THE LICENSEE AND THE USER REPRESENTS THAT IT HAS THE POWER AND AUTHORITY TO ACCEPT THIS AGREEMENT ON BEHALF OF THE COMPANY. BY DOWNLOADING, INSTALLING AND/OR USING THE SOFTWARE, LICENSEE ACKNOWLEDGES THAT IT HAS READ THIS LICENSE AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. IF LICENSEE DOES NOT AGREE TO THE TERMS AND CONDITIONS OF THIS LICENSE, RUCKUS IS UNWILLING TO LICENSE THE SOFTWARE. IN THAT EVENT, LICENSEE MAY NOT DOWNLOAD, USE OR INSTALL THE SOFTWARE AND SHALL BE GIVEN A FULL REFUND OF ANY LICENSE FEES ACTUALLY PAID FOR THE SOFTWARE.'

1) Definitions
"Device" means a single Ruckus access point on Licensee's network. "Documentation" means the published technical manuals, including any updates thereto, relating to the use of the Software made generally available by Ruckus. "Evaluation Term" means the limited period of time following Licensee's initial download of the Software during which Licensee is permitted to use the Software without placing an Order; provided, that the Evaluation Term is subject to early termination as provided in this agreement. "Software" means a copy of a machine executable version of a Ruckus software product that Ruckus makes available to Licensee for download onto equipment owned or controlled by Licensee, and any error corrections, updates or upgrades of such software product that Ruckus makes available to Licensee. "Order" means one or more ordering documents or transactional records in the form required by Ruckus from Licensee (or a Ruckus Channel Partner for the benefit of Licensee) to activate the Software or increase the Authorized Device Limit. "Ruckus Channel Partner" means an entity

At the bottom of the dialog box are two buttons: 'Close' and 'Accept'.

Getting to Know the Dashboard

The **Dashboard**, which is the first page that appears after you log in to the RUCKUS IoT Controller, offers an overall picture and status of the IoT infrastructure. The **Dashboard** shows the total number of IoT devices and IoT APs, the top IoT APs by device count, and the devices and APs by protocol.

FIGURE 5 RUCKUS IoT Controller Dashboard




TABLE 4 Dashboard Elements

Box Name	Description
Devices Last seen	Shows the total number of devices last seen.
IoT APs By Device Count	Shows the total number of devices connected per Access Point.
Total Devices	Shows the total number of devices.
Total IoT APs	Shows the total number of Access Points.
Total Beacons	Shows the total number of Beacons.
Devices	Shows the status of devices that are connected to the RUCKUS IoT Controller.
Devices by Battery Level	Shows the status of devices that are grouped together by battery level.
Active Plugins	Shows the plugins that are enabled.
IoT AP	Shows the status of Access Points that are connected to the RUCKUS IoT Controller.
IoT AP By Protocol	Shows the number of APs running by the protocol being used. RUCKUS supports two protocols: BLE and Zigbee.
Device By Protocol	Shows the total number of devices connected by the protocol being used. RUCKUS supports two protocols: BLE and Zigbee.
Total LNS Hubs	Shows the total number of LoRa Network Server hubs connected to the RUCKUS IoT Controller.

Getting Started


Getting to Know the Dashboard

TABLE 4 Dashboard Elements (continued)



Box Name	Description
License status	Shows the total of number of licenses, and the status of the licenses that are available or used by the RUCKUS IoT Controller.

To set up the **Dashboard**, click the **Settings** button. The **Dashboard Settings** menu is displayed.

FIGURE 6 Dashboard Settings



You can perform the following actions to configure the **Dashboard**.

- To edit the **Dashboard**, click **Edit Dashboard** and either move the position of the tile using the  icon or delete the tile using the  icon.
- To reset the widgets, click **Reset Widgets** to retrieve the widgets on the **Dashboard**.
- To reset the widget display time, click **Refresh Interval** to change the display time of the widgets on the **Dashboard**.

NOTE

The default interval is 30 seconds.

The options under **Add Widgets** allow you to add widgets to the **Dashboard**. Click + for **Devices**, **Active Plugins**, **Total devices**, **License Status**, **Total Beacons**, **Total IoT APs**, and **Total LNS Hubs** to add widgets to the **Dashboard**.

Configuring N+1

- [Configuring Static Addresses for Primary and Secondary Controllers.....](#) 17
- [Configuring the N+1 Feature.....](#) 17

RUCKUS IoT Controller N+1 high availability (HA) ensures high system availability, reliability and scalability of the controller, and also enables load balancing, backup, and failover. To configure an HA cluster, all the hosts in the cluster must have access to the same shared storage, which allows virtual machines (VMs) on a given host to fail over to another host without any downtime in the event of a failure.

Before beginning to use N+1, pay attention to the following prerequisites for configuring the primary and secondary controllers:

- The primary and secondary controllers must be in the same subnet and reachable.
- The primary and secondary controllers must be configured with static IP addresses.
- The primary and secondary controllers must be running the same version.
- The primary and secondary controllers must have a synchronized date and time.
- The primary and secondary controllers must have different host names.
- The secondary controller services must be started for N+1 to work.
- The primary and secondary controller must have same password configured for the user admin.
- Enter the N+1 password.

Configuring Static Addresses for Primary and Secondary Controllers

The static IP addresses of the primary and secondary controllers can be configured in two ways:

1. From the RUCKUS IoT Controller main menu, select **Admin > VM Configurations**.
2. Set the static addresses of the primary and secondary controller on the **Initialization** page. Refer to [Logging In to RUCKUS IoT Controller](#) on page 11.

Configuring the N+1 Feature

After configuring the static IP addresses for primary and secondary controller, N+1 can be enabled by performing the following steps.

1. Log in to the console of the RUCKUS IoT Controller.

Configuring N+1

Configuring the N+1 Feature

2. Enter 5 in the **Enter Choice** field.

FIGURE 7 RUCKUS IoT Controller Main Menu

```
172.16.112.243 - PuTTY
Ruckus IoT Controller
Main Menu
-----
1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Disabled
-----

N+1 Configure(1) / Disable(2) / Exit(x) :1
Start Primary Controller(1) / Secondary Controller(2) / Exit(x) :1

-----
N+1 Configure:
-----
To Configure N+1 ensure following requirements:
-----
* Primary Controller and Secondary Controller should be in same subnet and reachable.
* Primary Controller and Secondary Controller should be configured with static ip address.
* Primary Controller and Secondary Controller should be running in same version.
* Primary Controller and Secondary Controller should have synchronized date/time.
* Primary Controller and Secondary Controller should have same password configured for the User admin.

Enter Secondary Controller IP : █
```

3. Enter 1 to continue the configuration.

FIGURE 8 Continuing the Configuration

```
*****
Ruckus IoT Controller
Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Disabled
-----

N+1 Configure(1) / Disable(2) / Exit(x) :1
Start Primary Controller(1) / Secondary Controller(2) / Exit(x) : █
```

4. To configure the primary controllers, enter **1** and type the IP address of the secondary controller in the **Enter Secondary Controller IP** field.

FIGURE 9 Configuring the Primary Controller

```
172.16.112.243 - PuTTY
.....
Ruckus IoT Controller
Main Menu
.....

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Disabled
-----

N+1 Configure(1) / Disable(2) / Exit(x) :1
Start Primary Controller(1) / Secondary Controller(2) / Exit(x) :1

-----
N+1 Configure:
-----
To Configure N+1 ensure following requirements:
.....
* Primary Controller and Secondary Controller should be in same subnet and reachable.
* Primary Controller and Secondary Controller should be configured with static ip address.
* Primary Controller and Secondary Controller should be running in same version.
* Primary Controller and Secondary Controller should have synchronized date/time.
* Primary Controller and Secondary Controller should have same password configured for the User admin.

Enter Secondary Controller IP : █
```

Configuring N+1

Configuring the N+1 Feature

5. Type the preferred IP address in the **Enter preferred Virtual IP** field.

NOTE

The preferred virtual IP address must not be the same as the primary or secondary controller IP addresses.

Enter the admin password and type a preferred N+1 password

```
172.16.113.178 - PuTTY
.....
Ruckus IoT Controller
Main Menu
.....
1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
N+1 Mode      : Disabled
-----

N+1 Configure(1) / Disable(2) / Exit(x) :1
Start Primary Controller(1) / Secondary Controller(2) / Exit(x) :1
-----
N+1 Configure:
-----
To Configure N+1 ensure following requirements:
*****
* Primary Controller and Secondary Controller should be in same subnet and reachable.
* Primary Controller and Secondary Controller should be configured with static ip address.
* Primary Controller and Secondary Controller should be running in same version.
* Primary Controller and Secondary Controller should have synchronized date/time.
* Primary Controller and Secondary Controller should have same password configured for the User admin.

Enter Secondary Controller IP :172.16.113.102
Enter preferred Virtual IP :171.16.113.111
Enter admin password for configuring N+1:

Enter new password for configuring N+1
New password should contain atleast 1 uppercase, 1 number , 1 Symbol and atleast 8 characters length
:

N+1 will stop all services & configurations in Secondary Controller. Enter Y/N to continue : █
```

6. Enter Y to continue with the N+1 configuration.

FIGURE 10 Completing the Primary Controller Configuration

```
172.16.113.178 - PuTTY
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Disabled
-----

N+1 Configure(1) / Disable(2) / Exit(x) :1
Start Primary Controller(1) / Secondary Controller(2) / Exit(x) :1
-----
N+1 Configure:
-----
To Configure N+1 ensure following requirements:
*****
* Primary Controller and Secondary Controller should be in same subnet and reachable.
* Primary Controller and Secondary Controller should be configured with static ip address.
* Primary Controller and Secondary Controller should be running in same version.
* Primary Controller and Secondary Controller should have synchronized date/time.
* Primary Controller and Secondary Controller should have same password configured for the User admin.

Enter Secondary Controller IP :172.16.113.102
Enter preferred Virtual IP :172.16.113.111
Enter admin password for configuring N+1:

Enter new password for configuring N+1
New password should contain atleast 1 uppercase, 1 number , 1 Symbol and atleast 8 characters length
:

N+1 will stop all services & configurations in Secondary Controller. Enter Y/N to continue : Y

Configuring takes around 5-10 minutes. Please wait
Primary Controller configuration started..
```

After configuring the primary controller, the configuration of secondary controller begins.

Configuring N+1

Configuring the N+1 Feature

FIGURE 11 Continuing with the Secondary Controller Configuration

```
172.16.113.178 - PuTTY
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Disabled
-----

N+1 Configure(1) / Disable(2) / Exit(x) :1
Start Primary Controller(1) / Secondary Controller(2) / Exit(x) :1
-----
N+1 Configure:
-----
To Configure N+1 ensure following requirements:
*****
* Primary Controller and Secondary Controller should be in same subnet and reachable.
* Primary Controller and Secondary Controller should be configured with static ip address.
* Primary Controller and Secondary Controller should be running in same version.
* Primary Controller and Secondary Controller should have synchronized date/time.
* Primary Controller and Secondary Controller should have same password configured for the User admin.

Enter Secondary Controller IP :172.16.113.102
Enter preferred Virtual IP :172.16.113.111
Enter admin password for configuring N+1:

Enter new password for configuring N+1
New password should contain atleast 1 uppercase, 1 number , 1 Symbol and atleast 8 characters length
:

N+1 will stop all services & configurations in Secondary Controller. Enter Y/N to continue : Y

Configuring takes around 5-10 minutes. Please wait
Primary Controller configuration started..
Secondary Controller configuration started..
```

FIGURE 12 N+1 Configuration Completed

```
172.16.113.178 - PuTTY
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Disabled
-----

N+1 Configure(1) / Disable(2) / Exit(x) :1
Start Primary Controller(1) / Secondary Controller(2) / Exit(x) :1
-----
N+1 Configure:
-----
To Configure N+1 ensure following requirements:
*****
* Primary Controller and Secondary Controller should be in same subnet and reachable.
* Primary Controller and Secondary Controller should be configured with static ip address.
* Primary Controller and Secondary Controller should be running in same version.
* Primary Controller and Secondary Controller should have synchronized date/time.
* Primary Controller and Secondary Controller should have same password configured for the User admin.

Enter Secondary Controller IP :172.16.113.102
Enter preferred Virtual IP :172.16.113.111
Enter admin password for configuring N+1:

Enter new password for configuring N+1
New password should contain atleast 1 uppercase, 1 number , 1 Symbol and atleast 8 characters length
:

N+1 will stop all services & configurations in Secondary Controller. Enter Y/N to continue : Y

Configuring takes around 5-10 minutes. Please wait
Primary Controller configuration started..
Secondary Controller configuration started..
Configuring N+1 completed..
-----
```

You have configured N+1 successfully.

7. To verify the IP addresses of the primary controller or active primary controller, and the secondary controller or active secondary controller, enter **5** in the **Enter Choice** field.

FIGURE 13 Verifying the IP Address of the Active Primary Controller

```
172.16.113.178 - PuTTY
*****
                        Ruckus IoT Controller
                        Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode       : Enabled
      Virtual IP     : 172.16.113.111
      Mode           : Active Primary Controller
      My IP          : 172.16.113.178
      Secondary Controller IP : 172.16.113.102
      ConfigSync     : Not Applicable, Controller is Active.
      Node Status    : vriot(2): normal
vriot_prim(1): normal
-----

N+1 Configure(1) / Disable(2) / Exit(x) : █
```

Configuring N+1

Configuring the N+1 Feature

- To replace the secondary controller, enter 3.

NOTE

While replacing the node, both controller should have same admin password and user needs to enter the password while replacing the node.

FIGURE 14 Replacing the IP Address of Secondary Controller

```
*****
                        Ruckus IoT Controller
                        Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode       : Enabled
      Virtual IP     : 10.174.113.180
      Mode           : Active Primary Controller
      My IP          : 10.174.113.173
      Secondary Controller IP : 10.174.113.177
      ConfigSync     : Not Applicable, Controller is Active.
      Node Status    : vriot-shriram-151020-esx138(1): normal
vriot-shriram-151020-slave-es138(2): normal(offline)
-----

N+1 Configure(1) / Disable(2) / Replace Secondary Controller(3) / Exit(x) : █
```


FIGURE 15 Successful Completion of Replacing the Node

```
*****
                        Ruckus IoT Controller
                        Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

[Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode       : Enabled
      Virtual IP     : 10.174.113.180
      Mode           : Active Primary Controller
      My IP          : 10.174.113.173
      Secondary Controller IP      : 10.174.113.177
      ConfigSync     : Not Applicable, Controller is Active.
      Node Status    : vriot-shriram-151020-esx138(1): normal
vriot-shriram-151020-slave-es138(2): normal(offline)
-----

[N+1 Configure(1) / Disable(2) / Replace Secondary Controller(3) / Exit(x) :3
-----
N+1 Replace :
-----
[ Enter Secondary Controller IP to replace:10.174.113.172
Deleted nodes
█
```

Configuring N+1

Configuring the N+1 Feature

9. To enable Forced Fallback, enter 3 to continue the configuration.

FIGURE 16 Configuring Forced Fallback

```
172.16.113.178 - PuTTY
*****
                        Ruckus IoT Controller
                        Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode       : Enabled
      Virtual IP     : 172.16.113.111
      Mode           : Primary Controller
      My IP          : 172.16.113.178
      Secondary Controller IP : 172.16.113.102
      ConfigSync     : 05/20/2021 08:05:03
      Node Status    : vriot(2): normal
vriot_prim(1): normal
-----

N+1 Configure(1) / Disable(2) / Forced Fallback(3) / Exit(x) : █
```

10. To replace the primary controller, enter 3.

FIGURE 17 Replacing the Primary Controller

```
*****
                        Ruckus IoT Controller
                        Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

[Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Enabled
      Virtual IP    : 10.174.113.180
      Mode          : Active Secondary Controller
      My IP         : 10.174.113.172
      Primary Controller IP : ["10.174.113.173"]
      ConfigSync    : Not Applicable, Controller is Active.
      Node Status   : vriot-shriram-151020-es15-slave2(2): normal
vriot-shriram-151020-esx138(1): normal(offline)
-----

N+1 Configure(1) / Disable(2) / Replace Primary Controller(3) / Exit(x) : █
```

Configuring N+1

Configuring the N+1 Feature

11. Enter the IP address of the primary controller.

FIGURE 18 Continuing with Replacing the Primary Controller

```
*****
                                Ruckus IoT Controller
                                Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

[Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode       : Enabled
      Virtual IP     : 10.174.113.180
      Mode           : Active Secondary Controller
      My IP          : 10.174.113.172
      Primary Controller IP : ["10.174.113.173"]
      ConfigSync     : Not Applicable, Controller is Active.
      Node Status    : vriot-shriram-151020-es15-slave2(2): normal
vriot-shriram-151020-esx138(1): normal(offline)
-----

[N+1 Configure(1) / Disable(2) / Replace Primary Controller(3) / Exit(x) :3
-----
N+1 Replace :
-----
      Enter Primary Controller IP to replace:10.174.113.177
```

Replacing the primary controller has been successfully completed.

FIGURE 19 Successful Completion of Replacing the Primary Controller

```
*****
                        Ruckus IoT Controller
                        Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

[Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode       : Enabled
      Virtual IP     : 10.174.113.180
      Mode           : Active Secondary Controller
      My IP          : 10.174.113.172
      Primary Controller IP : ["10.174.113.173"]
      ConfigSync     : Not Applicable, Controller is Active.
      Node Status    : vriot-shriram-151020-es15-slave2(2): normal
vriot-shriram-151020-esx138(1): normal(offline)
-----

[N+1 Configure(1) / Disable(2) / Replace Primary Controller(3) / Exit(x) :3
-----
N+1 Replace :
-----
[ Enter Primary Controller IP to replace:10.174.113.177
  Error: N+1 is already enabled!
Deleted nodes
  Start replacing master
  Secondary Controller configuration started..
Replace node taking more time to start services
Replacing node completed
-----
█
```


Disabling N+1

Complete the following steps to disable N+1 configuration.

1. Log in to the console of the Primary controller IP.
2. Enter 5 in the **Enter Choice** field.

FIGURE 20 Disabling the N+1 Configuration

```
*****
                                Ruckus IoT Controller
                                Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

[Enter Choice: 5

-----
N+1 Status:
-----

      N+1 Mode       : Enabled
      Virtual IP     : 10.174.113.180
      Mode           : Active Primary Controller
      My IP          : 10.174.113.173
      Secondary Controller IP : 10.174.113.172
      ConfigSync     : Not Applicable, Controller is Active.
      Node Status    : vriot-shriram-151020-es15-slave1(2): normal
vriot-shriram-151020-esx138(1): normal
-----

[N+1 Configure(1) / Disable(2) / Exit(x) :2
-----
N+1 Disable :
-----

      Secondary Controller 10.174.113.172 will be reset.
      Disable N+1 completed...
-----
```

3. Enter 2 to disable the N+1 configuration.

NOTE

After the N+1 configuration is disabled from the active primary controller, the secondary controller resets automatically.

Managing IoT Controller System Configuration

- Managing Services..... 33
- Activating and Editing the Plugins..... 42
- Changing the Password..... 71
- Configuring Virtual Machines..... 71
- Uploading Versions and Patches..... 72
- Backing Up Files..... 73
- Backing up Rules..... 74
- Uploading the RUCKUS IoT Controller License..... 75
- Change the Settings..... 77
- Rebooting RUCKUS IoT Controller..... 79
- Resetting RUCKUS IoT Controller..... 79

Managing Services


The administrator can restart or manage the mandatory and optional services.

Complete the following steps to restart or manage the services.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Services**.

FIGURE 21 Services

FIGURE 22 Managing Services Page



The currently running services and their details are displayed.

3. Select a service to start or stop.

Enabling Samsung SmartThings

You can connect the Samsung Smart Hub dongle through the USB port in RUCKUS AP. The Samsung Smart Hub dongle has two radios: Zigbee and Z-Wave. The Samsung SmartThings mobile app displays the configurations, status, information, device list, and device status of the Samsung Smart Hub.


You must perform the following steps to enable Samsung SmartThings service.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Services**.
3. Click **Start** to activate the service.

NOTE

By default SmartThings is disabled.

FIGURE 23 Starting Samsung SmartThings



4. After receiving an Upgrade Success message for the ST Upgrade event on the IoT Controller Events page, press and hold the reset button on the Smart Hub for 10 seconds.

FIGURE 24 SmartThing Device




NOTE

For more information on upgrade events, refer [Viewing SmartThings Event](#) on page 122.

5. Download the SmartThings app and enter your login credentials.


6. Connect your mobile and AP in the same network or connect the mobile to the SSID of the AP.

FIGURE 25 SmartThings User Interface




7. After the mobile device connects to Wi-Fi, click **ADD NOW** in the SmartThings device pop-up.

FIGURE 26 Connecting to Wi-Fi




8. If the pop-up does not display, perform the following steps to add your mobile device to SmartThings.
 - a) Click **Device** and select **Scan nearby**.

FIGURE 27 Selecting a Device



The **Smart Home** link is displayed under **Available devices**.

FIGURE 28 Scanning for the device



- b) Click **Smart Home Link**.
- c) Select the location and room for your hub and wait for your device to connect successfully.

FIGURE 29 Selecting the Location and Room for Your Hub





FIGURE 30 Waiting for Successful Connection



- d) After the hub connects successfully, rename your hub. The hub name will be displayed on the home page.

FIGURE 31 Renaming the Hub






FIGURE 32 Hub Name on the Home Page



9. Add the SmartThings hub to the app.

FIGURE 33 Locating the SmartThings Hub




10. Click the + icon in the app and go to the **Devices** page to add the hub.

NOTE

Samsung SmartThings hub supports only zigbee/z-wave devices that are listed in add device page.


FIGURE 34 Adding Devices to Hub



11. From the main menu, click **IoT APs**.
The IoT Access Points page is displayed.

12. Select an AP from the list. The sidebar on the right displays the SmartThings information for the selected AP, such as the hub version, dongle status, hub status, hardware version, and serial number.

FIGURE 35 SmartThings Information in the Right Pane



Activating and Editing the Plugins

Plugins are the external vendor connectors that can be connected to a vendor infrastructure after the successful activation of a plugin. Ruckus supports Assa Abloy locks and plugins such as Kontakt.io, iBeacon, Eddystone, Beacon as a Service, Controller Data Stream, Telkonet, Soter, BLE Scan, Dormakaba locks, and React Mobile.

Activating and Editing the Kontakt.io Beacons Plugin


The RUCKUS IoT Controller provides support for the Kontakt.io Beacons plugin.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.

3. In the **Select a Plugin to Activate** list, select the Kontakt.io plugin and click **Activate**.

FIGURE 36 Activating the Kontakt.io Plugin



4. After the Kontakt.io plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE

If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.

- b) For **Aggregation Interval**, set the time interval between the two packets.
- c) Enter the API Key.

The RUCKUS IoT Controller posts the beacon messages using the API Key provided. The Vendor application is responsible for authenticating the API Keys.

- d) Enter the API URL.

The RUCKUS IoT Controller connects to the vendor/connector URL to send the beacon messages. The URL can be a DNS-resolvable, FQDN-based address.

NOTE

The plugin supports HTTP and HTTPS modes.

- e) Enter the Version number.

The default version number is 9.

5. Click **Apply**.


The Kontakt.io plugin is added in the **Active Plugin List**.

Managing IoT Controller System Configuration

Activating and Editing the Plugins


- To deactivate the Kontakt.io plugin, select it and click **Deactivate**.

FIGURE 37 Deactivating the Kontakt.io Plugin



- To edit the configuration of the Kontakt.io plugin, select it and click **Update**.

FIGURE 38 Updating the Configuration Parameters




Activating and Editing the Assa Abloy Plugin

The RUCKUS IoT Controller provides support for the Assa Abloy door locks plugin. The RUCKUS IoT Controller reads the packet from the IoT AP and routes the packets to the Visionline Server.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.
3. In the **Select a Plugin to Activate** list, select the Assa Abloy plugin and click **Activate**.

FIGURE 39 Activating the Assa Abloy Plugin



4. After the Assa Abloy plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to the IoT AP by adding the connector name tag to the IoT AP.

NOTE

If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.

- b) For **Username**, enter the name of the user connecting to the Visionline Server
- c) For **Password**, enter the password of the user connecting to the Visionline Server.
- d) Enter the **Visionline IP address or FQDN**.

NOTE

By default, the port number is 443.


5. Click **Apply**.
The Assa Abloy plugin is added in the **Active Plugin List**.

Managing IoT Controller System Configuration

Activating and Editing the Plugins


6. To deactivate the Assa Abloy plugin, select it and click **Deactivate**.

FIGURE 40 Deactivating the Assa Abloy Plugin



7. To edit the configuration of the Assa Abloy plugin, select it and click **Update**.

FIGURE 41 Updating the Configuration Parameters



Activating and Editing the Eddystone Plugin


The RUCKUS IoT Controller provides support for the Bluetooth Low Energy (BLE) Eddystone plugin. The RUCKUS IoT Controller reads the packet from IoT AP, and routes the packets to the BLE beacon vendor cloud services.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.

3. In the **Select a Plugin to Activate** list, select the Eddystone plugin and click **Activate**.

FIGURE 42 Activating the Eddystone Plugin



Managing IoT Controller System Configuration

Activating and Editing the Plugins

4. After the Eddystone plugin is activated, enter the following configuration parameters.

- a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE

If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.

- b) For **Aggregation Interval**, set the time interval between the two packets.

- c) Enter the Key.

The RUCKUS IoT Controller posts the beacon messages using the Key provided. The Vendor application is responsible for authenticating the Keys.

- d) Enter the API URL.

The RUCKUS IoT Controller connects to the vendor/connector URL to send the beacon messages. The URL can be a DNS-resolvable, FQDN-based address.

NOTE

The plugin supports HTTP and HTTPS modes.

- e) Enter the Port number.

This is the port number on which the vendor/connector web server is running.

- f) Enter the API Endpoint.

This is the API route where the BLE beacon vendor cloud services receive the beacon payload.

- g) Enter the UUID Filter.

The filter allows only the BLE ADV packets with the specified UUID to be passed on to the vendor application.

- h) Enable heartbeat.


Enabling heartbeat allows the vendor application to receive the IoT AP status, such as online or offline.

5. Click **Apply**.

The Eddystone plugin is added in the **Active Plugin List**.


- To deactivate the Eddystone plugin, select it and click **Deactivate**.

FIGURE 43 Deactivating the Eddystone Plugin



- To edit the configuration of the Eddystone plugin, select it and click **Update**.

FIGURE 44 Updating the Configuration Parameters




Activating and Editing the iBeacon Plugin

The RUCKUS IoT Controller provides support for the Bluetooth Low Energy (BLE) iBeacon plugin. The RUCKUS IoT Controller reads the packet from the IoT AP, and routes the packets to the BLE beacon vendor cloud services.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.
3. In the **Select a Plugin to Activate** list, select the iBeacon plugin and click **Activate**.

FIGURE 45 Activating the iBeacon Plugin



4. After the iBeacon plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE

If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.

- b) For **Aggregation Interval**, set the time interval between two packets.
- c) Enter the Key.

The RUCKUS IoT Controller posts the beacon messages using the Key provided. The Vendor application is responsible for authenticating the Keys.

- d) Enter the API URL.

The RUCKUS IoT Controller connects to the vendor/connector URL to send the beacon messages. The URL can be a DNS-resolvable, FQDN-based address.

NOTE

The plugin supports HTTP and HTTPS modes.

- e) Enter the Port number.

This is the port number on which the vendor/connector web server is running.

- f) Enter the API Endpoint.

This is the API route where the BLE beacon vendor cloud services receive the beacon payload.

- g) Enter the UUID Filter.

The filter allows only the BLE ADV packets with the specified UUID to be passed on to the vendor application.

- h) Enable heartbeat.

Enabling heartbeat allows the vendor application to receive the IoT AP status, such as online or offline.

5. Click **Apply**.


The iBeacon plugin is added in the **Active Plugin List**.

Managing IoT Controller System Configuration

Activating and Editing the Plugins


- To deactivate the iBeacon plugin, select it and click **Deactivate**.

FIGURE 46 Deactivating the iBeacon Plugin



- To edit the configuration of the iBeacon plugin, select it and click **Update**.

FIGURE 47 Updating the Configuration Parameters



Activating and Editing the Beacon as a Service Plugin (iBeacon, Eddystone and Custom)


The RUCKUS IoT Controller provides support for the Bluetooth Low Energy (BLE) beaconing service. An AP can begin transmitting BLE beacons (iBeacons) that can be used by the user for various cases, such as wayfinding and pushing.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.


3. In the **Select a Plugin to Activate** list, select the Beacon as a Service plugin and click **Activate**.

FIGURE 48 Activating the Beacon as a Service Plugin (iBeacon)




The screenshot shows the 'Beacon as a Service' configuration window. At the top, there is a title 'Beacon as a Service' and a close button. Below the title, there is a checkbox labeled 'Globally enable connector on all valid APs' which is checked. Underneath, there is a slider for 'Advertisement Interval' set to 100 ms. The 'Beacon Type' dropdown menu is set to 'iBeacon'. Below that, there are text input fields for 'UUID' (0047e70a5dc147258799830544ae04f6), 'Major No' (0102), 'Minor No' (0000), and 'Tx Power Level @1m' (0). An 'Update' button is located at the bottom right.

FIGURE 49 Activating Beacon as a Service (Eddystone)



The screenshot shows the 'Beacon as a Service' configuration window. At the top, there is a title 'Beacon as a Service' and a close button. Below the title, there is a checkbox labeled 'Globally enable connector on all valid APs' which is checked. Underneath, there is a slider for 'Advertisement Interval' set to 100 ms. The 'Beacon Type' dropdown menu is set to 'Eddystone'. Below that, there are text input fields for 'Namespace ID' (48d815a81b09b25a41b1), 'Instance ID' (6b2441d56920), 'URL' (http://www.ruckuswireless.com), and 'Tx Power Level @0m' (0). An 'Update' button is located at the bottom right.

FIGURE 50 Activating Beacon as Service (Generic)



4. After the Beacon as Service plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE
If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.
 - b) In the **Beacon Type** list, select the type of beacon.
 - c) Provide relevant values for given fields based on Beacon Type. For iBeacon, a common 32 characters UUID can be given which will be applied to all APs. If Append AP MAC is checked, Controller will append 12 characters of AP MAC at the end of 20 characters UUID, so that it will be unique for every AP data.
 - d) For **Advertisement Interval**, set the time interval to send the advertisement packets. The advertisement interval ranges from 100 through 1000 milliseconds. The default interval is 100 milliseconds.
5. Click **Apply**.


The Beacon as a Service plugin is added in the **Active Plugin List**.

Managing IoT Controller System Configuration

Activating and Editing the Plugins

- To deactivate the Beacon as a Service plugin, select it and click **Deactivate**.

FIGURE 51 Deactivating the Beacon as a Service Plugin



- To edit the configuration of the Beacon as a Service plugin, select it and click **Update**.

FIGURE 52 Updating the Configuration Parameters (iBeacon)




FIGURE 53 Updating Configuration parameters (Eddystone)





FIGURE 54 Updating Configuration Parameters (Generic)




Activating and Editing the Beacon as a Service Plugin (React Mobile)

The RUCKUS IoT Controller provides support for the React Mobile beaconing service. An AP can begin transmitting React Mobile beacons that can be used by the user for various cases, such as wayfinding and pushing.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.
3. In the **Select a Plugin to Activate** list, select the Beacon as a Service plugin and click **Activate**.

FIGURE 55 Activating the Beacon as a Service Plugin




4. After the Beacon as Service plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE

If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.

- b) For **Advertisement Interval**, set the time interval to send the advertisement packets. The advertisement interval ranges from 100 through 1000 milliseconds. The default interval is 100 milliseconds.
 - c) In the **Beacon Type** list, select the type of beacon as Custom.
 - d) In the **Vendor Type** list, select the type as **React Mobile**.
5. Click **Apply**.
The Beacon as a Service plugin is added in the **Active Plugin List**.
6. To deactivate the Beacon as a Service plugin, select it and click **Deactivate**.

FIGURE 56 Deactivating the Beacon as a Service Plugin



Activating and Editing the BLE Scan Plugin


The RUCKUS IoT Controller provides support for the Bluetooth Low Energy (BLE) BLE Scan Plugin . The RUCKUS IoT Controller reads the packet from the IoT AP and routes the packets to the BLE beacon vendor cloud services.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.

3. In the **Select a Plugin to Activate** list, select the BLE Scan plugin and click **Activate**.

FIGURE 57 Activating the BLE Scan Plugin



4. After the BLE Scan plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE

If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.

- b) For **Aggregation Interval**, set the time interval between the two packets.
- c) Enter the Key.

The RUCKUS IoT Controller posts the beacon messages using the Key provided. The Vendor application is responsible for authenticating the Keys.

- d) Enter the API URL.

The RUCKUS IoT Controller connects to the vendor/connector URL to send the beacon messages. The URL can be a DNS-resolvable, FQDN-based address.

NOTE

The plugin supports HTTP and HTTPS modes.

- e) Enter the Port number.

This is the port number on which the vendor/connector web server is running.

- f) Enter the API Endpoint.

This is the API route where the BLE beacon vendor cloud services receive the beacon payload.

- g) Enter the UUID Filter.


The filter allows only the BLE ADV packets with the specified UUID to be passed on to the vendor application.

- h) Enable heartbeat.

Enabling heartbeat allows the vendor application to receive the IoT AP status, such as online or offline.


5. Click **Apply**.
The BLE Scan plugin is added in the **Active Plugin List**.
6. To deactivate the BLE Scan plugin, select it and click **Deactivate**.

FIGURE 58 Deactivating the BLE Scan Plugin



7. To edit the configuration of the BLE Scan plugin, select it and click **Update**.

FIGURE 59 Updating the Configuration Parameters




Activating and Editing the Controller Data Stream Plugin

The RUCKUS IoT Controller provides support for the Controller Data Stream plugin. The Controller Data Stream is a Message Queue Telemetry Transport (MQTT) data stream. When it is enabled, it sends IoT device-related details to the third-party MQTT endpoint (MQTT Broker). The device data stream is sent to third-party every 300 seconds.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.
3. In the **Select a Plugin to Activate** list, select the Controller Data Stream plugin and click **Activate**.

FIGURE 60 Activating the Controller Data Stream Plugin



The screenshot shows the configuration page for the Controller Data Stream plugin. The page title is "Controller Data Stream" with a close button in the top right corner. Below the title, there is a checkbox labeled "Globally enable connector on all valid APs". The main configuration area includes several input fields: "MQTT Broker IP" with a placeholder "Enter MQTT Broker IP", "MQTT Broker Port" with a placeholder "Enter MQTT Broker Port", and "MQTT Publish Topic" with a placeholder "Eg /topic" and an information icon. Below these is a "Periodic Update Interval" field with the value "10". There are two toggle switches: "Device reporting" which is currently turned off (labeled "No"), and "Validate Server Certificate" which is currently turned on (labeled "Yes"). At the bottom, there is a "Certificate" section with a "Choose file" button and the text "No file chosen". An "Apply" button is located in the bottom right corner.

4. After the Controller Data Stream plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE


If **Globally enable connector on all valid APs** is not selected then you can activate the plugin for each AP by adding tag. Refer [Adding Tags to an AP](#) on page 88 for more information.

- b) In **MQTT Broker IP**, enter the IP address of your MQTT broker.
 - c) In **MQTT Broker Port**, enter the network port to which you want to connect.
 - d) In **MQTT Publish Topic**, enter the topic name as a simple string that is hierarchically structured with forward slashes (/) as delimiters. An MQTT client can publish messages as soon as it connects to a broker.
 - e) In **Periodic Update Interval** enter the interval to receive MQTT Publish.
 - f) Enable **Device Reporting** and enter the topic endpoint which will publish message whenever a device change event is received.
 - g) Enable **Validate Server Certificate** to secure the connection with SSL.
5. Click **Apply**.

The Controller Data Stream plugin is added in the **Active Plugin List**.


6. To deactivate the Controller Data Stream plugin, select it and click **Deactivate**.

FIGURE 61 Deactivating the Controller Data Stream Plugin



7. To edit the configuration of the Controller Data Stream, select it and click **Update**.

FIGURE 62 Updating the Configuration Parameters



Activating and Editing the Dormakaba Plugin


The RUCKUS IoT Controller provides support for for the Dormakaba Door Locks. The RUCKUS IoT Controller reads the packet from the IoT AP and routes the packets to the Ambiance Server.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.

3. In the **Select a Plugin to Activate** list, select the Dormakaba plugin and click **Activate**.

FIGURE 63 Activating the Dormakaba Plugin



4. After the Dormakaba plugin is activated, enter the following configuration parameters.
 - a) Enter the **Client Id** used for connecting to Ambiance Server.
 - b) Enter the **Client Secret** used for connecting to Ambiance Server.
 - c) Enter the **Ambiance IP Address**.
 - d) Enter the **Ambiance Host**.

NOTE

The URL for Host is <https://exmaple.test.net>.

- e) Enter the **Ambiance Port**.
 - f) Enter the **Ambiance Auth Path**.
 - g) Enter the **Ambiance API Path**.
 - h) Enter the **Ambiance API VER Path**.
 - i) Select the **Certificate Mode**.
 - j) Click **Choose file**.
5. Click **Apply**.


The Dormakaba plugin is added in the **Active Plugin List**.

Managing IoT Controller System Configuration

Activating and Editing the Plugins


6. To deactivate the Dormakaba plugin, select it and click **Deactivate**.

FIGURE 64 Deactivating the Dormakaba Plugin



7. To edit the configuration of the Dormakaba plugin, select it and click **Update**.

FIGURE 65 Updating the Configuration Parameters



Activating and Editing the Telkonet Plugin


The RUCKUS IoT Controller provides support for the Telkonet devices and their respective MQTT APIs.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.

2. In the left navigation pane, click **Plugins**.
3. In the **Select a Plugin to Activate** list, select the Telkonet plugin and click **Activate**.

FIGURE 66 Activating the Telkonet Plugin



4. After the Telkonet plugin is activated, enter the following configuration parameters.
 - a) Select **Globally enable connector on all valid APs** to add all respective IoT APs automatically. Connectors are mapped to IoT AP by adding the connector name tag to the IoT AP.

NOTE

If **Globally enable connector on all valid APs** is not selected, you can activate the plugin for each AP by adding a tag. Refer to [Adding Tags to an AP](#) on page 88 for more information.


- b) Enter the IP Address.
This is the IP address of the Telkonet controller.
 - c) Enter the Port number.
This is the port number on which the vendor/connector web server is running.
5. Click **Apply**.
The Telkonet plugin is added in the **Active Plugin List**.

Managing IoT Controller System Configuration

Activating and Editing the Plugins


- To deactivate the Telkonet plugin, select it and click **Deactivate**.

FIGURE 67 Deactivating the Telkonet Plugin



- To edit the configuration of the Telkonet plugin, select it and click **Update**.

FIGURE 68 Updating the Configuration Parameters




Activating and Editing the Soter Plugin

The RUCKUS IoT Controller provides support for the Soter plugin. The Soter Sensor must have IoT Controller MQTT Broker details for the Soter Sensor MQTT Client to connect and transmit data.

To establish a connection to a vendor infrastructure, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Plugins**.
3. In the **Select a Plugin to Activate** list, select the Soter plugin and click **Activate**.

FIGURE 69 Activating the Soter Plugin



4. After the Soter plugin is activated, enter the following configuration parameters.
 - a) Enter the Soter URL.

This URL is used to establish the MQTT connection between the controller and the Soter server.
 - b) Enter the Port number.

This is the port number on which the MQTT server is running.

NOTE

The default MQTT port is 8883.

- c) Enter the Key.

The Vendor application is responsible for authenticating the Keys.
5. Click **Apply**.


The Soter plugin is added in the **Active Plugin List**.

Managing IoT Controller System Configuration

Activating and Editing the Plugins


- To deactivate the Soter plugin, select it and click **Deactivate**.

FIGURE 70 Deactivating the Soter Plugin



- To edit the configuration of the Soter plugin, select it and click **Update**.

FIGURE 71 Updating the Configuration Parameters



Changing the Password

A single administrator is responsible for creating a RUCKUS IoT Controller account. This administrator manages system operations.

To change the password, the administrator must perform the following steps.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Account**.

FIGURE 72 Changing the Password

The screenshot shows a web form for changing a password. At the top right is an "Update password" button. Below it are three input fields, each with a "Show" button to toggle visibility: "Current Password" (placeholder: "Enter Current password"), "New Password" (placeholder: "Enter New password"), and "Confirm New Password" (placeholder: "Retype New password").

3. Change the password and click **Update password**.

Configuring Virtual Machines

Complete the following steps to configure a virtual machine (VM).

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **VM Configurations**.

FIGURE 73 Configuring a Virtual Machine

The screenshot shows the "Admin" page with a left navigation pane. The "VM Configurations" option is highlighted. The main content area contains configuration fields: "Hostname" (value: "vriot"), "Time Zone" (value: "America/Los_Angeles"), "NTP Address" (value: "ntp.ubuntu.com", marked as optional), and radio buttons for "Set Time Automatically using NTP" (selected) and "Set Time Manually". There are "Certificate" and "Key" sections, each with a "Choose file" button and "No file chosen" text. At the bottom are "Upload certificate & Key" and "Download CA certificate" buttons. An "Update" button is located at the bottom right of the configuration area.

Managing IoT Controller System Configuration

Uploading Versions and Patches

3. Complete the configuration information.
 - a) In the **Hostname** field, enter the host name.
 - b) In the **Time Zone** list, select the time zone.
 - c) Select **Set Time Automatically using NTP** or **Set Time Manually** to set the time.
 - d) Click **DHCP** or **Static** to set the RUCKUS IoT Controller configuration.

NOTE

The RUCKUS IoT Controller is configured with a self-signed certificate, but a proper (CA-signed) certificate can be added to the system.

4. Click **Update**.

Uploading Versions and Patches


RUCKUS frequently releases updates to RUCKUS IoT Controller. The administrator normally receives any updates about new and updated software by email.

Uploading an Image

RUCKUS sends periodic notifications by email regarding new versions of the RUCKUS IoT Controller.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Version & Patches**.

FIGURE 74 Uploading an Image




3. Click **Upload Image** to upload the upgrade package.
Once uploaded, the new version is listed in the **Version list**.
4. Select the latest version to upgrade and click **Set**. To remove a version, select it and click **Delete**.

Uploading a Patch

Patches to the software can be downloaded from the RUCKUS Support portal.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Versions & Patches**.

FIGURE 75 Uploading a Patch



3. Click **Upload Patch** to upload the patch.

ATTENTION


You cannot revert a patch.

Backing Up Files

The RUCKUS IoT Controller allows you to back up and restore the configuration and data files. You can restore an existing configuration file on the RUCKUS IoT Controller from which it originated, or restore a configuration file from a different RUCKUS IoT Controller. Backed up files are in the tar.gz format.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **DB Backup**.

FIGURE 76 Backing Up or Restoring Files



3. Click **Create Backup now** to perform a backup manually.
4. Click **Download** to download the backup files.
5. Click **Upload Backup** to upload and restore a DB backup file.

NOTE

The RUCKUS IoT Controller maintains the backups of the last five configuration files. While uploading or restoring database backup file, a dialogue box appears with a message

Use Network Configuration Present in Backup
, so you can select either static or dynamic network configuration present in the backup file.


Backing up Rules

The RUCKUS IoT Controller allows you to back up and restore the static files, and node-red flows. You can restore an existing flow or file on the RUCKUS IoT Controller from which it originated, or restore a from a different RUCKUS IoT Controller. Backed up files are in the tar.gz format.

1. From the main menu, click **Admin**.

- In the left navigation pane, click **Rules Backup**.

FIGURE 77 Backing Up or Restoring Rules




- Select either of the following from the drop-down, and click **Create Rules Backup**.

- **Full Backup**: It is the back up of statics files and nodal flows.
- **Flows Backup**: It is the back up of nodal flows.
- **Static Files Backup**: It is the back up of static files.

- Click **Upload Rules Backup** to upload back up.

A dialog-box appears as below, click **Confirm**.

FIGURE 78 Confirming Upload of Backup File



- Click **Download** to download the backup, **Restore** to restore the backup, and **Delete** to delete the backup.

Uploading the RUCKUS IoT Controller License

To obtain and activate the license, refer to "Activating a License" in the *RUCKUS IoT Controller Software Installation Guide*.

Complete the following steps to upload a license for the RUCKUS IoT Controller.

- From the main menu, click **Admin**.

Managing IoT Controller System Configuration

Uploading the RUCKUS IoT Controller License

2. In the left navigation pane, click **License**.

FIGURE 79 Uploading a License

Controller serial number: 10NUH24GD5M6CC37W57AUD1C1XDK Upload License

AP capacity license used: 11

AP capacity license remaining: 9

AP capacity license total: 20

License List

Name	License type	Description	Start date	Expiry date	Count
INSTANCE-IOTC	Enabled	Permanent License	31-oct-2019	permanent	1
CAPACITY-AP-IOTC	Enabled	Permanent License	31-oct-2019	permanent	20

- Click **Upload License** to upload the license. The License check-out means consuming an AP capacity license, and License check-in means forfeiting an AP capacity license. The License check-out happens when AP is approved. The License check-in happens when AP is deleted or unapproved.

NOTE


In N+1 configuration, for secondary controller the license capacity is unlimited for 30 days.

The Upload License page displays the following information:

- Controller serial number : Displays the number of the RUCKUS IoT Controller serial number which can be used to activate the license.
- AP capacity license used: Displays the number of licenses used by APs.

NOTE

If the number of approved APs are greater than total number of licenses available in the controller , then the GUI is redirected to a warning message as below, and access to the controller comes to an halt until you unapprove or delete the APs to match the license count. The mismatch usually occurs due to DB restore, after upgrade or N+1 failover or fallback.



- AP capacity licenses remaining: Displays the number of unused licenses by APs.
- AP capacity license total : By default, the total number of licenses is 5. If you need an additional license, you must generate a license. To generate a license, refer to "Activating a License" in the *RUCKUS IoT Controller Software Installation Guide*.
- License List: Lists the details of the license, such as **Name**, **License Type**, **Description**, **Start date**, **Expiry date** and **count**.

Change the Settings

N+1 Configuration and Hot Upgrade can be performed only when SSH is enabled.

- From the main menu, click **Admin**.

Managing IoT Controller System Configuration

Change the Settings

- In the left navigation pane, click **Settings**.

FIGURE 80 Settings Page



- Enable **SSH**.

NOTE

If SSH is disabled, the N+1 configuration cannot be established and the following error is observed.

FIGURE 81 Showing Error on Disabling SSH

```
*****
Ruckus IoT Controller
Main Menu
*****

1 - Ethernet Network
2 - System Details
3 - NTP Setting
4 - System Operation
5 - N+1
6 - Comm Debugger
x - Log Off

[Enter Choice: 5

-----
N+1 Status:
-----
      N+1 Mode      : Disabled
-----

[N+1 Configure(1) / Disable(2) / Exit(x) :1
[Start Primary Controller(1) / Secondary Controller(2) / Exit(x) :1

-----
N+1 Configure:
-----
To Configure N+1 ensure following requirements:
*****
* Primary Controller and Secondary Controller should be in same subnet and reachable.
* Primary Controller and Secondary Controller should be configured with static ip address.
* Primary Controller and Secondary Controller should be running in same version.
* Primary Controller and Secondary Controller should have synchronized date/time.

[ Enter Secondary Controller IP :10.174.113.91
[ Enter preferred Virtual IP :10.174.113.70
[ N+1 will stop all services & configurations in Secondary Controller. Enter Y/N to continue : y

[ Error: To configure N+1 please enable SSH in vRIoT controller.
-----
```


Rebooting RUCKUS IoT Controller

If the RUCKUS IoT Controller is experiencing an issue, attempt a reboot to resolve the issue.

Complete the following steps to reboot the RUCKUS IoT Controller.

1. From the main menu, click **Admin**.
2. In the left navigation pane, click **Reset & Reboot**.

FIGURE 82 Rebooting RUCKUS IoT Controller



3. Click **Reboot**.

Resetting RUCKUS IoT Controller

To remove all of the settings that are configured on the RUCKUS IoT Controller, reset it to the factory default settings.

Complete the following steps to reset the RUCKUS IoT Controller to its factory default settings.




CAUTION

Performing the reset action is irreversible.

1. From the main menu, click **Admin**.

2. In the left navigation pane, click **Reset & Reboot**.

FIGURE 83 Resetting RUCKUS IoT Controller



3. Click **Factory Reset**.

Managing IoT Access Points

- IoT AP Overview..... 81
- Adding an IoT AP..... 84
- Editing an IoT AP..... 86
- Adding Tags to an AP..... 88
- Approval of IoT APs..... 90
- Exporting IoT APs to CSV..... 90

IoT AP Overview

SmartZone (SZ) holds the IoT AP firmware. You must make sure the IoT Access Point (AP) connects to SZ and downloads the appropriate IoT firmware. An IoT AP discovers SZ using discovery methods such as DHCP Option 43, Domain Name System (DNS), and Access Point Registry (APR) modes.

The RUCKUS IoT Controller displays the IoT AP hierarchy (Domain, Zone, Group) information, which is derived from the IoT AP and SmartZone connection. Therefore, it is important to ensure that the IoT AP is running the latest appropriate IoT firmware.

An IoT Access Point discovers the RUCKUS IoT Controller by using Option 43 or the RUCKUS Command Line Interface (RKSLI). RKSLI mode is not encouraged, and must be used only if a DHCP server is not present.

DHCP Option 43

The IoT Access Point supports Option 43 with the following suboptions:


- Suboption 21: Used to configure a RUCKUS IoT Controller IPv4 address or FQDN (mandatory)
- Suboption 22: Used to set the control VLAN for IoT Control/Data traffic (optional)

Option 43 supports both binary and ASCII formats. The IoT Access Point bootup process checks for Option 43 and suboptions 06, 21 and 22. Once the application receives this information, it uses the information to connect to the controller over the Pubsub channel.

You can use the DHCP Option 43 sub-option code 06 to set the SCG/vSZ/SZ IP address in the format SubCode /Length/ (Value In Hex). For example : If the IP address is 10.24.123.4, then the hex string is as follows 06 0b 31302e32342e3132332e34.

The DHCP Option 43 sub-option code 21 and 22 is used to set the RUCKUS IoT Controller IP address.

For Example, Windows DHCP Configuration with Sub-option 21 and 22:



Linux DHCP option 43, sub option 21 configuration is as follows:

- option RKUS.scg-address "192.168.0.3"
- option RKUS.riot-address "192.168.0.2";

dhcp_opt43 configuration subopt 22- "vlan_mode.vlan_id"

- #option RKUS.iotvlan-address "0.4" -enables onlink VLAN
- #option RKUS.iotvlan-address "1.4" -enables offlink VLAN
- Offlink VLAN configuration is used when the IOT Gateway/AP and IOT controller are in different networks.
- Onlink VLAN configuration is used when the IOT Gateway/AP and IOT controller are in same network.

RUCKUS Command Line Interface

The `set iotg-mqtt-brokeripRUCKUS-IoT-Controller-IP-address` command can be used to discover the RUCKUS IoT Controller.

USB Power

If an AP does not have enough USB power, it is displayed in the **IoT APs** page with the following message: USB is not having enough power.

FIGURE 84 Displaying a Shortage of USB Power

The screenshot shows the RUCKUS IoT Controller web interface. The top navigation bar includes 'Dashboard', 'IoT APs', 'IoT Devices', 'Events', 'Admin', and 'IoT API'. The user is logged in as 'vriot_B390_primary' with 'N+1 : Disabled'. The version is '1.4.0.0.17' and the location is 'America/Los Angeles'.

The main content area is titled 'IoT Access Points'. On the left, there are two panels: '0 IoT AP Selected' and 'Pre-Approve IoT APs'. The 'Pre-Approve IoT APs' panel contains a table with the following data:

Name	MAC ID	IP Address	Protocols
dhcp-172-16-113-73	E8:1D:A8:0A:F2:80	172.16.113.73	BLE

The right-hand panel shows the configuration for 'dhcp-172-16-113-73', which is 'Online'. It includes a 'Pre-Approve IoT APs' section with a red warning banner: 'USB is not having enough power'. Below this, there are settings for 'IoT AP Approve' (set to 'Yes'), 'IoT Management VLAN' (set to 'No'), and 'IoT CoExistence' (set to 'Off'). At the bottom, there are fields for IP (172.16.113.73), MAC (E8:1D:A8:0A:F2:80), Net Mask (255.255.254.0), and DNS (172.16.200.3).

NOTE

If there is a shortage in USB power, you must contact the customer support team for more details.


Adding an IoT AP

The administrator can add an IoT AP to the RUCKUS IoT Controller to manage IoT devices.

Complete the following steps to add an IoT AP to the controller.

1. From the main menu, click **IoT APs**.
The **IoT Access Points** page is displayed.

FIGURE 85 IoT Access Points Page



2. Click **Pre-Approve IoT APs**.
The **Pre-Approve IoT APs** page is displayed.

3. To add a single IoT AP, click **Single**.

FIGURE 86 Adding a Single IoT AP

The screenshot displays a web interface for adding IoT APs. At the top, the title is "Pre Approve IoT APs". Below the title are two tabs: "Single" (which is highlighted in orange) and "Batch". A horizontal line separates the tabs from the input fields. The first field is labeled "MAC *" and contains the text "0E:0D:6F:00:0F:00". The second field is labeled "Tag" and contains the text "Add new tag". At the bottom of the form, there are two buttons: "Cancel" on the left and "Save" on the right.

4. Enter the MAC address of the IoT AP and click **Save**.

The IoT AP is now added to the IoT AP list.

NOTE

To add multiple IoT APs, click **Batch** and download the CSV template. Enter the required details in the CSV template and click **Upload**.

FIGURE 87 Adding a Batch of IoT APs

The screenshot shows a web interface for adding IoT APs. At the top, there is a section titled "Pre Approve IoT APs" with two tabs: "Single" and "Batch". The "Batch" tab is selected and highlighted in orange. Below the tabs, there is a "Download CSV Template" button. Underneath that is a file selection area with a "Choose File" button and the text "No file chosen". At the bottom of the interface, there are two buttons: "Cancel" on the left and "Upload" on the right.

Editing an IoT AP

The administrator can edit an IoT AP to change its settings and name. Edits can be made on a single IoT AP or on IoT APs in bulk.


Single IoT Access Point Mode

You can use Single IoT Access Point Mode to edit a single IoT AP.

Complete the following steps to edit a single IoT AP.

1. From the main menu, click **IoT APs**.
A list of selected IoT APs is displayed.
2. Click an IoT AP to edit.

FIGURE 88 Single IoT AP Mode



Existing information displays, and the following options can be edited:

- **Add New Tag**
- **Scan for IoT Devices**
- **Restart IoT Service**
- **IoT AP Approve**
- **Mode** (Zigbee, BLE, Zigbee Assa Abloy)
- **IoT Coexistence**
- **Set Channel**
- **Set TxPower**
- **IoT Management VLAN**
- **AP Firmware**
- **AP Model**

In addition, the status of the IoT AP module is available, such as network information, IoT AP module information, and properties.

3. Click **IoT Management VLAN** to configure the VLAN mode.
4. Select **ONLINK** to configure the VLAN within the same network.
5. Select **OFFLINK** to configure the VLAN within different network or different region.

Adding Tags to an AP


The AP tags are a way of grouping APs together by applying identifying tags. If the **Globally enable connector on all valid APs** is disabled when activating a plugin, complete the following steps to add tags to an AP to activate a plugin on the AP.

1. From the main menu, click **IoT APs**.
A list of IoT APs is displayed.
2. Select an IoT AP.

NOTE

You can select one or more APs to add tags.


FIGURE 89 Selecting an AP to Add Tags



3. Select **Add Tags** from the **Batch Actions** list.

- Click **Apply**. The **Add Tags on Selected IoT APs** page is displayed. Enter the tag name in the field **Add new tag** field and click **Add**.

FIGURE 90 Adding a Tag



To activate a plugin, you must label the plugin with the respective tag name. The following table lists the plugins and corresponding tag names.

TABLE 5 Plugins and Corresponding Tag Names

Plugin	Tag Name
Kontakt.io Beacons	kontakt
iBeacon	ibeacon
Beacon as a Service	baas
Eddystone	eddstone
BLE Scan	blescan

Approval of IoT APs

The IoT APs must be approved by the administrator. The RUCKUS I100 IoT Module is activated only for approved APs. There is an option to disapprove a previously approved AP. This operation can be performed on a single AP (using Single IoT Access Point Mode) or on multiple APs (using Bulk AP Mode).

Exporting IoT APs to CSV

You can export IoT APs to CSV by clicking **Export IoT APs to CSV**, which allows to download all the APs in the IoT APs page, and the corresponding information into a CSV format file that can be saved.

The screenshot displays the 'IoT Access Points' management page. On the left, a panel shows '0 IoT AP Selected' and '[No Data Available]'. The main area features a 'Pre-Approve IoT APs' section with a table of APs. The table has columns for Name, MAC ID, IP Address, Protocols, Uptime, and Actions. One AP is listed: 'RuckusAP' with MAC ID '20:50:69:11:09:10', IP Address '192.168.25.104', and Protocols 'BLE, ZigBee'. The Actions column contains icons for search, delete, and a dropdown menu with options: All, RuckusAP, hantek, Stream, eddyline, dan, limcau. At the bottom left, the 'Total IoT APs:' label is followed by a button labeled 'Export IoT APs to CSV', which is highlighted with a red rectangle. The bottom right shows 'Displaying 10 gateways' and navigation buttons for 'Previous' and 'Next'.

Managing Devices

- Devices Overview..... 91
- Managing OSRAM Light Bulbs..... 94
- Managing an Assa Abloy Lock..... 95
- Managing the Dormakaba Locks..... 96

Devices Overview


The RUCKUS IoT Controller requires explicit user approval of devices. Only an approved device can be allowed into the IoT infrastructure.

To add devices to the RUCKUS IoT Controller or to view the beacons for an AP, from the main menu, click **IoT Devices**.

The **IoT Devices** page shows the following items:

- A list of devices
- The operations on devices (such as remove, blacklist, and device-specific operations)

FIGURE 91 IoT Devices Page




The device scan operation must be performed to start the device discovery process on the gateway.

NOTE

It is important that the IoT devices are scanned and onboarded to the nearest AP for good RSSI/LQI. For more information about RSSI/LQI for reliable connection, refer to <https://support.ruckuswireless.com/articles/000011687>.


Upon starting device discovery, a dialog box is displayed, as shown in the following figure.

FIGURE 92 Device Discovery Dialog Box



A device gets added to the RUCKUS IoT Controller through Discover IoT Devices operations. If a device is pre-approved, the discovered device automatically joins the list of discovered devices. If the discovered device is not pre-approved, then you must select **Accept** or **Blacklist**. If the device is accepted, it joins the list of discovered devices.

FIGURE 93 Adding Device After Discovery



The **Beacons** page shows the list of beacons for the selected AP.

FIGURE 94 Beacons Page

IoT Devices

Devices Beacons

IoT AP
0C:F4:D5:1E:97:D0

Beacon Info

Vendor ID : 0x004C (45)
Latitude : 0 Longitude : 0

Device MAC	Last Seen	RSSI	Data
00:00:2C:B4:3A:1A:22:BE	a few seconds ago	-81	02011A0BFF4C000906032C00000000
00:00:2C:B4:3A:1A:22:BE	a few seconds ago	-83	02011A0BFF4C000906032C00000000
00:00:D5:7C:FF:20:F8:93	a few seconds ago	-72	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893E897E0D83B3
00:00:C5:D5:A5:CB:6C:81	a few seconds ago	-78	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893E6D608F43B3
00:00:F8:DA:65:7E:5F:9D	a few seconds ago	-76	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893E42C5A64FB3
00:00:F1:83:5D:72:C9:33	a few seconds ago	-65	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893E17BF0E0FB3
00:00:F1:83:5D:72:C9:33	a few seconds ago	-64	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893E17BF0E0FB3
00:00:F1:83:5D:72:C9:33	a few seconds ago	-61	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893E17BF0E0FB3
00:00:F7:85:E7:B5:18:16	a few seconds ago	-78	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893E2F870E08B3
00:00:FE:0A:A0:AC:80:DA	a few seconds ago	-64	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893EEC13910FB3
00:00:FE:0A:A0:AC:80:DA	a few seconds ago	-59	0201061AFF4C000215F7826DA64FA24E988024BC5B71E0893EEC13910FB3

Total Beacons : 62

Previous Next

The **Export IoT Devices to CSV** will allow to download all the Devices in the IoT devices page and corresponding information into a CSV format file which can be saved.

FIGURE 95 Exporting IoT Devices to CSV

IoT Devices

0 Device Selected

Devices Beacons Pre-Approve IoT Devices

Batch Actions: Select Apply

Name	MAC ID	IoT AP MAC	Protocol	Type	LQI	RSSI	Last Seen	Action	Tags
Telko-PH01	00:0A:80:00:11:00:37:1D	20:5B:69:11:09:10	zigbee	IAS Zone	66	-58	5 minutes ago	⊗	All Telko-PH01
Telko-PH02	00:0A:80:00:11:00:30:4E	20:5B:69:11:09:10	zigbee	IAS Zone	61	-60	6 minutes ago	⊗	All Telko-PH02
Telko-PH03	00:0A:80:00:11:00:33:F3	20:5B:69:11:09:10	zigbee	IAS Zone	72	-54	5 minutes ago	⊗	All Telko-PH03
ST-button	28:40:97:00:01:08:43:2D	20:5B:69:11:09:10	zigbee	IAS Zone	72	-54	10 minutes ago	⊗	All ST-button
ST-water	28:40:97:00:01:08:08:24	20:5B:69:11:09:10	zigbee	IAS Zone	58	-63	6 minutes ago	⊗	All ST-water
ST-PIR	28:40:97:00:01:06:A0:17	20:5B:69:11:09:10	zigbee	IAS Zone	77	-51	5 minutes ago	⊗	All ST-PIR
Telko-Door	00:0A:80:00:10:00:50:18	20:5B:69:11:09:10	zigbee	IAS Zone	45	-71	3 hours ago	⊗	All Telko-Door
erle-motion	00:15:80:00:01:A6:C9:34	20:5B:69:11:09:10	zigbee	IAS Zone	36	-77	23 minutes ago	⊗	All erle-motion

Total Devices : **Export IoT Devices to CSV**

Displaying 10 devices

Previous Next


Managing OSRAM Light Bulbs

To discover OSRAM light bulbs, complete the following operations.

1. Ensure that the bulb is in the OFF state.
2. Switch on the power for five seconds.
3. Switch off the power for two seconds.
4. Repeat steps 2 and 3 five times.
5. Switch on the power.

The OSRAM light bulb on the Reset/Initiate discovery blinks blue, green, and red, and then the light bulb remains on.

FIGURE 96 Managing OSRAM Light Bulb



After clicking the device, the right pane is displayed. In this pane, you can edit device configurations and device operations. To change device configurations, set the device name in the **IoT Device Name** field, select an AP association from the **IoT AP** list, select the device tag from the **Add new tag** list, and set the device blacklist from the **BlackList Device** list. Device operations depend on the device selected.

NOTE

In the preceding figure, the device operations are on/off, color, and brightness, because the discovered device type is an OSRAM light bulb.

Managing an Assa Abloy Lock

Assa Abloy locks cannot be controlled using the RUCKUS IoT Controller. To discover an Assa Abloy lock and to add it in the RUCKUS IoT Controller, perform the following steps.

1. Swipe the AA Lock Discover Card across the lock.
2. Ensure that the LED blinks green.
3. Add the lock to the RUCKUS IoT Controller (if it is not already pre-approved).

Assa Abloy locks operate using the Visionline server. To establish the initial connection (after adding the lock) between an Assa Abloy lock and the Visionline server, perform the following steps.

1. Swipe the card (guest or staff card) in front of the lock.
2. Verify the event log from the Visionline Server Event Log to ensure that the connection is established.

NOTE

For more information, refer to the Visionline documentation for instructions on installing Visionline.

FIGURE 97 Visionline Server Event Log

Room Event List						
Ro...	Regist...	Time	Event	Card Name	User Group	SeqNum
102	100085	8/18/2017 6:53:00 PM	Guest Card accepted (67)	Guest (MC)	Guest	2
102	100085	8/18/2017 6:53:00 PM	A loyalty card was encoded (1264)	Guest (MC)	Guest	1
102	100085	8/18/2017 6:53:00 PM	Added a card image to the loyalty-card list (120)	Online Command	Online	0
104	100083	8/18/2017 6:52:00 PM	Guest Card accepted (67)	Guest (MC)	Guest	6
101	100084	8/18/2017 6:51:00 PM	Guest Card accepted (67)	Guest (MC)	Guest	11


Managing the Dormakaba Locks

The communication between Ambiance Server and RUCKUS IoT Controller takes place through API Endpoints.

You must configure the IP address of the controller by performing the following steps.


1. In the Ambiance Server, go to `C:\Program Files\dormakaba\Ambiance Server\Web\WebAPI\web.config` file and open the web.config file in notepad.

FIGURE 98 Locating the web config file



- From the row, **HubGatewayServiceUri** value="http://10.74.136.127/", select the IP address of the controller.

FIGURE 99 Finding the IP Address



```
web - Notepad
File Edit Format View Help
<add key="PmsRestApiURL" value="http://localhost:45226/" />

<add key="PMSRestAPIUser" value="admin01" />
<add key="PMSRestAPIKey" value="admin@01" />

<add key="timeout" value="3600000" />
<add key="ConnectionToRabbitMQRetrialCount" value="1" />
<add key="ConnectionToRabbitMQRetrialDelayInSeconds" value="20" />
<add key="DependencyServerRetryDelaySeconds" value="2" />
<add key="DependencyServerRetryCount" value="5" />

<!--Rest EndPoint URI TODO Move to syssetting-->
<add key="HubGatewayServiceUri" value="http://192.168.0.2/" />
<!--Log and Tracing Settings-->
<add key="enableTracing" value="false" />
<add key="log4net.Internal.Debug" value="false" />
<add key="logConfigFile" value="%katimavik_root%\log4net.config" />

<add key="ClientInstallationPackageLocation" value="C:\Program Files\dormakaba\Ambiance Server\Web\Ambiance_Client.exe" />
<add key="ClientInstallationPackageName" value="Ambiance_client.exe" />
<add key="ClientInstallationConfigPackageLocation" value="C:\Program Files\dormakaba\Ambiance Server\Web\serverURL.config" />
<add key="ClientInstallationConfigPackageName" value="serverURL.config" />
</appSettings>
<system.web>
  <trace enabled="false" pageOutput="false" requestLimit="40" localOnly="false" />
  <compilation debug="true" targetFramework="4.6.2" />
  <httpRuntime maxRequestLength="1048576" targetFramework="4.5" />
</system.web>
<runtime>
  <ThrowUnobservedTaskExceptions enabled="false" />
  <assemblyBinding xmlns="urn:schemas-microsoft-com:asm.v1">
    <dependentAssembly>
      <assemblyIdentity name="System.Net.Http" publicKeyToken="B03F5F7F11D50A3A" culture="neutral"/>
      <bindingRedirect oldVersion="0.0.0.0-4.2.0.0" newVersion="4.0.0.0"/>
    </dependentAssembly>
  </assemblyBinding>
</runtime>
```

Discovering Dormakaba Lock

Dormakaba locks cannot be controlled using the RUCKUS IoT Controller. To discover a Dormakaba lock and to add it in the controller, perform the following steps.


- Select the Gateway and start a Device Scan from Ambiance UI.
A scan window appears in the UI.
- Swipe the Dormakaba Pairing Card across the lock.
- Ensure that the LED blinks.
Dormakaba Lock details will show in the Scan Window of the controller.
- Add the lock to the Ruckus IoT Controller (if it is not already pre-approved).
- Go to **Device Management** page, select the **Gateway**, click on **Next** to Access Points in the Ambiance UI.
You can now verify if the lock has established its communication with Ambiance Server.

Blocking and Unblocking Dormakaba Lock

Dormakaba locks operate using the Ambiance server. Complete the steps below to onboard lock.


1. Login to the Ambiance Server. The default username and password is **Admin01** and **Admin@01**.

FIGURE 100 Login into Dormakaba Plugin



2. Click **Device Management**.

FIGURE 101 Selecting Device Management



Managing Devices

Managing the Dormakaba Locks

3. Click Register Gateways & Paired Access Points.

FIGURE 102 Selecting Register Gateways and Paired Access points


The screenshot displays the 'Ambiance™ - Device Management' web interface. The main heading is 'REGISTERED GATEWAYS & PAIRED ACCESS POINTS'. Below this, there are three metrics: 'ONLINE GATEWAYS - 4/4' at 100%, 'ONLINE ACCESS POINTS - 1/8' at 12.5%, and 'LOW BATTERY - 0/8' at 0%. The 'Gateways' section is active, showing a list of four gateways. The first gateway, 'Gateway-8CFE741071A0', is selected and has its 'Pairing' status set to 'ON'. A 'Send Command' button is visible. Below the table, there are navigation buttons: 'Back to device selection', 'Delete Gateway(s)', and 'Next to access points'. The footer shows '© 2020 - Ambiance™ - 2.4.1.3' and the date '10/12/2020 12:05 PM'.

Gateway	Status	Type	MAC Address	IP Address	Antenna	Last
<input checked="" type="checkbox"/> Gateway-8CFE741071A0		dormakaba Gateway	8CFE741071A0	192.168.0.4	Pairing OFF	10/12
<input type="checkbox"/> Gateway-B479CB1E60C0		dormakaba Gateway	B479CB1E60C0	192.168.0.2	Pairing OFF	10/12
<input type="checkbox"/> Gateway-CB03F5109440		dormakaba Gateway	CB03F5109440	192.168.0.2	Pairing OFF	10/12
<input type="checkbox"/> Gateway-CB087318B840		dormakaba Gateway	CB087318B840	192.168.0.2	Pairing OFF	10/12

4. From the **Gateways**, select a gateway, and from the pull down select **Pairing ON** and click **Send Command** to start the gateway in scanning mode.
5. Swipe RF Pairing key card.
The LED pattern blinks green LED once, and amber colour LED thrice.
6. Lock will appear in IoT Controller's **Scan Window**, give name to the Lock and click **Accept**.
7. Select the same **Gateway**, from pull down menu and select **Pairing OFF**, and click **Send Command** to stop pairing.

- Click **Device manager > Registered Gateways & Access Points**, and select the Access point.

FIGURE 103 Displaying the Lock




- To confirm the lock connection, select the sage gateway, and click **Next to Access Point**.

Blocking the Key Remotely

Perform the below steps to block the key remotely.


1. Go to Dormakaba Homepage.

FIGURE 104 Dormakaba Homepage




2. Click **System Keys**.

FIGURE 105 Selecting the System Keys




3. Click **Block Keys**.

FIGURE 106 Selecting the Block Keys




4. Click **Next to credential**.

FIGURE 107 Clicking the option Next to credential




- From the list, select **Guest** to block a **Guest room**.

FIGURE 108 Selecting Guest from the drop-down list



- Select a guest room number from the drop-down list to block the key.

FIGURE 109 Selecting the Guest Room Number



- Click **Block Key Remotely**.


After you click **Block Key Remotely**, the LEDs will glow in the following pattern - one solid red LED, six green, and yellow LED together.

Unblocking the Key Remotely

Perform the below steps to unblock the keys remotely.


1. Go to the Dormakaba Homepage.

FIGURE 110 Dormakaba Homepage



2. Click **System Keys**.


FIGURE 111 Selecting the Unblock Keys



Managing Devices Managing the Dormakaba Locks


3. Click **Next to Credential**.

FIGURE 112 Clicking the option Next to Credential



4. From the list select **Guest** to unblock a guest room.

FIGURE 113 Selecting Guest from the drop-down list



5. Select a guest room number to unblock.

6. Click **Unblock Key Remotely**.

After you click **Unblock Key Remotely**, the LEDs will glow in the following pattern - one solid red LED, six green, and yellow LED together.

Rules Engine

- Rules Engine Overview..... 110
- Configuring Rules..... 110
- Rules-Dashboard..... 111

Rules Engine Overview

The RUCKUS IoT Controller provides a provision to write custom rules using the Node-RED tool. The Rules Engine provides a browser-based Node-RED editor that makes design flows using the wide range of nodes in the palette. These nodes can be deployed at runtime in a single click.

Configuring Rules

The RUCKUS IoT Controller allows you to configure a rule or design a flow for an AP or device by using a wide range of the nodes in the palette of Node-RED editor.


Complete the following steps to configure a rule.

1. From the main menu, click **Rules > Configuration**.

NOTE


To create the rules, refer to <https://nodered.org/docs/>.

FIGURE 114 Configuring a Rule



- Click the **http request** node.

FIGURE 115 Editing the HTTP Request Node



Enter the login credentials, such as username and password, in the **Username** and **Password** fields, respectively.

- Click **Deploy**.

The workflow is ready to be deployed.

Rules-Dashboard

The **Rules-Dashboard** displays the configured rules.

- From the main menu, click **Rules > Rules-Dashboard**.

FIGURE 116 Rules-Dashboard

Name	MAC ID	IoT AP MAC	Protocol	Type	LQI	RSSI	Last Seen
Sample	00:00:00:00:00:00	20:58:69:38:B8:F0	NA	Simple Sensor	0	0	0
20:58:69:38:B8:F0	20:58:69:38:B8:22	20:58:69:38:B8:F0	NA	Simple Sensor	0	0	0
20:58:69:38:B8:11	20:58:69:38:B8:11	20:58:69:38:B8:F0	NA	Simple Sensor	0	0	0

The **Rules-Dashboard** lists the configured devices.



2. Click  .
A browser opens with the **Rules-Dashboard** page.
3. Click File-Manager.
A File-Manager page opens
4. Click **Upload Files**.

FIGURE 117 Uploading Files in the File Manager



NOTE

The following file-formats are supported to upload the file.

- HTML
- CSS
- PNG
- JPEG
- GIF

LoRaWAN

- [LoRaWAN Overview.....](#) 113
- [Logging In to the LoRa Network](#) 113
- [LoRaWAN Dashboard.....](#) 114
- [Configuring LoRa Devices](#) 115
- [Configuring LoRaWAN Routers.....](#) 117

LoRaWAN Overview

LoRa is a wireless technology used for IoT applications. LoRaWAN can be provisioned using the LoRa Network Server (LNS) that is embedded in the RUCKUS IoT Controller. The RUCKUS IoT LNS is able to communicate with LoRa routers, end devices, and as well as with LoRa application servers through its northbound interfaces.


Logging In to the LoRa Network

LoRaWAN is a media access control (MAC) protocol for wide area networks. It is designed to allow low-powered devices to communicate with Internet-connected applications over long-range wireless connections.

Complete the following steps to access the LoRa network.

1. From the main menu, click **LoRa LNS**.
The LoRaWAN login page is displayed.

FIGURE 118 Logging In to the LoRaWAN



2. Enter the login credentials and click **Submit**.


NOTE

The login credentials for the LoRaWAN network and the RUCKUS IoT Controller are the same.

LoRaWAN Dashboard

The LoRaWAN dashboard provides the count of routers and devices connected to the LoRa Network Server (LNS) of the RUCKUS IoT Controller. It also displays the messages related to network traffic.

FIGURE 119 LoRaWAN Dashboard



- 1. Header Panel
- 2. Main Control Panel
- 3. Navigation Bar

The following table describes the components of the LoRaWAN dashboard.

TABLE 6 Identifying the Various Components of the LoRaWAN Dashboard

Name	Components
Header Panel	<p>Consists of the following components:</p> <ul style="list-style-type: none"> • Help icon • Refresh icon • Name of the user

TABLE 6 Identifying the Various Components of the LoRaWAN Dashboard (continued)


Name	Components
Main Content Panel	<p>Consists of the following components:</p> <ul style="list-style-type: none"> • Devices: Displays the count of LoRa devices connected to the LNS. <p style="text-align: center;">NOTE If you click Management, the Devices page is displayed with more information about the devices.</p> • Routers: Displays the count of LoRa routers connected to LNS. If you click Management, the Routers page is displayed with more information about the routers. • Traffic: Displays the traffic in the network. <p style="text-align: center;">NOTE If you click Message, the Message traffic page is displayed. If you click Inspect, the Watchboard page is displayed.</p> • Downloads: Allows you to download API specification files. • Notifications: Displays the notifications. • Version History: Displays the version history of LoRa Network Server (LNS).

Configuring LoRa Devices

Before you add LoRa devices to the Lora Network Server (LNS), you must provision the device.


1. On the **Devices** page, click  to provision the device.

FIGURE 120 Configuring LoRa Devices




The following example shows the configuration of the device Semtech TBDW100 Door/Window Sensor device. Different devices have different ways to configure the gateway to communicate with the LNS of the Ruckus IoT Controller.

FIGURE 121 Provisioning the Device



2. Enter values for the device parameters. (Refer to the previous figure for an example.)
 - **Device EUI:** The MAC ID of the device.
 - **Owner:** Select the one who is provisioned from the list.
 - **Derivation:** Select the check box to derive keys from a specified secret.
 - **Region:** Must be U.S. or block0 (from menu).
 - **LoRaWAN Version:** The version number of the LoRaWAN.
 - **Device class:** Must be A, B, or C.
 - **Join EUI:** A group indicator with no actual configuration-enforcing meaning, though in a product there are conventions to follow.
 - **Network Key:** Enter the network key provided by the manufacturer.
 - **App Key:** Enter the application key provided by the manufacturer.
3. Click **Add**. The device is added to the LNS.

FIGURE 122 Device Joining the LNS



NOTE

When the FCntUp variable receives a packet, the state changes from ProV to ALIVE.

Configuring LoRaWAN Routers

To add a router to the LoRa Network Server (LNS), you must provision the router.

Complete the following steps to configure the Semtech LoRa PicoCell Gateway to communicate with the LoRa Network Server (LNS) in the Ruckus IoT Controller.


NOTE

Different routers have different ways of provisioning the gateway.

Preparing the Semtech LoRa PicoCell Gateway


1. Load PicoGW_UI_Release_V1.0.3.4 and run **Setup**.
2. In the **Properties_UI** dialog box, address the following options:
 - Select the **Use a cloud network** check box.
 - Click **Get Gateway Unique**.
 - Select the **Use custom gateway ID** check box.
 - Copy the ID to the copy buffer to use later in the process.
 - Change the **Server address** to the IP address of the TrackCentral LNS.
 - Set **Port up** and **Port down** to **1680**.
 - For **Tx lut**, select **Tx_Lut_15** and set the **Rf power** to **30 dBm** (to allow the end device to join the ACK TX).

FIGURE 123 Configuring the LoRa Picocell Gateway



3. Select the Global Conf option, and launch the packet forwarder by selecting **Show packet forwarder console**.

FIGURE 124 Starting Packet Forwarder



Configuring the Semtech LoRa PicoCell Gateway as a Router in the LNS

Complete the following steps to configure the Semtech LoRa PicoCell Gateway as a router in the LoRa Network Server (LNS).



1. On the **Routers** page, click  to configure the router.
 - a) In the **Owner** field, enter the name of the owner.
 - b) In the **MAC address** field, enter the MAC address or router ID by adding a colon between every four characters.
 - c) In the **Router name** field, enter the name of the router.
 - d) In the **Region** field, select a region from the list.

FIGURE 125 Configuring the Router



The screenshot shows the RUCKUS IoT Controller interface. At the top, there is a navigation bar with the RUCKUS logo and 'IoT Controller' text, followed by menu items: Dashboard, IoT APs, IoT Devices, Events, Admin, Rules, LoRa LNS, and IoT API. Below this is a 'LoRaWAN' header. A blue bar contains a hamburger menu icon, the word 'Routers', and an 'Admin' button. Underneath, there are two tabs: 'ROUTER-TABLE' (selected) and 'ROUTER-MAP'. A search bar is present with a magnifying glass icon and a search icon. To the right of the search bar is a '+', a minus, a pencil, a gear, a trash, a refresh, and a '15' count. A dropdown menu is open, showing a list of router IDs: 'Router ID' and 'router-1:'. The main configuration form is displayed with the following fields:

- Name**: Name/::1
- Owner ID**: 3535:3032:2E00:6300
- Name**: Test Router PicoCell
- MAC address or router ID**: Address or Lat,Lon
- Router name**: 0,0
- Region**: US902/block0
- Hardware specification**: pkfwd
- RxDelay**: RX1DRoff
- Delay for RX1/2**: Datarate offset for RX1.

At the bottom of the form, there are 'ADD', 'CLOSE', and a help icon (?) buttons.


LoRaWAN

Configuring LoRaWAN Routers

2. Click **ADD**.

The router is added to the LNS.

FIGURE 126 Adding the Router to the LNS



The screenshot shows the RUCKUS IoT Controller interface. The top navigation bar includes "RUCKUS IoT Controller" and various menu items like "Dashboard", "IoT APs", "IoT Devices", "Events", "Admin", "Rules", "LoRa LNS", and "IoT API". The main content area is titled "LoRaWAN" and shows a "Routers" table. The table has columns for "Router ID", "Name", "Connected", and "Region". Two routers are listed: "router-1:" with "IsAlive System Health" and "EU863", and "router-3535.3032.2e00.6300" with "TestRouter" and "US902/block0". Below the table, there is a detailed view for the selected router, showing fields like "Router ID", "Name", "Connected", "Owner", "Region", "GPS Location", "MAC Address", "Connection", "Firmware", "#Up", "#Down", "Last Uptime", "Last Dntime", and "Last Connect".

Router ID	Name	Connected	Region
router-1:	IsAlive System Health		EU863
router-3535.3032.2e00.6300	TestRouter		US902/block0

ROUTER-INFO

RID: 3834023649654121000
Router ID: router-3535.3032.2e00.6300
Name: TestRouter
Connected:

Owner: owner-1
Region: US902/block0
GPS Location: 0.0000,0.0000
MAC Address: 30:32:2E:00:63:00
Connection: udp://192.168.0.32:52981@muxs-...
Firmware: Protocol Version 2
#Up: 0
#Down: 0
Last Uptime: 69-12-31-16:00:00
Last Dntime: 69-12-31-16:00:00
Last Connect: 69-12-31-16:00:00

Events

- Viewing Events..... 121
- Viewing SmartThings Event..... 122

Viewing Events


An event is an occurrence or the detection of certain conditions in and around the RUCKUS I100 IoT Module. An AP rebooting, detection of a RUCKUS I100 IoT Module, module undetection, and module swap are all examples of events.

Complete the following steps to view events.

1. From the main menu, click **Events**.

The **Events** page is displayed.

FIGURE 127 Events Page



Time	AP MAC	ID	Event	Message
2020-10-14 06:51:30.895026	18:4B:0D:22:A1:90	5	Radio Message Delivery Failed	00:17:7A:D1:06:03:EA:07 is not responding for command '0x00AA'
2020-10-14 06:24:37.472023	B4:79:C8:3E:75:40	5	Radio Message Delivery Failed	0xFFFD is not responding for command '0x00FF'
2020-10-14 05:34:27.287314	B4:79:C8:3E:75:40	5	Radio Message Delivery Failed	0xFFFD is not responding for command '0x00FF'
2020-10-14 03:25:00.686952	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.675017	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.663326	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.651257	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.640624	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.628133	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.615276	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.602752	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.589194	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.575277	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 03:25:00.550865	C8:08:73:26:AA:D0	5	Radio Message Delivery Failed	00:0A:80:00:10:00:3D:04 is not responding for command '0x0000'
2020-10-14 00:53:29.808857	B4:79:C8:3E:75:40	5	Radio Message Delivery Failed	0xFFFD is not responding for command '0x00FF'

2. Click **Download** to download the event logs file.

The event logs file contains the time of the event occurrence, its MAC address, and event name.

3. Click **Clear** to clear the log file.

Events

Viewing SmartThings Event

Viewing SmartThings Event


The **Events** page shows the SmartThings events from AP.

Complete the following steps to view events.

1. From the main menu, click **Events**.

The **Events** page is displayed.

FIGURE 128 Event page for Smartthings



Time	AP MAC	ID	Event	Message
2020-12-15 07:43:49.999590	94:F6:65:2A:2A:50	200	ST Upgrade	Upgrade Success
2020-12-15 07:43:49.951628	94:F6:65:2A:2A:50	200	ST Upgrade	Upgrade Success
2020-12-15 07:41:37.561340	94:F6:65:2A:2A:50	6	Upgrade	Controller version 1.7.0.0.20 supports AP st firmware version 1.7.0.32.12, Gateway 94:F6:65:2A:2A:50 is in st firmware version 0 - Send upgrade.
2020-12-15 07:41:37.151674	94:F6:65:2A:2A:50	6	Upgrade	Controller version 1.7.0.0.20 supports AP st firmware version 1.7.0.32.12, Gateway 94:F6:65:2A:2A:50 is in st firmware version 0 - Send upgrade.
2020-12-15 07:41:17.499438	94:F6:65:2A:2A:50	6	Upgrade	Controller version 1.7.0.0.20 supports AP st firmware version 1.7.0.32.12, Gateway 94:F6:65:2A:2A:50 is in st firmware version 0 - Send upgrade.
2020-12-15 07:41:17.064761	94:F6:65:2A:2A:50	6	Upgrade	Controller version 1.7.0.0.20 supports AP st firmware version 1.7.0.32.12, Gateway 94:F6:65:2A:2A:50 is in st firmware version 0 - Send upgrade.

2. Click **Download** to download the event logs file.

The event logs file contains the time of the event occurrence, its MAC address, and event name.

3. Click **Clear** to clear the log file.

COMMScope®
RUCKUS®

© 2021 CommScope, Inc. All rights reserved.
350 West Java Dr., Sunnyvale, CA 94089 USA
<https://www.commscope.com>