



COMMAND REFERENCE GUIDE

# RUCKUS ZoneDirector 10.4.1

## Command Line Interface

### Reference Guide

**Supporting ZoneDirector 10.4.1**

# Copyright, Trademark and Proprietary Rights Information

© 2022 CommScope, Inc. All rights reserved.

No part of this content may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from CommScope, Inc. and/or its affiliates ("CommScope"). CommScope reserves the right to revise or change this content from time to time without obligation on the part of CommScope to provide notification of such revision or change.

## Export Restrictions

These products and associated technical data (in print or electronic form) may be subject to export control laws of the United States of America. It is your responsibility to determine the applicable regulations and to comply with them. The following notice is applicable for all products or technology subject to export control:

*These items are controlled by the U.S. Government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations.*

## Disclaimer

THIS CONTENT AND ASSOCIATED PRODUCTS OR SERVICES ("MATERIALS"), ARE PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, COMMSCOPE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, NON-INFRINGEMENT, FREEDOM FROM COMPUTER VIRUS, AND WARRANTIES ARISING FROM COURSE OF DEALING OR COURSE OF PERFORMANCE. CommScope does not represent or warrant that the functions described or contained in the Materials will be uninterrupted or error-free, that defects will be corrected, or are free of viruses or other harmful components. CommScope does not make any warranties or representations regarding the use of the Materials in terms of their completeness, correctness, accuracy, adequacy, usefulness, timeliness, reliability or otherwise. As a condition of your use of the Materials, you warrant to CommScope that you will not make use thereof for any purpose that is unlawful or prohibited by their associated terms of use.

## Limitation of Liability

IN NO EVENT SHALL COMMSCOPE, COMMSCOPE AFFILIATES, OR THEIR OFFICERS, DIRECTORS, EMPLOYEES, AGENTS, SUPPLIERS, LICENSORS AND THIRD PARTY PARTNERS, BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER, EVEN IF COMMSCOPE HAS BEEN PREVIOUSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, WHETHER IN AN ACTION UNDER CONTRACT, TORT, OR ANY OTHER THEORY ARISING FROM YOUR ACCESS TO, OR USE OF, THE MATERIALS. Because some jurisdictions do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of liability for consequential or incidental damages, some of the above limitations may not apply to you.

## Trademarks

ARRIS, the ARRIS logo, COMMSCOPE, RUCKUS, RUCKUS WIRELESS, the Ruckus logo, the Big Dog design, BEAMFLEX, CHANNELFLY, FASTIRON, ICX, SMARTCELL and UNLEASHED are trademarks of CommScope, Inc. and/or its affiliates. Wi-Fi Alliance, Wi-Fi, the Wi-Fi logo, Wi-Fi Certified, the Wi-Fi CERTIFIED logo, Wi-Fi Protected Access, the Wi-Fi Protected Setup logo, Wi-Fi Protected Setup, Wi-Fi Multimedia and WPA2 and WMM are trademarks or registered trademarks of Wi-Fi Alliance. All other trademarks are the property of their respective owners.

# Contents

---

<b>Preface.....</b>	<b>27</b>
Contacting RUCKUS Customer Services and Support.....	27
What Support Do I Need?.....	27
Open a Case.....	27
Self-Service Resources.....	28
Document Feedback.....	28
RUCKUS Product Documentation Resources.....	28
Online Training Resources.....	28
Document Conventions.....	29
Notes, Cautions, and Safety Warnings.....	29
Command Syntax Conventions.....	29
<b>About This Guide.....</b>	<b>31</b>
Introduction.....	31
What's New in this Release.....	31
<b>Understanding the ZoneDirector Command Line Interface.....</b>	<b>33</b>
Introduction.....	33
Accessing the Command Line Interface.....	33
Requirements.....	33
Step 1: Connecting the Administrative Computer to ZoneDirector.....	33
Step 2: Start and Configure the SSH Client.....	34
Step 3: Log Into the CLI.....	37
ZoneDirector CLI Setup Wizard.....	37
Using the ? Command.....	38
Using the Help Command.....	38
Top-Level Commands.....	38
disable.....	39
ping.....	39
reboot.....	39
shutdown.....	40
set-factory.....	40
data-privacy.....	40
config.....	41
logo.....	41
debug.....	42
reset radius-statistics.....	42
monitor.....	42
<b>Viewing Current Configuration.....</b>	<b>43</b>
Show Commands Overview.....	44
Show Location Services Commands.....	44
show location-services all.....	44
show location-services name .....	44
Show AAA Commands.....	45
show aaa all .....	45
show aaa name .....	46
Show DHCP Commands.....	47

show dhcp all.....	47
show dhcp name.....	47
Show Access Point Commands.....	49
show ap all.....	49
show ap devname.....	51
show ap mac.....	52
Show AP Group Commands.....	54
show ap-group all.....	54
show ap-group name.....	55
Show AP Policy Commands.....	57
show ap-policy.....	57
Show System Configuration Commands.....	58
show config.....	58
Show Performance Commands.....	60
show performance.....	60
show performance ap-radio2-4 .....	60
show performance ap-radio5.....	60
show performance station.....	61
Show System Information Commands.....	63
show sysinfo.....	63
Show Ethernet Info Commands.....	64
show ethinfo.....	64
Show Technical Support Commands.....	65
show techsupport.....	65
Show Management ACL Commands.....	67
show mgmt-acl all.....	67
show mgmt-acl name.....	67
show mgmt-acl-ipv6 all.....	67
show mgmt-acl-ipv6 name.....	67
Show Static Route Commands.....	69
show static-route all.....	69
show static-route name.....	69
show static-route-ipv6 all.....	69
show static-route-ipv6 name.....	69
Show WLAN Commands.....	71
show wlan.....	71
Show WLAN Group Commands.....	73
show wlan-group all.....	73
show wlan-group name.....	73
Show L2 Access Control List Commands.....	75
show l2acl all.....	75
show l2acl name.....	75
Show Whitelist Commands.....	77
show whitelist all.....	77
show whitelist name.....	77
Show L3 Access Control List Commands.....	79
show l3acl all.....	79
show l3acl-ipv6 all.....	79
show l3acl name.....	80
show l3acl-ipv6 name.....	80

Show Hotspot Commands.....	82
show hotspot all.....	82
show hotspot name.....	83
show hs20op all.....	83
show hs20op name.....	85
show hs20sp all.....	87
show hs20sp name.....	87
Show Guest Policy Commands.....	89
show guest-access-service.....	89
show guest-access-generation.....	90
show portal-auth-generation.....	91
Show Hotspot 2.0 Operator Commands.....	92
show hs20op.....	92
Show Hotspot 2.0 Service Provider Commands.....	93
show hs20sp.....	93
Show Role Commands.....	94
show role all.....	94
show role name.....	94
Show VLAN Pool Commands.....	96
show vlan-pool.....	96
Show User Commands.....	97
show user all.....	97
show user name.....	97
Show Currently Active Clients Commands.....	99
show current-active-clients all.....	99
show current-active-clients mac.....	100
Show Mesh Commands.....	101
show mesh info.....	101
show mesh topology.....	101
Show Dynamic PSK Commands.....	103
show dynamic-psks.....	103
Show Guest Pass Commands.....	104
show guest-passes.....	104
show guest-access-generation.....	105
show portal-auth-generation.....	106
Show Rogue Device Commands.....	107
show rogue-devices.....	107
Show Events and Activities Commands.....	108
show events-activities.....	108
Show Alarm Commands.....	109
show alarm.....	109
Show License Commands.....	110
show license.....	110
Show USB Software Commands.....	111
show usb-software.....	111
Show Application Policy Commands.....	112
show app-denial-policy.....	112
show user-defined-app.....	112
show app-port-mapping.....	112
Show Session-Timeout Commands.....	113

show session-timeout.....	113
Show Active Wired Client Commands.....	114
show active-wired-client all.....	114
show active-wired-client mac.....	114
Show RADIUS Statistics Commands.....	115
show radius-statistics.....	115
reset radius-statistics.....	115
Show Load Balancing Commands.....	117
show load-balance.....	117
Monitor AP MAC Commands.....	118
monitor ap mac.....	118
Monitor Currently Active Client Commands.....	120
monitor current-active-clients.....	120
monitor current-active-clients-mcs-info.....	120
Monitor Sysinfo Commands.....	122
monitor sysinfo.....	122
<b>Configuring Controller Settings.....</b>	<b>123</b>
Configuration Commands Overview.....	124
General Config Commands.....	124
help.....	124
history.....	124
abort.....	124
end.....	124
exit.....	125
quit.....	125
Configure Context Show Commands.....	126
show aaa.....	126
show dhcp.....	126
show admin.....	126
show mgmt-acl.....	126
show mgmt-acl-ipv6.....	126
show static-route.....	126
show static-route-ipv6.....	126
show ap.....	126
show l2acl.....	127
show l3acl.....	127
show whitelist.....	127
show l3acl-ipv6.....	127
show prece.....	127
show dvcpcy.....	128
show user-app-ip.....	128
show user-app-port.....	128
show url-filtering.....	128
show load-balancing.....	129
show wlan.....	129
show wlan-group.....	129
show role.....	130
show vlan-pool.....	130
show user.....	130
show hotspot.....	130

show guest-access-service.....	130
show guest-access-generation.....	130
show portal-auth-generation.....	130
show ap-group.....	130
show ap-policy.....	131
show usb-software.....	131
show location-services.....	131
show hs20op.....	132
show hs20sp.....	133
show mdnsproxyrule.....	133
show mdnsproxy.....	133
show bonjour-policy.....	133
Configure Location Services Commands.....	134
location-services.....	134
no location-services.....	135
Configure AAA Server Commands.....	136
aaa.....	136
Configure DHCP Server Commands.....	139
dhcp.....	139
no dhcp.....	139
show.....	140
name.....	140
description.....	140
first.....	140
second.....	140
no second.....	140
Configure Admin Commands.....	141
admin.....	141
name.....	141
name password.....	141
show.....	143
Admin Authentication Commands.....	144
Configure AD Domain Server Commands.....	145
ad-domainsvr.....	145
no ad-domainsvr.....	146
Configure Access Points Commands.....	147
ap.....	147
no ap.....	147
devname.....	148
no devname.....	148
bonjour-gateway.....	148
no bonjour-gateway.....	148
description.....	149
no description.....	149
gps.....	149
no gps.....	150
location.....	150
no location.....	150
group.....	150
ip.....	151

ipv6.....	152
no ipv6.....	153
usb-software.....	153
no usb-software.....	153
no usb-software-override.....	153
status-leds.....	153
no status-leds-override.....	154
status-lacp.....	154
no status-lacp-override.....	154
usb-port.....	154
no usb-port-override.....	155
poe-out.....	155
no poe-out-override.....	155
external-antenna.....	155
no external-antenna-override.....	156
spectra-analysis 2.4GHz.....	156
spectra-analysis 5GHz.....	156
internal-heater.....	156
no internal-heater-override.....	157
cband-channels.....	157
no cband-channels-override.....	157
cband-license.....	157
no cband-license-override.....	158
ipmode.....	158
no ipmode-override.....	159
venue-name.....	159
no venue-name.....	159
lldp.....	159
no lldp-override.....	160
power-mode.....	160
no power-mode-override.....	161
802.3af-txchain.....	161
no 802.3af-txchain-override.....	161
Radio 2.4/5 GHz Commands.....	163
Mesh Commands.....	167
AP Port Setting Commands.....	169
Configure AP Policy Commands.....	181
ap-policy.....	181
show.....	181
ap-management-vlan.....	181
no ap-management-vlan.....	182
ap-auto-approve.....	182
no ap-auto-approve.....	183
limited-zd-discovery.....	183
no limited-zd-discovery.....	184
limited-zd-discovery prefer-primary-zd.....	184
no limited-zd-discovery prefer-primary-zd.....	184
limited-zd-discovery keep-ap-setting.....	185
no limited-zd-discovery keep-ap-setting.....	185
auto-recovery.....	185

no auto-recovery.....	185
vlan-qos.....	185
no vlan-qos.....	186
timeout.....	187
no timeout.....	187
import-aplist.....	187
exit.....	187
abort.....	187
quit.....	187
Configure AP Group Commands.....	188
ap-group.....	188
no ap-group.....	188
exit.....	189
abort.....	189
quit.....	189
show.....	189
description.....	189
no description.....	189
Configure Location Based Service Commands.....	191
Radio 2.4/5 GHz Commands.....	195
QoS Commands (AP).....	202
Model-Specific Commands.....	203
AP Group Membership.....	223
LLDP Commands.....	225
Configure Certificate Commands.....	229
quit.....	229
restore.....	229
re-generate-private-key.....	229
Configure Hotspot Redirect Settings.....	231
hotspot_redirect_https.....	231
no hotspot_redirect_https.....	231
no blocked-client.....	231
Configure Layer 2 Access Control Commands.....	232
acl.....	232
no acl.....	232
abort.....	233
end.....	233
exit.....	233
quit.....	233
show.....	233
name.....	234
description.....	234
add-mac.....	235
mode allow.....	235
mode deny.....	235
del-mac.....	236
Configure Layer 3 Access Control Commands.....	237
l3acl.....	237
no l3acl.....	237
l3acl-ipv6.....	238

no l3acl-ipv6.....	238
abort.....	238
end.....	238
exit.....	239
quit.....	239
show.....	239
name.....	239
description.....	240
mode allow.....	240
mode deny.....	241
rule-order.....	241
no rule-order.....	244
<b>Layer 3 Access Control Rule Commands.....</b>	<b>245</b>
end.....	245
exit.....	245
order.....	245
description.....	245
type allow.....	246
type deny.....	246
destination address.....	247
destination port.....	247
protocol.....	247
show.....	248
<b>Layer 3 IPv6 Access Control List Commands.....</b>	<b>249</b>
l3acl-ipv6.....	249
abort.....	249
end.....	249
exit.....	249
quit.....	249
name.....	249
description.....	249
mode allow.....	249
mode deny.....	249
no rule-order.....	249
rule-order.....	250
<b>Configure L3 IPv6 Rule Commands.....</b>	<b>251</b>
end.....	251
exit.....	251
order.....	251
description.....	251
type allow.....	251
type deny.....	251
destination.....	251
destination address.....	251
destination port.....	251
protocol.....	251
icmpv6-type Any.....	252
icmpv6-type number.....	252
show.....	252
<b>Configure Precedence Policy Commands.....</b>	<b>253</b>

prece.....	253
no prece.....	253
end.....	253
exit.....	253
quit.....	254
name.....	254
description.....	254
show.....	254
Configure Precedence Policy Rule Commands.....	255
Configure Device Policy Commands.....	257
dvcpcy.....	257
no dvcpcy.....	258
rule.....	258
Configure Application Policy Commands.....	260
app-policy.....	260
no app-policy.....	260
description.....	261
show.....	261
Configure Application Policy Rules.....	262
Configuring User-Defined Applications.....	264
user-app-ip.....	264
no user-app-ip.....	264
abort.....	264
end.....	264
exit.....	264
destination-IP.....	264
netmask.....	265
destination-port.....	265
protocol.....	265
application-name.....	265
Configuring User-Defined Applications Based on Port Mapping.....	266
user-app-port.....	266
no user-app-port.....	266
abort.....	266
end.....	266
exit.....	266
port.....	266
protocol.....	267
application-name.....	267
Configure URL Filtering Settings.....	268
url-filtering.....	268
no url-filtering.....	268
description.....	269
filtering-level.....	269
blocked-category.....	269
create-blacklist.....	269
delete-blacklist.....	270
create-whitelist.....	270
delete-whitelist.....	270
google-safe-search.....	270

no google-safe-search.....	271
google-ip.....	271
youtube-safe-search.....	271
no youtube-safe-search.....	271
youtube-ip.....	272
bing-safe-search.....	272
no bing-safe-search.....	272
bing-ip.....	272
show.....	273
Configure Whitelist Commands.....	274
whitelist.....	274
no whitelist.....	274
name.....	274
description.....	274
Configuring Whitelist Rules.....	275
Configure Band Balancing Commands.....	276
band-balancing.....	276
abort.....	276
end.....	276
exit.....	276
quit.....	276
enable.....	276
disable.....	276
Proactive.....	278
percent-2.4G <NUMBER>.....	278
show.....	278
Configure Load Balancing Commands.....	279
load-balancing.....	279
adj-threshold.....	279
weak-bypass.....	280
strong-bypass.....	280
act-threshold.....	281
new-trigger.....	281
headroom.....	282
disable wifi0.....	282
disable wifi1.....	282
enable wifi0.....	282
enable wifi1.....	283
show.....	283
Configure STP Commands.....	284
stp.....	284
no stp.....	284
Configure System Commands.....	285
system.....	285
dot11-country-code.....	285
hostname.....	286
Interface Commands.....	287
NTP Commands.....	291
Timezone Commands.....	292
FTP Commands.....	294

Smart Redundancy Commands.....	295
Management Interface Commands.....	297
SNMPv2 Commands.....	301
SNMPv3 Commands.....	305
Syslog Settings Commands.....	309
Management Access Control List Commands.....	314
QoS Commands.....	317
tunnel-mtu.....	319
lwapp-mgmt-qlen-threshold.....	320
bonjour.....	320
no bonjour.....	321
telnetd.....	321
no telnetd.....	321
static-route.....	322
no static-route.....	322
static-route-ipv6.....	323
no static-route-ipv6.....	323
snmp-trap.....	323
no snmp-trap.....	324
no snmpv2-trap.....	324
no snmpv3-trap.....	324
no snmpv2.....	325
no snmpv3.....	325
login-warning.....	325
no login-warning.....	326
event-log-level.....	326
support-entitle.....	327
URL-Filtering-License-Renew.....	327
session-stats-resv.....	327
no session-stats-resv.....	327
arc-data-transmission.....	329
no arc-data-transmission .....	330
session-limit-unauth-stats.....	330
no session-limit-unauth-stats.....	330
eapol-no-retry.....	331
no eapol-no-retry.....	332
shared-username-control-enable.....	332
no shared-username-control-enable.....	332
show.....	332
show support-entitle.....	334
show URL-Filtering-License.....	334
show shared-username-control.....	334
Configure UPNP Settings.....	335
upnp.....	335
no upnp.....	335
Configure Zero-IT Settings.....	336
zero-it.....	336
zero-it-auth-server.....	336
Configure Dynamic PSK Expiration.....	337
dynamic-psk-expiration.....	337

Configure WLAN Settings Commands.....	338
wlan.....	338
no wlan.....	338
abort.....	338
end.....	338
exit.....	339
quit.....	339
description.....	339
called-station-id-type.....	339
ssid.....	340
beacon-interval.....	340
wlan-bind.....	341
mgmt-tx-rate.....	341
name.....	341
type.....	342
open.....	343
zero-it-activation.....	346
no zero-it-activation.....	346
mac none.....	347
mac owe.....	347
mac wpa2.....	347
mac wpa3.....	348
mac wpa23-mixed.....	348
mac wpa-mixed.....	349
mac wep-64.....	349
mac wep-128.....	350
auth-server.....	351
shared wep-64.....	351
shared wep-128.....	351
dot1x eap-type EAP-SIM auth-server.....	351
dot1x eap-type PEAP auth-server.....	352
dot1x wpa2.....	353
dot1x wpa2 algorithm auto auth-server.....	354
dot1x wpa-mixed algorithm AES auth-server.....	354
dot1x wpa-mixed algorithm auto auth-server.....	355
dot1x authentication encryption wep-64 auth-server.....	356
dot1x wep-128 auth-server.....	356
dot1x none.....	357
dot1x-mac.....	357
dot1x wpa3.....	358
bgscan.....	358
no bgscan.....	358
ft-roaming.....	358
no ft-roaming.....	359
rrm-neigh-report.....	359
no rrm-neigh-report.....	359
https-redirection.....	359
no https-redirection.....	359
client-flow-log.....	359
no client-flow-log.....	359

client-connect-log.....	360
no client-connect-log.....	360
bypasscna.....	360
no bypasscna.....	360
client-isolation.....	361
whitelist.....	361
no whitelist.....	361
load-balancing.....	361
no load-balancing.....	362
band-balancing.....	362
no band-balancing.....	362
send-eap-failure.....	362
no send-eap-failure.....	363
pap-authenticator.....	363
no pap-authenticator.....	363
nasid-type.....	363
priority low.....	364
priority high.....	364
web-auth.....	364
no web-auth.....	365
grace-period.....	365
no grace-period.....	366
acct-server.....	366
acct-server interim-update.....	366
no acct-server.....	367
inactivity-timeout.....	367
web-auth-timeout.....	368
vlan.....	368
dynamic-vlan.....	369
no dynamic-vlan.....	369
mcast-filter.....	370
no mcast-filter.....	370
hide-ssid.....	370
no hide-ssid.....	370
ofdm-only.....	371
no ofdm-only.....	371
admission-control.....	371
no admission-control.....	371
transient-client-management.....	371
no transient-client-management.....	371
join-wait-time.....	372
join-wait-threshold.....	372
join-expire-time.....	372
min-client-rssi.....	373
bss-minrate.....	373
no bss-minrate.....	373
dtim-period.....	374
no dtim-period.....	375
directed-threshold.....	376
no directed-threshold.....	377

tunnel-mode.....	377
no tunnel-mode.....	377
dhcp-relay.....	378
no dhcp-relay.....	378
smart-roam.....	378
no smart-roam.....	378
force-dhcp.....	378
force-dhcp-timeout.....	379
no force-dhcp.....	379
Configuring DHCP Option 82 Sub-Option Settings.....	380
sta-info-extraction.....	381
no sta-info-extraction.....	381
max-clients.....	381
802dot11d.....	382
no 802dot11d.....	382
arc.....	382
no arc.....	383
apply-arc-policy.....	383
no apply-arc-policy.....	383
url-filtering.....	383
no url-filtering.....	384
url-filtering-profile.....	384
auto-proxy.....	384
no auto-proxy.....	385
pmk-cache.....	385
no pmk-cache.....	385
pmk-cache-for-reconnect.....	385
no pmk-cache-for-reconnect.....	385
sae-anti-clogging-threshold.....	386
roaming-acct-interim-update.....	386
no roaming-acct-interim-update.....	386
show.....	386
Configure Dynamic PSK Commands.....	389
dynamic-psk enable.....	389
dynamic-psk external.....	389
dynamic-psk passphrase-len.....	390
dynamic-psk type.....	390
no dynamic-psk.....	390
limit-dpsk.....	390
no limit-dpsk.....	390
shared-dpsk.....	391
no shared-dpsk.....	391
dynamic-psk-expiration.....	391
no l2acl.....	392
no role-based-access-ctrl.....	392
no l3acl.....	392
no l3acl-ipv6.....	392
no vlanpool.....	392
no dvpcy.....	392
rate-limit.....	393

no rate-limit.....	393
vlanpool.....	393
no mac-addr-format.....	394
mac-addr-format.....	394
acl dvpcy.....	394
acl prece.....	394
acl role-based-access-ctrl.....	394
qos classification.....	395
no qos classification.....	395
qos heuristics-udp.....	395
no qos heuristics-udp.....	395
qos directed-multicast.....	395
no qos directed-multicast.....	395
qos igmp-snooping.....	395
no qos igmp-snooping.....	395
qos mld-snooping.....	395
no qos mld-snooping.....	396
qos tos-classification.....	396
no qos tos-classification.....	396
qos priority high.....	396
qos priority low.....	396
qos directed-threshold.....	396
disable-dgaf.....	396
no disable-dgaf.....	396
proxy-arp.....	397
no proxy-arp.....	397
80211w-pmf.....	397
no 80211w-pmf.....	397
ignor-unauth-stats.....	397
no ignor-unauth-stats.....	397
show.....	397
Configure WLAN Group Commands.....	400
wlan-group.....	400
no wlan-group.....	400
abort.....	401
end.....	401
exit.....	402
quit.....	402
name.....	403
description.....	403
wlan.....	404
no wlan.....	404
wlan vlan override none.....	405
wlan vlan override tag.....	405
show.....	406
Configure Role Commands.....	407
role.....	407
no role.....	407
abort.....	408
end.....	408

exit.....	408
quit.....	409
name.....	409
description.....	410
group-attributes.....	410
wlan-allowed.....	411
specify-wlan-access.....	411
no specify-wlan-access.....	412
guest-pass-generation.....	412
no guest-pass-generation.....	412
admin.....	413
no admin.....	413
access-ctrl.....	414
no access-ctrl.....	414
dvc-type-allowed.....	415
specify-dvc-policy.....	415
vlan.....	415
rate-limit uplink.....	415
rate-limit uplink downlink.....	415
no rate-limit.....	415
apply-arc-policy.....	416
no apply-arc-policy.....	417
url-filtering.....	417
no url-filtering.....	417
show.....	417
Configure VLAN Pool Commands.....	419
vlan-pool.....	419
no vlan-pool.....	420
Configure User Commands.....	421
user.....	421
no user.....	421
abort.....	422
end.....	422
exit.....	422
quit.....	423
user-name.....	423
full-name.....	424
password.....	424
role.....	425
show.....	425
Configure Guest Access Commands.....	427
guest-access.....	427
no guest-access.....	427
abort.....	427
end.....	427
exit.....	427
quit.....	427
guest-access-force-https-redirection.....	428
no guest-access-force-https-redirection.....	429
guest-access-guestpass-effective.....	430

name.....	430
self-service.....	430
no self-service.....	430
guestpass-duration.....	430
guestpass-reauth.....	430
no guestpass-reauth.....	431
guestpass-share-number.....	431
guestpass-sponsor.....	431
no guestpass-sponsor.....	431
guestpass-sponsor-auth-server.....	431
guestpass-sponsor-number.....	431
guestpass-notification.....	431
guestpass-terms-and-conditions.....	432
no guestpass-terms-and-conditions.....	432
onboarding.....	432
no onboarding.....	432
no authentication.....	432
authentication guest-pass-and-social-login.....	433
authentication only-social-login.....	434
no term-of-use.....	434
term-of-use.....	434
redirect.....	435
welcome-text.....	435
walled-garden.....	437
no walled-garden.....	438
social-media-login.....	438
show.....	440
web-portal-force-https-redirection.....	442
no web-portal-force-https-redirection.....	443
portal-auth-force-dns-server.....	444
no portal_auth-force-dns-server.....	445
guest-access-auth-server.....	446
Configuring Guest Access Restriction Rules.....	447
no restrict-access-order.....	447
restrict-access-order.....	448
show.....	448
order.....	449
description.....	449
type allow.....	449
type deny.....	450
destination address.....	450
destination port.....	451
protocol.....	451
IPv6 Guest Restrict Access Commands.....	453
no restrict-access-order-ipv6.....	453
restrict-access-order-ipv6.....	453
show.....	454
order.....	455
description.....	455
type allow.....	456

type deny.....	456
destination address.....	456
destination port.....	457
protocol.....	457
icmpv6-type.....	458
<b>Configure Hotspot Commands.....</b>	<b>459</b>
hotspot.....	459
no hotspot.....	459
abort.....	460
end.....	460
exit.....	460
quit.....	461
show.....	461
name.....	462
smartclient.....	462
no smartclient.....	463
login-page.....	463
start-page.....	464
no session-timeout.....	464
session-timeout.....	465
no grace-period.....	465
grace-period.....	465
auth-server local.....	466
auth-server name.....	466
auth-server name no-mac-bypass.....	467
auth-server name mac-bypass.....	467
auth-server name mac-bypass mac-addr-format.....	468
acct-server.....	468
no acct-server.....	469
acct-server interim-update.....	469
client-isolation.....	470
whitelist.....	470
location-id.....	471
location-name.....	471
walled-garden.....	471
no walled-garden.....	472
<b>Configuring Hotspot Restricted Access Rules.....</b>	<b>473</b>
restrict-access-order.....	473
no restrict-access-order.....	474
restrict-access-order-ipv6.....	474
no restrict-access-order-ipv6.....	475
icmpv6-type.....	476
<b>Hotspot Access Restriction Commands.....</b>	<b>477</b>
end.....	477
exit.....	477
show.....	477
order.....	478
description.....	478
type allow.....	479
type deny.....	479

destination address.....	480
destination port.....	480
protocol.....	480
intrusion-prevention.....	481
no intrusion-prevention.....	481
Configure Hotspot 2.0 Commands.....	482
hs20op.....	482
no hs20op.....	482
Configure Hotspot 2.0 Operator Settings.....	483
hs20sp.....	492
no hs20sp.....	492
Configure Hotspot 2.0 Service Provider Settings.....	493
nai-realm.....	494
name.....	495
encoding.....	495
eap-method.....	495
eap-method eap-mthd.....	495
eap-method auth-info.....	496
Configure Mesh Commands.....	499
mesh.....	499
abort.....	499
end.....	499
exit.....	499
quit.....	499
show.....	499
ssid.....	500
passphrase.....	500
hops-warn-threshold.....	501
no detect-hops.....	501
fan-out-threshold.....	502
no detect-fanout.....	502
beacon-interval.....	502
mgmt-tx-rate.....	503
mesh-uplink-selection static.....	503
mesh-uplink-selection dynamic.....	504
mesh-radio-option.....	505
zero-touch-mesh.....	506
no zero-touch-mesh.....	507
zt-mesh-serial.....	508
no zt-mesh-serial.....	509
Configure Alarm Commands.....	510
alarm.....	510
no alarm.....	510
abort.....	510
end.....	510
exit.....	511
quit.....	511
e-mail.....	511
show.....	511
Configure Alarm-Event Settings.....	513

alarm-event.....	513
event.....	513
no event.....	515
Configure Services Commands.....	517
abort.....	517
end.....	517
exit.....	517
quit.....	518
auto-channel-background-scanning.....	518
auto-adjust-ap-channel radio-2.4.....	522
auto-adjust-ap-power radio-5.....	523
auto-adjust-ap-channel radio-2.4.....	524
auto-adjust-ap-channel radio-5.....	524
raps.....	525
no raps.....	525
channelfly.....	526
no channelfly.....	526
background-scan.....	527
background-scan low-threshold.....	527
no background-scan.....	528
aeroscout-detection.....	529
no aeroscout-detection.....	529
ekahau.....	529
no ekahau.....	530
tun-encrypt.....	530
no tun-encrypt.....	531
tun-block-mcast all.....	532
tun-block-mcast non-well-known.....	532
no tun-block-mcast.....	532
tun-block-bcast.....	532
no tun-block-bcast.....	533
tun-proxy-arp.....	533
no tun-proxy-arp.....	533
tun-ip-ageing.....	533
pif.....	533
no pif.....	534
show.....	534
Configure WIPS Commands.....	536
wips.....	536
Configure Email Server Commands.....	538
email-server.....	538
from.....	539
enable.....	540
no enable.....	540
smtp-server-name.....	540
smtp-server-port.....	541
smtp-auth-name.....	541
smtp-auth-password.....	542
smtp-wait-time.....	542
tls-smtp-encryption.....	542

no tls-smtp-encryption.....	543
Configure SMS Server Commands.....	544
sms-server.....	544
no sms-server.....	545
country-code.....	545
Configure mDNS (Bonjour) Commands.....	547
mdnsproxy.....	547
no mdnsproxy.....	547
mdnsproxyrule.....	547
no mdnsproxyrule.....	547
Configure Bonjour Policy.....	548
bonjour-policy.....	548
no bonjour-policy.....	548
Configure mDNS Proxy Rules.....	550
Configure Bonjour Fencing Policy.....	551
show.....	552
description.....	553
fencerule.....	554
source-type.....	555
device-mac.....	556
anchor-ap.....	557
service.....	558
fencing-range.....	559
<b>Using Debug Commands.....</b>	<b>561</b>
Debug Commands Overview.....	561
General Debug Commands.....	561
help.....	561
list-all.....	561
history.....	561
quit.....	561
fw_upgrade.....	561
restore.....	562
restore all.....	562
restore failover.....	563
restore policy.....	563
delete-station.....	563
restart-ap.....	563
wlaninfo.....	564
save_debug_info.....	565
save-config.....	566
emfd-malloc-stats.....	566
speedflex.....	567
Show Commands.....	568
show ap.....	568
show station.....	570
show logs.....	571
show tls.....	571
show speedflex.....	571
show remote-troubleshooting.....	572
ps.....	572

Accessing a Remote AP CLI.....	575
remote_ap_cli.....	575
Working with Debug Logs and Log Settings.....	577
logs all.....	577
no logs all.....	577
logs comp sys-mgmt.....	578
no logs comp sys-mgmt.....	578
logs comp mesh.....	578
no logs comp mesh.....	578
logs comp web-auth.....	579
no logs comp web-auth.....	579
logs comp rf-mgmt.....	579
no logs comp rf-mgmt.....	579
logs comp radius.....	579
no logs comp radius.....	579
logs comp hotspot-srv.....	579
no logs comp hotspot-srv.....	579
logs comp aps.....	579
no logs comp aps.....	579
logs comp net-mgmt.....	579
no logs comp net-mgmt.....	580
logs comp 802.1x.....	580
no logs comp 802.1x.....	580
logs comp web-svr.....	580
no logs comp web-svr.....	580
logs comp 802.11.....	580
no logs comp 802.11.....	580
logs comp dvlan.....	580
no logs comp dvlan.....	580
logs comp smart-redundancy.....	580
no logs comp smart-redundancy.....	580
logs comp bonjour-gateway.....	581
no logs comp bonjour-gateway.....	581
logs comp mdnsd.....	581
no logs comp mdnsd.....	581
logs comp client-association.....	581
no logs comp client-association.....	581
logs mac.....	581
no logs mac.....	582
logs play.....	582
no logs play.....	583
logs winbind.....	583
support-tls.....	583
no support-tls.....	584
Remote Troubleshooting.....	585
remote-troubleshooting server.....	585
remote-troubleshooting start.....	585
remote-troubleshooting stop.....	585
radius-stats-wlan.....	586
radius-stats-authsvr.....	586

AP Core Dump Collection.....	587
collect_ap_coredump.....	587
no collect_ap_coredump.....	587
Script Execution.....	589
script.....	589
quit.....	589
list.....	589
del.....	590
info.....	590
exec.....	590



# Preface

---

• Contacting RUCKUS Customer Services and Support.....	27
• Document Feedback.....	28
• RUCKUS Product Documentation Resources.....	28
• Online Training Resources.....	28
• Document Conventions.....	29
• Command Syntax Conventions.....	29

## Contacting RUCKUS Customer Services and Support

The Customer Services and Support (CSS) organization is available to provide assistance to customers with active warranties on their RUCKUS products, and customers and partners with active support contracts.

For product support information and details on contacting the Support Team, go directly to the RUCKUS Support Portal using <https://support.ruckuswireless.com>, or go to <https://www.commscope.com/ruckus> and select **Support**.

### What Support Do I Need?

Technical issues are usually described in terms of priority (or severity). To determine if you need to call and open a case or access the self-service resources, use the following criteria:

- Priority 1 (P1)—Critical. Network or service is down and business is impacted. No known workaround. Go to the **Open a Case** section.
- Priority 2 (P2)—High. Network or service is impacted, but not down. Business impact may be high. Workaround may be available. Go to the **Open a Case** section.
- Priority 3 (P3)—Medium. Network or service is moderately impacted, but most business remains functional. Go to the **Self-Service Resources** section.
- Priority 4 (P4)—Low. Requests for information, product documentation, or product enhancements. Go to the **Self-Service Resources** section.

### Open a Case

When your entire network is down (P1), or severely impacted (P2), call the appropriate telephone number listed below to get help:

- Continental United States: 1-855-782-5871
- Canada: 1-855-782-5871
- Europe, Middle East, Africa, Central and South America, and Asia Pacific, toll-free numbers are available at <https://support.ruckuswireless.com/contact-us> and Live Chat is also available.
- Worldwide toll number for our support organization. Phone charges will apply: +1-650-265-0903

We suggest that you keep a physical note of the appropriate support number in case you have an entire network outage.

## Preface

Document Feedback

## Self-Service Resources

The RUCKUS Support Portal at <https://support.ruckuswireless.com> offers a number of tools to help you to research and resolve problems with your RUCKUS products, including:

- Technical Documentation—<https://support.ruckuswireless.com/documents>
- Community Forums—<https://forums.ruckuswireless.com/>
- Knowledge Base Articles—<https://support.ruckuswireless.com/answers>
- Software Downloads and Release Notes—[https://support.ruckuswireless.com/#products\\_grid](https://support.ruckuswireless.com/#products_grid)
- Security Bulletins—<https://support.ruckuswireless.com/security>

Using these resources will help you to resolve some issues, and will provide TAC with additional data from your troubleshooting analysis if you still require assistance through a support case or RMA. If you still require help, open and manage your case at [https://support.ruckuswireless.com/case\\_management](https://support.ruckuswireless.com/case_management).

## Document Feedback

RUCKUS is interested in improving its documentation and welcomes your comments and suggestions.

You can email your comments to RUCKUS at [#Ruckus-Docs@commscope.com](mailto:#Ruckus-Docs@commscope.com).

When contacting us, include the following information:

- Document title and release number
- Document part number (on the cover page)
- Page number (if appropriate)

For example:

- RUCKUS SmartZone Upgrade Guide, Release 5.0
- Part number: 800-71850-001 Rev A
- Page 7

## RUCKUS Product Documentation Resources

Visit the RUCKUS website to locate related documentation for your product and additional RUCKUS resources.

Release Notes and other user documentation are available at <https://support.ruckuswireless.com/documents>. You can locate the documentation by product or perform a text search. Access to Release Notes requires an active support contract and a RUCKUS Support Portal user account. Other technical documentation content is available without logging in to the RUCKUS Support Portal.

White papers, data sheets, and other product documentation are available at <https://www.commscope.com/ruckus>.

## Online Training Resources

To access a variety of online RUCKUS training modules, including free introductory courses to wireless networking essentials, site surveys, and products, visit the RUCKUS Training Portal at <https://commscopeuniversity.myabsorb.com/>. The registration is a two-step process described in this [video](#). You create a CommScope account and then register for, and request access for, CommScope University.

# Document Conventions

The following table lists the text conventions that are used throughout this guide.

**TABLE 1** Text Conventions

Convention	Description	Example
monospace	Identifies command syntax examples	device(config)# interface ethernet 1/1/6
<b>bold</b>	User interface (UI) components such as screen or page names, keyboard keys, software buttons, and field names	On the <b>Start</b> menu, click <b>All Programs</b> .
<i>italics</i>	Publication titles	Refer to the <i>RUCKUS Small Cell Release Notes</i> for more information.

## Notes, Cautions, and Safety Warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

### NOTE

A NOTE provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

### ATTENTION

An ATTENTION statement indicates some information that you must read before continuing with the current action or task.



### CAUTION

A CAUTION statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



### DANGER

A DANGER statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

# Command Syntax Conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
<b>bold</b> text	Identifies command names, keywords, and command options.
<i>italic</i> text	Identifies a variable.
[ ]	Syntax components displayed within square brackets are optional.  Default responses to system prompts are enclosed in square brackets.
{x y z}	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member</i> [ <i>member</i> ...].
\	Indicates a “soft” line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.



# About This Guide

---

• <a href="#">Introduction</a>	31
• <a href="#">What's New in this Release</a>	31

## Introduction

The *Ruckus ZoneDirector CLI Reference Guide* contains the syntax and commands for configuring and managing ZoneDirector from a command line interface.

This guide is written for service operators and system administrators who are responsible for managing, configuring, and troubleshooting Ruckus Wireless devices. Consequently, it assumes a basic working knowledge of local area networking, wireless networking, and wireless devices.

### NOTE

If release notes are shipped with your product and the information there differs from the information in this guide, follow the instructions in the release notes.

Most user guides and release notes are available in Adobe Acrobat Reader Portable Document Format (PDF) or HTML on the Ruckus Wireless Support Web site at

<https://support.ruckuswireless.com/documents>.

## What's New in this Release

### Deprecated Commands in 10.4.1 (April 2022)

- radio 2.4 11n-only Auto
- radio 2.4 11n-only N-only
- no radio 2.4 11n-only-override
- radio 5 11n-only Auto
- radio 5 11n-only N-only
- no radio 5 11n-only-override

The following table lists the changes in CLI commands between this release (10.4.1) and the previous release (10.4).

New	Old	Change
no system-dst	None	New in 10.4.1.
no userdefined-dst	None	New in 10.4.1.
system-timezone	timezone	Changed "timezone" to "system-timezone".
userdefined-timezone	None	New in 10.4.1.
system-dst	None	New in 10.4.1.
userdefined-dst	None	New in 10.4.1.
auto-channel-background-scanning	None	New in 10.4.1.
no radio-2.4	None	New in 10.4.1.
no radio-5	None	New in 10.4.1.
no off-period	None	New in 10.4.1.

## About This Guide

### What's New in this Release

New	Old	Change
radio-2.4	None	New in 10.4.1.
radio-5	None	New in 10.4.1.
off-period	None	New in 10.4.1.
clients	None	New in 10.4.1.
interval	None	New in 10.4.1.
threshold	None	New in 10.4.1.
show	None	New in 10.4.1.
simulate	None	New in 10.4.1.
deploy	None	New in 10.4.1.
no auto-adjust-ap-channel radio-2.4	None	New in 10.4.1.
no auto-adjust-ap-channel radio-5	None	New in 10.4.1.
auto-adjust-ap-channel radio-2.4	None	New in 10.4.1.
auto-adjust-ap-channel radio-5	None	New in 10.4.1.
None	sta-favorite	Removed in 10.4.1.
None	no sta	Removed in 10.4.1.
None	sta <MAC>	Removed in 10.4.1.
None	show	Removed in 10.4.1.
None	show sta-favorite	Removed in 10.4.1.
show speedflex	None	New in 10.4.1.
speedflex	None	New in 10.4.1.
no speedflex	None	New in 10.4.1.

# Understanding the ZoneDirector Command Line Interface

---

• Introduction.....	33
• Accessing the Command Line Interface.....	33
• ZoneDirector CLI Setup Wizard.....	37
• Using the ? Command.....	38
• Using the Help Command.....	38
• Top-Level Commands.....	38

## Introduction

The Ruckus ZoneDirector Command Line Interface (CLI) is a software tool that allows you to configure and manage ZoneDirector, Ruckus's wireless LAN controller, and all currently managed APs via ZoneDirector CLI commands.

Using the command line interface, you can configure controller system settings, access points, wireless networks and client connection settings, or view current status information for each component of your Ruckus wireless network. Each command performs a specific action for configuring device settings or returning information about the status of a specific device feature.

## Accessing the Command Line Interface

This section describes the requirements and the procedure for accessing the ZoneDirector CLI.

### NOTE

The ZoneDirector CLI supports a maximum of 8 simultaneous SSH sessions, and a maximum 4 sessions from the same IP address.

## Requirements

To access the ZoneDirector CLI, you will need the following:

- A computer that you want to designate as administrative computer
- A network connection to ZoneDirector, or
- An RS-232 serial to Ethernet cable
- A Telnet or SSH (secure shell) client program

## Step 1: Connecting the Administrative Computer to ZoneDirector

The ZoneDirector Command Line Interface can be accessed in one of two ways:

- [Using an Ethernet Connection](#) on page 34
- [Using a Serial Connection](#) on page 34

## Understanding the ZoneDirector Command Line Interface

Accessing the Command Line Interface

### Using an Ethernet Connection

1. Ensure that ZoneDirector's IP address is reachable from the administrative computer. In factory default state, ZoneDirector's IP address is 192.168.0.2.
2. Continue to [Step 2: Start and Configure the SSH Client](#) on page 34.

### Using a Serial Connection

To connect to ZoneDirector via serial connection, you need an RS-232 to Ethernet cable.

1. Connect the RJ-45 end of the cable to the port labeled **Console** on ZoneDirector.
2. Connect the RS-232 end of the cable to a COM port on the administrative computer.

## Step 2: Start and Configure the SSH Client

Before starting this procedure, make sure that your SSH client is already installed on the administrative computer.

#### NOTE

The following procedure uses PuTTY, a free and open source Telnet/SSH client, for accessing the ZoneDirector CLI. If you are using a different Telnet/SSH client, the procedure may be slightly different (although the connection settings should be the same). For more information on PuTTY, visit [www.putty.org](http://www.putty.org).

### Using SSH


To start and configure the SSH client

1. Start PuTTY. The PuTTY Configuration dialog box appears, showing the **Session** screen.
2. In **Connection type**, select **SSH**.

#### NOTE

Telnet access is disabled by default for security reasons. SSH is the recommended access method and you will not be allowed to access the ZoneDirector CLI via Telnet unless you have specifically enabled Telnet access.

**FIGURE 1** Selecting SSH as the connection type




3. Enter the ZoneDirector IP address in the **Host Name (or IP address)** field.
4. Click **Open**. The PuTTY console appears and displays the login prompt.

## Using a Serial Connection

To start and configure the SSH client:


1. Start PuTTY. The PuTTY Configuration dialog box appears, showing the **Session** screen.
2. In **Connection type**, select **Serial** if you are connecting via serial cable.

**FIGURE 2 Select Serial as the connection type**



3. Under **Category**, click **Connection > Serial**. The serial connection options appear on the right side of the dialog box, displaying PuTTY's default serial connection settings.

**FIGURE 3 PuTTY's default serial connection settings**




## Understanding the ZoneDirector Command Line Interface

### Accessing the Command Line Interface

4. Configure the serial connection settings as follows:


- **Serial line to connect to:** Type the COM port name to which you connected the RS-232 cable.
- **Bits per second:** 115200
- **Data bits:** 8
- **Stop bits:** 1
- **Parity:** None
- **Flow control:** None

FIGURE 4 PuTTY's serial connection settings for connecting to ZoneDirector



5. Click **Open**. The PuTTY console appears and displays the login prompt.

FIGURE 5 The PuTTY console displaying the login prompt



You have completed configuring the Telnet/SSH client to connect to ZoneDirector.

## Step 3: Log Into the CLI

1. At the **login** as prompt, press <Enter> once.
2. At the **Please login** prompt, enter the ZoneDirector login name (default: **admin**), and then press <Enter>.
3. At the **Password** prompt, enter the ZoneDirector login password (default: **admin**), and then press <Enter>. The Ruckus ZoneDirector CLI welcome message and the **ruckus>** prompt appears.

You are now logged into the ZoneDirector CLI as a user with limited privileges. As a user with limited privileges, you can view a history of commands that were previously executed and ping a device. If you want to run more commands, you can switch to privileged mode by entering enable at the root prompt.

To view a list of commands that are available at the root level, enter **help** or **?**.

### NOTE

You can tell if you are logged into the CLI in limited or privileged mode by looking at the ruckus prompt. If you are in limited mode, the prompt appears as **rickus>** (with a **greater than** sign). If you are in privileged mode, the prompt appears as **rickus#** (with a pound sign).

To enable privileged mode when another user session is enabled, use the <force> option with the enable command to force disconnect of the previous user session. (i.e., **enable force**).

## ZoneDirector CLI Setup Wizard

The CLI setup wizard allows you to quickly configure your controller with basic settings using a short series of CLI commands.

ZoneDirector's default IP address is **192.168.0.2**, and the default admin login name and password are: **admin/admin**. You can change these settings from their default values, set the system name and country code, and deploy your first WLAN using the setup wizard.

```
login as:
```

```
Please login: admin
Password:
```

```
Welcome to the Ruckus Wireless ZoneDirector CLI Wizard Configuration Tool
```

```
Would you like to start setup wizard? [yes/no]: y
```

```
Begin wizard from CLI :
```

```
...
...
...
```

```
Please review the following settings:
System Name= ZoneDirector
Administrator Name= admin
Country Code= US
Mesh Supported= Enable
IPv4 Supported= Enable
IPv4 Mode= DHCP
IPv6 Supported= Disable
Wireless LANs ESSID= Ruckus1
Wireless Authentication= WPA2_PSK
```

```
Are you sure to complete the setup wizard? [yes/no]: y
```

```
The ZoneDirector will periodically connect to Ruckus Wireless and Ruckus Wireless will collect
the ZoneDirector serial number, software version and build number. Ruckus Wireless will transmit
```

## Understanding the ZoneDirector Command Line Interface

### Using the ? Command

a file back to the ZoneDirector and this will be used to display the current status of the ZoneDirector Support Contract. Please be advised that this information may be transferred and stored outside of your country of residence where data protection standards may be different.

Hi, enter YES to accept these terms to proceed: [yes]:

Save the configuration ...

Welcome to the Ruckus Wireless ZoneDirector 1200 Command Line Interface  
ruckus>

## Using the ? Command

To display a brief list of commands that are available within a specific context, use the **? command**.

### Example

```
ruckus(config)# admin
ruckus(config-admin)# ?
  help                      Shows available commands.
  history                   Shows a list of previously run commands.
  abort                     Exits the config-admin context without saving changes.
  end                       Saves changes, and then exits the config-admin context.
  exit                      Saves changes, and then exits the config-admin context.
  quit                      Exits the config-admin context without saving changes.
  name <WORD>               Sets the admin name.
  no                        Contains commands that can be executed from within the context.
  auth-server <WORD>        Enables administrator authentication with a remote server and sets the
                            authentication server to the specified address.
  show                      Displays administrative settings.
ruckus(config-admin) #
```

## Using the Help Command

To display all commands that the Ruckus Wireless CLI supports, use the **help** command.

#### NOTE

Entering the help command into the CLI prints a long list of commands on the screen. If you only want to view the commands that are available from within a specific context, use the **? command**. See *Using the ? Command* above for more information.

## Top-Level Commands

The following table lists the top-level CLI commands available in privileged mode.

Command	Description
exit	Ends the CLI session.
help	Shows available commands.
quit	Ends the CLI session.
history	Shows a list of previously run commands.
disable	Disables privileged commands.
ping	Sends ICMP echo packets to an IP/IPv6 address or domain name.

Command	Description
reboot	Reboots the controller.
shutdown	Shuts down ZoneDirector. To power on ZoneDirector again, press the power button. When the Status LED is lit steadily, you can then reconnect to CLI.
set-factory	Resets the controller to factory default settings.
data-privacy	Executes data privacy commands.
config	Enters the config context to configure options and settings.
logo	Enables/disables suppression of the Ruckus dog logo.
debug	Enters the debug context to perform debug operations.
show	Displays system options and settings.
reset	Resets system options and settings.
session-timeout	Sets the CLI session timeout.
monitor	Monitors system options and settings.

## disable

To disable privileged commands, use the following command:

**disable**

### Example

```
ruckus# disable
ruckus>
```

## ping

To send ICMP echo packets to an IP address or domain name, use the following command:

**ping <IP-ADDR/DOMAIN-NAME>**

### Example

```
ruckus> ping google.com
PING google.com (172.217.6.142) : 56 data bytes
64 bytes from 172.217.6.142: seq=0 ttl=56 time=40.252 ms
64 bytes from 172.217.6.142: seq=1 ttl=56 time=33.652 ms
64 bytes from 172.217.6.142: seq=2 ttl=56 time=32.560 ms

--- google.com ping statistics ---
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 32.560/35.488/40.252 ms
ruckus>
```

## reboot

To reboot the controller, use the following command:

**reboot**

## **Understanding the ZoneDirector Command Line Interface**

### **Top-Level Commands**

#### **Example**

```
ruckus# reboot  
ruckus#
```

## **shutdown**

To shut down the controller, use the following command:

### **shutdown**

Use this command to shut down ZoneDirector. To power on ZoneDirector again, press the power button. When the Status LED is lit steadily, you can then reconnect to the CLI.

#### **Example**

```
ruckus# shutdown  
ruckus#
```

## **set-factory**

To reset the controller to factory default settings, use the following command:

### **set-factory**

#### **Example**

```
ruckus# set-factory  
ruckus#
```

## **data-privacy**

To execute data privacy PII (personally identifiable information) commands, use the following command:

### **data-privacy**

#### **Example**

```
ruckus# data-privacy  
You have all rights in this mode.  
ruckus(data-privacy)#  
  help           Shows available commands.  
  history        Shows a list of previously run commands.  
  abort          Exits current context without saving changes.  
  end            Saves changes, and then exits the current context.  
  exit            Saves changes, and then exits the current context.  
  quit           Exits current context without saving changes.  
  show            Shows settings.  
  search <MAC>   Search PII Data by device MAC.  
  delete <MAC>   Delete PII Data by device MAC.  
  ftpurl <FTP Url> Enter the FTP URL like  
                  ftp://[username:password@]serverip[:port] [/subdirectory/]  
ruckus(data-privacy) #
```

## **search**

To Search PII Data by device MAC, use the following command:

## search <MAC>

### Example

```
ruckus (data-privacy) # search 00:01:02:03:04:05
Please input ftp url first
ruckus (data-privacy) #
```

## delete

To delete PII data by device MAC, use the following command:

## delete <MAC>

### Example

```
ruckus (data-privacy) # delete 00:01:02:03:04:05
Please input ftp url first
ruckus (data-privacy) #
```

## ftpurl

To configure the FTP URL for data privacy, use the following command:

## ftpurl <FTP Url>

Enter the FTP URL in the following format:

```
ftp://[username:password@]serverip[:port][/:subdirectory/]
```

### Example

```
ruckus (data-privacy) # ftpurl ftp://admin:admin@192.168.40.10:443/ftp
FTP server is not reachable or wrong ftp url ftp://admin:admin@192.168.40.10:443/ftp
ruckus (data-privacy) #
```

## config

To enter the config context and configure the controller, use the following command:

## config

### Example

```
ruckus# config
You have all rights in this mode.
ruckus(config) #
```

## logo

To enable or disable suppression of the Ruckus dog logo, use the following command:

## logo [nodog|default]

### **Example**

```
ruckus# logo nodog
ln: /etc/airespider-images/oem/logo.png: File exists
ruckus# logo default
ln: /etc/airespider-images/oem/logo.png: File exists
ruckus#
```

## **debug**

To enter the debug context to manage system debug options, use the following command:

```
debug
```

### **Example**

```
ruckus# debug
You have all rights in this mode.
ruckus(debug) #
```

## **reset radius-statistics**

To reset controller RADIUS statistics, use the following command:

```
reset radius-statistics [server-all|server-name <WORD>| wlan-all| wlan-name <NAME>
```

### **Example**

```
ruckus# reset radius-statistics wlan-all
Reset all WLANs RADIUS statistics successfully
ruckus#
```

## **monitor**

See [Viewing Current Configuration](#) on page 43.

# Viewing Current Configuration

---

• Show Commands Overview.....	44
• Show Location Services Commands.....	44
• Show AAA Commands.....	45
• Show DHCP Commands.....	47
• Show Access Point Commands.....	49
• Show AP Group Commands.....	54
• Show AP Policy Commands.....	57
• Show System Configuration Commands.....	58
• Show Performance Commands.....	60
• Show System Information Commands.....	63
• Show Ethernet Info Commands.....	64
• Show Technical Support Commands.....	65
• Show Management ACL Commands.....	67
• Show Static Route Commands.....	69
• Show WLAN Commands.....	71
• Show WLAN Group Commands.....	73
• Show L2 Access Control List Commands.....	75
• Show Whitelist Commands.....	77
• Show L3 Access Control List Commands.....	79
• Show Hotspot Commands.....	82
• Show Guest Policy Commands.....	89
• Show Hotspot 2.0 Operator Commands.....	92
• Show Hotspot 2.0 Service Provider Commands.....	93
• Show Role Commands.....	94
• Show VLAN Pool Commands.....	96
• Show User Commands.....	97
• Show Currently Active Clients Commands.....	99
• Show Mesh Commands.....	101
• Show Dynamic PSK Commands.....	103
• Show Guest Pass Commands.....	104
• show guest-access-generation.....	105
• show portal-auth-generation.....	106
• Show Rogue Device Commands.....	107
• Show Events and Activities Commands.....	108
• Show Alarm Commands.....	109
• Show License Commands.....	110
• Show USB Software Commands.....	111
• Show Application Policy Commands.....	112
• Show Session-Timeout Commands.....	113
• Show Active Wired Client Commands.....	114
• Show RADIUS Statistics Commands.....	115
• Show Load Balancing Commands.....	117
• Monitor AP MAC Commands.....	118
• Monitor Currently Active Client Commands.....	120
• Monitor Sysinfo Commands.....	122

## **Viewing Current Configuration**

Show Commands Overview

# Show Commands Overview

Show commands display the controller's current configuration and status information, such as system status and system configuration settings, along with the status and configurations of the controller's WLAN services, users, roles, AAA servers, access points, connected clients, AP groups and WLAN groups, etc.

Monitor commands allow the administrator to enter monitoring mode to view status and configuration changes as they occur.

## Show Location Services Commands

Use the **show location-services** commands to display information about the location servers that have been configured on the controller.

### **show location-services all**

To display a list of all location services servers that have been added to the controller, use the following command:

**show location-services all all**

#### **Syntax Description**

**show**

Displays information

**location-services**

Display location server information

**all**

All location servers

#### **Defaults**

None.

#### **Example**

```
ruckus# show location-services all
Venue:
ID:
 1:
  Status          = Disabled
  Venue Name      = MyVenue
  Location Server FQDN = lbls.ruckuslbs.com
  Location Server Port = 8883
  Location Server PSK   = password

ruckus#
```

### **show location-services name**

To display information on the specified location server, use the following command:

**show location-services name WORD**

# Show AAA Commands

Use the **show aaa** commands to display information about the authentication, authorization and accounting servers (AAA) servers that have been added to the controller.

## show aaa all

To display a list of all AAA servers that have been added to the controller, use the following command:

**show aaa all all**

### Syntax Description

**show**  
Display AAA server information

**aaa**  
Display AAA server information

**all**  
All AAA servers

### Defaults

None.

### Example

```
ruckus# show aaa all
AAA:
ID:
1:

Name= Local Database
Type= Local

2:
Name= Guest Accounts
Type= Guest

3:
Name= RADIUS Accounting
Type= RADIUS Accounting server
Primary RADIUS Accounting:
IP Address= 192.168.11.7
Port= 1813
Secret= secret
Secondary RADIUS Accounting:
Status= Disabled

4:
Name= Ruckus RADIUS
Type= RADIUS server
Auth Method=
Primary RADIUS:
IP Address= 192.168.11.99
Port= 1812
Secret= secret
Secondary RADIUS:
Status= Disabled
```

## Viewing Current Configuration

Show AAA Commands

```
5:  
Name= Ruckus AD  
Type= Active Directory  
IP Address= 192.168.11.17  
Port= 389  
Windows Domain Name= domain.ruckuswireless.com  
Global Catalog= Disabled  
Admin DN=domain  
Admin Password=password  
  
ruckus#
```

## show aaa name

To display information about a specific AAA server that has been added to the controller, use the following command:

**show aaa name WORD**

### Syntax Description

**show**

Display information

**aaa name**

Display information about the specified AAA server name

**WORD**

Name of the AAA server

### Defaults

None.

## Example

```
ruckus# show aaa name "Ruckus RADIUS"  
AAA:  
ID:  
4:  
Name= Ruckus RADIUS  
Type= RADIUS server  
Auth Method=  
Primary RADIUS:  
IP Address= 192.168.11.99  
Port= 1812  
Secret= secret  
Secondary RADIUS:  
Status= Disabled  
  
ruckus#
```

# Show DHCP Commands

Use the **show dhcp** commands to display the current settings for any DHCP servers configured for DHCP relay agent use.

## show dhcp all

To display a list of all DHCP servers that have been configured on the controller, use the following command:

**show dhcp all**

### Syntax Description

**show**  
Display information  
**dhcp**  
Display information about the specified DHCP server name  
**all**  
Display a list of all DHCP servers

### Defaults

None.

### Example

```
ruckus# show dhcp all
DHCP servers for DHCP relay agent:
ID:
 1:
  Name= DHCP Server 1
  Description=
  IP Address= 192.168.11.1
  IP Address=

ruckus#
```

## show dhcp name

To display a list of all DHCP servers that have been configured on the controller, use the following command:

**show dhcp name WORD**

### Syntax Description

**show**  
Display information  
**dhcp**  
Display information about the specified DHCP server name  
**name**  
Display the DHCP server specified

## **Viewing Current Configuration**

### Show DHCP Commands

WORD

Name of the DHCP server

### **Defaults**

None.

### **Example**

```
ruckus# show dhcp name "DHCP Server 1"
DHCP servers for DHCP relay agent:
ID:
 1:
  Name= DHCP Server 1
  Description=
  IP Address= 192.168.11.1
  IP Address=

ruckus#
```

# Show Access Point Commands

Use the **show ap** commands to display the current settings of managed devices, including their network address settings, device names, radio settings, and others.

## show ap all

To display a summary of all devices that have been approved, use the following command:

**show ap all**

### Syntax Description

**show**

Display information

**ap**

Show device information

**all**

All devices that have been approved by the controller

### Defaults

None.

### Example

```
ruckus# show ap all
AP:
ID:
1:
MAC Address= 04:4f:aa:0c:b1:00
Model= zf7962
Approved= Yes
Device Name= 7962 - MAP
Description= 7962 MAP (Living Room)
Location= Living Room
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
Protocol mode= IPv4 and IPv6
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.6
```

## **Viewing Current Configuration**

Show Access Point Commands

```
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server=
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart

2:
MAC Address= 00:24:82:3f:14:60
Model= zf7363
Approved= Yes
Device Name= 7363 - RAP
Description= 7363 - RAP (Study)
Location= Study
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
Protocol mode= IPv4 and IPv6
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.3
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server= 192.168.11.1
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address=
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart
```

ruckus#

## show ap devname

To display information about a specific device using its device name, use the following command:

**show ap devname WORD**

### Syntax Description

**show**  
Display information

**ap devname**  
Show information about the specified device name

**WORD**  
The name of the device

### Defaults

None.

### Example

```
ruckus# show ap devname "7962 - MAP"
AP:
ID:
1:
MAC Address= 04:4f:aa:0c:b1:00
Model= zf7962
Approved= Yes
Device Name= 7962 - MAP
Description= 7962 MAP (Living Room)
Location= Living Room
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
Protocol mode= IPv4 and IPv6
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.6
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server=
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
```

## **Viewing Current Configuration**

Show Access Point Commands

```
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart

ruckus#
```

## **show ap mac**

To search for the device that matches the specified MAC address, use the following command:

```
show ap mac MAC
```

### **Syntax Description**

**show**

Display information

**ap mac**

Display information about the device with the specified MAC address

**MAC**

The MAC address of the device

### **Defaults**

None.

### **Example**

```
ruckus# show ap mac 04:4f:aa:0c:b1:00
AP:
ID:
1:
MAC Address= 04:4f:aa:0c:b1:00
Model= zf7962
Approved= Yes
Device Name= 7962 - MAP
Description= 7962 MAP (Living Room)
Location= Living Room
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
```

```
Protocol mode= IPv4 and IPv6
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.6
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server=
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart

ruckus#
```

## **Viewing Current Configuration**

Show AP Group Commands

# Show AP Group Commands

Use the **show ap-group** commands to display Access Point Group settings.

## **show ap-group all**

To display all AP groups and their settings (including the default AP group), use the following command:

**show ap-group all**

### **Syntax Description**

**show**

Display information

**ap-group**

Display access point group information

**all**

All AP groups

### **Defaults**

None.

### **Example**

```
ruckus# show ap-group all
APGROUP:
ID:
1:
Name= System Default
Description= System default group for Access Points
Radio 11bgn:
Channelization= Auto
Channel= Auto
Enable auto channel selection which select from 1,6,11= Yes
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Radio 11an:
Channelization= Auto
Channel= Auto
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Members:
MAC= 04:4f:aa:0c:b1:00
MAC= 00:24:82:3f:14:60
MAC= 74:91:1a:2b:ff:a0

APGROUP:
ID:
2:
Name= ap group 2
Description=
Radio 11bgn:
Channelization= Auto
Channel= Auto
Enable auto channel selection which select from 1,6,11= Yes
Tx. Power= Auto
```

```

11N only Mode= Auto
WLAN Group= Default
Radio 11an:
Channelization= Auto
Channel= Auto
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Members:

APGROUP:
ID:
3:
Name= ap group 1
Description=
Radio 11bgn:
Channelization= Auto
Channel= Auto
Enable auto channel selection which select from 1,6,11= Yes
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Radio 11an:
Channelization= Auto
Channel= Auto
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Members:

ruckus#

```

## show ap-group name

To display details about a specific AP group, use the following command:

**show ap-group name WORD**

### Syntax Description

**show**

Display information

**ap-group name**

Display information about the AP group with the specified name

**WORD**

The name of the AP group

### Defaults

None.

### Example

```

ruckus# show ap-group name "System Default"
APGROUP:
ID:
1:
Name= System Default
Description= System default group for Access Points
Radio 11bgn:

```

## **Viewing Current Configuration**

Show AP Group Commands

```
Channelization= Auto
Channel= Auto
Enable auto channel selection which select from 1,6,11= Yes
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Radio 11an:
Channelization= Auto
Channel= Auto
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Members:
MAC= 04:4f:aa:0c:b1:00
MAC= 00:24:82:3f:14:60
MAC= 74:91:1a:2b:ff:a0
```

ruckus#

# Show AP Policy Commands

Use the **show ap-policy** command to display global access point policies that have been configured on the controller.

## show ap-policy

```
show ap-policy
```

### Example

```
ruckus# show ap-policy
Automatically approve all join requests from APs= Enabled
Limited ZD Discovery:
Status= Disabled
Management VLAN:
Status= Keep AP's setting
Balances the number of clients across adjacent APs= Disabled
Max. clients for 11BG radio= 100
Max. clients for 11N radio= 100
LWAPP message MTU= 1450
ruckus#
```

## **Viewing Current Configuration**

Show System Configuration Commands

# Show System Configuration Commands

Use the **show config** commands to display the controller's system configuration settings.

## **show config**

To display the current system configuration settings, including network addressing, management VLAN, country code, logging, AAA servers, WLAN services, WLAN groups, AP list, SNMP, and ACLs, etc., use the following command:

**show config**

### **Syntax Description**

**show**

Display information

**config**

Display system configuration settings

### **Defaults**

None.

### **Example**

```
ruckus# show config
Protocol Mode= IPv4-Only
Device IP Address:
    Mode= Manual
    IP Address= 192.168.40.100
    Netmask= 255.255.255.0
    Gateway Address= 192.168.40.1
    Primary DNS= 192.168.40.1
    Secondary DNS=

Management VLAN:
    VLAN ID= 1

Country Code:
    Code= United States

Identity:
    Name= Ruckus

NTP:
    Status= Enabled
    Address= ntp.ruckuswireless.com

Log:
    Status= Disabled
    Address= 192.168.3.10
    Facility= local0
    Priority= emerg
    AP Facility= local0
    AP Priority= emerg

Tunnel MTU:
    Tunnel MTU= 1500

Bonjour Service:
    Status= Disabled
```

```
Telnet Server:  
  Status= Disabled  
  
FTP Server:  
  Status= Enabled  
  Anonymous Status= Enabled  
  
FlexMaster:  
  Status= Disabled  
  Address=  
  Interval= 15  
  
AAA:  
  ID:  
    1:  
      Name= Local Database  
      Type= Local  
  
    2:  
      Name= Guest Accounts  
      Type= Guest  
...  
...  
ruckus#
```

# Show Performance Commands

Use the **show performance** commands to display performance details on an AP radio or client station.

## show performance

Use the following command to display performance details:

**show performance**

## show performance ap-radio2-4

Use the following command to display performance details for the AP's 2.4 GHz radio.

**show performance ap-radio2-4**

### Syntax Description

**show**  
Display information

**performance**  
Display performance information

**ap-radio-2-4**  
Display AP 2.4 GHz radio performance

**mac MAC**  
The MAC address of the AP

### Defaults

None.

### Example

```
ruckus# show performance ap-radio2-4 mac c4:10:8a:1f:d1:f0
AP performance:
 1:
  Radio b/g/n:
  MAC Address= c4:10:8a:1f:d1:f0
  Estimated Capacity= 9930
  Downlink= 67
  Uplink= 0
  RF pollution= 11
  Associated clients= 1
  Other APs= 0

ruckus#
```

## show performance ap-radio5

Use the following command to display performance details for the AP's 5 GHz radio:

**show performance ap-radio5 mac MAC**

## Syntax Description

**show performance**  
Display performance information

**ap-radio-5**  
Display AP 5 GHz radio performance

**mac MAC**  
The MAC address of the AP

## Defaults

None.

## Example

```
ruckus# show performance ap-radio5 mac c4:10:8a:1f:d1:f0
AP performance:
 1:
   Radio a/n:
   MAC Address= c4:10:8a:1f:d1:f0
   Estimated Capacity= 20891
   Downlink= 77
   Uplink= 2
   RF pollution= 3
   Associated clients= 1
   Other APs= 0
ruckus#
```

## show performance station

Use the following command to display performance details for a connected client/station:

**show performance station mac MAC**

## Syntax Description

**show performance**  
Display performance information

**station**  
Display station performance

**mac MAC**  
The MAC address of the station

## Defaults

None.

## Example

```
ruckus# show performance station mac 00:22:fb:ad:1b:2e
Station performance:
  MAC Address= 00:22:fb:ad:1b:2e
```

## **Viewing Current Configuration**

Show Performance Commands

```
Estimated Capacity= 61401
Downlink= 76
Uplink= 18
ruckus#
```

# Show System Information Commands

Use the **show sysinfo** commands to display the controller's system information.

## show sysinfo

To display an overview of the system status, including system, devices, usage summary, user activities, system activities, access points, and support information, use the following command:

**show sysinfo**

### Syntax Description

**show**  
Display information

**sysinfo**  
Display an overview of various system statuses

### Defaults

None.

### Example

```
ruckus# show sysinfo
System Overview:
  Name= ZoneDirector
  IP Address= 192.168.0.6
  IPv6 Address= fc00::2
  MAC Address= f8:e7:1e:3a:4c:20
  Uptime= 5d 19h 12m
  Model= ZD1200
  Licensed APs= 5
  Serial Number= 951608000220
  Version= 10.4.0.0 build 7

Devices Overview:
  Number of APs= 4
  Number of Client Devices= 6
  Number of Rogue Devices= 28

Usage Summary:
  Usage of 1 hr:
    Max. Concurrent Users= 6
    Bytes Transmitted= 148.58M
    Number of Rogue Devices= 28
  Usage of 24 hr:
    Max. Concurrent Users= 6
    Bytes Transmitted= 137.91G
    Number of Rogue Devices= 54

Memory Utilization:
  Used Bytes= 91528 (kB)
  Used Percentage= 5%
  Free Bytes= 1857716 (kB)
  Free Percentage= 95%

rukus#
```

## **Viewing Current Configuration**

Show Ethernet Info Commands

# Show Ethernet Info Commands

Use the **show ethinfo** command to display current system Ethernet status.

## **show ethinfo**

**show ethinfo**

### **Syntax Description**

**show**

Display information

**ethinfo**

Display the current system Ethernet status

### **Defaults**

None.

### **Example**

```
ruckus# show ethinfo
System Ethernet Overview:
  Port 0:
    Interface= eth0
    MAC Address= f8:e7:1e:3a:4c:20
    Physical Link= up
    Speed= 1000Mbps
  Port 1:
    Interface= eth1
    MAC Address= f8:e7:1e:3a:4c:21
    Physical Link= down
    Speed= 100Mbps
ruckus#
```

# Show Technical Support Commands

Use the following commands to display information that Ruckus Wireless may need when providing technical support.

## show techsupport

To display system information required by Technical Support, use the following command:

**show techsupport**

### Syntax Description

**show**

Display information

**techsupport**

Display information about the controller that may be required by Ruckus Wireless Technical Support

### Defaults

None.

### Example

```
ruckus# show
techsupport
System Overview:
Name= ZoneDirector
IP Address= 192.168.0.4
IPv6 Address= fc00::2
MAC Address= f8:e7:1f:3a:4c:20
Uptime= 5d 19h 16m
Model= ZD1200
Licensed APs= 5
Serial Number= 951608003220
Version= 10.4.0.0 build 7

Devices Overview:
Number of APs= 4
Number of Client Devices= 6
Number of Rogue Devices= 27

Usage Summary:
Usage of 1 hr:
Max. Concurrent Users= 6
Bytes Transmitted= 189.42M
Number of Rogue Devices= 27
Usage of 24 hr:
Max. Concurrent Users= 6
Bytes Transmitted= 137.95G
Number of Rogue Devices= 54

Memory Utilization:
Used Bytes= 91616(kB)
Used Percentage= 5%
Free Bytes= 1857628(kB)
Free Percentage= 95%


...
```

**Viewing Current Configuration**  
Show Technical Support Commands

ruckus#

# Show Management ACL Commands

Use the **mgmt-acl** and **mgmt-acl-ipv6** commands to display information about the management access control lists configured on the controller.

## show mgmt-acl all

To display all management ACLs that have been configured on the controller, use the following command:

```
show mgmt-acl all
```

## show mgmt-acl name

To display information about a specific management ACL, use the following command:

```
show mgmt-acl name NAME
```

## show mgmt-acl-ipv6 all

To display all management ACLs that have been configured on the controller, use the following command:

```
show mgmt-acl-ipv6 all
```

## show mgmt-acl-ipv6 name

To display information about a specific management ACL, use the following command:

```
show mgmt-acl-ipv6 name NAME
```

### Syntax Description

**show**

Display information

**mgmt-acl**

Display management ACL settings

**mgmt-acl-ipv6**

Display IPv6 management ACL settings

**all**

All configured management ACLs

**name**

Display information about a specific management ACL

**NAME**

The name of the management ACL

### Defaults

None.

## **Viewing Current Configuration**

Show Management ACL Commands

### **Example**

```
ruckus# show mgmt-acl all
Management ACL:
Name= New Name
  Restriction Type= range
  IP range= 192.168.11.1-192.168.11.253

Name= Remote 1
  Restriction Type= single
  IP address= 172.17.17.150

Name= Remote admin 2
  Restriction Type= single
  IP address= 172.17.16.12

ruckus#
```

# Show Static Route Commands

Use the **static-route** commands to display information about static routes configured on the controller.

## show static-route all

To display all static route information, use the following command:

**show static-route all**

## show static-route name

**show static-route name NAME**

## show static-route-ipv6 all

**show static-route-ipv6 all**

## show static-route-ipv6 name

**show static-route-ipv6 name NAME**

### Syntax Description

**show**

Display information

**static-route**

Display static route settings

**static-route-ipv6**

Display IPv6 static route settings

**all**

All configured static routes

**name**

Display information about a specific configured static route

**NAME**

The name of the static route entry

### Defaults

None.

### Example

```
ruckus# show static-route all
Static Route:
ID= 1
Name= Static Route 1
```

## **Viewing Current Configuration**

Show Static Route Commands

```
IP subnet= 192.168.11.1/24  
IP gateway= 192.168.11.1
```

```
ruckus#
```

# Show WLAN Commands

Use the following commands to display information about available WLANs on the controller.

## show wlan

To display all available WLAN services (SSIDs), use the following command:

**show wlan [ all | name <WORD>]**

### Syntax Description

**show**  
Display information  
**wlan**  
Display WLAN services (SSIDs) settings  
**all**  
Display all WLAN services  
**name <WORD>**  
Display the named WLAN only

### Defaults

None.

### Example

```
ruckus# show wlan all
WLAN Service:
ID:
1:
  NAME = Ruckus1
  Tx. Rate of Management Frame(2.4GHz) = 2.0Mbps
  Tx. Rate of Management Frame(5GHz) = 6.0Mbps
  Beacon Interval = 100ms
  SSID = Ruckus1
  Description = Ruckus1
  Type = Standard Usage
  Authentication = open
  Encryption = wpa2
  Algorithm = aes
  Passphrase = secretpassphrassgoeshere
  FT Roaming = Disabled
  802.11k Neighbor report = Disabled
  Web Authentication = Disabled
  Authentication Server = Disabled
  Accounting Server = Disabled
  Called-Station-Id type = wlan-bssid
  Tunnel Mode = Disabled
  DHCP relay = Disabled
  Max. Clients = 100
  Isolation per AP = Disabled
  Isolation across AP = Disabled
  Zero-IT Activation = Enabled
  Load Balancing = Disabled
  Band Balancing = Disabled
  Dynamic PSK = Enabled
```

## Viewing Current Configuration

Show WLAN Commands

```
Dynamic PSK Passphrase Length =
Dynamic PSK Expire Time = unlimited
Dynamic PSK Validity Period =
Limit Dynamic PSK = Disabled
Auto-Proxy configuration:
    Status = Disabled
Inactivity Timeout:
    Status = Disabled
VLAN-ID = 1
Dynamic VLAN = Disabled
Closed System = Disabled
Https Redirection = Disabled
OFDM-Only State = Disabled
Multicast Filter State = Disabled
802.11d State = Disabled
Force DHCP State = Disabled
Force DHCP Timeout = 0
DHCP Option82:
    Status = Disabled
    Option82 sub-Option1 = Disabled
    Option82 sub-Option2 = Disabled
    Option82 sub-Option150 = Disabled
    Option82 sub-Option151 = Disabled
Ignore unauthorized client statistic = Disabled
STA Info Extraction State = Enabled
BSS Minrate = Disabled
DTIM period = 1
Directed MC/BC Threshold = 5
Call Admission Control State = Disabled
PMK Cache Timeout= 720 minutes
PMK Cache for Reconnect= Enabled
NAS-ID Type= wlan-bssid
Roaming Acct-Interim-Update= Disabled
PAP Message Authenticator = Enabled
Send EAP-Failure = Disabled
L2/MAC = No ACLS
L3/L4/IP Address = No ACLS
L3/L4/IPv6 Address = No ACLS
Precedence = No ACLS
Proxy ARP = Disabled
Device Policy = No ACLS
Vlan Pool = No Pools
Role based Access Control Policy = Disabled
SmartRoam = Disabled Roam-factor = 1
White List = No ACLS
Application Recognition & Control = Disabled
Apply ARC Policy = NO POLICY
Wlan Bind = all
Client Flow Data Logging = Disabled
Client Connection Data = Disabled
```

ruckus#

# Show WLAN Group Commands

Use the following commands to display information about the WLAN groups that exist on the controller.

## show wlan-group all

To display a list of existing WLAN groups, use the following command:

**show wlan-group all**

### Syntax Description

**show**  
Display information

**wlan-group**  
Display information about the specified WLAN group

**all**  
Show all WLAN groups

### Defaults

None.

### Example

```
ruckus# show wlan-group all
WLAN Group:
ID:
1:
Name= Default
Description= Default WLANs for Access Points
WLAN Service:
WLAN1:
NAME= Ruckus1
VLAN=
WLAN2:
NAME= Ruckus2
VLAN=

2:
Name= Guest WLAN Group
Description= 1st floor APs only
WLAN Service:
WLAN1:
NAME= Ruckus-Guest
VLAN=


ruckus#
```

## show wlan-group name

To display information about the specified WLAN group name, use the following command:

**show wlan-group name WORD**

## **Viewing Current Configuration**

Show WLAN Group Commands

### **Syntax Description**

**show**

Display information

**wlan-group name**

Display information about the specified WLAN group name

**WORD**

The name of the WLAN group

### **Defaults**

None.

### **Example**

```
ruckus# show wlan-group name Default
WLAN Group:
ID:
1:
Name= Default
Description= Default WLANs for Access Points
WLAN Service:
WLAN1:
NAME= Ruckus1
VLAN=
WLAN2:
NAME= Ruckus2
VLAN=
ruckus#
```

# Show L2 Access Control List Commands

Use the **show l2acl** commands to display Layer 2 access control list rules that have been added to the controller.

## show l2acl all

To display all Layer 2 access control list (ACL) rules that have been added to the controller and their settings, use the following command:

**show l2acl all**

### Syntax Description

**show**  
Display information

**l2acl**  
Display L2 ACL information

**all**  
All L2 ACL

### Defaults

None.

### Example

```
ruckus# show l2acl all
L2/MAC ACL:
ID:
1:
Name= System
Description= System
Restriction: Deny only the stations listed below
Stations:
2:
Name= blocked-sta-list
Description=
Restriction: Deny only the stations listed below
Stations:
```

## show l2acl name

To display the settings of a specific L2 ACL rule that has been added to the controller, use the following command:

**show l2acl name WORD**

### Syntax Description

**show**  
Display information

**l2acl**  
Display L2 ACL information

## **Viewing Current Configuration**

Show L2 Access Control List Commands

### **name**

Display information about the specified L2 ACL rule name

#### **WORD**

Name of the L2 ACL rule

### **Defaults**

None.

### **Example**

```
ruckus# show l2acl name 1
L2/MAC ACL:
ID:
2:
Name= 1
Description=
Restriction: Deny only the stations listed below
Stations:
MAC Address= 00:33:22:45:34:88
```

# Show Whitelist Commands

Use the **show whitelist** commands to display client isolation whitelists that have been added to the controller.

## show whitelist all

To display all whitelists that have been added to the controller and their settings, use the following command:

**show whitelist all**

### Syntax Description

**show**  
Display information

**whitelist**  
Display whitelist information

**all**  
All whitelists

### Defaults

None.

### Example

```
ruckus# show whitelist all
White Lists:
ID:
1:
Name= printer whitelist
Description= printer
Rules:
1:
Description= printer
MAC = 12:34:56:78:90:00
IP Address = 192.168.4.10

ruckus#
```

## show whitelist name

To display a specified whitelist that has been added to the controller by name, use the following command:

**show whitelist name WORD**

### Syntax Description

**show**  
Display information

**whitelist**  
Display whitelist information

## **Viewing Current Configuration**

### Show Whitelist Commands

**name WORD**

Specify the name of the whitelist

### **Defaults**

None.

### **Example**

```
ruckus# show whitelist name "printer whitelist"
White Lists:
ID:
1:
Name= printer whitelist
Description= printer
Rules:
1:
Description= printer
MAC = 12:34:56:78:90:00
IP Address = 192.168.4.10

ruckus#
```

# Show L3 Access Control List Commands

Use the **show l3acl** commands to display Layer 3 access control list rules that have been added to the controller.

## show l3acl all

To display all Layer 3 access control list (ACL) rules that have been added to the controller and their settings, use the following command:

**show l3acl all**

## show l3acl-ipv6 all

To display all IPv6 Layer 3 access control list (ACL) rules that have been added to the controller and their settings, use the following command:

**show l3acl-ipv6 all**

### Syntax Description

**show**  
Display information  
**l3acl**  
Display L3 ACL information  
**l3acl-ipv6**  
Display IPv6 L3 ACL information  
**all**  
All L3 ACL

### Defaults

None.

### Example

```
ruckus# show l3acl all
L3/L4/IP ACL:
ID:
4:
Name= test2
Description= test2
Default Action if no rule is matched= Deny all by default
Rules:
Order= 1
Description=
Type= Allow
Destination Address= Any
Destination Port= 53
Protocol= Any
Order= 2
Description=
Type= Allow
Destination Address= Any
Destination Port= 67
Protocol= Any
```

## **Viewing Current Configuration**

Show L3 Access Control List Commands

```
Order= 3
Description=
Type= Allow
Destination Address= 8.8.8.8/24
Destination Port= 25
Protocol= 6
```

## **show l3acl name**

To display the settings of a specific L3 ACL rule that has been added to the controller, use the following command:

**show l3acl name WORD**

## **show l3acl-ipv6 name**

To display the settings of a specific IPv6 L3 ACL rule that has been added to the controller, use the following command:

**show l3acl-ipv6 name WORD**

### **Syntax Description**

**show**  
Display information

**l3acl**  
Display L3 ACL information

**l3acl-ipv6**  
Display IPv6 L3 ACL information

**name**  
Display information about the specified L3 ACL rule

**WORD**  
Name of the L3 ACL rule

### **Defaults**

None.

### **Example**

```
ruckus# show l3acl name test2
L3/L4/IP ACL:
ID:
4:
Name= test2
Description= test2
Default Action if no rule is matched= Allow all by default
Rules:
Order= 1
Description=
Type= Allow
Destination Address= Any
Destination Port= 53
Protocol= Any
Order= 2
Description=
Type= Allow
```

```
Destination Address= Any
Destination Port= 67
Protocol= Any
Order= 3
Description=
Type= Allow
Destination Address= 8.8.8.8/24
Destination Port= 25
Protocol= 6
```

## **Viewing Current Configuration**

Show Hotspot Commands

# Show Hotspot Commands

Use the **show hotspot** commands to display the controller's hotspot configuration settings.

## **show hotspot all**

To display a list of all hotspot services that have been created on the controller, use the following command:

**show hotspot all**

### **Syntax Description**

**show**

Display information

**hotspot**

Display hotspot information

**all**

All available hotspots

### **Defaults**

None.

### **Example**

```
ruckus# show hotspot all
Hotspot:
  ID:
    1:
      Name= Hotspot 1
      WISPr Smart Client Support:
        Status= None
      Login Page Url= http://192.168.1.12/login.htm
      Start Page= redirect to the URL that the user intends to visit
      Session Timeout:
        Status= Disabled
      Grace Period:
        Status= Disabled
      Intrusion Prevention= Enabled
      Authentication Server= Local Database
      Accounting Server:
        Status= Disabled
      Isolation per AP = Disabled
      Isolation across AP = Disabled
      White List = No ACLS
      Location ID=
      Location Name=
      Walled Garden 1= 1.1.1.1
      IPv4 Rules:
        IPv6 Rules:

ruckus#
```

## show hotspot name

To display information about the specific hotspot service, use the following command:

**show hotspot name WORD**

If the hotspot name includes a space, you must put the name in quotation marks (for example, "hotspot name").

### Syntax Description

**show**

Display information

**hotspot name**

Display hotspot information

**WORD**

The name of the hotspot

### Defaults

None.

### Example

```
ruckus# show hotspot name "Hotspot 1"
Hotspot:
ID:
 1:
  Name= Hotspot 1
  WISPr Smart Client Support:
    Status= None
  Login Page Url= http://192.168.1.12/login.htm
  Start Page= redirect to the URL that the user intends to visit
  Session Timeout:
    Status= Disabled
  Grace Period:
    Status= Disabled
  Intrusion Prevention= Enabled
  Authentication Server= Local Database
  Accounting Server:
    Status= Disabled
  Isolation per AP = Disabled
  Isolation across AP = Disabled
  White List = No ACLS
  Location ID=
  Location Name=
  Walled Garden 1= 1.1.1.1
  IPv4 Rules:

  IPv6 Rules:

ruckus#
```

## show hs20op all

To display information about all Hotspot 2.0 Operators, use the following command:

**show hs20op all**

## **Viewing Current Configuration**

Show Hotspot Commands

### **Syntax Description**

**show**

Display information

**hs20op**

Display Hotspot 2.0 Operator

**all**

Display all HS2.0 operators

### **Defaults**

None.

### **Example**

```
ruckus# show hs20op all
Hotspot 2.0 Operator:
ID:
1:
  NAME= operator1
  Description=
  Venue Group= Unspecified
  Venue Type= Unspecified
  ASRA Option:
    Status= Disabled
    Internet Option= Disabled
    Access Network Type= Private
    IPv4 Address Type= Not Available
    IPv6 Address Type= Not Available
  HESSID=
  Friendly Name List:
  Service Provider Profiles:
    ID= 1
    Name= provider1
  WAN Metrics:
    Enable Symmetric Link= Disabled
    WAN at Capability= Disabled
    Link Status= Link Up
    WAN Downlink Load= 0
    WAN Downlink Speed= 0
    WAN Uplink Load= 0
    WAN Uplink Speed= 0
    Load Measurement Duration= 0
  Connection Capability:
    Description= ICMP
    IP Protocol= 1
    Port Number= 0
    Status= Closed
    Description= FTP
    IP Protocol= 6
    Port Number= 20
    Status= Closed
    Description= SSH
    IP Protocol= 6
    Port Number= 22
    Status= Closed
    Description= HTTP
    IP Protocol= 6
    Port Number= 80
    Status= Closed
    Description= Used by TLS VPNs
    IP Protocol= 6
    Port Number= 443
    Status= Closed
```

```
Description= Used by PPTP VPNs
  IP Protocol= 6
  Port Number= 1723
  Status= Closed
Description= VoIP
  IP Protocol= 6
  Port Number= 5060
  Status= Closed
Description= Used by IKEv2 (IPSec VPN)
  IP Protocol= 17
  Port Number= 500
  Status= Closed
Description= VoIP
  IP Protocol= 17
  Port Number= 5060
  Status= Closed
Description= May be used by IKEv2 (IPSec VPN)
  IP Protocol= 17
  Port Number= 4500
  Status= Closed
Description= ESP, used by IPSec VPNs
  IP Protocol= 50
  Port Number= 0
  Status= Closed
Additional Connection Capability:
Advanced GAS Settings:
  GAS query response buffering time= 1000
  GAS DOS detection= Disabled
  GAS DOS maximum request number= 200
Hotspot 2.0 Capability:
  Operating Class Indication= Unspecified
```

ruckus#

## show hs20op name

To display information about the named Hotspot 2.0 Operator, use the following command:

**show hs20op name WORD**

### Syntax Description

**show**

Display information

**hs20op name**

Display specific Hotspot 2.0 Operator

**WORD**

The name of the HS2.0 operator

### Defaults

None.

### Example

```
ruckus# show hs20op name operator1
Hotspot 2.0 Operator:
  ID:
    1:
```

## Viewing Current Configuration

### Show Hotspot Commands

```
NAME= operator1
Description=
Venue Group= Unspecified
Venue Type= Unspecified
ASRA Option:
    Status= Disabled
Internet Option= Disabled
Access Network Type= Private
IPv4 Address Type= Not Available
IPv6 Address Type= Not Available
HESSID=
Friendly Name List:
Service Provider Profiles:
    ID= 1
        Name= provider1
WAN Metrics:
    Enable Symmetric Link= Disabled
    WAN at Capability= Disabled
    Link Status= Link Up
    WAN Downlink Load= 0
    WAN Downlink Speed= 0
    WAN Uplink Load= 0
    WAN Uplink Speed= 0
    Load Measurement Duration= 0
Connection Capability:
    Description= ICMP
        IP Protocol= 1
        Port Number= 0
        Status= Closed
    Description= FTP
        IP Protocol= 6
        Port Number= 20
        Status= Closed
    Description= SSH
        IP Protocol= 6
        Port Number= 22
        Status= Closed
    Description= HTTP
        IP Protocol= 6
        Port Number= 80
        Status= Closed
    Description= Used by TLS VPNs
        IP Protocol= 6
        Port Number= 443
        Status= Closed
    Description= Used by PPTP VPNs
        IP Protocol= 6
        Port Number= 1723
        Status= Closed
    Description= VoIP
        IP Protocol= 6
        Port Number= 5060
        Status= Closed
    Description= Used by IKEv2 (IPSec VPN)
        IP Protocol= 17
        Port Number= 500
        Status= Closed
    Description= VoIP
        IP Protocol= 17
        Port Number= 5060
        Status= Closed
    Description= May be used by IKEv2 (IPSec VPN)
        IP Protocol= 17
        Port Number= 4500
        Status= Closed
    Description= ESP, used by IPSec VPNs
        IP Protocol= 50
        Port Number= 0
        Status= Closed
Additional Connection Capability:
Advanced GAS Settings:
    GAS query response buffering time= 1000
```

```
GAS DOS detection= Disabled  
GAS DOS maximum request number= 200  
Hotspot 2.0 Capability:  
Operatiing Class Indication= Unspecified  
  
ruckus#
```

## show hs20sp all

To display information about the Hotspot 2.0 Service Provider, use the following command:

```
show hs20sp all
```

### Syntax Description

```
show  
    Display information  
  
hs20sp  
    Display Hotspot 2.0 Service Provider  
  
all  
    Display all HS2.0 Service Providers
```

### Defaults

None.

### Example

```
ruckus# show hs20sp all  
Hotspot 2.0 Service Provider:  
    ID:  
        1:  
            NAME= provider1  
            Description=  
            Realm List:  
            Domain Name List:  
            Roaming Consortium List:  
            3GPP Cellular Network information:  
  
ruckus#
```

## show hs20sp name

To display information about a specific Hotspot 2.0 Service Provider, use the following command:

```
show hs20sp name WORD
```

### Syntax Description

```
show  
    Display information  
  
hs20sp name  
    Display specific Hotspot 2.0 Service Provider
```

## **Viewing Current Configuration**

### Show Hotspot Commands

WORD

The name of the HS2.0 Service Provider

### **Defaults**

None.

### **Example**

```
ruckus# show hs20sp name provider1
Hotspot 2.0 Service Provider:
ID:
 1:
  NAME= provider1
  Description=
  Realm List:
  Domain Name List:
  Roaming Consortium List:
  3GPP Cellular Network information:

ruckus#
```

# Show Guest Policy Commands

Use the following commands to display guest access services.

## show guest-access-service

To display a list of guest access services or a specific service, use the following command:

**show guest-access-service [ all | name WORD ]**

### Example

```
ruckus# show guest-access all
Guest Access:
  Name = guestpolicy1
  Onboarding Portal:
    Aspect = Guest pass and ZeroIT
  Authentication:
    Mode = Use Guest Pass and Social login authentication
    Title = hello
  Terms of Use:
    Status = Disabled
  Redirection:
    Mode = To the URL that the user intends to visit
  Restricted Subnet Access:
    Rules:
      1:
        Description=
        Type= Deny
        Destination Address= local
        Destination Port= Any
        Protocol= Any
      2:
        Description=
        Type= Deny
        Destination Address= 10.0.0.0/8
        Destination Port= Any
        Protocol= Any
      3:
        Description=
        Type= Deny
        Destination Address= 172.16.0.0/12
        Destination Port= Any
        Protocol= Any
      4:
        Description=
        Type= Deny
        Destination Address= 192.168.0.0/16
        Destination Port= Any
        Protocol= Any
  Restricted IPv6 Access:
    Rules:
      1:
        Description=
        Type= Deny
        Destination Address= local
        Destination Port= Any
        Protocol= Any
        ICMPv6 Type= Any
ruckus#
```

## **Viewing Current Configuration**

Show Guest Policy Commands

## **show guest-access-generation**

To display generation information for guest access, use the following command:

**show guest-access-generation**

### ***Example***

```
ruckus(config)# show guest-access-generation
  Authentication Server: radius1
  Force HTTPS Redirection: Disabled
ruckus(config)#{
```

## show portal-auth-generation

To display generation information for portal authentication, use the following command:

**show portal-auth-generation**

### **Example**

```
ruckus(config)# show portal-auth-generation
  Force DNS server: Disabled
ruckus(config)#+
```

## **Viewing Current Configuration**

Show Hotspot 2.0 Operator Commands

# Show Hotspot 2.0 Operator Commands

Use the following commands to display Hotspot 2.0 Operators.

## **show hs20op**

To display a list of Hotspot 2.0 operators, use the following command:

**show hs20op [all|name WORD]**

### ***Example***

```
ruckus# show hs20op all
```

# Show Hotspot 2.0 Service Provider Commands

Use the following commands to display Hotspot 2.0 Service Providers.

## show hs20sp

To display a list of Hotspot 2.0 service providers, use the following command:

**show hs20sp [all|name WORD]**

### *Example*

```
ruckus# show hs20sp all
```

## **Viewing Current Configuration**

Show Role Commands

# Show Role Commands

Use the **show role** commands to display details about roles that have been created on the controller.

## **show role all**

To display a list of all roles that have been created on the controller, use the following command:

**show role all**

### **Syntax Description**

<b>show</b>	Display information
<b>role</b>	Display role information
<b>all</b>	All roles that have been created

### **Defaults**

None.

### **Example**

```
ruckus# show role all
Role:
ID:
1:
  Name= Default
  Description= Allow Access to All WLANs
  Group Attributes=
  Guest Pass Generation= Allowed
  ZoneDirector Administration:
    Status= Allowed
    Allow ZoneDirector Administration= Super Admin
  Allow All WLANs:
    Mode= Allow access to all WLANs
  Access Control Policy= Disallowed

ruckus#
```

## **show role name**

To display information about the specific role, use the following command:

**show role name WORD**

### **Syntax Description**

<b>show</b>	Display information
-------------	---------------------

**role name**

Display role information

*WORD*

The name of the role

**Defaults**

None.

**Example**

```
ruckus# show role name Default
Role:
ID:
 1:
  Name= Default
  Description= Allow Access to All WLANs
  Group Attributes=
  Guest Pass Generation= Allowed
  ZoneDirector Administration:
    Status= Allowed
    Allow ZoneDirector Administration= Super Admin
  Allow All WLANs:
    Mode= Allow access to all WLANs
  Access Control Policy= Disallowed

ruckus#
```

## **Viewing Current Configuration**

Show VLAN Pool Commands

# Show VLAN Pool Commands

Use the following commands to display VLAN pools.

## **show vlan-pool**

To display a list of VLAN pools, use the following command:

**show vlan-pool [ all | name WORD]**

### ***Example***

```
ruckus# show vlan-pool all
VLAN Pool:
ID:
 1:
  Name = vlan pool 1
  Description =
  Option = 1
  VLANSET = 10,20,30,40,50-55

ruckus#
```

# Show User Commands

Use the **show user** commands to display details about user accounts that exist on the controller.

## show user all

To display a list of all existing user accounts, use the following command:

**show user all**

### Syntax Description

**show**  
Display information  
**user**  
Display user information  
**all**  
All existing user accounts

### Defaults

None.

### Example

```
ruckus# show user all
User:
ID:
1:
User Name= test22
Full Name= test11
Password= test1234
Role= Default
```

## show user name

To display information about the specific user, use the following command:

**show user name user\_name**

### Syntax Description

**show**  
Display information  
**user name**  
Display user information  
**WORD**  
The name of the user

## **Viewing Current Configuration**

Show User Commands

### **Defaults**

None.

### **Example**

```
ruckus# show user name test22
User:
ID:
1:
User Name= test22
Full Name= test11
Password= test1234
Role= Default
```

# Show Currently Active Clients Commands

Use the **show current-active-clients** commands to display a list of wireless clients that are associated with the APs that the controller manages.

## show current-active-clients all

To display a list of all existing user accounts, use the following command:

**show current-active-clients all**

### Syntax Description

**show**

Display information

**current-active-clients**

Display currently active wireless clients

**all**

All active wireless clients

### Defaults

None.

### Example

```
ruckus# show current-active-clients all
Current Active Clients:
Clients:
Mac Address= 00:22:fb:5c:e2:32
User/IP= 172.18.30.2
User/IPv6=
Access Point= 04:4f:aa:13:30:f0
BSSID= 04:4f:aa:13:30:fa
Connect Since=2011/03/01 02:48:22
Auth Method= OPEN
WLAN= 11jojoe
VLAN= None
Channel= 6
Radio= 802.
Signal= 0
Status= Authorized

Last 300 Events/Activities:
Activity:
Date/Time= 2011/03/01 02:49:05
Severity= Low
User=
Activities= User[00:22:fb:5c:e2:32] joins WLAN[11jojoe] from AP[04:4f:aa:13:30:f0]
Activity:
Date/Time= 2011/03/01 02:48:22
Severity= Low
User=
Activities= User[00:22:fb:5c:e2:32] joins WLAN[11jojoe] from AP[04:4f:aa:13:30:f0]
...
...
ruckus#
```

## **Viewing Current Configuration**

Show Currently Active Clients Commands

## **show current-active-clients mac**

To display information about the specific active client, use the following command:

**show current-active-clients mac MAC**

### **Syntax Description**

**show**

Display information

**current-active-clients mac**

Display currently active wireless clients

**MAC**

The MAC address of the wireless client

### **Defaults**

None.

### **Example**

```
ruckus# show current-active-clients mac 6c:62:6d:1b:e3:00
Current Active Clients:
Clients:
Mac Address= 6c:62:6d:1b:e3:00
User/IP= 192.168.11.11
User/IPv6=
Access Point= 04:4f:aa:0c:b1:00
BSSID= 04:4f:aa:0c:b1:08
Connect Since=2012/01/10 06:22:44
Auth Method= OPEN
WLAN= Ruckus1
VLAN= None
Channel= 6
Radio= 802.11gn
Signal= 53
Status= Authorized
Received from client= 20746 pkts / 6274531 bytes
Transmitted to client= 25777 pkts / 6714433 bytes
Tx. drops due to retry failure= 1 pkts

Last 300 Events/Activities:
Activitiy:
Date/Time= 2012/01/10 06:22:44
Severity= Low
User=
Activities= User[6c:62:6d:1b:e3:00]> joins WLAN[Ruckus1] from AP[7962 - MAP@04:4f:aa:0c:b1:00]
Activitiy:
Date/Time= 2012/01/09 18:52:28
Severity= Low
User=
Activities= User[6c:62:6d:1b:e3:00]disconnects from WLAN[Ruckus1] at AP[7363 - RAP@00:24:82:3f:14:60]
Activitiy:
Date/Time= 2012/01/08 06:08:52
Severity= Low
User=
Activities= AP[7363 - RAP@00:24:82:3f:14:60] radio [11g/n] detects User[6c:62:6d:1b:e3:00] in
WLAN[Ruckus1] roams from AP[7962 - MAP@04:4f:aa:0c:b1:00]
...
...
ruckus#
```

# Show Mesh Commands

Use the **show mesh** commands to display the controller's mesh network configuration and topology.

## show mesh info

To display a list of mesh information, use the following command:

**show mesh info**

### Syntax Description

<b>show</b>	Display information
<b>mesh</b>	Display mesh network information
<b>info</b>	Show mesh information

### Defaults

None.

### Example

```
ruckus# show mesh info
Mesh Settings:
  Mesh Status= Enabled
  Mesh Name (ESSID)= Mesh-951608000220
  Mesh Passphrase= bzb9Y0kEpkxOPzPXYKqLrJHZSAAnbtfaTm7Ebh6qps24PFcc5MtCijGGwFZBG
  Mesh Radio Option= 5G
  Mesh Uplink Selection Algorithm = default(static)
  Mesh Hop Detection:
    Status= Disabled
  Mesh Downlinks Detection:
    Status= Disabled
  Tx. Rate of Management Frame= 2Mbps
  Beacon Interval= 200ms
  Zero-Touch-Mesh status= Enabled
Zero Touch Mesh Pre-Approved Serial Number List:
serial number = 921802014959, approved = 0, time = 0, id = 1
serial number = 441e981cf0d0, approved = 0, time = 0, id = 2
serial number = 4f1e681cf3f0, approved = 0, time = 0, id = 3
serial number = c41e781bd7c0, approved = 0, time = 0, id = 4
ruckus#
```

## show mesh topology

To display the topology of existing mesh networks, use the following command:

**show mesh topology**

## **Viewing Current Configuration**

Show Mesh Commands

### **Syntax Description**

**show**

Display information

**mesh**

Display mesh network information

**topology**

Show mesh topology

### **Defaults**

None.

### **Example**

```
ruckus# show mesh topology
Mesh Topology (Mesh-951608000220):
  Root Access Points= d4:c1:9e:35:c9:50
    Signal (dB) Downlink=  / Uplink=
    Description=
    Channel= 36 (11ac)
    IP Address= 192.168.0.3
  Mesh Access Points= 44:1e:98:1b:f0:d0
    Signal (dB) Downlink= 44 / Uplink= 36
    Description=
    Channel= 36
    IP Address= 192.168.0.10

ruckus#
```

# Show Dynamic PSK Commands

Use the **show dynamic-psks** commands to display information about Dynamic PSKs that have been generated. Use the following command:

## show dynamic-psks

**show dynamic-psks**

### Syntax Description

**show**

Display information

**dynamic-psks**

Display dynamic PSKs that have been generated

### Defaults

None.

### Example

```
ruckus# show dynamic-psks
Generated Dynamic PSKs:
DPSK:
User= BatchDPSK_User_1
Mac Address= 00:00:00:00:00:00
Created= 2011/03/01 03:30:01
Expired= Unlimited
DPSK:
User= BatchDPSK_User_2
Mac Address= 00:00:00:00:00:00
Created= 2011/03/01 03:30:02
Expired= Unlimited
DPSK:
User= DPSK-User-2
Mac Address= 00:11:22:33:44:55
Created= 2011/03/01 03:30:47
Expired= Unlimited
```

## **Viewing Current Configuration**

Show Guest Pass Commands

# Show Guest Pass Commands

Use the **show guest-passes** commands to display information about guest passes that have been generated. Use the following command:

**show guest-passes**

## **show guest-passes**

**show guest-passes**

### **Syntax Description**

**show**

Display information

**guest-passes**

Display guest passes that have been generated

### **Defaults**

None.

### **Example**

```
ruckus# show guest-passes
Generated Guest Passes:
ID:
Guest Name= John Doe
Remarks=
Expires= 2012/01/11 08:32:15
Re-auth=
Creator= ruckus
Sharable= No
Wlan= Ruckus-Guest

ruckus#
```

# show guest-access-generation

Display generation information for guest access.

## Examples

```
ruckus# show guest-access-generation
  Authentication Server: radius1
  Force HTTPS Redirection: Disabled
ruckus#
```

## **Viewing Current Configuration**

show portal-auth-generation

# **show portal-auth-generation**

Display generation information for portal authentication.

## **Examples**

```
ruckus# ruckus# show portal-auth-generation
  Force DNS server: 192.168.40.10
ruckus#
```

# Show Rogue Device Commands

Use the **show rogue-devices** commands to display information about rogue devices that the controller has detected on the network. Use the following command.

## show rogue-devices

**show**

Display information

**rogue-devices**

Display rogues devices that have been detected on the network

### Defaults

None.

### Example

```
ruckus# show rogue-devices
Current Active Rogue Devices:
Rogue Devices:
Mac Address= 00:25:c4:52:1c:a1
Channel= 6
Radio= 802.11bg
Type= AP
Encryption= Open
SSID= V54-HOME001
Last Detected= 2011/03/01 02:03:43

Known/Recognized Rogue Devices:
```

## **Viewing Current Configuration**

Show Events and Activities Commands

# Show Events and Activities Commands

Use the **show events-activities** commands to display information events and network activities that have been recorded by the controller. Use the following command:

## **show events-activities**

**show events-activities**

### **Syntax Description**

**show**

Display information

**events-activities**

Display a list of events and activities records by the controller

### **Defaults**

None.

### **Example**

```
ruckus# show events-activities
ruckus# show events-activities
Last 300 Events/Activities:
Activitiy:
Date/Time= 2012/01/10 08:33:17
Severity= Low
User=
Activities= Admin[ruckus] logs in from [192.168.11.7]
Activitiy:
Date/Time= 2012/01/10 08:32:00
Severity= Low
User=
Activities= WLAN[Ruckus-Guest] with BSSID[04:4f:aa:4c:b1:08 configuration has been updated on radio
[11g/n] of AP[7962 - MAP@04:4f:aa:0c:b1:00]
Activitiy:
Date/Time= 2012/01/10 08:32:00
Severity= Low
User=
...
...
```

# Show Alarm Commands

Use the **show alarm** commands to display alarms that have been generated by the controller. Use the following command:

## show alarm

**show alarm**

### Syntax Description

**show**

Display information

**alarm**

Display a list of alarms that have been generated by the controller

### Defaults

None.

### Example

```
ruckus# show alarm
Last 300 Alarms:
Alarms:
  Date/Time= 2013/03/27 15:36:59
  Name= AP Lost Contact
  Severity= High
  Activities= Lost contact with AP[7372 - MAP@c0:c5:20:3b:91:f0]
Alarms:
  Date/Time= 2013/03/18 14:44:21
  Name= ZD warm restart
  Severity= Medium
  Activities= System warm restarted with [user reboot].
...
...
ruckus#
```

## **Viewing Current Configuration**

Show License Commands

# Show License Commands

Use the **show license** commands to display the controller's license information, including the model number, the maximum number of APs that it can support, and the maximum number of wireless clients that managed APs can support. Use the following command:

## **show license**

**show license**

### **Syntax Description**

**show**

Display information

**license**

Display the controller's license information

### **Defaults**

None.

### **Example**

```
ruckus# show license
License:
  Model= ZD1112
  Max. AP Number= 12
  Max. Client Number= 1250
ruckus#
```

# Show USB Software Commands

Use the **show usb-software** command to display current USB software package information.

## show usb-software

**show**

Display information

**usb-software**

Display USB software package information

## Defaults

None.

## Example

```
ruckus# show usb-software
Sorry, the USB Software hasn't been found.
ruckus#
```

## **Viewing Current Configuration**

Show Application Policy Commands

# Show Application Policy Commands

Use the following commands to display application policies, user-defined applications and application port-mapping settings.

## **show app-denial-policy**

Displays the application denial policy settings.

### *Example*

```
ruckus# show app-denial-policy
Application Denial Policy:
  ID:
    1:
      Name= facebook
      Description= deny facebook
      Default Mode= accept
      Rules:
        1:
          Application= HTTP hostname
          Description= facebook.com

ruckus#
```

## **show user-defined-app**

Displays the user defined application settings.

### *Example*

```
ruckus# show user-defined-app
User Defined Application:
  ID:
    1:
      Application= angry birds
      DST-IP= 216.146.46.10
      Netmask= 255.255.255.0
      DST-Port= 5050
      Protocol= tcp

ruckus#
```

## **show app-port-mapping**

Displays the application category mapping settings.

### *Example*

```
ruckus# show app-port-mapping
Application Port Mapping:
  ID:
    1:
      Name= 2100-tcp
      Port= 2100
      Protocol= tcp
      Description= Facebook

ruckus#
```

# Show Session-Timeout Commands

Use the **show session-timeout** command to display the current session timeout interval.

## show session-timeout

**show session-timeout**

### Syntax Description

**show**

Display information

**session-timeout**

Display the current session timeout interval

### Defaults

None.

### Example

```
ruckus# show session-timeout
Current session timeout interval is 30 minutes
ruckus#
```

## **Viewing Current Configuration**

Show Active Wired Client Commands

# Show Active Wired Client Commands

Use the **show active-wired-client** commands to display information about currently active wired clients.

## **show active-wired-client all**

**show active-wired-client all**

## **show active-wired-client mac**

**show active-wired-client mac MAC**

### **Syntax Description**

**show**

Display information

**active-wired-client**

Display the currently active wired client information

**all**

Show all wired clients

**mac**

Show a specific client information by MAC address

**MAC**

The MAC address of the specific client

### **Defaults**

None.

### **Example**

```
ruckus# show active-wired-client all
Current Active Wired Clients:
ruckus#
```

# Show RADIUS Statistics Commands

Use the following commands to display RADIUS statistics or to reset RADIUS statistics.

## show radius-statistics

To display a list of RADIUS server statistics, use the following command:

```
show radius-statistics [ server-all | server-name WORD ] | [ wlan-all | wlan-name NAME ] [ latest-ten-min | latest-one-hour | latest-one-day ]
```

### Syntax Description

#### show radius-statistics

Display list of RADIUS server statistics.

#### server-all

Display statistics for all servers. (Default: recorded from power on.)

#### server-name WORD

Display statistics for the specified server. (Default: recorded from power on.)

#### wlan-all

Display statistics for all WLANs. (Default: recorded for the last day.)

#### wlan-name NAME

Display statistics for the specified WLAN. (Default: recorded for the last day.)

#### latest-ten-min

Display statistics for the last 10 minutes.

#### latest-one-hour

Display statistics for the last hour.

#### latest-one-day

Display statistics for the last day.

## reset radius-statistics

To reset RADIUS statistics, use the following command:

```
reset radius-statistics [ server-all | server-name WORD ] [ master | standby ] [ latest-ten-min | latest-one-hour | latest-one-day ]
```

### Syntax Description

#### reset radius-statistics

Reset RADIUS server statistics.

#### server-all

Reset statistics for all servers to zero. (Default: recorded from power on.)

#### server-name WORD

Reset statistics for the specified server to zero. (Default: recorded from power on.)

## **Viewing Current Configuration**

Show RADIUS Statistics Commands

### **wlan-all**

Reset statistics for all WLANs. (Default: recorded for the last day.)

### **wlan-name NAME**

Reset statistics for the specified WLAN. (Default: recorded for the last day.)

### **master**

Reset statistics of the master server to zero.

### **standby**

Reset statistics of the standby server to zero.

### **latest-ten-min**

Reset statistics recorded for the last 10 minutes

### **latest-one-hour**

Reset statistics recorded for the last hour

### **latest-one-day**

Reset statistics recorded for the last day

# Show Load Balancing Commands

Use the following commands to display AP load balancing information.

## show load-balance

To display AP load balancing information, use the following command:

**show load-balance**

### Example

```
ruckus# show load-balance
*** Show AP load balance
Radio---Enable---Scan---ActThresh---AdjThresh---WeakBypass---StrongBypass---NewActTrigger---Headroom
 2GHz      0    2000        10       50       33       55       3       3
 5GHz      0    2000        10       43       35       55       3       3
----MAC Address---Cli-New-Lim---Allow----Fallbk---Adjacent 2-GHz Radios [MacAdrs FwdRssi RevRssi
SumRssi]
  c4:10:8a:1f:d1:f0   1   0   0 1000000000 0000000000
  c0:c5:20:3b:91:f0   2   0   0 1000000000 0000000000
----MAC Address---Cli-New-Lim---Allow----Fallbk---Adjacent 5-GHz Radios [MacAdrs FwdRssi RevRssi
SumRssi]
  c4:10:8a:1f:d1:f0   0   0   0 1000000000 0000000000
  c0:c5:20:3b:91:f0   1   0   0 1000000000 0000000000
ruckus#
```

# Monitor AP MAC Commands

Use the **monitor ap mac** command to monitor details on a specific access point.

## monitor ap mac

**monitor ap mac** MAC

### Syntax Description

**monitor**

Begin monitoring mode

**ap mac**

Designate the access point to begin monitoring

**MAC**

The MAC address of the specific access point

### Defaults

None.

### Example

```
ruckus# monitor ap mac 04:4f:aa:0c:b1:00
-----
ID MAC Approved Device-Name Description
104:4f:aa:0c:b1:00 Yes7962 - MAP7962 MAP (Living
-----
IPv4-ADDRMASK GATEWAYPRI-DNS
192.168.11.6 255.255.255.0192.168.11.1
-----
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G) Retries (%)
Radio a/n 36.9/2.028.6/2.00.0
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G) Retries (%)
Radio b/g/n 37.8/2.012.4/2.00.3
-----
Status Mode LocationUplink-Status
EnabledAuto Living Room Smart
-----
ID MAC Approved Device-Name Description
104:4f:aa:0c:b1:00 Yes7962 - MAP7962 MAP (Living
-----
IPv4-ADDRMASK GATEWAYPRI-DNS
192.168.11.6 255.255.255.0192.168.11.1
-----
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G) Retries (%)
Radio a/n 36.9/2.028.6/2.00.0
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G) Retries (%)
Radio b/g/n 37.8/2.012.4/2.00.3
-----
Status Mode LocationUplink-Status
EnabledAuto Living Room Smart
-----
ID MAC Approved Device-Name Description
104:4f:aa:0c:b1:00 Yes7962 - MAP7962 MAP (Living
-----
IPv4-ADDRMASK GATEWAYPRI-DNS
```

```
192.168.11.6 255.255.255.0192.168.11.1
-----
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G) Retries (%)
Radio a/n 36.9/2.028.6/2.00.0
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G) Retries (%)
Radio b/g/n 37.8/2.012.4/2.00.3
-----
Status Mode LocationUplink-Status
EnabledAuto Living Room Smart
-----
```

ruckus#

## **Viewing Current Configuration**

Monitor Currently Active Client Commands

# **Monitor Currently Active Client Commands**

Use the **monitor current-active-clients** command to monitor details on a specific client.

## **monitor current-active-clients**

**monitor current-active-clients mac MAC**

### **Syntax Description**

**monitor**

Begin monitoring mode

**current-active-clients mac**

Designate the currently active client to begin monitoring

**MAC**

The MAC address of the specific client

### **Defaults**

None.

### **Example**

```
ruckus# monitor current-active-clients mac 00:22:fb:ad:1b:2e
```

```
-----  
04:4f:aa:0c:b1:00 192.168.11.7 Ruckus1 None Authorized  
-----
```

```
04:4f:aa:0c:b1:0c153 11an43 OPEN  
-----
```

```
44.3/6.743.2/17.0 36  
-----
```

```
ruckus#
```

## **monitor current-active-clients-mcs-info**

To monitors MCS information for the specified current active clients, use the following command:

**monitor current-active-clients-mcs-info sta-mac MAC ap-mac MAC bssid BSSID**

### **Syntax Description**

**monitor**

Begin monitoring mode

**current-active-clients-mcs-info**

Monitor MCS info of currently active clients

**sta-mac MAC**

The MAC address of the specific client

**ap-mac** *MAC*

MAC address of the AP

**bssid** *BSSID*

Monitor clients connected to the specified BSSID

# Monitor Sysinfo Commands

Use the **monitor sysinfo** command to monitor system information.

## monitor sysinfo

**monitor sysinfo**

### Syntax Description

**monitor**

Begin monitoring mode

**sysinfo**

Display the system information

### Example

```
ruckus# monitor sysinfo
-----
IPv4-ADDR IPv6-ADDR MAC Uptime Model MAX-APs
192.168.11.100NULL 00:13:11:01:01 12d 1h 29mZD111212
-----
Number-of-APs Number-of-ClientsNumber-of-Rogues Name
2 10ruckus
-----
Usage of 1 hr|Usage of 24 hr
Max-Concurrent-Users TX-BytesRogues | Max-Concurrent-Users TX-BytesRogues
12.33M 02297.58M 2
-----
Used-Bytes Used-Percentage Free-BytesFree-Percentage
71675904 55% 57483264 45%
-----
IPv4-ADDR IPv6-ADDR MAC Uptime Model MAX-APs
192.168.11.100NULL 00:13:11:01:01 12d 1h 29mZD111212
-----
Number-of-APs Number-of-ClientsNumber-of-Rogues Name
2 10ruckus
-----
Usage of 1 hr|Usage of 24 hr
Max-Concurrent-Users TX-BytesRogues | Max-Concurrent-Users TX-BytesRogues
12.39M 02297.64M 2
-----
Used-Bytes Used-Percentage Free-BytesFree-Percentage
71675904 55% 57483264 45%
```

# Configuring Controller Settings

---

• Configuration Commands Overview.....	124
• General Config Commands.....	124
• Configure Context Show Commands.....	126
• Configure Location Services Commands.....	134
• Configure AAA Server Commands.....	136
• Configure DHCP Server Commands.....	139
• Configure Admin Commands.....	141
• Configure AD Domain Server Commands.....	145
• Configure Access Points Commands.....	147
• Configure AP Policy Commands.....	181
• Configure AP Group Commands.....	188
• Configure Certificate Commands.....	229
• Configure Hotspot Redirect Settings.....	231
• Configure Layer 2 Access Control Commands.....	232
• Configure Layer 3 Access Control Commands.....	237
• Layer 3 Access Control Rule Commands.....	245
• Layer 3 IPv6 Access Control List Commands.....	249
• Configure L3 IPv6 Rule Commands.....	251
• Configure Precedence Policy Commands.....	253
• Configure Device Policy Commands.....	257
• Configure Application Policy Commands.....	260
• Configuring User-Defined Applications.....	264
• Configuring User-Defined Applications Based on Port Mapping.....	266
• Configure URL Filtering Settings.....	268
• Configure Whitelist Commands.....	274
• Configure Band Balancing Commands.....	276
• Configure Load Balancing Commands.....	279
• Configure STP Commands.....	284
• Configure System Commands.....	285
• Configure UPNP Settings.....	335
• Configure Zero-IT Settings.....	336
• Configure Dynamic PSK Expiration.....	337
• Configure WLAN Settings Commands.....	338
• Configure Dynamic PSK Commands.....	389
• Configure WLAN Group Commands.....	400
• Configure Role Commands.....	407
• Configure VLAN Pool Commands.....	419
• Configure User Commands.....	421
• Configure Guest Access Commands.....	427
• web-portal-force-https-redirection.....	442
• no web-portal-force-https-redirection.....	443
• portal-auth-force-dns-server.....	444
• no portal_auth-force-dns-server.....	445
• guest-access-auth-server.....	446
• Configuring Guest Access Restriction Rules.....	447
• IPv6 Guest Restrict Access Commands.....	453
• Configure Hotspot Commands.....	459
• Configuring Hotspot Restricted Access Rules.....	473

• Hotspot Access Restriction Commands.....	477
• Configure Hotspot 2.0 Commands.....	482
• Configure Mesh Commands.....	499
• Configure Alarm Commands.....	510
• Configure Alarm-Event Settings.....	513
• Configure Services Commands.....	517
• Configure WIPS Commands.....	536
• Configure Email Server Commands.....	538
• Configure SMS Server Commands.....	544
• Configure mDNS (Bonjour) Commands.....	547
• Configure Bonjour Policy.....	548
• Configure Bonjour Fencing Policy.....	551

## Configuration Commands Overview

This section describes the commands that you can use to configure ZoneDirector via the **config** context. From the privileged commands context, type **config** to enter the configuration context. To show a list of commands available from within the **config** context, type **help** or **?**.

## General Config Commands

The following section describes general configuration commands can be executed from within the **config** context. To save your configuration changes and exit the **config** context, use the **end** or **exit** command. To discard your changes and exit the **config** context, use the **abort** or **quit** command.

Some sub-contexts within the **config** context do not allow the use of the **abort** or **quit** commands; you must save your changes and exit the sub-context. Many commands offer a corresponding “no” command to undo your configuration changes (for example, use “no wlan” to delete a WLAN).

### help

Shows available commands.

### history

Shows a list of previously run commands.

### abort

Exits the **config** context without saving changes. Some contexts do not allow **abort**, you must save your changes to exit the context (**end** or **exit**).

### end

Saves changes, and then exits the **config** context.

## exit

Saves changes, and then exits the **config** context.

## quit

Exits the **config** context without saving changes. Some contexts do not allow quit, you must save your changes to exit the context (**end** or **exit**).

# Configure Context Show Commands

Use the following show commands to display configured settings within the **config** context.

## show aaa

Displays a list of available AAA servers.

## show dhcp

Displays a list of available DHCP servers.

## show admin

Displays information about the administrator login settings.

### *Example*

```
ruckus(config)# show admin
Administrator Name/Password:
  Name= admin
  Password= *****
  Authenticate:
    Mode= Authenticate using the admin name and password
ruckus(config) #
```

## show mgmt-acl

Displays a list of all management access controls.

## show mgmt-acl-ipv6

Displays a list of IPv6 management access controls.

## show static-route

Displays a list of all static route entries.

## show static-route-ipv6

Shows the static route for IPv6.

## show ap

Displays a list of all approved devices.

## show l2acl

Displays a list of L2 Access Control Lists.

## show l3acl

Displays a list of L3/L4/IP ACL.

## show whitelist

Displays a list of client isolation white lists.

## show l3acl-ipv6

Displays a list of L3/L4/IPv6 ACL.

## show prece

Displays a list of Precedence Policies.

### Defaults

Name= Default

Description= None

Attribute=vlan

- Order = AAA,Device Policy,WLAN

Attribute = rate-limit

- Order = AAA,Device Policy,WLAN

### Example

```
ruckus(config)# show prece
Precedence Policy:
 ID:
 1:
  Name= Default
  Description=
  Rules:
   1:
    Description=
    Attribute = vlan
    Order = AAA,Device Policy,WLAN
 2:
  Description=
  Attribute = rate-limit
  Order = AAA,Device Policy,WLAN

ruckus(config) #
```

## show dvcpcy

Displays a list of Device Policies.

## show user-app-ip

Displays the IP-based user-defined applications.

### *Example*

```
ruckus(config)# show user-app-ip
User defined application hasn't been found.
ruckus(config)#+
```

## show user-app-port

Displays the user-defined port-based application settings.

### *Example*

```
ruckus(config)# show user-app-port
Application based on port hasn't been found.
ruckus(config)#+
```

## show url-filtering

Displays URL Filtering profiles.

### *Example*

```
ruckus(config)# show url-filtering
Url Filtering Profiles:
 1:
   Url Name: URL Filter 1
   Filter Type: NO_ADULT
   Number of Blocked Categories: 19
   Blocked Categories:
     Abortion
     Adult and Pornography
     Confirmed SPAM Sources
     Cult and Occult
     Dating
     Dead Sites
     Hate and Racism
     Illegal
     Keyloggers and Monitoring
     Malware Sites
     Marijuana
     Nudity
     Pay to Surf
     Phishing and Other Frauds
     SPAM URLs
     Spyware and Adware
     Unconfirmed SPAM Sources
     Violence
     Weapons
   Blacklist-Domains: Not Configured
   Whitelist-Domains: Not Configured
```

```
Google Safe Search: Disabled  
YouTube Safe Search: Disabled  
Bing Safe Search: Disabled  
ruckus(config) #
```

## show load-balancing

Displays information about Load balancing.

### *Example*

```
ruckus(config) # show load-balancing  
Load Balancing:  
  Radio 0:  
    Status= Disabled  
    AdjacentThreshold= 50  
    WeakBypass= 33  
    StrongBypass= 55  
    ActivationThreshold= 10  
    NewTrigger= 3  
    Headroom= 3  
  
  Radio 1:  
    Status= Disabled  
    AdjacentThreshold= 43  
    WeakBypass= 35  
    StrongBypass= 55  
    ActivationThreshold= 10  
    NewTrigger= 3  
    Headroom= 3  
  
ruckus(config) #
```

## show wlan

Displays a list of all WLAN services (Names).

## show wlan-group

Displays a list of existing WLAN groups.

### *Example*

```
ruckus(config) # show wlan-group  
WLAN Group:  
  ID:  
    1:  
      Name= Default  
      Description= Default WLANs for Access Points  
      WLAN Service:  
        WLAN1:  
          NAME= Ruckus1  
          VLAN=  
  
ruckus(config) #
```

## **show role**

Displays a list of roles.

## **show vlan-pool**

Displays a list of VLAN pools.

## **show user**

Displays a list of users.

## **show hotspot**

Displays a list of hotspot entries.

## **show guest-access-service**

To display a list of guest access services, use the following command:

**show guest-access-service**

## **show guest-access-generation**

To display generation information for guest access, use the following command:

**show guest-access-generation**

### ***Example***

```
ruckus(config)# show guest-access-generation
  Authentication Server: Local Database
  Force HTTPS Redirection: Disabled
ruckus(config)#End
```

## **show portal-auth-generation**

To display generation information for portal authentication, use the following command:

**show portal-auth-generation**

### ***Example***

```
ruckus(config)# show portal-auth-generation
  Force DNS server: Disabled
  Force Web Portal HTTPS Redirection: Enabled
ruckus(config)#End
```

## **show ap-group**

To display all or specified AP groups, use the following command:

**show ap-group [ all | name WORD ]**

## show ap-policy

Displays the ap policy settings.

### *Example*

```
ruckus(config)# show ap-policy
    Automatically approve all join requests from APs= Enabled
    Limited ZD Discovery:
        Status= Disabled
    Management VLAN:
        Status= Keep AP's setting
        Auto Recovery= 30 minutes
ruckus(config)#+
```

## show usb-software

Displays USB Software Package information.

## show location-services

Displays a list of configured location services.

## **Configuring Controller Settings**

Configure Context Show Commands

### **show hs20op**

Displays a list of hotspot 2.0 operators.

## show hs20sp

Displays a list of hotspot 2.0 service providers.

## show mdnsproxyrule

To display Mdnsproxy rules, use the following command:

**show mdnsproxyrule *ID-From ID-to***

## show mdnsproxy

To display Mdnsproxy status, use the following command:

**show mdnsproxy *ID-From ID-to***

## show bonjour-policy

To display Bonjour policy rules, use the following command:

**show bonjour-policy *name***

## Configuring Controller Settings

Configure Location Services Commands

# Configure Location Services Commands

This section describes the commands that you can use to configure Location Service entries on the controller. The following commands can be executed from within the **config-location-services** context. To show a list of commands available from within the **aaa** context, type **help** or **?**.

## location-services

To create or modify a location server, use the following command:

**location-services WORD**

### Syntax Description

**location-services WORD**

Creates a new location server or modifies an existing location server.

**abort**

Exits the config-location-services context without saving changes.

**end**

Saves changes, and then exits the config-location-services context.

**exit**

Saves changes, and then exits the config-location-services context.

**quit**

Exits the config-location-services context without saving changes.

**fqdn WORD**

Sets the location server FQDN.

**port PORT-NUM**

Sets the location server port.

**password WORD**

Sets the location server preshared key.

**show**

Displays configured location services for all venues.

### Example

```
ruckus(config)# location-services locationserver1
The location venue 'locationserver1' has been created. To save it, type 'end' or 'exit'.
ruckus(config-location-services)# fqdn ruckuslbs.ruckuswireless.com
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-location-services)# password secret1234
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-location-services)# show
Venue:
ID:
:
Status          = Disabled
Venue Name      = locationserver1
Location Server FQDN = ruckuslbs.ruckuswireless.com
Location Server Port = 8883
Location Server PSK  = secret1234

ruckus(config-location-services)# end
```

```
The location venue 'locationserver1' has been updated and saved.  
Your changes have been saved.  
ruckus(config)#
```

## no location-services

To delete a location server from the list of location servers, use the following command:

**no location-services WORD**

# Configure AAA Server Commands

This section describes the commands that you can use to configure AAA server entries on the controller. The following commands can be executed from within the **config-aaa** context. To show a list of commands available from within the context, type **help** or **?**.

## aaa

Use the following command to configure an AAA server entry and enter the config-aaa context:

**aaa WORD**

### Syntax Description

#### abort

Exits the config-aaa context without saving changes.

#### end

Saves changes, and then exits the config-aaa context.

#### exit

Saves changes, and then exits the config-aaa context.

#### quit

Exits the config-aaa context without saving changes.

#### name WORD

Sets the AAA server name.

#### show

Displays a list of available AAA servers.

#### CaseSensitive

Sets the 'CaseSensitive' value of AD/LDAP server to 'enabled'.

#### type

Sets the type of AAA server.

#### type ad

Sets the AAA server type to 'Active Directory'.

#### type ldap

Sets the AAA server type to 'LDAP'.

#### type ad-802.1x

Sets the AAA server type to 'Active Directory For 802.1x'.

#### type radius-auth

Sets the AAA server type to 'RADIUS'.

#### type tacplus-auth

Sets the AAA server type to 'TACPLUS'.

#### type radius-acct

Sets the AAA server type to 'RADIUS Accounting'.

#### radius-encryption

Sets the AAA server encryption type.

**radius-encryption tls**

Sets the AAA server encryption type to 'TLS'.

**auth-method pap**

Sets the authentication method to PAP.

**auth-method chap**

Sets the authentication method to CHAP.

**ip-addr IP-ADDR**

Sets the AAA server's IP/IPv6 address.

**port PORT-NUM**

Sets the AAA server's port.

**tacplus-service WORD**

Sets TACPLUS service name with length (1-64 bytes).

**domain-name WORD**

Sets the windows/base domain name.

**domainServer-deviceNameWORD**

Sets the domain server device name.

**no radius-encryption**

Disables the AAA server encryption.

**no ad-global-catalog**

Disables global catalog support.

**no grp-search**

Disables group attribute lookup support.

**no encryption-TLS**

Disable the TLS Encryption

**no backup**

Disables the backup function.

**ad-global-catalog**

Enables global catalog support.

**grp-search**

Enables group attribute lookup support.

**admin-dn WORD**

Sets the admin domain name.

**admin-password WORD**

Sets the admin password.

**key-attribute WORD**

Sets the LDAP key attribute.

**search-filter WORD**

Sets the LDAP search filter.

**radius-secret WORD**

Sets the AAA server's shared secret.

## Configuring Controller Settings

### Configure AAA Server Commands

#### **tacplus-secret WORD**

Sets the TACPLUS server's shared secret.

#### **encryption-TLS**

Enables the TLS Encryption

#### **backup**

Enables the backup function.

#### **backup-ip-addr IP-ADDR**

Sets the backup AAA server's IP/IPv6 address.

#### **backup-port PORT-NUM**

Sets the backup AAA server's port.

#### **backup-radius-secret WORD**

Sets the backup AAA server's shared secret.

#### **request-timeout NUMBER**

Sets the failover request timeout (2~20 seconds).

#### **retry-count NUMBER**

Sets the failover retry count (2~10 times).

#### **consecutive-drop-packet NUMBER**

Sets the number of consecutive dropped packet (range:1~10 , default is 1).

#### **reconnect-primary-interval NUMBER**

Sets the failover re-connect to primary interval (1~86400 minutes).

## Example

```
ruckus(config)# aaa activedir
The AAA server 'activedir' has been created. To save the AAA server, type 'end' or 'exit'.
ruckus(config-aaa)# type ad
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-aaa)# ip-addr 192.168.10.40
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-aaa)# show
AAA:
ID:
:
Name= activedir
Type= Active Directory
IP Address= 192.168.10.40
Port= 389
Windows Domain Name=
Global Catalog= Disabled
Admin DN=
Admin Password=
Group Search= Enabled
encryption-TLS = Disabled

ruckus(config-aaa)# end
The AAA server 'activedir' has been updated and saved.
Your changes have been saved.
ruckus(config)#

```

# Configure DHCP Server Commands

This section describes the commands that you can use to configure DHCP server entries on the controller. These DHCP server entries are used by the DHCP Relay feature, if enabled for a tunneled WLAN. The following commands can be executed from within the **config-dhcp** context.

## dhcp

Use the **dhcp** command from within the **config** context to create or edit a DHCP server entry.

**dhcp WORD**

### Syntax Description

**dhcp**

Configure the DHCP server settings

**WORD**

Name of the DHCP server entry

### Defaults

none

### Example

```
ruckus(config)# dhcp dhcp_server_2
The DHCP server 'dhcp_server_2' has been created. To save the DHCP server, type 'end' or 'exit'.
ruckus(config-dhcp)# first 192.168.11.99
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dhcp)# show
DHCP servers for DHCP relay agent:
ID:
:
Name= dhcp_server_2
Description=
IP Address= 192.168.11.99
ruckus(config-dhcp)# end
The DHCP server 'dhcp_server_2' has been updated and saved.
Your changes have been saved.
ruckus(config)# show dhcp
DHCP servers for DHCP relay agent:
ID:
1:
Name= DHCP Server 1
Description=
IP Address= 192.168.11.1
IP Address=
2:
Name= dhcp_server_2
Description=
IP Address= 192.168.11.99
IP Address=
ruckus(config)#

```

## no dhcp

Use the no **dhcp** command to delete a DHCP server entry.

## Configuring Controller Settings

### Configure DHCP Server Commands

**no dhcp WORD**

#### Example

```
ruckus(config)# no dhcp dhcp_server_2  
The DHCP server 'dhcp_server_2' has been deleted.  
ruckus(config)#+
```

## show

Displays a list of available DHCP servers.

**show**

## name

Sets the DHCP server name.

**name WORD**

## description

Sets the DHCP server description.

**description WORD**

## first

Sets the DHCP server's first IP address.

**first IP-ADDR**

## second

Sets the DHCP server's second IP address.

**second IP-ADDR**

## no second

Deletes the DHCP server's second IP address.

**no second IP-ADDR**

# Configure Admin Commands

Use the admin commands to enter the **config-admin** context to set the admin user name, password and admin authentication server settings.

## admin

To enter the config-admin context and configure administrator preference, use the following command:

**admin**

### *Example*

```
ruckus(config)# admin  
ruckus(config-admin)
```

## name

To set the administrator user name, use the following command:

**name WORD**

### *Syntax Description*

**name**

Configure the admin name setting

**WORD**

Set the admin name to this name

### *Defaults*

**admin**

### *Example*

```
ruckus(config)# admin  
ruckus(config-admin)# name admin  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-admin)# end  
The administrator preferences have been updated.  
Your changes have been saved.  
ruckus(config)#[/pre]
```

## name password

To set the admin name and password at the same time, use the following command:

**name WORD password WORD**

## Configuring Controller Settings

### Configure Admin Commands

#### Syntax Description

##### **name**

Configure the admin name setting

##### **WORD**

Set the admin name to this name

##### **password**

Configure the admin password

##### **WORD**

Set the admin password to this password

#### Defaults

admin

#### Example

```
ruckus(config)# admin
ruckus(config-admin)# name admin password admin
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-admin)# end
The administrator preferences have been updated.
Your changes have been saved.
ruckus(config)#
```

## show

To view the current admin login and authentication settings, use the following command:

**show**

### **Example**

```
ruckus(config-admin) # show
Administrator Name/Password:
  Name= admin
  Password= *****
  Authenticate:
    Mode= Authenticate using the admin name and password
ruckus(config-admin) #
```

## Admin Authentication Commands

Use the **auth-server** commands to set the administrator authentication options with an external authentication server.

### **auth-server**

To enable administrator authentication with a remote server and set the authentication server, use the following command:

**auth-server WORD**

#### Syntax Description

##### **auth-server**

Admin authentication with an external server

##### **WORD**

Set the authentication server to this server

#### Defaults

None.

#### Example

```
ruckus(config-admin)# auth-server radius  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-admin)#[/pre]
```

### **no auth-server**

To disable administrator authentication with a remote server, use the following command:

**no auth-server**

#### Syntax Description

##### **no auth-server**

Disable admin authentication with an external server

#### Defaults

None.

#### Example

```
ruckus(config-admin)# no auth-server  
The command was executed successfully.[/pre]
```

## **auth-server with-fallback**

To enable fallback authentication (for use when the remote server is unavailable), use the following command:

**auth-server WORD with-fallback**

### **Syntax Description**

**auth-server**

Admin authentication with an external server

**WORD**

Set the auth-server to this server

**with-fallback**

Enable fallback authentication if the remote authentication server is unavailable

### **Defaults**

None.

### **Example**

```
ruckus(config-admin)# auth-server radius with-fallback
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-admin)# show
Administrator Name/Password:
Name= admin
Password= admin
Authenticate:
Mode= Authenticate with authentication server 'radius'
Fallback= Enabled
ruckus(config-admin)#

```

# **Configure AD Domain Server Commands**

Use the following commands to configure Active Directory Domain server.

## **ad-domainsvr**

To set the AD domain server, use the following command:

**ad-domainsvr<DOMAIN> <IP-ADDR> <Service-Device-Name> <Password> <PORT> <Admin DN>**

### **Syntax Description**

**ad-domainsvr**

Active Directory domain server.

<DOMAIN> <IP-ADDR> <Service-Device-Name> <Password> <PORT> <Admin DN>

Configure domain server address details.

## **Configuring Controller Settings**

Configure AD Domain Server Commands

### **Defaults**

None.

### **Example**

```
ruckus(config)# ad-domainsvr ruckus.com 10.10.10.1 host1 pass1234 14 admin-dn  
The saving conf [adauthsvr] does not exist in current or default database  
ruckus(config)#[/pre]
```

## **no ad-domainsvr**

To delete the AD domain server, use the following command:

```
no ad-domainsvr
```

### **Example**

```
ruckus(config)# no ad-domainsvr  
ruckus(config)#[/pre]
```

# Configure Access Points Commands

The following commands can be used from within the config-ap context to configure a specific Access Point.

## ap

To enter the config-ap context, enter the following command:

**ap MAC**

### Syntax Description

**ap**

Access Point

**MAC**

MAC address of the access point for configuration

### Defaults

None.

### Example

```
ruckus(config)# ap 04:4f:aa:0c:b1:00
The AP '04:4f:aa:0c:b1:00' has been loaded. To save the AP, type 'end' or 'exit' .
ruckus(config-ap) #
```

## no ap

To delete an AP from the list of approved devices, use the following command:

**no ap MAC**

### Syntax Description

**no ap**

Delete Access Point

**MAC**

MAC address of the access point

### Defaults

None.

### Example

```
ruckus(config)# no ap 04:4f:aa:0c:b1:00
The AP '04:4f:aa:0c:b1:00' has been deleted.
ruckus(config) #
```

## devname

To set the device name, use the following command:

**devname WORD**

### Syntax Description

**devname**

Device name

**WORD**

Set the device name to this name

### Defaults

None.

### Example

```
ruckus(config)# ap 04:4f:aa:0c:b1:00
The AP '04:4f:aa:0c:b1:00' has been loaded. To save the AP, type 'end' or 'exit'.
ruckus(config-ap)# devname 7962
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)# end
The device information has been updated.
Your changes have been saved.
ruckus(config)#[/pre]
```

## no devname

To delete the device's name, use the following command:

**no devname**

## bonjour-gateway

To bind a bonjour gateway policy to this AP, use the following command:

**bonjour-gateway WORD**

### Example

```
ruckus(config-ap)# bonjour-gateway bonjour1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)#[/pre]
```

## no bonjour-gateway

To unbind a bonjour gateway policy, use the following command:

**no bonjour-gateway**

## Example

```
ruckus(config-ap)# no bonjour-gateway  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#[/pre]
```

## description

To set the device description, use the following command:

**description WORD**

### Syntax Description

**description**

Device description

**WORD**

Set the device description to this text

### Defaults

None.

## Example

```
ruckus(config-ap-00:13:92:00:33:1C)# description this-is-the-device-description  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#[/pre]
```

## no description

To delete the device's description, use the following command:

**no description**

## gps

To set the device GPS coordinates, use the following command:

**gps GPS-COORDINATE**

### Syntax Description

**gps**

Set the device GPS coordinates

**GPS-COORDINATE**

Enter the device's GPS coordinates for the latitude and longitude. Use a comma (,) to separate the latitude and longitude. The first coordinate is for the latitude. The second coordinate is for the longitude. Ex. A,B or -37,38.

## Defaults

None.

## Example

```
ruckus(config-ap)# gps 37.3,-122  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#[/pre>
```

## no gps

To delete the device's GPS coordinates, use the following command:

```
no gps
```

## location

To set the device location, use the following command:

```
location WORD
```

## Syntax Description

**location**

Device location

**WORD**

Set the device location to this address

## Defaults

None.

## Example

```
ruckus(config-ap)# location sunnyvale-office  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#[/pre>
```

## no location

To delete the device's location, use the following command:

```
no location
```

## group

To set the AP group for this AP, use the following command:

```
group [name WORD] | system-default
```

## Syntax Description

### group

Set the AP group that this AP is a member of

### name

Set the AP to be a member of the named AP group

### WORD

The name of the AP group

### system-default

Set the AP as a member of the system default AP group

## Defaults

system-default

## Example

```
ruckus(config-ap)# group system-default  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap) #
```

## ip

To set the AP's IPv4 address, use the following command from within the config-ap context:

```
ip [enable|disable] addr IP-ADDR NET-MASK name-server DNS-ADDR mode [dhcp|static|keep]
```

## Syntax Description

### ip

Set the AP's IPv4 addressing

### enable

Enable IPv4 addressing

### disable

Disable IPv4 addressing

### addr

Set the AP's IPv4 address

### IP-ADDR

The IPv4 address

### NET-MASK

The IPv4 netmask

### name-server

Set the device's DNS servers. Use a space ( ) to separate primary and secondary DNS servers

### DNS-ADDR

The IP address of the DNS server

**mode**

Set the device's IP addressing mode (DHCP, static or "keep AP's setting")

**dhcp**

Set the device's IP address mode to DHCP

**static**

Set the device's IP address mode to static

**keep**

Set the device to use its current network settings

## Defaults

none

## Example

```
ruckus(config-ap)# ip enable mode dhcp  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#[/pre]
```

## ipv6

To set the AP's IPv6 address, use the following command from within the config-ap context:

```
ipv6 [ enable ] addr IPv6-ADDR IPv6-PREFIX-LENGTH name-server DNS-ADDR mode [ auto | manual | keep ]
```

## Syntax Description

**ipv6**

Set the AP's IPv6 addressing

**enable**

Enable IPv6 addressing

**addr**

Set the AP's IPv6 address

*IPv6-ADDR*

The IPv6 address

*IPv6-PREFIX-LENGTH*

The IPv6 prefix length. Use a space ( ) to separate the IPv6 address and prefix length

**name-server**

Set the device's DNS servers. Use a space ( ) to separate primary and secondary DNS servers

*DNS-ADDR* [*DNS-ADDR*]

The IP address of the DNS server

**mode**

Set the device's IP addressing mode (auto, manual or "keep AP's setting")

**auto**

Set the device's IPv6 address mode to auto

**manual**

Set the device's IPv6 address mode to manual

**keep**

Set the device to use its current network settings

**Defaults**

none

**Example**

```
ruckus(config-ap)# ipv6 enable mode auto  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#[/pre]
```

**no ipv6**

To disable the AP's IPv6 mode, use the following command:

**no ipv6**

**usb-software**

To set the AP USB software package vendor ID (VID) and product ID (PID), and version, use the following command:

**usb-software VID-PID-VERSION**

**no usb-software**

To delete a USB software package from the list of USB software packages, use the following command:

**no usb-software**

**no usb-software-override**

To disable the override of the AP USB software package, use the following command:

**no usb-software-override**

**status-leds**

To enable or disable the AP's status LEDs, use the following command:

**status-leds [enable | disable ]**

**Defaults**

Enabled.

## Syntax Description

**status-leds**  
Configure status LEDs

**enable**  
Override group config, enable status LEDs

**disable**  
Override group config, disable status LEDs

## Example

```
ruckus(config-ap)# status-leds disable  
ruckus(config-ap)#[/pre]
```

## no status-leds-override

To disable override of status LEDs for this AP, use the following command:

**no status-leds-override**

## status-lacp

To enable or disable LACP, use the following command:

**status-lacp [enable | disable ]**

## Defaults

Disabled.

## Example

```
ruckus(config-ap)# status-lacp enable  
ruckus(config-ap)#[/pre]
```

## no status-lacp-override

To disable override of AP group LACP settings, use the following command:

**no status-lacp-override**

## Example

```
ruckus(config-ap)# no status-lacp-override  
ruckus(config-ap)#[/pre]
```

## usb-port

To disable the override the group configuration and enable/disable the USB port for this AP, use the following command:

**usb-port [ enable | disable ]**

## no usb-port-override

To disable the override of the USB port for the specified AP model, use the following command:

**no usb-port-override**

## poe-out

To enable or disable the AP's PoE Out port, use the following command:

**poe-out [ enable | disable]**

### Defaults

Disabled.

### Syntax Description

**poe-out**

Configure PoE Out port

**enable**

Override group config, enable PoE Out port

**disable**

Override group config, disable PoE Out port

### Example

```
ruckus(config-ap)# poe-out enable  
ruckus(config-ap)#[/pre]
```

## no poe-out-override

To disable override of the PoE out port settings, use the following command:

**no poe-out-override**

## external-antenna

To configure the AP's external antenna settings, use the following command:

**external-antenna [ 2.4G | 5G ] [ enable | disable ] [ gain NUMBER ] cable-loss NUMBER [ 2-antennas | 3-antennas ]**

### Syntax Description

**2.4G**

Configure external 2.4GHz antenna

**5G**

Configure external 5GHz antenna

**enable|disable**  
Enable/disable external antenna

**gain**  
Set external antenna gain for 2.4/5GHz radio

**cable-loss NUMBER**  
Enter the external antenna loss (0-90 dB)

**2-antennas**  
Select two external antennas for the specified radio

**3-antennas**  
Select three external antennas for the specified radio

### **Defaults**

Varies by AP model.

## **no external-antenna-override**

To disable the external antenna override settings, use the following command:

**no external-antenna-override**

## **spectra-analysis 2.4GHz**

To enable or disable the spectrum analysis feature for this radio, use the following command:

**spectra-analysis 2.4GHz [ enable | disable ]**

## **spectra-analysis 5GHz**

To enable or disable the spectrum analysis feature for this radio, use the following command:

**spectra-analysis 5GHz [ enable | disable ]**

## **internal-heater**

To enable or disable the AP's internal heater, use the following command:

**internal-heater [ enable | disable ]**

### **Defaults**

Disabled.

### **Syntax Description**

**internal-heater**  
Configure internal heater

**enable**  
Override group config, enable internal heater  
**disable**  
Override group config, disable internal heater

### **Example**

```
ruckus(config-ap)# internal-heater enable  
ruckus(config-ap)#{}
```

## **no internal-heater-override**

To disable override of the internal heater for this AP, use the following command:

**no internal-heater-override**

## **cband-channels**

To enable or disable the 5.8 GHz C-band channels, use the following command:

**cband-channels [ enable | disable ]**

### **Defaults**

Disabled.

### **Syntax Description**

**cband-channels**  
Configure C-band channels  
**enable**  
Override group config, enable C-band channels  
**disable**  
Override group config, disable C-band channels

### **Example**

```
ruckus(config-ap)# cband-channels enable  
ruckus(config-ap)#{}
```

## **no cband-channels-override**

To disable override of the 5.8 GHz channels, use the following command:

**no cband-channels-override**

## **cband-license**

To override the group configuration and enable or disable 5.8 GHz radio full power for this device, use the following command:

## Configuring Controller Settings

### Configure Access Points Commands

**cband-license [ enable | disable ]**

#### Defaults

Disabled.

#### Example

```
ruckus(config-ap)# cband-license enable  
Model r610 doesn't support to configure cband-license.  
ruckus(config-ap)#[/pre]
```

## no cband-license-override

To disable the override of the 5.8 GHz Channels License for this AP, use the following command:

**no cband-license-override**

#### Defaults

Disabled.

#### Example

```
ruckus(config-ap)# no cband-license override  
Model r610 doesn't support to configure cband-license.  
ruckus(config-ap)#[/pre]
```

## ipmode

To set the AP's IP mode, use the following command:

**ipmode WORD**

#### Defaults

Dual-stack IPv4/IPv6 mode

## Syntax Description

**ipmode**

Configure IP addressing mode

**ipv4**

Set to IPv4 only mode

**ipv6**

Set to IPv6 only mode

**dual**

Set to dual-stack IPv4/IPv6 mode

## Example

```
ruckus(config-ap)# ipmode dual  
ruckus(config-ap)#+
```

## no ipmode-override

To disable override of the IP mode, use the following command:

```
no ipmode-override
```

## venue-name

To set the venue name of the AP, use the following command:

```
venue-name [ language ] WORD
```

## Syntax Description

**venue-name**

Set the venue name for the AP

**[ language ]**

Set the language of the venue name. Valid languages are: English, Chinese, Czech, Danish, Dutch, French, German, Japanese, Spanish, Swedish, Turkish)

**WORD**

Set the venue name to the name specified

## Example

```
ruckus(config-ap)# venue-name english venue1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#+
```

## no venue-name

To remove a venue name entry, use the following command:

```
no venue-name [ language ]
```

## Example

```
ruckus(config-ap)# no venue-name english  
The entry 'English' has been removed. To save the changes, type 'end' or 'exit'.  
ruckus(config-ap)#+
```

## lldp

To enable, disable or configure the AP's Link Layer Discover Protocol settings, use the following lldp commands from within the config-ap context.

## Syntax Description

### **lldp**

Configure LLDP settings.

#### **enable**

Enable LLDP with current settings.

#### **disable**

Disable LLDP with current settings.

#### **interval NUMBER**

Set packet transmit interval in second(s).

#### **holdtime NUMBER**

Set amount of time receiving device should retain the information.

#### **ifname eth NUMBER**

Enter the AP port number.

#### **mgmt enable**

Enable LLDP management IP address of the AP.

#### **mgmt disable**

Disable LLDP management IP address of the AP.

## Example

```
ruckus(config-ap)# lldp enable  
ruckus(config-ap)#[/pre]
```

## no lldp-override

To disable the AP's LLDP override settings (use parent settings), use the following command:

### **no lldp-override**

## Example

```
ruckus(config-ap)# no lldp-override  
ruckus(config-ap)#[/pre]
```

## power-mode

To set the PoE mode of the AP, use the following command:

### **power-mode <WORD>**

## Syntax Description

### **power-mode**

Set the PoE power mode.

#### **auto**

Set the PoE power mode to auto.

### **802.3af**

Set the PoE power mode to 802.3af.

### **802.3at**

Set the PoE power mode to 802.3at.

### **802.3bt5**

Set the PoE power mode to 802.3bt5.

### **802.3bt6**

Set the PoE power mode to 802.3bt6.

### **802.3bt7**

Set the PoE power mode to 802.3bt7.

## **Example**

```
ruckus(config-ap)# power-mode 802.3af  
ruckus(config-ap)#+
```

## **no power-mode-override**

To disable the override of the PoE mode, use the following command:

**no power-mode-override**

## **802.3af-txchain**

To set the number of 2.4 GHz radio transmit chains in 802.3af PoE power mode, use the following command:

**802.3af-txchain WORD**

## **Syntax Description**

### **802.3af-txchain**

Set the number of 2.4 GHz radio transmit chains in 802.3af power mode.

**1**

Set the number of tx chains to 1.

**2**

Set the number of tx chains to 2.

**4**

Set the number of tx chains to 4.

## **Example**

```
ruckus(config-ap)# 802.3af-txchain 2  
ruckus(config-ap)#+
```

## **no 802.3af-txchain-override**

To disable the override of the 2.4GHz radio transmit chains in 802.3af PoE mode, use the following command:

## Configuring Controller Settings

### Configure Access Points Commands

**no 802.3af-txchain-override**

#### *Example*

```
ruckus(config-ap)# no 802.3af-txchain-override  
ruckus(config-ap)#+
```

## Radio 2.4/5 GHz Commands

Use the radio 2.4 or radio 5 commands to configure the 2.4/5 GHz radio settings independently.

### **radio**

Use the radio command from within the config-ap context to configure the 2.4GHz or 5GHz radios independently.

**radio [ 2.4 | 5 ] arguments**

### Syntax Description

#### **2.4**

Configure the 2.4 GHz radio

#### **5**

Configure the 5 GHz radio

#### **channelization [ auto | NUMBER ]**

Set channel width to 20 MHz, 40 MHz or Auto

#### **channel [ auto | NUMBER ]**

Set channel to Auto or manually set channel

#### **tx-power [ auto | full | min | num 1-10 ]**

Set transmit power to auto, full, min, or a number (-1dB~10dB)

#### **admission-control VALUE**

Set the radio to use the specified call admission control airtime usage limit (%)

#### **channel-range NUMBER-LIST**

Set the allowed list of channels for the specified radio

#### **wlan-group WORD**

Set the AP radio as a member of a WLAN group

#### **wlan-service [ enable | disable ]**

Enable WLAN service on this radio

#### **wlan-service-override**

Enable the override of the WLAN service settings for this radio

#### **extant-gain NUMBER**

Set external antenna gain (on APs that support external antennas) (dBi)

### Defaults

channelization: Auto

channel: Auto

wlan-group: Default

wlan-service: Enabled

wlan-service-override: Disabled

tx-power: Auto

## Configuring Controller Settings

### Configure Access Points Commands

admission-control: Disabled

spectralink-compatibility: Disabled

### Example

```
ruckus(config-ap)# radio 2.4 channelization auto
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)# radio 2.4 channel auto
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)# radio 2.4 wlan-group Default
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)# radio 2.4 wlan-service
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)# radio 2.4 tx-power auto
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)# end
The device information has been updated.
Your changes have been saved.
ruckus(config)#

```

### no radio

Use the no radio 2.4 or no radio 5 commands from within the config-ap context to disable AP group overrides for the 2.4GHz or 5GHz radio settings.

**no radio [ 2.4 | 5 ] arguments**

### Syntax Description

#### **no radio**

Disable override of 2.4/5GHz radio settings

#### **2.4**

Disable 2.4GHz radio override settings

#### **5**

Disable 5GHz radio override settings

#### **wlan-service**

Disable override of WLAN service settings

#### **channel-range-override**

Disables override of channel range settings

#### **channel-override**

Disables override of channel settings

#### **channelization-override**

Disables override of 5GHz channelization settings

#### **tx-power-override**

Disables override of Tx power

#### **wlan-group-override**

Disables override of WLAN group settings

#### **admission-control**

Disables call admission control on the radio

**admission-control-override**

Disables override of call admission control settings

**wlan-service**

Disables WLAN service for the radio

**wlan-service-override**

Disables the override of the WLAN service settings for this radio.

**channel-range-override**

Disables override of channel range settings

**Example**

```
ruckus(config-ap)# no radio 2.4 tx-power-override
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)#End
```

**show**

To display the AP's current configuration settings, use the following command:

**show**

**Example**

```
ruckus(config)# ap c0:8a:de:21:a8:10
The AP 'c0:8a:de:21:a8:10' has been loaded. To save the AP, type 'end' or 'exit'.
ruckus(config-ap)# show
AP:
ID:
1:
MAC Address= c0:8a:de:21:a8:10
Model= zf7982
Approved= Yes
Device Name= RuckusAP
Description=
Location=
GPS=
CERT = Complex
Bonjour-policy=
Bonjour-fencing= Disabled
Group Name= System Default
Channel Range:
A/N= 36,40,44,48,149,153,157,161 (Disallowed= )
B/G/N= 1,2,3,4,5,6,7,8,9,10,11 (Disallowed= )
Radio a/n:
    Channelization= Auto
    Channel= Auto
    WLAN Services enabled= Yes
    Tx. Power= Auto
    WLAN Group Name= Default
    Call Admission Control= OFF
    Protection Mode= Auto
Radio b/g/n:
    Channelization= Auto
    Channel= Auto
    WLAN Services enabled= Yes
    Tx. Power= Auto
    WLAN Group Name= Default
    Call Admission Control= OFF
    Protection Mode= 2
Override global ap-model port configuration= No
Network Setting:
```

## Configuring Controller Settings

### Configure Access Points Commands

```
Protocol mode= Use Parent Setting
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 10.10.3.51
Netmask= 255.255.0.0
Gateway= 10.10.0.1
Primary DNS Server= 10.10.0.1
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Disabled
LLDP:
Status = Use Parent Setting
Venue Name List:
LAN Port:
0:
Interface= eth0
Dot1x= None
LogicalLink= Up
PhysicalLink= Up 100Mbps full
Label= 10/100/1000 PoE LAN1
1:
Interface= eth1
Dot1x= None
LogicalLink= Down
PhysicalLink= Down
Label= 10/100/1000 LAN2

ruckus(config-ap) #
```

## Mesh Commands

Use the following commands to configure the AP's mesh-related settings.

### ***mesh mode***

Use the mesh mode command from within the config-ap context to configure the AP's mesh mode settings.

**mesh mode [ auto | root-ap | mesh-ap | disable ]**

### **Syntax Description**

#### **mesh mode**

Configure the AP's mesh mode

#### **auto**

Set mesh mode to Auto

#### **root-ap**

Configure AP as a Root AP

#### **mesh-ap**

Configure AP as a Mesh AP

#### **disable**

Disable mesh

### **Defaults**

Auto.

### **Example**

```
ruckus(config-ap)# mesh mode auto
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)#End
```

## Configuring Controller Settings

### Configure Access Points Commands

#### **mesh uplink-selection**

Use the mesh uplink-selection command from within the config-ap context to configure the AP's mesh uplink selection settings.

```
mesh uplink-selection [auto | manual] add-mac | del-mac MAC
```

#### Syntax Description

##### **mesh uplink-selection**

Configure the AP's mesh uplink selection mode

##### **auto**

Set mesh uplink selection to Auto

##### **manual**

Set mesh uplink selection to manual

##### **add-mac**

Add a manual uplink selection AP

##### **del-mac**

Delete a manual uplink selection AP

##### **MAC**

The MAC address of the uplink AP

#### Defaults

Auto.

#### Examples

```
ruckus(config-ap)# mesh uplink-selection manual add-mac 00:24:82:3f:14:60
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)#
ruckus(config-ap)# mesh uplink-selection auto
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)#

```

#### **maxhops**

To set the maximum mesh hops for the AP (0-3), use the following command:

```
maxhops <NUMBER>
```

#### Example

```
ruckus(config-ap)# maxhops 3
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap)#

```

## AP Port Setting Commands

To override AP group configuration settings and configure the AP's Ethernet ports individually, you must first enter the **config-ap-model** context from within the **config-ap** context.

### **port-setting**

Use the following command to enter the config-ap-model context and override AP group settings to configure AP ports individually:

**port-setting**

#### Syntax Description

**port-setting**

Configure AP port settings

**lan NUMBER {Arguments}**

Configure the AP LAN port

**no lan NUMBER**

Disable the AP LAN port

**uplink WORD**

Set the AP port to use the specified type (trunk, access or general)

**untag NUMBER**

Set the AP port to use the specified VLAN ID(1-4094)

**member NUMBER**

Set the AP port to use the specified members(1-4094)

**opt82 [ enabled | disabled ]**

Enable the AP port DHCP Option 82 settings

**tunnel [ enabled | disabled ]**

Enable the AP port tunnel settings

**guest-vlan NUMBER**

Set the AP port to use the specified guest VLAN ID(1-4094)

**dylan [ enabled | disabled ]**

Enable the AP port dynamic VLAN settings

**no dot1x authsvr acctsrv mac-auth-bypass**

Disable authentication server, accounting server, or MAC auth bypass for the AP's 802.1X settings

**dot1x authsvr acctsrv mac-auth-bypass**

Enable authentication server, accounting server, or MAC auth bypass for the AP's 802.1X settings

**authsvr WORD**

Enter the RADIUS server name

**acctsrv WORD**

Enter the RADIUS accounting server name

**mac-auth-bypass**

Enable MAC authentication bypass for the 802.1X-enabled port

## Configuring Controller Settings

### Configure Access Points Commands

**dot1x supplicant [ username | password ] WORD**

Set the username/password for AP 802.1X supplicant

**dot1x supplicant mac**

Set the username and password to use AP MAC address for AP 802.1X supplicant

## Defaults

Enable LAN: Yes

LAN Type: trunk

Untag ID: 1

Members: 1-4094

Guest VLAN: Disabled

Dynamic VLAN: Disabled

802.1X: disabled

DHCP opt82: Disabled

Tunnel= Disabled

MLD Snooping: Disabled

IGMP Snooping: Enabled

## Example

```
ruckus(config-ap)# port-setting
ruckus(config-ap-model)# lan 1 uplink trunk
ruckus(config-ap-model)# show
PORTS:
    LAN ID:
        1:
            Enable LAN = Yes
            LAN Type= trunk
            Untag ID= 1
            Members= 1-4094
            Guest VLAN=
            Enable Dynamic VLAN= Disabled
            802.1X= disabled
            DHCP opt82= Disabled
            Tunnel= Disabled
            MLD Snooping= Disabled
            IGMP Snooping= Enabled
        2:
            Enable LAN = Yes
            LAN Type= trunk
            Untag ID= 1
            Members= 1-4094
            Guest VLAN=
            Enable Dynamic VLAN= Disabled
            802.1X= disabled
            DHCP opt82= Disabled
            Tunnel= Disabled
            MLD Snooping= Disabled
            IGMP Snooping= Enabled

ruckus(config-ap-model)#

```

## abort

To exit the port-setting context without saving changes, use the abort command.

**abort**

## end

To save changes, and then exit the port-setting context, use the following command:

**end**

## exit

To save changes, and then exit the config-ap-model context, use the following command:

**exit**

## quit

To exit the config-ap-model context without saving changes, use the quit command.

**quit**

## show

To display the current port settings, use the following command:

**show**

## Example

```
ruckus(config)# ap 04:4f:ab:0c:b1:00
ruckus(config-ap)# port-setting
ruckus(config-ap-model)# show
PORTS:
    LAN ID:
        1:
            Enable LAN = Yes
            LAN Type= trunk
            Untag ID= 1
            Members= 1-4094
            Guest VLAN=
            Enable Dynamic VLAN= Disabled
            802.1X= disabled
            DHCP opt82= Disabled
            Tunnel= Disabled
            MLD Snooping= Disabled
            IGMP Snooping= Enabled
        2:
            Enable LAN = Yes
            LAN Type= trunk
            Untag ID= 1
            Members= 1-4094
            Guest VLAN=
            Enable Dynamic VLAN= Disabled
            802.1X= disabled
            DHCP opt82= Disabled
            Tunnel= Disabled
            MLD Snooping= Disabled
            IGMP Snooping= Enabled
ruckus(config-ap-model)#

```

## Configuring Controller Settings

### Configure Access Points Commands

#### lan

To enable the LAN port, use the following command:

**lan NUMBER**

#### Syntax Description

##### lan

Enable the LAN port

##### NUMBER

Specify the LAN port to enable

##### uplink WORD

Sets the AP port to use the specified type(trunk,access or general).

##### untag NUMBER

Sets the AP port to use the specified VLAN ID(1-4094) or none.

##### member NUMBER

Sets the AP port to use the specified members(1-4094).

##### opt82

Sets the AP port DHCP Option 82.

##### tunnel

Sets the AP port tunnel.

##### guest-vlan NUMBER

Sets the AP port to use the specified guest VLAN ID(1-4094).

##### dylan

Sets the AP port dynamic VLAN.

##### dot1x

Sets the AP port 802.1X.

#### Defaults

Enable LAN = Yes

LAN Type= trunk

Untag ID= 1

Members= 1-4094

Guest VLAN=

Enable Dynamic VLAN= Disabled

802.1X= disabled

DHCP opt82= Disabled

Tunnel= Disabled

MLD Snooping= Disabled

IGMP Snooping= Enabled

## Example

```
ruckus(config-ap-model)# lan 1  
ruckus(config-ap-model)#{/pre>
```

## no lan

To disable the LAN port, use the following command:

```
no lan NUMBER
```

## Syntax Description

**no lan**

Disable the LAN port

**NUMBER**

Specify the LAN port to disable

## Defaults

None.

## Example

```
ruckus(config-ap-model)# no lan 1  
ruckus(config-ap-model)#{/pre>
```

## lan uplink

To sets the AP port type (Trunk, Access or General), use the following command:

```
lan NUMBER uplink WORD
```

## Syntax Description

**lan uplink**

Set the LAN port type

**NUMBER**

Specify the LAN port to configure

**uplink**

Set the port type to the specified type

**WORD**

LAN port type (Trunk port, Access port, General port)

## Defaults

For all APs other than 7025/7055: Trunk

For 7025/7055 LAN 5: Trunk

For 7025/7055 LAN 1-LAN 4: Access

## Configuring Controller Settings

### Configure Access Points Commands

#### Example

```
ruckus(config-ap-model)# lan 1 uplink access  
ruckus(config-ap-model)#{/pre>
```

#### lan untag

To set the LAN port untag VLAN ID (native VLAN, for Trunk ports), use the following command:

```
lan NUMBER untag NUMBER
```

#### Syntax Description

##### lan untag

Set the LAN port untag VLAN ID

*NUMBER*

Specify the LAN port to configure

*NUMBER*

Set the untag VLAN ID (1~4094)

#### Defaults

1

#### Example

```
ruckus(config-ap-model)# lan 1 untag 1  
ruckus(config-ap-model)#{/pre>
```

#### lan member

To set the LAN port VLAN membership (only General ports have configurable membership; Trunk ports are members of all VLANs, and Access port membership must be the same as the Untag VLAN), use the following command:

```
lan NUMBER member NUMBER
```

#### Syntax Description

##### lan member

Set the LAN port VLAN membership

*NUMBER*

Specify the LAN port to configure

*NUMBER*

Set the VLAN membership (1~4094, range separated by hyphen, multiple VLANs separated by commas)

#### Defaults

1

## Example

```
ruckus(config-ap-model)# lan 2 member 1-10,100,200
ruckus(config-ap-model)# show
PORTS:
LAN ID:
 1:
    Enable LAN = Yes
    LAN Type= trunk
    Untag ID= 1
    Members= 1-4094
    Guest VLAN=
    Enable Dynamic VLAN= Disabled
    802.1X= disabled
    DHCP opt82= Disabled
    Tunnel= Disabled
    MLD Snooping= Disabled
    IGMP Snooping= Enabled
 2:
    Enable LAN = Yes
    LAN Type= general
    Untag ID= 1
    Members= 1-10,100,200
    Guest VLAN=
    Enable Dynamic VLAN= Disabled
    802.1X= disabled
    DHCP opt82= Disabled
    Tunnel= Disabled
    MLD Snooping= Disabled
    IGMP Snooping= Enabled
ruckus(config-ap-model)#

```

## lan opt82

To enable or disable DHCP option 82 for a LAN port, use the following command:

```
lan NUMBER opt82 [ enabled | disabled ]
```

## Syntax Description

### opt82

Enable or disable DHCP option 82

### enabled

Enable option 82

### disabled

Disable option 82

## Defaults

Disabled

## Example

```
ruckus(config-ap-model)# lan 1 opt82 enable
ruckus(config-ap-model)#

```

## Configuring Controller Settings

### Configure Access Points Commands

#### lan tunnel

To enable or disable Ethernet port tunnel mode for the port, use the following command:

```
lan NUMBER tunnel [ enabled | disabled ]
```

#### Syntax Description

##### tunnel

Enable or disable port tunnel mode

##### enabled

Enable tunnel mode

##### disabled

Disable tunnel mode

#### Defaults

Disabled

#### Example

```
ruckus (config-ap-model)# lan 1 tunnel enable
ruckus (config-ap-model)# show
PORTS:
    LAN ID:
        1:
            Enable LAN = Yes
            LAN Type= trunk
            Untag ID= 1
            Members= 1-4094
            Guest VLAN=
            Enable Dynamic VLAN= Disabled
            802.1X= disabled
            DHCP opt82= Disabled
            Tunnel= Enabled
            MLD Snooping= Disabled
            IGMP Snooping= Enabled
        2:
            Enable LAN = Yes
            LAN Type= trunk
            Untag ID= 1
            Members= 1-4094
            Guest VLAN=
            Enable Dynamic VLAN= Disabled
            802.1X= disabled
            DHCP opt82= Disabled
            Tunnel= Disabled
            MLD Snooping= Disabled
            IGMP Snooping= Enabled

ruckus (config-ap-model) #
```

#### lan guest-vlan

To set the AP port to use the specified Guest VLAN ID, use the following command:

```
lan NUMBER guest-vlan NUMBER
```

## **lan dvlan enabled**

To enable dynamic VLAN for the port, use the following command:

**lan NUMBER dvlan enabled**

## **lan dvlan disabled**

To disable dynamic VLAN for the port, use the following command:

**lan NUMBER dvlan disabled**

## **lan dot1x**

To configure 802.1X settings for a LAN port, use the following command:

**lan NUMBER dot1x [ disable | supplicant | auth-port-based | auth-mac-based ]**

### **Syntax Description**

#### **lan dot1x**

Configure 802.1X settings for this port

#### **NUMBER**

LAN port number to configure

#### **disabled**

Disable 802.1X

#### **supplicant**

Configure this LAN port as an 802.1X supplicant

#### **supplicant username WORD**

Set the username for AP 802.1X supplicant

#### **supplicant password WORD**

Set the password for AP 802.1X supplicant

#### **supplicant mac**

Set the username and password to use AP MAC address for AP 802.1X supplicant

#### **auth-port-based**

Configure this LAN port as an 802.1X authenticator (port-based)

#### **auth-mac-based**

Configure this LAN port as an 802.1X authenticator (MAC-based)

### **Defaults**

Disabled

### **Example**

```
ruckus(config-ap-model)# lan 1 dot1x supplicant  
ruckus(config-ap-model)#[/pre]
```

## **Configuring Controller Settings**

### Configure Access Points Commands

#### ***dot1x authsvr***

To configure the 802.1X authentication server for the AP, use the following command:

**dot1x authsvr WORD**

#### **Syntax Description**

**dot1x authsvr**

Configure 802.1X authentication server

**WORD**

Name of AAA server

#### **Defaults**

None

#### **Example**

```
ruckus (config-ap-model) # dot1x authsvr radius  
ruckus (config-ap-model) #
```

#### ***dot1x acctsvr***

To configure the 802.1X accounting server for the AP, use the following command:

**dot1x acctsvr WORD**

#### **Syntax Description**

**dot1x acctsvr**

Configure 802.1X accounting server

**WORD**

Name of AAA server

#### **Defaults**

None

#### **Example**

```
ruckus (config-ap-model) # dot1x acctsvr radius-acct  
ruckus (config-ap-model) #
```

#### ***dot1x mac-auth-bypass***

To configure 802.1X MAC authentication bypass, use the following command:

**dot1x mac-auth-bypass**

## Syntax Description

### **dot1x mac-auth-bypass**

Enable 802.1X MAC authentication bypass

## Defaults

Disabled

## Example

```
ruckus (config-ap-model) # dot1x mac-auth-bypass  
ruckus (config-ap-model) #
```

## **dot1x supplicant username**

To configure 802.1X supplicant user name, use the following command:

### **dot1x supplicant username WORD**

## Syntax Description

### **dot1x supplicant username**

Configure 802.1X supplicant user name

#### **WORD**

Set the 802.1X supplicant user name

## Defaults

None

## Example

```
ruckus (config-ap-model) # dot1x supplicant username johndoe  
ruckus (config-ap-model) #
```

## **dot1x supplicant password**

To configure 802.1X supplicant password, use the following command:

### **dot1x supplicant password WORD**

## Syntax Description

### **dot1x supplicant password**

Configure 802.1X supplicant password

#### **WORD**

Set the 802.1X supplicant password

## Configuring Controller Settings

### Configure Access Points Commands

#### Defaults

None

#### Example

```
ruckus(config-ap-model)# dot1x supplicant password test123  
ruckus(config-ap-model)#[/pre]
```

### ***dot1x supplicant mac***

To set the 802.1X supplicant user name and password as the AP's MAC address, use the following command:

**dot1x supplicant mac**

#### Syntax Description

**dot1x supplicant mac**

Set the supplicant user name and password as the AP's MAC address

#### Defaults

None

#### Example

```
ruckus(config-ap-model)# dot1x supplicant mac  
ruckus(config-ap-model)#[/pre]
```

# Configure AP Policy Commands

Use the **ap-policy** commands to configure global AP policies such as automatic AP approval, limited ZD discovery, management VLAN, load balancing across APs and max clients per AP radio. To run these commands, you must first enter the config-ap-policy context.

## ap-policy

To enter the ap-policy context and configure global AP policies, enter the following command:

**ap-policy**

### Syntax Description

**ap-policy**

Enter config-ap-policy context and configure global AP policies

### Defaults

None.

### Example

```
ruckus(config)# ap-policy  
ruckus(config-ap-policy)#{
```

## show

To display the current device policy, use the following command:

**show**

### Example

```
ruckus(config-ap-policy)# show  
Automatically approve all join requests from APs= Enabled  
Limited ZD Discovery:  
    Status= Disabled  
Management VLAN:  
    Status= Keep AP's setting  
    Auto Recovery= 30 minutes  
ruckus(config-ap-policy)#{
```

## ap-management-vlan

To enable the AP management VLAN and set to either “keep AP’s setting” or to the specified VLAN ID, use the following command:

**ap-management-vlan [ keeping ] NUMBER**

### Syntax Description

**ap-management-vlan**

Enable and configure the global AP management VLAN

## Configuring Controller Settings

### Configure AP Policy Commands

#### **keeping**

Sets management VLAN to “Keep AP’s setting”

#### **NUMBER**

Set management VLAN to the number specified

#### **Defaults**

None.

#### **Example**

```
ruckus(config-ap-policy)# ap-management-vlan keeping  
The command was executed successfully.  
ruckus(config-ap-policy)#[/pre]
```

## no ap-management-vlan

To disable the AP management VLAN, use the following command:

#### **no ap-management-vlan**

#### **Syntax Description**

##### **no ap-management-vlan**

Disable the AP management VLAN

#### **Defaults**

None.

```
ruckus(config-ap-policy)# no ap-management-vlan
```

#### **Example**

```
The command was executed successfully.  
ruckus(config-ap-policy)#[/pre]
```

## ap-auto-approve

To enable the automatic approval of join requests from devices, use the following command:

#### **ap-auto-approve**

#### **Syntax Description**

##### **ap-auto-approve**

Enable the automatic approval of join requests from devices

#### **Defaults**

None.

## Example

```
ruckus (config-ap-policy) # ap-auto-approve  
The AP automatically approve policy has been updated.
```

## no ap-auto-approve

To disable the automatic approval of join requests from devices, use the following command:

```
no ap-auto-approve
```

### Syntax Description

**no ap-auto-approve**

Disable the automatic approval of join requests from devices

### Defaults

None.

## Example

```
ruckus (config-ap-policy) # no ap-auto-approve  
The AP automatically approve policy has been updated.  
ruckus (config-ap-policy) #
```

## limited-zd-discovery

To configure devices to connect to a specific ZoneDirector and to set the primary and secondary ZoneDirector's IP addresses, use the following command:

```
limited-zd-discovery zd-addr | zd-ip PRIMARY SECONDARY
```

### Syntax Description

**limited-zd-discovery**

Configure devices to connect to a specific ZoneDirector

**zd-addr**

Set ZoneDirector's IP/IPv6/FQDN address

**zd-ip**

Set ZoneDirector's IP/IPv6 address

**PRIMARY**

Address of primary ZD

**SECONDARY**

Address of secondary ZD

### Defaults

Disabled.

## Configuring Controller Settings

### Configure AP Policy Commands

#### Example

```
ruckus(config-ap-policy)# limited-zd-discovery zd-addr 192.168.11.100 192.168.11.200
The Limited ZoneDirector discovery function has been updated.
ruckus(config-ap-policy)# show
Automatically approve all join requests from APs= Enabled
Limited ZD Discovery:
Status= Enabled
Primary ZoneDirector ADDR= 192.168.11.100
SecondaryZoneDirector ADDR= 192.168.11.200
Prefer Primary ZoneDirector = false
Management VLAN:
Status= Disabled
Balances the number of clients across adjacent APs= Disabled
Max. clients for 11BG radio= 100
Max. clients for 11N radio= 100
LWAPP message MTU= 1450
ruckus(config-ap-policy)#

```

## no limited-zd-discovery

To disable limited ZD discovery, use the following command:

**no limited-zd-discovery**

#### Syntax Description

**no limited-zd-discovery**

Disable limited ZD discovery

#### Defaults

Disabled.

#### Example

```
ruckus(config-ap-policy)# no limited-zd-discovery
The Limited ZoneDirector discovery function has been updated.
ruckus(config-ap-policy)#

```

## limited-zd-discovery prefer-primary-zd

To force the AP to prefer the primary ZoneDirector when connected (and periodically attempt to reconnect to the primary ZD when disconnected from it), use the following command:

**limited-zd-discovery prefer-primary-zd**

#### Example

```
ruckus(config-ap-policy)# limited-zd-discovery prefer-primary-zd
The Limited ZoneDirector discovery function has been updated.
ruckus(config-ap-policy)#

```

## no limited-zd-discovery prefer-primary-zd

To disable the Limited ZD Discovery “prefer primary ZoneDirector” feature, use the following command:

**no limited-zd-discovery prefer-primary-zd**

## limited-zd-discovery keep-ap-setting

To disallow ZoneDirector modifying AP's original primary/secondary ZD settings, use the following command:

**limited-zd-discovery keep-ap-setting**

### Example

```
ruckus(config-ap-policy)# limited-zd-discovery keep-ap-setting  
The Limited ZoneDirector discovery function has been updated.  
ruckus(config-ap-policy)#[/pre]
```

## no limited-zd-discovery keep-ap-setting

To disable the Limited ZD Discovery “keep AP's setting” feature, use the following command:

**no limited-zd-discovery keep-ap-setting**

## auto-recovery

To set the value of auto recovery time (minutes) for AP reboot if AP can't connect to ZoneDirector, use the following command:

**auto-recovery NUMBER**

### Defaults

Enabled

30 minutes

### Example

```
ruckus (config-ap-policy)# auto-recovery 30  
The AP auto recovery policy has been updated.  
ruckus(config-ap-policy)#[/pre]
```

## no auto-recovery

To disable AP auto recovery, use the following command:

**no auto-recovery**

## vlan-qos

To configure the traffic class [ **voice** | **video** | **data** | **background** ] to the specific VLAN ID at the specific interface, use the following command:

**vlan-qos VID Traffic ClassInterface Name**

## Configuring Controller Settings

### Configure AP Policy Commands

#### Syntax Description

##### vlan-qos

Configure VLAN QOS settings

##### VID

VLAN ID

##### Traffic Class

Specify traffic classification [ **voice** | **video** | **data** | **background** ]

##### Interface Name

Specify interface name

#### Defaults

Disabled

#### Example

```
ruckus(config-ap-policy)# vlan-qos 10 voice eth0  
The VLAN QoS function has been updated.  
ruckus(config-ap-policy)#[/pre]
```

#### no vlan-qos

To disable VLAN traffic class QoS for the specific interface or all VLANs, use the following command:

**no vlan-qos all | VID Interface Name**

#### Syntax Description

##### no vlan-qos

Disable VLAN's QoS settings

##### VID

VLAN ID

##### Interface Name

Specify interface name

#### Defaults

Disabled

#### Example

```
ruckus(config-ap-policy)# no vlan-qos all eth0  
The VLAN QoS function has been updated.  
ruckus(config-ap-policy)#[/pre]
```

## timeout

To configure recovering of the APs' original Primary/Secondary ZD address if the AP can't find the desired Primary/Secondary ZD after timeout(minutes), use the following command:

**timeout NUMBER**

### Syntax Description

**timeout**

Enter the timeout value (minutes) for recovering APs' original primary/secondary ZD IP.

**NUMBER**

Timeout value in minutes.

### Example

```
ruckus (config-ap-policy-move-ap) # timeout 60  
Your changes have been saved.  
ruckus (config-ap-policy-move-ap) #
```

## no timeout

To disable the timeout function for moving APs, use the following command:

**no timeout**

## import-aplist

To import an AP list from backup files on a TFTP server, use the following command:

**import-aplist IP-ADDR FILE-NAME**

## exit

Saves changes, and then exits the config-ap-policy-move-ap context.

## abort

Exits the config-ap-policy-move-ap context without saving changes.

## quit

Exits the config-ap-policy-move-ap context without saving changes.

# Configure AP Group Commands

This section describes the commands that you can use to configure AP groups on the controller. The following commands can be executed from within the **config-apgrp** context. To show a list of commands available from within the context, type **help** or **?**.

## ap-group

To create a new AP group or configure an existing AP group and enter the config-apgrp context, enter the following command:

**ap-group WORD**

### Syntax Description

**ap-group**

Configure an AP group

**WORD**

Name of the AP group

### Defaults

"System Default"

### Example

```
ruckus(config)# ap-group "System Default"  
The AP group entry 'System Default' has been loaded. To save the AP group, type 'end' or 'exit'.  
ruckus(config-apgrp) #
```

## no ap-group

To delete an AP group from the list, enter the following command:

**no ap-group WORD**

### Syntax Description

**no ap-group**

Delete an AP group

**WORD**

Name of the AP group

### Defaults

None

### Example

```
ruckus(config)# no ap-group apgrp2  
The AP Group 'apgrp2' has been removed.  
ruckus(config) #
```

## exit

Saves changes, and then exits the config-ap-group context.

## abort

Exits the config-ap-group context without saving changes.

## quit

Exits the config-ap-group context without saving changes.

## show

To display current AP group configuration settings, use the following command from within the config-ap-group context:

**show**

### *Example*

```
ruckus(config)# ap-group apgroup1
The AP group 'apgroup1' has been created. To save the AP group, type 'end' or 'exit'.
ruckus(config-apgrp)# show
APGROUP:
  ID:
  :
    Name= apgroup1
    Description=
    Radio 11bgn:
      Channelization= Auto
      Channel= Auto
      Enable auto channel selection which select from 1,6,11= Yes
      Tx. Power= Auto
      11N only Mode= Auto
      WLAN Group= Default
      Call Admission Control= OFF
    Radio 11an:
      Channelization= Auto
      Channel= Auto
      Tx. Power= Auto
      11N only Mode= Auto
      WLAN Group= Default
      Call Admission Control= OFF
    Members:
ruckus(config-apgrp)#
exit
```

## description

To set the AP group description, use the following command:

**description WORD**

## no description

To delete the AP group description, use the following command:

**Configuring Controller Settings**  
Configure AP Group Commands

**no description**

## Configure Location Based Service Commands

Use the following commands to create and configure location services for an AP group. Use the **location-services** command to enter the **config-location-services** context from within the **config** context.

### **location-services**

To create and begin configuring location services for this AP group, use the following command:

**location-services WORD**

### Syntax Description

#### **help**

Set the IP addressing mode

#### **history**

IPv4, IPv6 or dual

#### **abort**

Exits the config-location-services context without saving changes.

#### **end**

Saves changes, and then exits the config-location-services context.

#### **exit**

Saves changes, and then exits the config-location-services context.

#### **quit**

Exits the config-location-services context without saving changes.

#### **fqdn WORD**

Sets the location server FQDN.

#### **port PORT-NUM**

Sets the location server port.

#### **password WORD**

Sets the location server preshared key.

#### **show**

Displays configured location services for all venues.

### Example

```
ruckus(config)# location-services locationservice1
The location venue 'locationservice1' has been created. To save it, type 'end' or 'exit'.
ruckus(config-location-services)# fqdn example1.ruckuswireless.com
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-location-services)# port 8883
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-location-services)# password password
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-location-services)# end
The location venue 'locationservice1' has been updated and saved.
Your changes have been saved.
ruckus(config)#

```

## **Configuring Controller Settings**

### Configure AP Group Commands

#### **no location-services**

To disable location-based service on this AP group, use the following command:

**no location-services WORD**

#### **Example**

```
ruckus(config)# no location-service locationservice1  
The location venue 'locationservice1' has been deleted.  
ruckus(config)#[/pre]
```

#### **ipmode**

To set the IP addressing mode of the AP group, use the following command:

**ipmode WORD**

#### **Syntax Description**

**ipmode**

Set the IP addressing mode

**WORD**

IPv4, IPv6 or dual

#### **Example**

```
ruckus(config-apgrp)# ipmode dual  
ruckus(config-apgrp)#[/pre]
```

#### **no ipmode-override**

To disable the override of IP mode, use the following command:

**no ipmode-override**

#### **channelflyoff**

The ChannelFly override setting allows APs to disable ChannelFly if the AP's uptime is higher than the specified value (in minutes). To enable the ChannelFly override feature for the AP group, use the following command:

#### **Defaults**

Disabled

30 minutes

#### **Example**

```
ruckus(config-apgrp)# channelflyoff 30  
ruckus(config-apgrp)# show  
APGROUP:  
ID:  
:  
Name= appgroup2[/pre]
```

```

Description=
Channel Range:
  B/G/N= 1,2,3,4,5,6,7,8,9,10,11 (Disallowed= )
  A/N Indoor= 36,40,44,48,149,153,157,161 (Disallowed= )
  A/N Outdoor= 36,40,44,48,149,153,157,161 (Disallowed= )
Radio 11bgn:
  Channelization= Auto
  Channel= Auto
  Tx. Power= Auto
  11N only Mode= Auto
  WLAN Group= Default
  Call Admission Control= OFF
  SpectraLink Compatibility= Disabled
Radio 11an:
  Channelization= Auto
  Indoor Channel= Auto
  Outdoor Channel= Auto
  Tx. Power= Auto
  11N only Mode= Auto
  WLAN Group= Default
  Call Admission Control= OFF
  SpectraLink Compatibility= Disabled
Network Setting:
  Protocol mode= Use Parent Setting
  Turn off channfly setting: enabled
    if AP's uptime is more than 30 minutes will turn off AP's ChannelFly
Members:
ruckus(config-apgrp)#

```

### **no channelflyoff**

To disable the ChannelFly off feature for the AP group, use the following command:

**no channelflyoff**

### **no channelflyoff-override**

To disable the override of ChannelFly settings (use parent settings), use the following command:

**no channelflyoff-override**

### **Example**

```

ruckus(config-apgrp)# no channelflyoff-override
ruckus(config-apgrp)# show
APGROUP:
  ID:
  :
  Name= apgroup2
  Description=
  Channel Range:
    B/G/N= 1,2,3,4,5,6,7,8,9,10,11 (Disallowed= )
    A/N Indoor= 36,40,44,48,149,153,157,161 (Disallowed= )
    A/N Outdoor= 36,40,44,48,149,153,157,161 (Disallowed= )
  Radio 11bgn:
    Channelization= Auto
    Channel= Auto
    Tx. Power= Auto
    11N only Mode= Auto
    WLAN Group= Default
    Call Admission Control= OFF
    SpectraLink Compatibility= Disabled
  Radio 11an:
    Channelization= Auto
    Indoor Channel= Auto

```

## Configuring Controller Settings

### Configure AP Group Commands

```
Outdoor Channel= Auto
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Call Admission Control= OFF
SpectralLink Compatibility= Disabled
Network Setting:
Protocol mode= Use Parent Setting
Turn off channfly setting: Use Parent Setting
Members:

ruckus (config-apgrp) #
```

## Radio 2.4/5 GHz Commands

Use the radio 2.4 or radio 5 commands to configure the 2.4/5 GHz radios on all APs within an AP group.

### radio

To configure radio settings for the 2.4 GHz or 5 GHz radios of an AP group, use the following command:

**radio [2.4|5]arguments**

### Syntax Description

#### radio

Configure AP group radio settings

#### 2.4

Configure 2.4 GHz radio

#### 5

Configure 5 GHz radio

#### no

Disables settings for the specified radios in the AP group

#### channel

Set radio channel (Auto or number)

#### channelization

Set radio channel width (Auto, 20MHz or 40MHz)

#### auto-channel-selection [four-channel| three-channel]

Set auto channel selection to four-channel (1,5,9,13) or three-channel (1,6,11)

#### tx-power

Set radio transmit power (Auto, Full, 1/2, 1/4, 1/8, Min) or NUMBER (-1dB~10dB)

#### wlan-group

Set radio to the specified WLAN group

#### admission-control

Set the radio to use the specific call admission control airtime usage limit (%)

#### spectralink-compatibility

Enable SpectraLink Compatibility settings on the radio (sets DTIM=2, minrate=5.5Mbps and enable RTS-CTS protection mode)

#### wlan-service

Disable or enable WLAN service on the radio

### Defaults

Channel: Auto

Channelization: Auto

Auto-Channel Selection: Three-channel

TX Power: Auto

WLAN group: Default

## Configuring Controller Settings

### Configure AP Group Commands

Admission Control: Off

SpecraLink Compatibility: Off

WLAN Service: Enabled

### Example

```
ruckus(config)# ap-group "System Default"
The AP group entry 'System Default' has been loaded. To save the AP group, type 'end' or 'exit'.
ruckus(config-apgrp)# radio 2.4 channel auto
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-apgrp)# radio 5 channelization auto
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-apgrp)# radio 5 wlan-group Default
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-apgrp)# radio 2.4 tx-power Num 1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-apgrp)# show
APGROUP:
 ID:
 1:
 Name= System Default
 Description= System default group for Access Points
 Radio 11bgn:
 Channelization= Auto
 Channel= Auto
 Enable auto channel selection which select from 1,6,11= Yes
 Tx. Power= -1dB
 WLAN Group= Default
 Radio 11an:
 Channelization= Auto
 Channel= Auto
 Tx. Power= Auto
 WLAN Group= Default
 Members:
 MAC= 04:4f:aa:0c:b1:00
 MAC= 00:24:82:3f:14:60
 MAC= 74:91:1a:2b:ff:a0
 MAC= 00:1f:41:2a:2b:10

ruckus(config-apgrp)# end
The AP group 'System Default' has been updated.
Your changes have been saved.
ruckus(config)#

```

### radio 2.4 channel auto

Sets the 2.4GHz radio to use 'Auto' channel.

### radio 2.4 channel number <NUMBER>

Sets the 2.4GHz radio to use the specified channel.

### radio 2.4 channelization auto

Sets the 2.4GHz radio to use 'Auto' channelization.

### radio 2.4 channelization number <NUMBER>

Sets the 2.4GHz radio to use the specified channelization.

### **radio 2.4 auto-channel-selection four-channel**

Enables the auto channel selection which always select from 1,5,9,13.

### **radio 2.4 auto-channel-selection three-channel**

Enables the auto channel selection which always select from 1,6,11.

### **radio 2.4 tx-power Auto**

Sets the 2.4GHz radio to use 'Auto' Tx. power setting.

### **radio 2.4 tx-power Full**

Sets the 2.4GHz radio to use the specified Tx. power setting.

### **radio 2.4 tx-power 1/2**

Sets the 2.4GHz radio to use the specified Tx. power setting.

### **radio 2.4 tx-power 1/4**

Sets the 2.4GHz radio to use the specified Tx. power setting.

### **radio 2.4 tx-power 1/8**

Sets the 2.4GHz radio to use the specified Tx. power setting.

### **radio 2.4 tx-power Min**

Sets the 2.4GHz radio to use the specified Tx. power setting.

### **radio 2.4 tx-power Num**

Sets the 2.4GHz radio to use the specified Tx by number from 1-10 (-1dB ~ -10dB).

### **radio 2.4 wlan-group <WORD>**

Assigns the 2.4GHz radio to the specified WLAN group.

### **radio 2.4 admission-control <VALUE>**

Sets the 2.4GHz radio to use the specific call admission control airtime usage limit(%).

## Configuring Controller Settings

### Configure AP Group Commands

#### **radio 2.4 prot-mode**

##### Syntax

```
radio 2.4 prot-mode { none | cts-only| rts-cts }
```

##### Options

- None: Sets Protection Mode to 'none'
- cts-only: Sets Protection Mode to 'cts-only'
- rts-cts: Sets Protection Mode to 'rts-cts'

##### Example

```
ruckus(config-ap)# radio 2.4 prot-mode rts-cts
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-ap) #
```

#### **radio 2.4 wlan-service [enable | disable]**

Enables or disables the WLAN service on the 2.4GHz radio.

#### **radio 2.4 channel-range <NUMBER-LIST>**

Sets the allowed list of channels used in 2.4GHz radio.

#### **radio 5 indoor channel auto**

Sets the 5GHz radio (indoor) to use 'Auto' channel.

#### **radio 5 indoor channel number <NUMBER>**

Sets the 5GHz radio (indoor) to use the specified channel.

#### **radio 5 indoor channel-range <NUMBER-LIST>**

Sets the allowed list of indoor channels used in 5GHz radio.

#### **radio 5 outdoor channel auto**

Sets the 5GHz radio (outdoor) to use 'Auto' channel.

#### **radio 5 outdoor channel number <NUMBER>**

Sets the 5GHz radio (outdoor) to use the specified channel.

#### **radio 5 outdoor channel-range <NUMBER-LIST>**

Sets the allowed list of outdoor channels used in 5GHz radio.

**radio 5 channel auto**

Sets the 5GHz radio to use 'Auto' channel.

**radio 5 channel number <NUMBER>**

Sets the 5GHz radio to use the specified channel.

**radio 5 channelization auto**

Sets the 5GHz radio to use 'Auto' channelization.

**radio 5 channelization number <NUMBER>**

Sets the 5GHz radio to use the specified channelization.

**radio 5 tx-power Auto**

Sets the 5GHz radio to use 'Auto' Tx. power setting.

**radio 5 tx-power Full**

Sets the 5GHz radio to use the specified Tx. power setting.

**radio 5 tx-power 1/2**

Sets the 5GHz radio to use the specified Tx. power setting.

**radio 5 tx-power 1/4**

Sets the 5GHz radio to use the specified Tx. power setting.

**radio 5 tx-power 1/8**

Sets the 5GHz radio to use the specified Tx. power setting.

**radio 5 tx-power Min**

Sets the 5GHz radio to use the specified Tx. power setting.

**radio 5 tx-power Num**

Sets the 5GHz radio to use the specified Tx by number from 1-10 (-1dB ~ -10dB).

**radio 5 wlan-group <WORD>**

Assigns the 5GHz radio to the specified WLAN group.

## **Configuring Controller Settings**

### Configure AP Group Commands

#### **radio 5 admission-control <VALUE>**

Sets the 5GHz radio to use the specific call admission control airtime usage limit(%).

#### **radio 5 wlan-service [enable | disable]**

Enables or disables the WLAN service on the 5GHz radio.

#### **no radio 2.4 channelization-override**

Disables the override of the 2.4GHz channelization settings.

#### **no radio 2.4 channel-range-override**

Disables the override of the 2.4GHz channel range settings.

#### **no radio 2.4 channel-override**

Disables the override of the 2.4GHz channel settings.

#### **no radio 2.4 tx-power-override**

Disables the override of the 2.4GHz Tx. power settings.

#### **no radio 2.4 wlan-group-override**

Disables the override of the 2.4GHz WLAN group settings.

#### **no radio 2.4 admission-control**

Disables call admission control function on the 2.4GHz radio.

#### **no radio 2.4 admission-control-override**

Disables the override of the 2.4GHz call admission control settings.

**no radio 2.4 prot-mode-override**

Disables the override of the 2.4GHz Protection Mode settings.

**no radio 2.4 wlan-service-override**

Disables the override of the 2.4GHz WLAN service settings.

**no radio 5 indoor channel-range-override**

Disables the override of the 5GHz indoor channel range settings.

**no radio 5 indoor channel-override**

Disables the override of the 5GHz indoor channel settings.

**no radio 5 outdoor channel-range-override**

Disables the override of the 5GHz outdoor channel range settings.

**no radio 5 outdoor channel-override**

Disables the override of the 5GHz outdoor channel settings.

**no radio 5 channelization-override**

Disables the override of the 5GHz channelization settings.

**no radio 5 tx-power-override**

Disables the override of the 5GHz Tx. power settings.

**no radio 5 wlan-group-override**

Disables the override of the 5GHz WLAN group settings.

**no radio 5 admission-control**

Disables call admission control function on the 5GHz radio.

**no radio 5 admission-control-override**

Disables the override of the 5GHz call admission control settings.

**no radio 5 wlan-service-override**

Disables the override of the 5GHz WLAN service settings.

## **QoS Commands (AP)**

Use the following commands to configure QoS settings for the AP group.

### ***qos***

Contains commands that can be executed from within the context.

### ***qos mld-query***

Contains commands that can be executed from within the context.

### ***qos mld-query v1***

Enables the mld-query v1.

### ***qos mld-query v2***

Enables the mld-query v2.

### ***qos igmp-query***

Contains commands that can be executed from within the context.

### ***qos igmp-query v2***

Enables the igmp-query v2.

### ***qos igmp-query v3***

Enables the igmp-query v3.

### ***no qos mld-query v1***

Disables the mld-query v1.

### ***no qos mld-query v2***

Disables the mld-query v2.

### ***no qos igmp-query v2***

Disables the igmp-query v2.

### ***no qos igmp-query v3***

Disables the igmp-query v3.

## Model-Specific Commands

The following commands are used to configure model-specific settings for all APs of a certain model within an AP group.

### **no model-setting**

To discard the model settings for this specified model, use the following command:

**no model-setting WORD**

### **model**

To configure model-specific settings for all APs of a certain model within an AP group, use the following command:

**model <WORD> <arguments>**

### Syntax Description

#### **model**

Configure AP group model-specific settings

#### **<WORD>**

Enter the AP model name.

#### **port-setting**

Configures the port setting for the specified AP model. Enters config-apgrp-port context. See [port-setting](#) on page 204 for more information.

#### **status-leds**

Configures the status LEDs for the specified AP model (enable, disable).

#### **usb-port**

Configures the USB port settings for the AP model (enable, disable).

#### **external-antenna**

Configures external antenna settings. See [external-antenna](#) on page 220.

#### **max-clients NUMBER**

Sets the maximum clients for the AP.

#### **usb-software VID-PID-VERSION**

Selects the USB Software Vendor ID, Product ID and version for the AP.

#### **poe-out**

Configures the PoE Out ports for the specified AP model (enable, disable).

#### **internal-heater**

Configures the internal heater for the specified AP model (enable, disable).

#### **cband-channels**

Configures the C-band (5.8 GHz) channels for the specified AP model (enable, disable). (UK country code only)

#### **cband-license**

Enable or disable 5.8 GHz Channels License for the specified AP model.

#### **lacp-status**

Configure LACP status for the specified AP model.

## Configuring Controller Settings

### Configure AP Group Commands

#### **power-mode**

Sets the PoE mode for the specified AP model.

#### **802.3af-txchain**

Sets the 2.4GHz radio transmit chains in 802.3af PoE mode for the specified AP model.

## Defaults

Status LEDs: Enabled

PoE Out: Disabled

USB Software: Disabled

Internal Heater: Disabled

C-band channels: Disabled

C-band license: Disabled

LACP status: Disabled

Power mode: Varies by AP model

USB Ports: Enabled

Power Mode: Default

802.3af-txchain: Varies by AP model

## Example

```
ruckus(config-apgrp) # model R610 status-leds enable  
ruckus(config-apgrp) # end  
The AP group 'System Default' has been updated.  
Your changes have been saved.  
ruckus(config) #
```

## port-setting

To modify model-specific port settings for all APs of the specified model within the AP group, use the following command:

**model <WORD> port-setting**

## Syntax Description

#### **port-setting**

Enters the port-setting context.

#### **no port-setting**

Disables the override of the global AP mode configuration.

#### **help**

Shows available commands.

#### **history**

Shows a list of previously run commands.

#### **abort**

Exits the config-apgrp-port context without saving changes.

**end**  
Saves changes, and then exits the config-apgrp-port context.

**exit**  
Saves changes, and then exits the config-apgrp-port context.

**quit**  
Exits the config-apgrp-port context without saving changes.

**show**  
Displays config-apgrp-port context.

**lan NUMBER**  
Enables the AP Ethernet port.

**lan NUMBER uplink WORD**  
Sets the AP port to use the specified type (trunk, access or general).

**lan NUMBER untag NUMBER**  
Sets the AP port to use the specified VLAN ID(1-4094).

**lan NUMBER member NUMBER**  
Sets the AP port to use the specified members(1-4094).

**lan NUMBER opt82 enabled**  
Enables the AP port DHCP option 82 settings.

**lan NUMBER opt82 disabled**  
Disables the AP port DHCP option 82 settings.

**lan NUMBER tunnel disabled**  
Disables the AP port tunnel settings.

**lan NUMBER tunnel enabled**  
Enables the AP port tunnel settings.

**lan NUMBER dot1x disabled**  
Disables the AP port 802.1X settings.

**lan NUMBER dot1x supplicant**  
Sets the AP port to 802.1X supplicant.

**lan NUMBER dot1x auth-port-based**  
Sets the AP port to port-based 802.1X.

**lanNUMBER dot1x auth-mac-based**  
Sets the AP port to mac-based 802.1X.

**lan NUMBER guest-vlan WORD**  
Sets the AP port to use the specified guest VLAN ID(1-4094).

**lan NUMBER dvlan enabled**  
Enables the AP port dynamic VLAN settings.

**lan NUMBER dvlan disabled**  
Disables the AP port dynamic VLAN settings.

**lan NUMBER qos mld-snooping**  
Enables the AP port MLD Snooping setting.

## Configuring Controller Settings

### Configure AP Group Commands

#### **lan NUMBER qos igmp-snooping**

Enables the AP port IGMP Snooping setting.

#### **lan NUMBER qos directed-mcast**

Enables the AP port Directed Multicast setting.

#### **dot1x supplicant mac**

Sets the username and password to use AP MAC address for AP 802.1X supplicant.

#### **dot1x supplicant user-name WORD**

Sets the username for AP 802.1X supplicant.

#### **dot1x supplicant user-name WORD password WORD**

Sets the password for AP 802.1X supplicant.

#### **dot1x authsvr WORD;**

Sets the authentication server for AP 802.1X.

#### **dot1x acctsvr WORD**

Sets the accounting server for AP 802.1X.

#### **dot1x mac-auth-bypass**

Enables MAC authentication bypass (Use device MAC address as username and password).

#### **no lan NUMBER**

Disables the AP Ethernet port.

#### **no dot1x authsvr**

Disables the auth server settings.

#### **no lan NUMBER qos mld-snooping**

Disables the AP port MLD Snooping setting.

#### **no lan NUMBER qos igmp-snooping**

Disables the AP port IGMP snooping setting.

#### **no lan NUMBER qos directed-mcast**

Disables the AP port Directed Multicast setting.

#### **no dot1x authsvr**

Disables the authentication server settings.

#### **no dot1x acctsvr**

Disables the accounting server settings.

#### **no dot1x mac-auth-bypass**

Disables the MAC authentication bypass.

## Example

```
ruckus (config-apgrp) # model zf7372 port-setting
ruckus (config-apgrp-port) # show
PORTS:
  LAN ID:
    1:
      Enable LAN = Yes
      LAN Type= trunk
      Untag ID= 1
      Members= 1-4094
      Guest VLAN=
      Enable Dynamic VLAN= Disabled
```

```
802.1X= disabled
DHCP opt82= Disabled
Tunnel= Disabled
MLD Snooping= Disabled
IGMP Snooping= Enabled
2:
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
Guest VLAN=
Enable Dynamic VLAN= Disabled
802.1X= disabled
DHCP opt82= Disabled
Tunnel= Disabled
MLD Snooping= Disabled
IGMP Snooping= Enabled

ruckus(config-apgrp-port) #
```

## Model-Specific Port Settings

This section describes the commands that you can use to configure port settings for all APs of a specific model within an AP group. The following commands can be executed from within the **config-apgrp-port** context. To show a list of commands available from within the context, type **help** or **?**.

### model port-setting

To configure the port settings for all APs of a specific model within an AP group, and enter the config-apgrp-port context, use the following command:

**model WORD port-setting**

#### Syntax Description

##### model

Configure AP group model-specific settings

##### WORD

Enter the AP model name (e.g., zf2942, zf2741, zf7025, zf7341, zf7343, zf7363, zf7761cm, zf7762, zf7762-s, zf7762-t, zf7762-ac, zf7762-s-ac, zf7762-t-ac, zf7942, zf7962).

##### port-setting

Configures the port setting for the specified AP model. Enters config-apgrp-port context.

#### Example

```
ruckus(config)# ap-group "System Default"  
The AP group entry 'System Default' has been loaded. To save the AP group, type 'end' or 'exit'.  
ruckus(config-apgrp)# model zf7025 port-setting  
ruckus(config-apgrp-port)#[/pre]
```

### abort

To exit the config-apgrp-port context without saving changes, use the following command:

**abort**

#### Syntax Description

##### abort

Exit the context without saving changes

#### Defaults

None.

#### Example

```
ruckus(config-apgrp-port)# abort  
ruckus(config-apgrp)#[/pre]
```

## end

To save changes, and then exit the config-apgrp-port context, use the following command:

**end**

### Syntax Description

**end**

Save changes, and then exit the context

### Defaults

None.

### Example

```
ruckus (config-apgrp-port) # end  
ruckus (config-apgrp) #
```

## exit

To save changes, and then exit the config-apgrp-port context, use the following command:

**exit**

### Syntax Description

**exit**

Save changes, and then exit the context

### Defaults

None.

### Example

```
ruckus (config-apgrp-port) # exit  
ruckus (config-apgrp) #
```

## quit

To exit the config-apgrp-port context without saving changes, use the following command:

**quit**

### Syntax Description

**quit**

Exit the context without saving changes

### Defaults

None.

## Configuring Controller Settings

### Configure AP Group Commands

#### Example

```
ruckus(config-apgrp-port)# quit  
ruckus(config-apgrp)#
```

#### show

To show a device's port state, use the following command:

```
show
```

#### Syntax Description

```
show
```

Display the device's port state

#### Defaults

None.

#### Example

```
ruckus(config-apgrp)# model zf7962 port-setting  
ruckus(config-apgrp-port)# show  
PORTS:  
LAN ID:  
1:  
Enable LAN = Yes  
LAN Type= trunk  
Untag ID= 1  
Members= 1-4094  
802.1X= disabled  
DHCP opt82= Disabled  
LAN ID:  
2:  
Enable LAN = Yes  
LAN Type= trunk  
Untag ID= 1  
Members= 1-4094  
802.1X= disabled  
DHCP opt82= Disabled  
ruckus(config-apgrp-port)#[/pre]
```

#### no lan

To disable a LAN port on APs in an AP group, use the following command:

```
no lan NUMBER
```

#### Syntax Description

```
no lan
```

Disable a specific port

```
NUMBER
```

Disable this port

### Defaults

Enabled.

### Example

```
ruckus(config-apgrp-port)# no lan 2  
ruckus(config-apgrp-port)#[/pre]
```

### lan

To enable a LAN port on APs in an AP group, use the following command:

```
lan NUMBER
```

### Syntax Description

#### lan

Enable a specific port

#### NUMBER

Enable this port

### Defaults

Enabled.

### Example

```
ruckus(config-apgrp-port)# lan 2  
ruckus(config-apgrp-port)#[/pre]
```

### lan uplink

To set port type, use the following command:

```
lan NUMBER uplink WORD
```

### Syntax Description

#### lan

Configure a specific port

#### NUMBER

Configure this port

#### uplink

Set the port type

#### WORD

Port type (Trunk port, Access port, General port)

### Defaults

All AP ports other than ZF 7025: Trunk

## Configuring Controller Settings

### Configure AP Group Commands

ZF 7025 port 5: Trunk

ZF 7025 LAN 1-LAN 4: Access

#### Example

```
ruckus (config-apgrp) # model zf7962 port-setting
ruckus (config-apgrp-port) # lan 2 uplink access
ruckus (config-apgrp-port) # show
PORTS:
LAN ID:
1:
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
802.1X= disabled
DHCP opt82= Disabled
LAN ID:
2:
Enable LAN = Yes
LAN Type= access
Untag ID= 1
Members= 1
802.1X= disabled
DHCP opt82= Disabled
ruckus (config-apgrp-port) #
```

## lan untag

To configure untag VLAN settings for a model-specific port, use the following command:

**lan NUMBER untag NUMBER**

#### Syntax Description

##### lan untag

Configure port untag VLAN

##### NUMBER

Configure this port

##### NUMBER

Set untag VLAN to this number

#### Defaults

1

#### Example

```
ruckus (config-apgrp-port) # lan 2 untag 20
ruckus (config-apgrp-port) #
```

## lan member

To set the LAN port VLAN membership (only General ports have configurable membership; Trunk ports are members of all VLANs, and Access port membership must be the same as the Untag VLAN), use the following command:

**lan NUMBER member NUMBER**

**Syntax Description**

**lan member**

Set the LAN port VLAN membership

**NUMBER**

Specify the LAN port to configure

**NUMBER**

Set the VLAN membership (1~4094, range separated by hyphen, multiple VLANs separated by commas)

**Defaults**

1

**Example**

```
ruckus(config-apgrp-port)# lan 2 uplink general
ruckus(config-apgrp-port)# lan 2 member 1-10,100,200
ruckus(config-apgrp-port)# show
PORTS:
LAN ID:
1:
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
802.1X= disabled
DHCP opt82= Disabled
LAN ID:
2:
Enable LAN = Yes
LAN Type= general
Untag ID= 20
Members= 1-10,100,200
802.1X= disabled
DHCP opt82= Disabled
ruckus(config-apgrp-port)#

```

**lan opt82**

To enable or disable DHCP option 82 for a LAN port, use the following command:

**lan NUMBER opt82 [ enable | disable ]**

**Syntax Description**

**lan opt82**

Enable or disable DHCP option 82

**enable**

Enable option 82

**disable**

Disable option 82

## Configuring Controller Settings

### Configure AP Group Commands

#### Defaults

Disabled

#### Example

```
ruckus(config-apgrp-port)# lan 2 opt82 enable  
ruckus(config-apgrp-port)#[/pre]
```

#### dot1x

To enable 802.1X on ports of all APs of a specific model in an AP group, use the following command:

```
model WORD dot1x  
lan NUMBER dot1x [ disable | supplicant | auth-port-based | auth-mac-based | guest-vlan NUMBER | dvlan ]
```

#### Syntax Description

##### lan dot1x

Configure 802.1X settings for this port

##### NUMBER

LAN port number to configure

##### disable

Disable 802.1X

##### supplicant

Configure this LAN port as an 802.1X supplicant

##### auth-port-based

Configure this LAN port as an 802.1X authenticator (port-based)

##### auth-mac-based

Configure this LAN port as an 802.1X authenticator (MAC-based)

#### Defaults

Disabled

#### Example

```
ruckus(config-apgrp)# model zf7025 port-setting  
ruckus(config-apgrp-port)# lan 1 dot1x supplicant  
ruckus(config-apgrp-port)#[/pre]  
PORTS:  
LAN ID:  
1:  
Enable LAN = Yes  
LAN Type= access  
Untag ID= 1  
Members= 1  
802.1X= supp  
DHCP opt82= Disabled
```

#### dot1x authsvr

To configure 802.1X authentication server, use the following command:

**dot1x authsvr WORD**

**Syntax Description**

**dot1x authsvr**

Configure 802.1X authentication server

**WORD**

Name of AAA server

**Defaults**

None

**Example**

```
ruckus(config-apgrp-port)# dot1x authsvr radius  
ruckus(config-apgrp-port)#{
```

**dot1x acctsrv**

To configure 802.1X accounting server, use the following command:

**dot1x acctsrv WORD**

**Syntax Description**

**dot1x acctsrv**

Configure 802.1X accounting server

**WORD**

Name of AAA server

**Defaults**

None

**Example**

```
ruckus(config-apgrp-port)# dot1x acctsrv radius-acct  
ruckus(config-apgrp-port)#{
```

**dot1x mac-auth-bypass**

To configure 802.1X MAC authentication bypass, use the following command:

**dot1x mac-auth-bypass**

**Syntax Description**

**dot1x mac-auth-bypass**

Enable 802.1X MAC authentication bypass

## **Configuring Controller Settings**

### Configure AP Group Commands

#### **Defaults**

Disabled

#### **Example**

```
ruckus(config-apgrp-port) # dot1x mac-auth-bypass  
ruckus(config-apgrp-port) #
```

#### **dot1x supplicant username**

To configure 802.1X supplicant user name, use the following command:

**dot1x supplicant username WORD**

#### **Syntax Description**

##### **dot1x supplicant username**

Configure 802.1X supplicant user name

**WORD**

Set the 802.1X supplicant user name

#### **Defaults**

None

#### **Example**

```
ruckus(config-apgrp-port) # dot1x supplicant username john Doe  
ruckus(config-apgrp-port) #
```

#### **dot1x supplicant password**

To configure 802.1X supplicant password, use the following command:

**dot1x supplicant password WORD**

#### **Syntax Description**

##### **dot1x supplicant password**

Configure 802.1X supplicant password

**WORD**

Set the 802.1X supplicant password

#### **Defaults**

None

#### **Example**

```
ruckus(config-apgrp-port) # dot1x supplicant password test123  
ruckus(config-apgrp-port) #
```

## dot1x supplicant mac

To set the 802.1X supplicant user name and password as the AP's MAC address, use the following command:

**dot1x supplicant mac**

### Syntax Description

**dot1x supplicant mac**

Set the supplicant user name and password as the AP's MAC address

### Defaults

None

### Example

```
ruckus(config-apgrp-port)# dot1x supplicant mac  
ruckus(config-apgrp-port)#[/pre]
```

## no dot1x

To disable 802.1X settings for an AP model, use the following command:

**no dot1x [ authsvr ] [ acctsvr ] [ mac-auth-bypass ]**

### Syntax Description

**no dot1x**

Disable dot1x settings for the AP

**authsvr**

Disable authentication server

**acctsvr**

Disable accounting server

**mac-auth-bypass**

Disable MAC authentication bypass

### Defaults

None

### Example

```
ruckus(config-apgrp-port)# no dot1x authsvr  
ruckus(config-apgrp-port)#[/pre]
```

## lan guest-vlan

To set the AP port to use the specified guest VLAN ID(1-4094), use the following command:

**lan NUMBER guest-vlan WORD**

## **Configuring Controller Settings**

### Configure AP Group Commands

#### **lan dylan**

To enable/disable dynamic VLAN for the AP port, use the following command:

**lan NUMBER dylan [ enabled | disabled ]**

#### **lan qos**

To set the AP port QoS settings, use the following command:

**lan NUMBER qos**

#### **lan qos mld-snooping**

To enable MLD snooping for the port, use the following command:

**lan NUMBER qos mld-snooping**

#### **lan qos igmp-snooping**

To enable IGMP snooping for the port, use the following command:

**lan NUMBER qos igmp-snooping**

#### **lan qos directed-mcast**

To enable Directed Multicast for the port, use the following command:

**lan NUMBER qos directed-mcast**

#### **no lan qos**

To disable QoS settings for the port, use the following command:

**no lan NUMBER qos**

#### **no lan qos mld-snooping**

To disable MLD snooping on the port, use the following command:

**no lan NUMBER qos mld-snooping**

#### **no lan qos igmp-snooping**

To disable IGMP snooping on the port, use the following command:

**no lan NUMBER qos igmp-snooping**

#### **no lan qos directed-mcast**

To disable Directed Multicast on the port, use the following command:

**no lan NUMBER qos directed-mcast**

**no dot1x**

To disable 802.1x settings for the port, use the following command:

**no dot1x**

**no dot1x authsvr**

To disable the authentication server settings, use the following command

**no dot1x authsvr**

**no dot1x acctsvr**

To disable the accounting server settings, use the following command:

**no dot1x acctsvr**

**no dot1x mac-auth-bypass**

To disable MAC authentication bypass, use the following command:

**no dot1x mac-auth-bypass**

## **external-antenna**

To configure the external antenna settings for all APs of the specified model within the AP group, use the following command:

**external-antenna <WORD>**

### **Syntax Description**

#### **external-antenna 2.4Ghz(11BG) enable**

Enables the external antenna setting for the 2.4GHz(11BG) radio.

#### **external-antenna 2.4Ghz(11BG) disable**

Disables the external antenna setting for the 2.4GHz(11BG) radio.

#### **external-antenna 2.4Ghz(11BG) gain**

Sets the external antenna gain for the 2.4GHz(11BG) radio.

#### **external-antenna 2.4Ghz(11BG) 2-antennas**

Selects the two external antennas for the 2.4GHz(11BG) radio.

#### **external-antenna 2.4Ghz(11BG) 3-antennas**

Selects the three external antennas for the 2.4GHz(11BG) radio.

#### **external-antenna 2.4Ghz(11NG) enable**

Enables the external antenna setting for the 2.4GHz(11NG) radio.

#### **external-antenna 2.4Ghz(11NG) disable**

Disables the external antenna setting for the 2.4GHz(11NG) radio.

#### **external-antenna 2.4Ghz(11NG) gain**

Sets the external antenna gain for the 2.4GHz(11NG) radio.

#### **external-antenna 2.4Ghz(11NG) 2-antennas**

Selects the two external antennas for the 2.4GHz(11NG) radio.

#### **external-antenna 2.4Ghz(11NG) 3-antennas**

Selects the three external antennas for the 2.4GHz(11NG) radio.

#### **external-antenna 5Ghz(11NA) enable**

Enables the external antenna setting for the 5GHz(11NA) radio.

#### **external-antenna 5Ghz(11NA) disable**

Disables the external antenna setting for the 5GHz(11NA) radio.

#### **external-antenna 5Ghz(11NA) gain**

Sets the external antenna gain for the 5GHz(11NA) radio.

#### **external-antenna 5Ghz(11NA) 2-antennas**

Selects the two external antennas for the 2.4GHz(11NA) radio.

#### **external-antenna 5Ghz(11NA) 3-antennas**

Selects the three external antennas for the 2.4GHz(11NA) radio.

#### **external-antenna 5Ghz(11A) enable**

Enables the external antenna setting for the 5GHz(11A) radio.

#### **external-antenna 5Ghz(11A) disable**

Disables the external antenna setting for the 5GHz(11A) radio.

**external-antenna 5Ghz(11A) gain**

Sets the external antenna gain for the 5GHz(11A) radio.

**external-antenna 5Ghz(11A) 2-antennas**

Selects the two external antennas for the 2.4GHz(11A) radio.

**external-antenna 5Ghz(11A) 3-antennas**

Selects the three external antennas for the 2.4GHz(11A) radio.

**power-mode**

To set the PoE mode of the AP, use the following command:

**model WORD power-mode WORD**

**Syntax Description**

**model WORD**

Set the AP model.

**power-mode**

Set the AP's PoE power mode.

**auto**

Set the power mode to Auto.

**802.3af**

Set the power mode to 802.3af.

**802.3at**

Set the power mode to 802.3at.

**Example**

```
ruckus (config-apgrp) # model R710 power-mode auto  
ruckus (config-apgrp) #
```

**no power-mode-override**

To disable the override of the PoE mode, use the following command:

**no model WORD power-mode-override**

**802.3af-txchain**

To set the number of 2.4 GHz radio transmit chains in 802.3af power mode for the AP, use the following command:

**model WORD 802.3af-txchain WORD**

**Syntax Description**

**model WORD**

Set the AP model.

## Configuring Controller Settings

### Configure AP Group Commands

#### 802.3af-txchain

Set the number of 2.4 GHz radio chains.

**1**

Set the radio chains to 1.

**2**

Set the radio chains to 2.

**4**

Set the radio chains to 4.

#### Example

```
ruckus(config-apgrp)# model R710 802.3af-txchain 1  
ruckus(config-apgrp)#[/pre]
```

#### no 802.3af-txchain-override

To disable the override of the 2.4 GHz radio transmit chains in 802.3af PoE mode, use the following command:

**no model WORD 802.3af-txchain-override**

## AP Group Membership

Use the following commands to configure AP group membership (move APs into or out of the current AP group, from within the **config-apgrp** context).

### **member**

Adds or moves the AP to the specified AP group.

**member [ add | move ] mac WORD [ system-default | name WORD ]**

#### **member add mac**

To add the AP to the specified AP group, use the following command:

**member add mac WORD**

#### **Example**

```
ruckus(config-apgrp)# member add mac c4:10:8a:1f:d1:f0
ruckus(config-apgrp)# show
APGROUP:
ID:
:
Name= apgroup2
Description=
Channel Range:
B/G/N= 1,2,3,4,5,6,7,8,9,10,11 (Disallowed= )
A/N Indoor= 36,40,44,48,149,153,157,161 (Disallowed= )
A/N Outdoor= 36,40,44,48,149,153,157,161 (Disallowed= )
Radio 11bgn:
Channelization= Auto
Channel= Auto
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Call Admission Control= OFF
SpectralLink Compatibility= Disabled
Radio 11an:
Channelization= Auto
Indoor Channel= Auto
Outdoor Channel= Auto
Tx. Power= Auto
11N only Mode= Auto
WLAN Group= Default
Call Admission Control= OFF
SpectralLink Compatibility= Disabled
Network Setting:
Protocol mode= Use Parent Setting
Turn off channfly setting: disabled
if AP's uptime is more than 30 minutes will turn off AP's ChannelFly
Members:
MAC= c4:10:8a:1f:d1:f0

ruckus(config-apgrp) #
```

#### **member mac move-to system-default**

To move the AP from the current AP group to the System Default AP group, use the following command:

**member mac WORD move-to system-default**

## Configuring Controller Settings

### Configure AP Group Commands

#### Example

```
ruckus(config-apgrp)# member mac c4:10:8a:1f:d1:f0 move-to system-default  
ruckus(config-apgrp)#[/pre]
```

#### **member mac move-to name**

To move the AP from the current AP group to the specified AP group, use the following command:

**member mac WORD move-to name WORD**

#### Example

```
ruckus(config-apgrp)# member mac c4:10:8a:1f:d1:f0 move-to name apgroup2  
ruckus(config-apgrp)#[/pre]
```

## LLDP Commands

To enable, disable or configure the Link Layer Discovery Protocol (LLDP) commands for the AP group, use the following commands from within the **config-apgrp** context.

### **lldp**

To enable, disable or configure the AP group's Link Layer Discover Protocol settings, use the following commands.

#### Syntax Description

##### **lldp**

Configure LLDP settings.

##### **enable**

Enable LLDP with current settings.

##### **disable**

Disable LLDP with current settings.

##### **interval NUMBER**

Set packet transmit interval in second(s).

##### **holdtime NUMBER**

Set amount of time receiving device should retain the information.

##### **ifname eth NUMBER**

Enter the AP port number.

##### **mgmt enable**

Enable LLDP management IP address of the AP.

##### **mgmt disable**

Disable LLDP management IP address of the AP.

#### Example

```
ruckus(config-apgrp) # lldp enable  
ruckus(config-apgrp) #
```

## Configuring Controller Settings

### Configure AP Group Commands

#### **no lldp**

To allow ZoneDirector to modify AP's LLDP settings, use the following command:

```
no lldp keep-ap-settings
```

#### Syntax Description

```
no lldp keep-ap-settings
```

#### Example

```
ruckus(config-ap)# no lldp keep-ap-setting  
ruckus(config-ap)#{
```

## **lldp keep-ap-setting**

To not let the controller modify the AP's LLDP settings, use the following command:

**lldp keep-ap-setting**

### **Example**

```
ruckus(config-apgrp)# lldp keep-ap-setting  
ruckus(config-apgrp)#{}
```

## Configuring Controller Settings

### Configure AP Group Commands

#### **no lldp keep-ap-setting**

To allow the controller to modify the AP's LLDP settings, use the following command:

**no lldp keep-ap-setting**

#### Example

```
ruckus(config-apgrp)# no lldp keep-ap-setting  
ruckus(config-apgrp)#[/pre]
```

# Configure Certificate Commands

Use the **config-certificate** commands to restore the default ZoneDirector certificate or to regenerate the private key. To run these commands, you must first enter the **config-certificate** context.

## quit

Exits the certificate settings context without saving changes.

## restore

To restore the default ZoneDirector certificate and private key, use the following command.

**restore**

### Syntax Description

**restore**

Restore the default ZoneDirectory certificate and private key. The restore process will be completed after ZoneDirector is rebooted.

### Defaults

None.

### Example

```
ruckus (config-certificate) # restore  
ZoneDirector will restart now to apply the changes in the certificate settings. If you want to  
configure other settings, log in again after ZoneDirector has completed restarting.
```

## re-generate-private-key

To regenerate the ZoneDirector private key, use the following command:

**re-generate-private-key {1024 | 2048}**

### Syntax Description

**re-generate-private-key**

Regenerate the ZoneDirector private key

**{1024 | 2048}**

Specify the length of the private key as either 1024 or 2048.

### Defaults

None.

## Configuring Controller Settings

### Configure Certificate Commands

#### Example

```
ruckus(config-certificate)# re-generate-private-key 1024
ZoneDirector will restart now to apply the changes in the certificate settings. If you want to
configure other settings, log in again after ZoneDirector has completed restarting.
The operation doesn't execute successfully. Please try again.
```

# Configure Hotspot Redirect Settings

To configure Hotspot redirect settings, use the following command:

## hotspot\_redirect\_https

To enable Hotspot redirect, use the following command:

```
hotspot_redirect_https
```

### Defaults

None.

### Example

```
ruckus(config)# hotspot_redirect_https  
/bin/hotspot_redirect_https enable  
ruckus(config)#End
```

## no hotspot\_redirect\_https

To disable Hotspot redirect, use the following command:

```
no hotspot_redirect_https
```

### Defaults

None.

### Example

```
ruckus(config)# no hotspot_redirect_https  
/bin/hotspot_redirect_https disable  
ruckus(config)#End
```

## no blocked-client

To remove a blocked client from the blocked clients list, use the following command:

```
no blocked-client MAC
```

### Defaults

None.

### Example

```
ruckus(config)# no blocked-client dc:2b:61:13:f7:72  
The L2 ACL 'dc:2b:61:13:f7:72' has been deleted.  
ruckus(config)#End
```

## Configuring Controller Settings

### Configure Layer 2 Access Control Commands

# Configure Layer 2 Access Control Commands

Use the layer2 access control commands to configure the Layer 2 Access Control List settings. To run these commands, you must first enter the **config-l2acl** context.

## acl

To create a new L2 ACL entry or update an existing entry, use the following command:

**acl WORD**

### Syntax Description

**acl**

Create a new ACL

**WORD**

Assign this name to the new ACL

### Defaults

None.

### Example

```
ruckus(config)# l2acl l2acl1  
The L2 ACL entry 'l2acl1' has been created.  
ruckus(config-l2acl)#[/pre]
```

## no acl

To delete an L2 ACL, use the following command:

**no acl WORD**

### Syntax Description

**no acl**

Delete an existing ACL

**WORD**

Delete this ACL

### Defaults

None.

### Example

```
ruckus(config)# no l2acl l2acl1  
The L2 ACL 'l2acl1' has been deleted.  
ruckus(config)#[/pre]
```

## abort

To exit the config-l2acl context without saving changes, use the following command:

**abort**

## end

To save changes, and then exit the config-l2acl context, use the following command:

**end**

### *Example*

```
ruckus(config-l2acl)# end  
The L2 ACL entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#[/pre]
```

## exit

To save changes, and then exit the config-l2acl context, use the following command:

**exit**

### *Example*

```
ruckus(config-l2acl)# exit  
The L2 ACL entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#[/pre]
```

## quit

To exit the config-l2acl context without saving changes, use the following command:

**quit**

### *Example*

```
ruckus(config-l2acl)# quit  
No changes have been saved.  
ruckus(config)#[/pre]
```

## show

To displays the L2 ACL settings, use the show command. You must run this command from within the config-l2acl context.

**show**

### *Example*

```
ruckus(config-l2acl)# show  
L2/MAC ACL:[/pre]
```

## Configuring Controller Settings

### Configure Layer 2 Access Control Commands

```
ID:  
:  
Name= l2acl1  
Description=  
Restriction= Deny only the stations listed below  
Stations:  
    MAC Address= 00:11:22:33:44:55  
  
ruckus(config-l2acl) #
```

## name

To rename an L2 ACL entry, use the following command:

```
name WORD
```

### Syntax Description

**name**

Sets the L2 ACL entry name.

**WORD**

Rename the ACL to this name.

### Defaults

None.

### Example

```
ruckus(config) # l2acl l2acl1  
The L2 ACL entry 'l2acl1' has been created.  
ruckus(config-l2acl) # name L2-ACL-1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-l2acl) #
```

## description

To set the description of an L2 ACL entry, use the following command (multiple word text must be enclosed in quotation marks):

```
description WORD
```

### Syntax Description

**description** WORD

Set the L2 ACL description.

### Defaults

None.

### Example

```
ruckus(config) # l2acl l2acl1  
The L2 ACL entry 'l2acl1' has been created.
```

```
ruckus(config-l2acl)# description "L2 ACL 1"  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-l2acl)#[/pre]
```

## add-mac

To add a MAC address to the L2 ACL, use the following command:

```
add-mac MAC
```

### Syntax Description

**add mac**

Add a MAC address to the ACL

**MAC**

Add this MAC address

### Defaults

None.

### Example

```
ruckus(config-l2acl)# add-mac 00:11:22:33:44:55  
The station '00:11:22:33:44:55' has been added to the ACL.  
ruckus(config-l2acl)#[/pre]
```

## mode allow

To set the ACL mode to 'allow', use the following command:

```
mode allow
```

### Syntax Description

**mode allow**

Set the ACL mode to allow

### Defaults

None.

### Example

```
ruckus(config-l2acl)# mode allow  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-l2acl)#[/pre]
```

## mode deny

To set the ACL mode to 'deny', use the following command:

## Configuring Controller Settings

### Configure Layer 2 Access Control Commands

**mode deny**

#### Syntax Description

**mode deny**

Set the ACL mode to deny

#### Defaults

None.

#### Example

```
ruckus(config-l2acl)# mode deny  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-l2acl)#[/pre]
```

## del-mac

To delete a MAC address from an L2 ACL, use the following command:

**del-mac MAC**

#### Syntax Description

**del-mac**

Delete a MAC address from the ACL

**MAC**

**Delete this MAC**

#### Defaults

None.

#### Example

```
ruckus(config-l2-acl)# del-mac 00:01:02:34:44:55  
The station '00:01:02:34:44:55' has been removed from the ACL.  
ruckus(config-l2-acl)# del-mac 00:01:02:34:44:55  
The station '00:01:02:34:44:55' could not be found. Please check the spelling, and then try again.[/pre]
```

# Configure Layer 3 Access Control Commands

Use the **l3acl** commands to configure the Layer 3 Access Control List settings. To run these commands, you must first enter the **config-l3acl** or **config-l3acl-ipv6** context.

## **l3acl**

To enter the config-l3acl context, run this command:

**l3acl WORD**

### **Syntax Description**

**l3acl**

Create or configure a Layer 3 Access Control List

**WORD**

Name of the L3 ACL

### **Defaults**

None.

### **Example**

```
ruckus(config)# l3acl "ACL 1"  
The L3/L4/IP ACL entry 'ACL 1' has been created.  
ruckus(config-l3acl) #
```

## **no l3acl**

To delete an L3/L4 ACL entry, use the following command:

**no l3acl WORD**

### **Syntax Description**

**no l3acl**

Delete a Layer 3 ACL

**WORD**

Name of the L3 ACL

### **Defaults**

None.

### **Example**

```
ruckus(config)# no l3acl "ACL test"  
The L3/L4/IP ACL 'ACL test' has been deleted.  
ruckus(config) #
```

## Configuring Controller Settings

Configure Layer 3 Access Control Commands

## l3acl-ipv6

To enter the config-l3acl-ipv6 context, run this command:

**l3acl-ipv6 WORD**

### Syntax Description

**l3acl-ipv6**

Create or configure a Layer 3 Access Control List

**WORD**

Name of the L3 ACL

### Defaults

None.

### Example

```
ruckus(config)# l3acl-ipv6 "ACL 2"  
The L3/L4/IPv6 ACL entry 'ACL 2' has been created.  
ruckus(config-l3acl-ipv6)#[/pre]
```

## no l3acl-ipv6

To disable Layer 3/4 IPv6 ACLs, use the following command:

**no l3acl-ipv6**

## abort

To exit the config-l3acl context without saving changes, use the following command:

**abort**

### Example

```
ruckus(config-l3acl)# abort  
No changes have been saved.  
ruckus(config)#[/pre]
```

## end

To save changes, and then exit the config-l3acl context, use the following command:

**end**

### Example

```
ruckus(config-l3acl)# end  
The L3/L4/IP ACL entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#[/pre]
```

## exit

To save changes, and then exit the config-l3acl context, use the following command:

**exit**

### Example

```
ruckus# config-l3acl  
ruckus(config-l3acl)# exit  
Your changes have been saved.
```

## quit

To exit the config-l3acl context without saving changes, use the following command:

**quit**

### Example

```
ruckus(config-l3acl)# quit  
No changes have been saved.  
ruckus(config)#
```

## show

To display the L3ACL settings, use the show command. You must run this command from within the config-l3acl context.

**show**

### Example

```
ruckus(config-l3acl)# show  
L3/L4/IP ACL:  
ID:  
3:  
Name= test_newname  
Description= justfortestCLI  
Default Action if no rule is matched= Deny all by default  
Rules:  
Order= 1  
Description=  
Type= Allow  
Destination Address= Any  
Destination Port= 53  
Protocol= Any  
Order= 2  
Description=  
Type= Allow  
Destination Address= Any  
Destination Port= 67  
Protocol= Any
```

## name

To set the name of an L3/L4/IP ACL entry, use the following command:

**name WORD**

## Configuring Controller Settings

### Configure Layer 3 Access Control Commands

#### Syntax Description

##### **name**

Set the name of an L3/L4/IP ACL entry

##### **WORD**

Name of the L3/L4/IP ACL entry

#### Defaults

None.

#### Example

```
ruckus(config-l3acl)# name test_newname  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## description

To set the description of an L3/L4/IP ACL entry, use the following command (multiple word text must be enclosed in quotes):

##### **description WORD**

#### Syntax Description

##### **description**

Set the L3/L4/IP ACL entry description

##### **WORD**

Set to this description

#### Defaults

None.

#### Example

```
ruckus(config-l3acl)# description justfortestCLI  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## mode allow

To set the ACL mode to 'allow', use the following command:

##### **mode allow**

#### Syntax Description

##### **mode**

Set the ACL mode

##### **allow**

Set the mode to 'allow'

## Defaults

None.

## Example

```
ruckus(config-l3acl)# mode allow  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## mode deny

To set the ACL mode to 'deny', use the following command:

**mode deny**

## Syntax Description

**mode**

Set the ACL mode

**deny**

Set the mode to 'deny'

## Defaults

None.

## Example

```
ruckus(config-l3acl)# mode deny  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## rule-order

To create or modify a rule in the L3/L4/IP ACL, use the following command:

**rule-order NUMBER**

## Syntax Description

**rule-order**

Create a new rule or modify an existing one

**NUMBER**

Create or modify this rule ID

## Defaults

None.

## **Configuring Controller Settings**

### Configure Layer 3 Access Control Commands

#### **Example**

For example, to set the current rule as the third ACL rule to apply, use the following command:

```
ruckus(config-l3acl)# rule-order 3  
ruckus(config-l3acl-rule) #
```

### **source address**

To set the source address of a L3/L4/IP ACL rule, use the following command:

**source address <IP-ADDR/WORD>**

#### **Example**

```
ruckus(config-l3acl-rule)# source address 192.168.0.1/24
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-l3acl-rule)#

```

## Configuring Controller Settings

### Configure Layer 3 Access Control Commands

#### source port

To set the source port of a L3/L4/IP ACL rule, use the following command:

```
source port <NUMBER/WORD>
```

#### Example

```
ruckus(config-l3acl-rule)# source port 880
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-l3acl-rule)#+
```

#### no rule-order

To delete a rule from the L3/L4/IP ACL, use the following command:

```
no rule-order NUMBER
```

#### Syntax Description

**no rule-order**

Delete a rule from the L3/L4/IP ACL

**NUMBER**

Delete this rule ID

#### Defaults

None.

#### Example

```
ruckus(config-l3acl)# no rule-order 3
The rule '3' has been removed from the ACL.
```

# Layer 3 Access Control Rule Commands

Use the **l3acl-rule** commands to configure the Layer 3/Layer 4/IP Access Control List rules. To run these commands, you must first enter the **config-l3acl-rule** context. To enter the **config-l3acl-rule** context, run this command:

**rule-order NUMBER**

## end

To save changes, and then exit the config-l3acl-rule context, use the following command:

**end**

## exit

To save changes, and then exit the config-l3acl-rule context, use the following command:

**exit**

## order

To set the L3/L4/IP ACL rule order, use the following command:

**order NUMBER**

### Example

```
ruckus(config-l3acl-rule)# order 1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-l3acl-rule) #
```

## description

To set the description of an L3/L4/IP ACL rule, use the following command (multiple word text must be enclosed in quotes):

**description WORD**

### Syntax Description

#### **description**

Set the L3/L4/IP ACL rule description

**WORD**

Set to this description

### Defaults

None.

## **Example**

```
ruckus(config-l3acl-rule)# description thirdl3rule  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **type allow**

To set the ACL rule type to 'allow', use the following command:

```
type allow
```

### **Syntax Description**

**type**  
Set the ACL rule type

**allow**  
Set the rule type to 'allow'

### **Defaults**

None.

## **Example**

```
ruckus(config-l3acl-rule)# type allow  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **type deny**

To set the ACL rule type to 'deny', use the following command:

```
type deny
```

### **Syntax Description**

**type**  
Set the ACL rule type

**deny**  
Set the rule type to 'deny'

### **Defaults**

None.

## **Example**

```
ruckus(config-l3acl-rule)# type deny  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## destination address

To set the destination address of the rule, use the following command:

**destination address IP-ADDR/WORD**

### Syntax Description

**destination address**

Set the destination address of the rule

**IP-ADDR/WORD**

Set the destination to this IP address

### Defaults

None.

### Example

```
ruckus(config-l3acl-rule)# destination address 192.168.1.22  
The destination IP address is invalid. Please enter 'Any' or check the IP address(for example:  
192.168.0.1/24), and then please try again.  
ruckus(config-l3acl-rule)# destination address 192.168.1.22/24  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## destination port

To set the destination port of the rule, use the following command:

**destination port NUMBER/WORD**

### Syntax Description

**destination port**

Set the destination port of the rule

**NUMBER/WORD**

Set the destination to this port number

### Defaults

None.

### Example

```
ruckus(config-l3acl-rule)# destination port 580  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## protocol

To set the protocol for the rule, use the following command:

## Configuring Controller Settings

### Layer 3 Access Control Rule Commands

**protocol** NUMBER/WORD

#### Syntax Description

**protocol**

Set the protocol for the rule

NUMBER/WORD

Set to this protocol

#### Defaults

None.

#### Example

```
ruckus(config-l3acl-rule)# protocol tcp  
The protocol must be a number between 0 and 254.  
ruckus(config-l3acl-rule)# protocol Any  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## show

To display L3/L4/IP ACL settings, use the following command:

**show**

#### Example

```
ruckus(config-l3acl)# show  
L3/L4/IP ACL:  
ID:  
:  
Name= l3acl1  
Description=  
Default Action if no rule is matched= Deny all by default  
Rules:  
1:  
    Description=  
    Type= Allow  
    Destination Address= 192.168.1.22/24  
    Destination Port= 53  
    Protocol= Any  
2:  
    Description=  
    Type= Allow  
    Destination Address= Any  
    Destination Port= 67  
    Protocol= Any  
ruckus(config-l3acl) #
```

# Layer 3 IPv6 Access Control List Commands

Use the **l3acl-ipv6** command to configure the IPv6 Layer 3/Layer 4/IP Access Control List. To run these commands, you must first enter the **config-l3acl** context.

## **l3acl-ipv6**

To enter the **config-l3acl-ipv6** context, run this command:

**l3acl-ipv6 WORD**

## **abort**

Exits the **config-l3acl-ipv6** context without saving changes.

## **end**

Saves changes, and then exits the **config-l3acl-ipv6** context.

## **exit**

Saves changes, and then exits the **config-l3acl-ipv6** context.

## **quit**

Exits the **config-l3acl-ipv6** context without saving changes.

## **name**

Sets the L3/L4/IPv6 ACL entry name.

## **description**

Sets the L3/L4/IPv6 ACL entry description.

## **mode allow**

Sets the ACL mode to 'allow'.

## **mode deny**

Sets the ACL mode to 'deny'.

## **no rule-order**

Deletes a rule name from the L3/L4/IPv6 ACL.

## rule-order

Creates a new L3/L4/IPv6 ACL rule or modifies an existing entry rule.

# Configure L3 IPv6 Rule Commands

Use the **l3acl-ipv6-rule** commands to configure the IPv6 Layer 3/Layer 4/IP Access Control List rules. To run these commands, you must first enter the **config-l3acl-ipv6-rule** context. To enter the **config-l3acl-ipv6-rule** context, run this command:

**rule-order NUMBER**

## end

Saves changes, and then exits the config-l3acl-ipv6-rule context.

## exit

Saves changes, and then exits the config-l3acl-ipv6-rule context.

## order

Sets the L3/L4/IPv6 ACL rule order.

## description

Sets the L3/L4/IPv6 ACL rule description.

## type allow

Sets the ACL rule type to 'allow'.

## type deny

Sets the ACL rule type to 'deny'.

## destination

Contains commands that can be executed from within the context.

## destination address

Sets the destination address of a L3/L4/IPv6 ACL rule.

## destination port

Sets the destination port of a L3/L4/IPv6 ACL rule.

## protocol

Sets the protocol of a L3/L4/IPv6 ACL rule.

## **icmpv6-type Any**

Sets the icmpv6 type of a L3/L4/IPv6 ACL rule.

## **icmpv6-type number**

Sets the icmpv6 type of a L3/L4/IPv6 ACL rule.

## **show**

Displays L3/L4/IPv6 ACL settings.

# Configure Precedence Policy Commands

Use the **prece** commands to configure precedence policy settings. Precedence policies are used to define the order in which VLAN and rate limiting policies are applied when the WLAN settings, AAA server configuration or Device Policy settings conflict.

To run these commands, you must first enter the **config-prece** context.

## prece

To create or modify a precedence policy, use the following command:

**prece WORD**

Enters the config-prece context. To save changes and exit the context, type exit or end. To exit the context without saving changes, type abort.

### *Example*

```
ruckus(config)# prece precedence1  
The Precedence Policy entry 'precedence1' has been created.  
ruckus(config-prece) #
```

## no prece

To delete a precedence policy entry, use the following command:

**no prece WORD**

## end

To save changes, and then exit the config-prece context, use the following command:

**end**

### *Example*

```
ruckus(config-prece)# end  
The Precedence Policy entry has saved successfully.  
Your changes have been saved.  
ruckus(config) #
```

## exit

To save changes, and then exit the config-prece context, use the following command:

**exit**

### *Example*

```
ruckus(config-prece)# exit  
The Precedence Policy entry has saved successfully.  
Your changes have been saved.  
ruckus(config) #
```

## Configuring Controller Settings

### Configure Precedence Policy Commands

## quit

To exit the config-prece context without saving changes, use the following command:

**quit**

### *Example*

```
ruckus(config-prece)# quit  
No changes have been saved.  
ruckus(config)#
```

## name

Sets the Precedence Policy entry name.

## description

Sets the Precedence Policy entry description.

## show

To display the precedence settings, use the show command from within the config-prece context.

**show**

### *Example*

```
ruckus(config-prece)# show  
Precedence Policy:  
ID:  
 2:  
    Name= precedence1  
    Description=  
    Rules:  
      1:  
        Description=  
        Attribute = vlan  
        Order = AAA,Device Policy,WLAN  
      2:  
        Description=  
        Attribute = rate-limit  
        Order = AAA,Device Policy,WLAN  
ruckus(config-prece) #
```

## Configure Precedence Policy Rule Commands

Use the following commands to configure precedence policy rules.

### **rule**

Creates a new Precedence Policy rule or modifies an existing entry rule. Enters the config-prece-rule context.

**rule NUMBER**

### Syntax Description

#### **rule**

Create a rule and enter the rule creation context.

#### **NUMBER**

Enter the rule number (1-2). Each precedence policy can have up to two rules.

#### **description**

Sets the Precedence Policy rule description.

#### **order WORD**

Sets the order of a Precedence Policy rule. The default order is AAA, Device Policy, WLAN.

#### **show**

Displays precedence policy settings.

### Example

```
ruckus(config)# prece precedence1
The Precedence Policy entry 'precedence1' has been created.
ruckus(config-prece)# rule 1
ruckus(config-prece-rule)# order "Device Policy" "WLAN" "AAA"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-prece-rule)# end
ruckus(config-prece)# show
Precedence Policy:
  ID:
  :
  Name= precedence1
  Description=
  Rules:
    1:
      Description=
      Attribute = vlan
      Order = Device Policy,WLAN,AAA
    2:
      Description=
      Attribute = rate-limit
      Order = AAA,Device Policy,WLAN

ruckus(config-prece)#
ruckus(config-prece)# end
The Precedence Policy entry has saved successfully.
Your changes have been saved.
```

## Configuring Controller Settings

### Configure Precedence Policy Commands

#### **description**

To set the Precedence Policy rule description, use the following command:

**description**

#### **Example**

```
ruckus(config-prece-rule)# description "Default precedence policy"  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-prece-rule)#[/pre]
```

#### **order**

To set the order of the precedence policy, use the following command from within the config-prece-rule context.

**order <WORD>**

#### **Syntax Description**

<WORD>: Enter the order of Precedence Policy (for example, "AAA" "Device Policy" "WLAN").

#### **Example**

```
ruckus(config-prece-rule)# order "AAA" "Device Policy" "WLAN"  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-prece-rule)#[/pre]
```

# Configure Device Policy Commands

Use the device policy commands to configure access control and rate limiting policies based on client type. To run these commands, you must first enter the **config-dvc-pcy** context.

## dvcpcy

To create a device policy or edit an existing device policy, enter the following command:

**dvcpcy WORD**

### Syntax Description

**show**

Display device policy settings.

**name WORD**

Set the device policy entry name.

**description WORD**

Sets the device policy entry description.

**mode WORD**

Sets the device policy entry default mode (allow or deny).

**no NUMBER**

Delete a rule.

**rule NUMBER**

Create or modify a rule. Enter the config-dvc-pcy-rule context. You can create up to nine rules per access policy (one for each OS/Type).

### Defaults

None.

### Example

```
ruckus(config)# dvcpcy devpcy1
The Device Policy entry 'devpcy1' has been loaded. To save the Device Policy entry, type end or exit.
ruckus(config-dvc-pcy)# name device_policy_1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy)# description "deny ios"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy)# rule 1
ruckus(config-dvc-pcy-rule)# type deny
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# devinfo "Apple IOS"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# vlan none
The command was executed successfully. To save the changes, type 'end' or 'exit'.

ruckus(config-dvc-pcy-rule)# rate-limit uplink 10 downlink 10
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# end
ruckus(config-dvc-pcy)# show
Device Policy:
ID:
```

## Configuring Controller Settings

### Configure Device Policy Commands

```
1:
  Name= device_policy_1
  Description= deny iOS
  Default Mode= deny
  Rules:
    1:
      Description=
      OS/Type = Apple iOS
      Type= deny
      VLAN = Any
      Rate Limiting Uplink = 10.00Mbps
      Rate Limiting Downlink = 10.00Mbps

ruckus(config-dvc-pcy)# end
The Device Policy entry has saved successfully.
Your changes have been saved.
ruckus(config)# show dvcpcy
Device Policy:
  ID:
  2:
    Name= device_policy_1
    Description= deny iOS
    Default Mode= deny
    Rules:
      1:
        Description=
        OS/Type = Apple iOS
        Type= deny
        VLAN = Any
        Rate Limiting Uplink = 10.00Mbps
        Rate Limiting Downlink = 10.00Mbps

ruckus(config)#

```

## no dvcpcy

To delete a device policy, use the following command:

**no dvcpcy WORD**

## rule

Use the rule command from within the config-dvc-pcy context to create or edit a device policy rule and enter the config-dvc-pcy-rule context. Up to 9 rules can be created per device policy.

### Syntax Description

**rule**

Create or edit a device policy rule. Enter the config-dvc-pcy-rule context.

**description WORD**

Set the Device Policy rule description.

**dvtctype WORD**

Sets the device type of a Device Policy rule.

**osvendor WORD**

Sets the os vendor of a Device Policy rule.

**type WORD**

Set the device policy rule type (allow or deny).

**vlan NUMBER**

Set the VLAN ID to the number specified or “none.”

**rate-limit uplink NUMBER downlink NUMBER**

Set the rate limiting uplink and downlink speeds in mbps.

**no rate-limit**

Set rate limiting to disabled.

**Example**

```
ruckus(config-dvc-pcy)# rule 2
ruckus(config-dvc-pcy-rule)# description "rate limit gaming devices"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# devinfo "Gaming"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# type allow
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# vlan none
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# rate-limit uplink 0.1 downlink 0.1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule)# end
ruckus(config-dvc-pcy)# show
Device Policy:
ID:
2:
Name= device_policy_1
Description= deny iOS
Default Mode= deny
Rules:
1:
Description=
OS/Type = Apple iOS
Type= deny
VLAN = Any
Rate Limiting Uplink = 10.00Mbps
Rate Limiting Downlink = 10.00Mbps
2:
Description= rate limit gaming devices
OS/Type = Gaming
Type= allow
VLAN = Any
Rate Limiting Uplink = 0.10Mbps
Rate Limiting Downlink = 0.10Mbps
ruckus(config-dvc-pcy)#

```

## Configuring Controller Settings

### Configure Application Policy Commands

# Configure Application Policy Commands

Use the following commands to create or modify application policies.

## app-policy

To create a new application policy or modify an existing policy, use the following command:

**app-policy WORD**

### Syntax Description

**app-policy:** Creates a new Application Policy entry or modifies an existing entry.

**<WORD>:** Enter a name for the application policy.

### Example

```
ruckus(config)# app-policy policy1  
The Application Policy entry 'policy1' has been created.  
ruckus(config-app-policy)#[/pre]
```

## no app-policy

To delete an Application Policy entry, use the following command:

**no app-policy WORD**

### Example

```
ruckus(config)# no app-policy policy1  
The Application Policy 'policy1' has been deleted.  
ruckus(config)#[/pre]
```

## description

To set the description for the policy, use the following command:

**description <WORD>**

### Example

```
ruckus(config-app-policy)# description "Block Facebook"  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-app-policy)#[/pre]
```

## show

To display the application policy settings, use the show command from within the config-app-policy context.

**show**

### Example

```
ruckus(config-app-policy)# show  
Application Policy:  
ID:  
:  
Name= policy1  
Description=  
Rules:  
1:  
    Rule Type= Denial Rules  
    Application Type= System Defined  
    Category= Social networks  
    Application= Facebook  
ruckus(config-app-policy)#[/pre]
```

## Configuring Controller Settings

Configure Application Policy Commands

# Configure Application Policy Rules

Use the following commands to configure application policy rules.

## rule

Creates a new application policy rule or modifies an existing entry. Enters the *config-app-policy-rule* context.

**rule NUMBER**

### Syntax Description

**rule:** Create or modify an application policy rule.

**<NUMBER>:** Enter a rule ID.

### Example

```
ruckus (config-app-policy) # rule 1  
ruckus (config-app-policy-rule) #
```

## no rule

To delete a rule, use the following command:

**no rule NUMBER**

## rule-type

To set the application policy rule type, use the following command:

**rule-type<WORD>**

### Syntax Description

**rule-type:** Sets Application Policy rule type.

**<WORD>:** Enter rule type(Denial Rules | QoS | Rate Limiting).

### Example

```
ruckus (config-app-policy-rule) # rule-type Denial Rules  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus (config-app-denial-rule) #
```

## application-type

To set the application type, use the following command:

**application-type<WORD>**

### Syntax Description

**application-type:** Sets Application Policy rule application type.

<WORD>: Enter application type ("System Defined" or "Port base User Defined Application" or "IP base User Defined Application" or "Application name").

### Example

```
ruckus(config-app-denial-rule)# application-type System Defined  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-app-denial-rule) #
```

### category

To set the application category, use the following command:

```
category<WORD>
```

### Syntax Description

category: Sets Application Policy rule application category.

<LIST>: Enter application name: [Instant messengers|Peer-to-peer networks|File sharing services and tools|Media streaming services|Email messaging services|VoIP services|Database tools|Online games|Management tools and protocols|Remote access terminals|Tunneling and proxy services|Investment platforms|Web services|Security update tools|Web instant messengers|Business tools|Network protocols (18)|Network protocols (19)|Network protocols (20)|Private protocols|Social networks]

### Example

```
ruckus(config-app-denial-rule)# category Social networks  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-app-denial-rule) #
```

### application

To set the application, use the following command:

```
application<WORD>
```

### Syntax Description

category: Sets Application Policy rule application name.

<LIST>: |Classmates|Yik Yak|Facebook|Flickr|Hi5|LinkedIn|Livejournal|Twitter|Plurk|MySpace|Khan Academy|Pinterest|Tumblr|MeetMe|VKontakte|Odnoklassniki|Niwota|Tagged|PerfSpot|Me2day|Mekusharim|Draugiem|Badoo|Meetup|Foursquare|Ning|i-Part/iPair|Dudu|Mig33|Hatena|eHarmony|Fotolog|Tencent QQ|Pixnet|Nk.PI|Twoo|Plaxo|Cyworld|Jivesoftware|WordPress|FMyLife|Dcinside|Class Chinaren|BaiSohu|Yammer|Douban|Gamer|Xuite|ChatMe|Clien.net|AdultFriendFinder|Fling.com|Delicious|Mei.fm|Streetlife|Daum-blog|Naver-blog|Panoramio|Blogger|FC2|Yahoo Blog|Friendster|Ameba|Bebo social network|Kaixin|Orkut|Aol-Answers|CoolTalk social network|RenRen.com|TweetDeck|Hootsuite|Xing|Lokalisten|meinVZ/studiVZ|Viadeo|Tuenti|Hyves|Mixi.jp|Yahoo-mbga.jp|GREE|Netlog|2ch|LoveTheseCurves|Weibo|Google+|Skyrock|51.com|Jackd|Touch|Skout|Instagram|Jiayuan|Zoosk|DatingDNA|500px|iAround|pairs|Path|WeHeartIt|Fancy|Vine|SnappyTV|Miliao|After School|Weico|

### Example

```
ruckus(config-app-denial-rule)# application Facebook  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-app-denial-rule) #
```

# Configuring User-Defined Applications

Use the following commands to configure user-defined IP-based applications. Once created, user-defined applications can be controlled using the application policy commands.

## user-app-ip

To configure IP-based user-defined application settings, and enter the config-user-app-ip context, use the following command:

**user-app-ip**

### *Example*

```
ruckus(config)# user-app-ip Application1  
The User Defined Application entry Application1 has been created.  
ruckus(config-user-app-ip)#[/pre]
```

## no user-app-ip

To delete a user-defined application entry, use the following command:

**no user-app-ipWORD**

### *Example*

```
ruckus(config)# no user-app-ip Application1  
The policy 'Application1' has been removed .  
ruckus(config)#[/pre]
```

## abort

Exits the config-user-app-ip context without saving changes.

## end

Saves changes, and then exits the config-user-app-ip context.

## exit

Saves changes, and then exits the config-user-app-ip context.

## destination-IP

To set the destination address of a user-defined application entry, use the following command:

**destination-IP IP-ADDR**

## **Example**

```
ruckus(config-user-app-ip) # destination-IP 192.168.40.3  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-ip) #
```

## **netmask**

To set the netmask of a user-defined application, use the following command:

**netmask IP-ADDR**

## **Example**

```
ruckus(config-user-app-ip) # netmask 255.255.255.0  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-ip) #
```

## **destination-port**

To set the destination port of a user-defined Application, use the following command:

**destination-port NUMBER**

## **Example**

```
ruckus(config-user-app-ip) # destination-port 883  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-ip) #
```

## **protocol**

To set the protocol of a user-defined application, use the following command:

**protocol WORD**

## **Example**

```
ruckus(config-user-app-ip) # protocol tcp  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-ip) #
```

## **application-name**

To set the name the application, use the following command:

**application WORD**

## **Example**

```
ruckus(config-user-app-ip) # application-name Blocked-Application-1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-ip) #
```

## Configuring Controller Settings

### Configuring User-Defined Applications Based on Port Mapping

# Configuring User-Defined Applications Based on Port Mapping

Use the following commands to configure user-defined applications based on port mapping. Once configured, these user-defined applications can be controlled using the application policy commands.

## user-app-port

Configures port-based user-defined application settings. Enters config-user-app-port context.

### Example

```
ruckus(config)# user-app-port Application2  
The Application Port Mapping entry Application2 has been created.  
ruckus(config-user-app-port)#End
```

## no user-app-port

To delete a port-based user-defined application, use the following command:

**no user-app-port WORD**

### Example

```
ruckus(config)# no user-app-port userapp1  
The policy 'userapp1' has been removed .  
ruckus(config)#
```

## abort

Exits the config-user-app-port context without saving changes.

## end

Saves changes, and then exits the config-user-app-port context.

## exit

Saves changes, and then exits the config-user-app-port context.

## port

To set the Port of the port-based application, use the following command:

**port NUMBER**

### Example

```
ruckus(config-user-app-port)# port 443  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-port)#[/pre>
```

## protocol

To set the Protocol for the port-based user-defined Application, use the following command:

**protocol WORD**

### Example

```
ruckus(config-user-app-port)# protocol tcp  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-port)#[/pre>
```

## application-name

To set the application name, use the following command:

**application-name<WORD>**

### Example

```
ruckus(config-user-app-port)# application-name Application2  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-user-app-port)#[/pre>
```

## Configuring Controller Settings

### Configure URL Filtering Settings

# Configure URL Filtering Settings

Use the following commands to configure URL Filtering settings.

## url-filtering

To configure a URL Filtering Profile and enter the *config-url-filtering* context, use the following command:

**url-filteringNAME**

### Example

```
ruckus(config)# url-filtering filter1
The Url Filtering "filter1" has been created.
ruckus(config-url-filtering)#
  help           Shows available commands.
  history        Shows a list of previously run commands.
  abort          Exits the config-url-filtering context without saving changes.
  end            Saves changes, and then exits the config-url-filtering-xxx context.
  exit            Saves changes, and then exits the config-url-filtering-xxx context.
  show            Displays the current Url Filtering settings.
  no              Contains commands that can be executed from within the context.
  description <WORD> Sets the Policy entry description.
  filtering-level <WORD>
    Selects a filtering categories level.
  blocked-category <list>
    Selects the blocked categories only for "CUSTOM" (for example: Abortion,
    Abused Drugs, Auctions).
  create-blacklist <domain>
    Creates a new Blacklist.
  delete-blacklist <domain>
    Deletes a exist Blacklist.
  create-whitelist <domain>
    Creates a new Wlacklist.
  delete-whitelist <domain>
    Deletes a exist Wlacklist.
  google-safe-search  Enables Google Safe Search.
  google-ip <IP-ADDR> Configures Google Safe Search Virtual IP(216.239.38.120).
  youtube-safe-search  Enables YouTube Safe Search.
  youtube-ip <IP-ADDR>
    Configures YouTube Safe Search Virtual IP(216.239.38.120).
  bing-safe-search   Enables Bing Safe Search.
  bing-ip <IP-ADDR> Configures Bing Safe Search Virtual IP(204.79.197.220).
ruckus(config-url-filtering)#
```

## no url-filtering

To delete a URL Filtering Profile, use the following command:

**no url-filteringNAME**

### Example

```
ruckus(config)# no url-filtering filter1
The policy 'filter1' has been removed .
ruckus(config)#

```

## description

To set the URL Filtering policy entry description, use the following command:

**description <WORD>**

### Example

```
ruckus(config-url-filtering)# description "Filter 1"  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#+
```

## filtering-level

To select a filtering level category, use the following command:

**filtering-level NO\_ADULT | CLEAN\_AND\_SAFE | CHILD\_AND\_STUDENT\_FRIENDLY | STRICT | CUSTOM**

### Example

```
ruckus(config-url-filtering)# filtering-level NO_ADULT  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#+
```

## blocked-category

To select a blocked category (only for "CUSTOM" for example: Abortion, Abused Drugs, Auctions), use the following command:

**blocked-category** *Abortion, Abused Drugs, Adult and Pornography, Alcohol and Tobacco, Auctions, Bot Nets, Business and Economy, Cheating, Computer and Internet Info, Computer and Internet Security, Confirmed SPAM Sources, Content Delivery Networks, Cult and Occult, Dating, Dead Sites, Dynamic Comment, Educational Institutions, Entertainment and Arts, Fashion and Beauty, Financial Services, Food and Dining, Gambling, Games, Government, Gross, Hacking, Hate and Racism, Health and Medicine, Home and Garden, Hunting and Fishing, Illegal, Image and Video Search, Internet Communications, Internet Portals, Job Search, Keyloggers and Monitoring, Kids, Legal, Local Information, Malware Sites, Marijuana, Military, Motor Vehicles, Music, News and Media, Nudity, Online Greeting cards, Open HTTP Proxies, Parked Domains, Pay to Surf, Peer to Peer, Personal Storage, Personal sites and Blogs, Philosophy and Political Advocacy, Phishing and Other Frauds, Private IP Addresses, Proxy Avoidance and Anonymizers, Questionable, Real Estate, Recreation and Hobbies, Reference and Research, Religion, SPAM URLs, Search Engines, Sex Education, Shareware and Freeware, Shopping, Social Networking, Society, Sports, Spyware and Adware, Stock and Advice Tools, Streaming Media, Swimsuits & Intimate Apparel, Training and Tools, Translation, Travel, Unconfirmed SPAM Sources, Violence, Weapons, Web Advertisements, Web Hosting, Web based Email*

### Example

```
ruckus(config-url-filtering)# blocked-category Violence  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#+
```

## create-blacklist

To create a new domain blacklist, use the following command:

**create-blacklist<domain>**

## Configuring Controller Settings

### Configure URL Filtering Settings

#### Example

```
ruckus(config-url-filtering)# create-blacklist facebook.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#[/pre>
```

## delete-blacklist

To delete a domain blacklist, use the following command:

**delete-blacklist<domain>**

#### Example

```
ruckus(config-url-filtering)# delete-blacklist facebook.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#[/pre>
```

## create-whitelist

To create a domain whitelist, use the following command:

**create-whitelist<domain>**

#### Example

```
ruckus(config-url-filtering)# create-whitelist ruckuswireless.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#[/pre>
```

## delete-whitelist

To delete a domain whitelist, use the following command:

**delete-whitelist<domain>**

#### Example

```
ruckus(config-url-filtering)# delete-whitelist ruckuswireless.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#[/pre>
```

## google-safe-search

To enable Google Safe Search, use the following command:

**google-safe-search**

#### Example

```
ruckus(config-url-filtering)# google-safe-search  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#[/pre>
```

## no google-safe-search

To disable Google Safe Search, use the following command:

**no google-safe-search**

### **Example**

```
ruckus(config-url-filtering)# no google-safe-search  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#+
```

## google-ip

To configure Google Safe Search Virtual IP (default: 216.239.38.120), use the following command:

**google-ipIP Address**

### **Defaults**

216.239.38.120

**google-ipIP Address**

### **Example**

```
ruckus(config-url-filtering)# google-ip 216.239.38.120  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#+
```

## youtube-safe-search

To enable Youtube Safe Search, use the following command:

**youtube-safe-search**

### **Example**

```
ruckus(config-url-filtering)# youtube-safe-search  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#+
```

## no youtube-safe-search

To disable Youtube Safe Search, use the following command:

**no youtube-safe-search**

### **Example**

```
ruckus(config-url-filtering)# no youtube-safe-search  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-url-filtering)#+
```

## **Configuring Controller Settings**

### Configure URL Filtering Settings

## **youtube-ip**

To configure the YouTube Safe Search Virtual IP (default: 216.239.38.120), use the following command:

```
youtube-ip IP-ADDR
```

### **Defaults**

216.239.38.120

### **Example**

```
ruckus(config-url-filtering)# youtube-ip 216.239.38.120
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-url-filtering)#+
```

## **bing-safe-search**

To enable Bing Safe Search, use the following command:

```
bing-safe-search
```

### **Example**

```
ruckus(config-url-filtering)# bing-safe-search
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-url-filtering)#+
```

## **no bing-safe-search**

To disable Bing Safe Search, use the following command:

```
no bing-safe-search
```

### **Example**

```
ruckus(config-url-filtering)# no bing-safe-search
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-url-filtering)#+
```

## **bing-ip**

To configure the Bing Safe Search Virtual IP (default: 204.79.197.220), use the following command:

```
bing-ip IP-ADDR
```

### **Defaults**

204.79.197.220

## **Example**

```
ruckus(config-url-filtering)# bing-ip 204.79.197.220
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-url-filtering)#[/pre]
```

## **show**

To display the current URL Filtering settings, use the following command:

```
show
```

## **Example**

```
ruckus(config-url-filtering)# show
:
Url Name: filter1
Filter Type: CUSTOM
Number of Blocked Categories: 1
Blocked Categories:
    Violence
Blacklist-Domains:
    cisco.com
    facebook.com
Whitelist-Domains:
    ruckuswireless.com
Google Safe Search: Disabled
YouTube Safe Search VIP: 216.239.38.120
Bing Safe Search VIP: 204.79.197.220
ruckus(config-url-filtering)#[/pre]
```

# Configure Whitelist Commands

Use the whitelist command to create a new client isolation whitelist or modify an existing whitelist, and enter the **config-whitelist** context.

## whitelist

To create a new white list entry or modify an existing entry, use the following command:

**whitelist WORD**

## no whitelist

To delete a whitelist entry, use the following command:

**no whitelist WORD**

## name

To set the White List entry name, use the following command:

**name WORD**

## description

To set the description of the whitelist entry, use the following command:

**description WORD**

## Configuring Whitelist Rules

Use the rule command from within the config-whitelist context to create a new rule or modify an existing rule, and enter the **config-whitelist-rule** context.

### **rule**

To create a new whitelist rule or modify an existing rule, use the following command:

**rule NUMBER**

### **no rule**

To delete a whitelist rule, use the following command:

**no rule NUMBER**

### **description**

To set the White List rule description, use the following command:

**description WORD**

### **mac**

To set the MAC address, use the following command (format: XX:XX:XX:XX:XX:XX):

**mac MAC**

### **ip**

To set the IP address, use the following command (format: 172.18.110.12).

**ip IP**

# Configure Band Balancing Commands

Client Band Balancing attempts to balance the number of clients across AP radios, allowing configurable thresholds for ratio of clients on the 2.4 vs. 5 GHz radio bands. Use the band-balancing commands to configure the controller's band balancing settings. To run these commands, you must first enter the **config-band-balancing** context.

## band-balancing

To enable load-balancing and enter the config-band-balancing context, use the following command:

**band-balancing**

## abort

Exits the band balancing context without saving changes.

## end

Saves changes, and then exits the band balancing context.

## exit

Saves changes, and then exits the band balancing context.

## quit

Exits the band balancing context without saving changes.

## enable

To enable band balancing, use the following command:

**enable**

## *Example*

```
ruckus (config-band-balancing) # enable  
The band balancing settings have been updated.  
ruckus (config-band-balancing) #
```

## disable

To disable band balancing, use the following command:

**disable**

**Example**

```
ruckus(config-band-balancing)# disable  
The band balancing settings have been updated.  
ruckus(config-band-balancing) #
```

## Configuring Controller Settings

### Configure Band Balancing Commands

## Proactive

To enable or disable Proactive Band Balancing, use the following command:

**Proactive <NUMBER>**

### Syntax

<NUMBER>: 0 for disable, 1 for enable

### Example

```
ruckus(config-band-balancing)# proactive 0
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-band-balancing)#

```

## percent-2.4G <NUMBER>

To configure the percentage of clients on the 2.4 GHz band, use the following command:

**percent-2.4G <NUMBER>**

### Defaults

25

### Example

```
ruckus(config-band-balancing)# percent-2.4G 25
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-band-balancing)#

```

## show

Displays information about Band balancing.

### Example

```
ruckus(config-band-balancing)# show
Band Balancing:
  Enable= 1
  Percent of clients on 2.4G band: 25%
  Proactive Status= 1

ruckus(config-band-balancing)#

```

# Configure Load Balancing Commands

Client Load Balancing attempts to balance the number of clients across APs, per radio band. Use the **load-balancing** commands to configure the controller's load balancing settings. To run these commands, you must first enter the **config-load-balancing** context.

## load-balancing

To enable load-balancing and enter the config-load-balancing context, use the following command:

**load-balancing**

### Example

```
ruckus (config) # load-balancing
ruckus (config-load-balancing) #
```

## adj-threshold

To configure the adjacent threshold for load balancing, use the following command:

**adj-threshold [ wifi0 | wifi1 ] NUMBER**

### Syntax Description

**adj-threshold**

Configure the adjacent threshold for load balancing

**wifi0, wifi1**

Configure this interface

**NUMBER**

Set the adjacent threshold value (1~100)

### Defaults

Wifi0: 50

Wifi1: 43

### Example

```
ruckus (config-load-balancing) # enable wifi0
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus (config-load-balancing) # adj-threshold wifi0 25
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus (config-load-balancing) # show
Load Balancing:
  Radio 0:
    Status= Enabled
    AdjacentThreshold= 25
    WeakBypass= 33
    StrongBypass= 55
    ActivationThreshold= 10
    NewTrigger= 3
    Headroom= 3
```

## Configuring Controller Settings

### Configure Load Balancing Commands

```
Radio 1:  
  Status= Disabled  
  AdjacentThreshold= 43  
  WeakBypass= 35  
  StrongBypass= 55  
  ActivationThreshold= 10  
  NewTrigger= 3  
  Headroom= 3
```

```
ruckus(config-load-balancing) #
```

## weak-bypass

To configure the weak bypass for load balancing, use the following command:

```
weak-bypass [ wifi0 | wifi1 ] NUMBER
```

### Syntax Description

#### **weak-bypass**

Configure the weak bypass for load balancing

#### **wifi0, wifi1**

Configure this interface

#### **NUMBER**

Set the weak-bypass value (1~100)

### Defaults

wifi0: 33

wifi1: 35

### Example

```
ruckus(config-load-balancing) # weak-bypass wifi0 33  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-load-balancing) #
```

## strong-bypass

To configure the strong bypass for load balancing, use the following command:

```
strong-bypass [ wifi0 | wifi1 ] NUMBER
```

### Syntax Description

#### **strong-bypass**

Configure the strong bypass for load balancing

#### **wifi0, wifi1**

Configure this interface

#### **NUMBER**

Set the strong-bypass value (1~100)

## Defaults

55

## Example

```
ruckus(config-load-balancing)# strong-bypass wifi0 55  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-load-balancing) #
```

## act-threshold

To configure the activation threshold for load balancing, use the following command:

```
act-threshold [ wifi0 | wifi1 ] NUMBER
```

### Syntax Description

#### act-threshold

Configure the activation threshold for load balancing.

#### wifi0, wifi1

Configure this interface.

#### NUMBER

Set the activation threshold value (1~100).

## Defaults

10

## Example

```
ruckus(config-load-balancing)# act-threshold wifi0 50  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-load-balancing) #
```

## new-trigger

To configure new trigger threshold (1-100), use the following command:

```
new-trigger [ wifi0 | wifi1 ] NUMBER
```

### Syntax Description

#### new-trigger

Configure a new trigger threshold for the specified interface.

#### wifi0, wifi1

Configure this interface.

#### NUMBER

Set the new trigger threshold value (1~100).

## Defaults

3

## Example

```
ruckus(config-load-balancing)# new-trigger wifi0 3  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-load-balancing)#[/pre]
```

## headroom

To configure headroom settings for the specified interface, use the following command:

```
headroom [ wifi0 | wifi1 ] NUMBER
```

## Syntax Description

**headroom**

Configure headroom for the specified interface.

**wifi0, wifi1**

Configure this interface.

**NUMBER**

Set the headroom value (1~100).

## Defaults

3

## Example

```
ruckus(config-load-balancing)# headroom wifi0 3  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-load-balancing)#[/pre]
```

## disable wifi0

Disable wifi0 load balancing.

## disable wifi1

Disable wifi1 load balancing.

## enable wifi0

Enable wifi0 load balancing.

## enable wifi1

Enable wifi1 load balancing.

## show

To display the current service settings, use the following command:

**show**

### Syntax Description

**show**

Display the current service settings

### Defaults

None.

### Example

```
ruckus(config-load-balancing)# show
Load Balancing:
    Radio 0:
        Status= Enabled
        AdjacentThreshold= 50
        WeakBypass= 33
        StrongBypass= 55
        ActivationThreshold= 10
        NewTrigger= 3
        Headroom= 3

    Radio 1:
        Status= Disabled
        AdjacentThreshold= 43
        WeakBypass= 35
        StrongBypass= 55
        ActivationThreshold= 10
        NewTrigger= 3
        Headroom= 3

ruckus(config-load-balancing) #
```

## Configuring Controller Settings

### Configure STP Commands

# Configure STP Commands

Both Ethernet ports are one logical interface. They are designed to provide high availability connections to separate switches and do not provide dual-port ISL channel bonding. Switches should use STP to block one path. The default is “no stp”.

## stp

To enable Spanning Tree Protocol, use the following command:

```
stp
```

## no stp

To disable Spanning Tree Protocol, use the following:

```
no stp
```

# Configure System Commands

Use the sys or system command to configure the controller's system settings, including its host name, FlexMaster server, NTP server, SNMP, and QoS settings. To run these commands, you must first enter the **config-sys** context.

## system

To enter the config-sys context and configure system settings, use the following command:

**system**

### Example

```
ruckus(config)# system  
ruckus(config-sys) #
```

## dot11-country-code

To set the controller's country code, use the following command:

**dot11-country-code COUNTRY-CODE {arguments}**

### Syntax Description

#### dot11-country-code

Configure the controller's country code setting

#### COUNTRY-CODE

Set the country code to this value

#### channel-mode

Contains commands that can be executed from within the context

#### allow-indoor

Allows ZoneFlex Outdoor APs to use channels regulated as indoor use-only

#### not-allow-indoor

Disallows ZoneFlex Outdoor APs to use channels regulated as indoor use-only

#### channel-optimization

Set channel optimization type (compatibility, interoperability, performance)

### Defaults

None.

### Example

To set the country code to US, enter the following command:

```
ruckus# configruckus(config)# system  
ruckus(config-sys) # dot11-country-code US  
The country code settings have been updated.  
ruckus(config-sys) #
```

## hostname

To set the system hostname, use the following command:

**hostname**

### Syntax Description

**hostname**

Set the controller's system hostname

### Defaults

None

### Example

```
ruckus(config-sys)# hostname ruckus-xjoe
The system identity/hostname settings have been updated.
```

## Interface Commands

Use the interface commands to configure the controller's IP address and VLAN settings. To run these commands, you must first enter the **config-sys-if** context.

### **interface**

To enter the config-sys-if context and configure IP address and VLAN settings, use the following command:

**interface**

#### **Example**

```
ruckus (config-sys) # interface  
ruckus (config-sys-if) #
```

### **ip enable**

To enable IPv4 addressing, use the following command:

**ip enable**

### **ip route gateway**

To set the controller's gateway IP address, use the following command:

**ip route gateway GATEWAY-ADDR**

#### **Syntax Description**

**ip route gateway**

Configure the controller's gateway IP address

**GATEWAY-ADDR**

Set the controller' gateway IP address to this value

#### **Defaults**

None.

#### **Example**

```
ruckus# config  
ruckus(config)# system  
ruckus(config-sys)# interface  
ruckus(config-sys-if)# ip route gateway 192.168.0.1  
The command was executed successfully.
```

### **ip name-server**

To set the controller's DNS servers, use the **ip name-server** command. Use a space to separate the primary and secondary DNS servers.

**ip name-server DNS-ADDR [ DNS-ADDR ]**

## Configuring Controller Settings

### Configure System Commands

#### Syntax Description

##### **ip name-server**

Configure the controller's DNS server address or addresses

##### *DNS-ADDR*

Set the DNS server address to this value. If entering primary and secondary DNS server addresses, use a space to separate the two addresses.

#### Defaults

192.168.0.1

#### Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# interface
ruckus(config-sys-if)# ip name-server 192.168.0.1
The command was executed successfully.
```

#### **ip addr**

To set the controller's IP address and netmask, use the following command:

##### **ip addr IP-ADDR NET-MASK**

Use a space to separate the IP address and netmask.

#### Syntax Description

##### **ip addr**

Configure the controller's IP address and netmask

##### *IP-ADDR*

Set the controller's IP address to this value

##### *NET-MASK*

Set the controller's netmask to this value

#### Defaults

IP address: 192.168.0.2

Subnet mask: 255.255.255.0

#### Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# interface
ruckus(config-sys-if)# ip addr 192.168.0.2 255.255.255.0
The command was executed successfully.
```

## **ip mode**

To set the controller's IP address mode, use the following command:

```
ip mode [ dhcp | static ]
```

### **Syntax Description**

#### **ip mode**

Configure the controller's IP address mode

#### **dhcp**

Set the controller's IP address mode to DHCP

#### **static**

Set the controller's IP address mode to static

### **Defaults**

None.

### **Example**

To set the controller's IP address mode to DHCP, enter the following command:

```
ruckus# config  
ruckus(config)# system  
ruckus(config-sys)# interface  
ruckus(config-sys-if)# ip mode dhcp  
The command was executed successfully.
```

## **show**

To display the current management interface settings, use the following command:

```
show
```

### **Syntax Description**

#### **show**

Display the current management interface settings

### **Defaults**

None.

### **Example**

```
ruckus# config  
ruckus(config)# system  
ruckus(config-sys)# interface  
ruckus(config-sys-if)# show  
Protocol Mode= IPv4-Only  
Device IP Address:  
Mode= Manual  
IP Address= 192.168.11.100  
Netmask= 255.255.255.0
```

## Configuring Controller Settings

### Configure System Commands

```
Gateway Address= 192.168.11.1
Primary DNS= 192.168.11.1
Secondary DNS= 168.95.1.1
```

```
Management VLAN:
Status= Disabled
VLAN ID=
```

```
ruckus (config-sys-if) #
```

## ipv6 enable

To enable IPv6 addressing, use the following command:

```
ipv6 enable
```

## ipv6 route gateway

To set the controller's IPv6 gateway addressing, use the following command:

```
ipv6 route gateway GATEWAY-ADDR
```

## ipv6 name-server

To set the IPv6 DNS server, use the following command:

```
name-server DNS-ADDR [DNS-ADDR ]
```

## ipv6 addr

To set the IPv6 addressing, use the following command:

```
addr IPv6-ADDR IPv6-PREFIX
```

## ipv6 mode

To set the IPv6 address mode, use the following command:

```
ipv6 mode [ auto | manual ]
```

## vlan

If the ZoneDirector is on a tagged Access VLAN, to set the VLAN ID, use the following command:

```
vlan NUMBER
```

## no ip

To disable IPv4 addressing, use the following command:

```
no ip
```

## no ipv6

To disable IPv6 addressing, use the following command:

**no ipv6**

## NTP Commands

Use the following commands to configure Network Time Protocol (NTP) server settings.

### **ntp**

To enable the NTP client, use the following command:

**ntp IP-ADDR/DOMAIN-NAME**

#### Syntax Description

**ntp**

Enable the NTP client

**IP-ADDR/DOMAIN-NAME**

Set the NTP server address to this IP address/domain name

#### Defaults

None.

#### Example

```
ruckus(config-sys)# ntp 192.168.2.21  
The NTP settings have been updated.  
ruckus(config-sys)# ntp sohu.com  
The NTP settings have been updated.
```

### **no ntp**

To disable the NTP client, use the following command:

**no ntp**

#### Syntax Description

**no ntp**

Disable the NTP client on the controller.

#### Defaults

Enabled. The default NTP server addresss is ntp.ruckuswireless.com.

#### Example

```
ruckus(config-sys)# no ntp  
The NTP settings have been updated.
```

## Configuring Controller Settings

### Configure System Commands

## Timezone Commands

Use the following commands to configure system time zone settings, including user-defined time zones and Daylight Savings Time (DST) customization.

### **system-timezone**

To configure time zone settings, use the following command:

```
system-timezone <TIMEZONE>
```

#### *Defaults*

GMT+0

#### *Example*

```
ruckus(config-sys)# system-timezone GMT+8  
The timezone settings have been updated.  
ruckus(config-sys) #
```

### **userdefined-timezone**

To configure user-defined time zone, use the following command:

```
userdefined-timezone <TIMEZONE>
```

#### *Defaults*

None

#### *Example*

```
ruckus(config-sys)# userdefined-timezone GMT+8:30  
The timezone settings have been updated.  
ruckus(config-sys) #
```

### **no userdefined-timezone**

To configure user-defined time zone, use the following command:

```
userdefined-timezone <TIMEZONE>
```

#### *Defaults*

None

#### *Example*

```
ruckus(config-sys)# userdefined-timezone GMT+8:30  
The timezone settings have been updated.  
ruckus(config-sys) #
```

## system-dst

To configure system Daylight Savings Time settings, use the following command:

**system-dst [enable | disable]**

### Defaults

Disabled

### Example

```
ruckus(config-sys)# system-dst enable  
The timezone settings have been updated.  
ruckus(config-sys)#[/pre]
```

## no system-dst

To disable the system Daylight Savings Time settings, use the following command:

**no system-dst**

### Defaults

Disabled

### Example

```
ruckus(config-sys)# no system-dst  
The timezone settings have been updated.  
ruckus(config-sys)#[/pre]
```

## userdefined-dst

To configure user-defined Daylight Savings Time settings, use the following command:

**userdefined-dst <DST>**

### Defaults

Disabled

### Example

```
ruckus(config-sys)# userdefined-dst M1.1.0/00,M1.2.0/00  
The timezone settings have been updated.  
ruckus(config-sys)#[/pre]
```

## no userdefined-dst

To delete the user-defined Daylight Savings Time settings, use the following command:

**no userdefined-dst**

## **Configuring Controller Settings**

### Configure System Commands

#### **Defaults**

Disabled

#### **Example**

```
ruckus(config-sys)# no userdefined-dst  
The timezone settings have been updated.  
ruckus(config-sys) #
```

## **FTP Commands**

Use the following commands to configure FTP settings.

### **ftp**

Enable FTP server.

### **no ftp**

Disable FTP server.

### **ftp-anon**

To enable FTP anonymous access, use the following command:

#### **ftp-anon**

### **no ftp-anon**

To disable FTP anonymous access, use the following command:

#### **no ftp-anon**

## Smart Redundancy Commands

To configure the Smart Redundancy settings, you must first enter the config-sys-smart-redundancy context from within the **config-sys** context.

### **smart-redundancy**

To enter the config-sys-smart-redundancy context and configure Smart Redundancy settings, use the following command:

**smart-redundancy**

### Syntax Description

#### **smart-redundancy**

Configures smart redundancy settings.

#### **abort**

Exits the smart redundancy context without saving changes.

#### **end**

Saves changes, and then exits the smart redundancy context.

#### **exit**

Saves changes, and then exits the smart redundancy context.

#### **quit**

Exits the smart redundancy context without saving changes

#### **peer-addr IP-ADDR**

Sets the peer's IP/IPv6 address.

#### **secret WORD**

Sets the shared secret to the specified secret.

#### **show**

Displays information about smart redundancy.

### Example

```
ruckus# config
ruckus(config)# system
ruckus(config-system)# smart-redundancy
ruckus(config-sys-smart-redundancy)# peer-addr 192.168.40.101
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-sys-smart-redundancy)# secret secret
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-sys-smart-redundancy)# show
Smart Redundancy:
  Status= Disabled
  Peer IP/IPv6 Address=
  Shared Secret=

ruckus(config-sys-smart-redundancy)# end
The smart redundancy settings have been updated.
Your changes have been saved.
ruckus(config-sys)#

```

## Configuring Controller Settings

### Configure System Commands

#### ***no smart-redundancy***

Disables the smart redundancy settings.

#### **Example**

```
ruckus(config-sys)# no smart-redundancy
The smart redundancy settings have been updated.
ruckus(config-sys)#+
```

## Management Interface Commands

To configure management interface settings, you must first enter the config-sys-mgmt-if context from the **config-sys** context.

### **mgmt-if**

To enter the config-sys-mgmt-if context and configure the management interface settings, use the following command:

**mgmt-if**

#### Syntax Description

**mgmt-if**

Configure the management interface settings

#### Defaults

None.

#### Example

```
ruckus(config-sys) # mgmt-if  
ruckus(config-sys-mgmt-if) #
```

### **no mgmt-if**

To disable the management interface, use the following command:

**no mgmt-if**

#### Syntax Description

**no mgmt-if**

Disable the management interface

#### Defaults

None.

#### Example

```
ruckus(config-sys) # no mgmt-if  
The management interface has been updated.
```

### **ip addr**

To set the management interface IP address, use the following command:

**ip addr IP-ADDR NET-MASK**

## Configuring Controller Settings

### Configure System Commands

#### gateway

To set the management interface gateway address, use the following command:

```
gateway GATEWAY-ADDR
```

#### no gateway

To disable the management interface gateway address, use the following command:

```
no gateway
```

#### vlan

To enable the management VLAN and set the VLAN ID, use the following command:

```
vlan NUMBER
```

#### mgmt-if-ipv6

To enter the config-sys-mgmt-if-ipv6 context and configure the management interface settings, use the following command:

```
mgmt-if-ipv6
```

#### Syntax Description

##### mgmt-if-ipv6

Configure the management interface settings

#### Defaults

None.

#### Example

```
ruckus (config-sys) # mgmt-if-ipv6
ruckus (config-sys-mgmt-if-ipv6) #
```

#### no mgmt-if-ipv6

To disable the management interface, use the following command:

```
no mgmt-if-ipv6
```

#### Syntax Description

##### no mgmt-if-ipv6

Disable the management interface

#### Defaults

None.

## Example

```
ruckus(config-sys) # no mgmt-if-ipv6  
The management interface has been updated.
```

## ipv6 addr

To set the management interface IP address, use the following command:

```
ip addr IPv6-ADDR IPv6-PREFIX
```

## gateway

To set the management interface gateway address, use the following command:

```
gateway GATEWAY-ADDR
```

## no gateway

To disable the management interface gateway address, use the following command:

```
no gateway
```

## vlan

To enable the management VLAN and set the VLAN ID, use the following command:

```
vlan NUMBER
```

## flexmaster

To set the FlexMaster server address and the periodic inform interval, use the following command:

```
flexmaster IP-ADDR/DOMAIN-NAME interval NUMBER
```

## Syntax Description

### flexmaster

Configure the FlexMaster server settings

#### IP-ADDR/DOMAIN-NAME

Set to this URL or IP address

#### interval

Configure the periodic inform interval

#### NUMBER

Set to this interval (in minutes)

## Defaults

None.

## **Configuring Controller Settings**

### Configure System Commands

#### **Example**

```
ruckus(config-sys) # flexmaster http://172.18.30.118 interval 30  
The FlexMaster Management settings have been updated.
```

#### **no flexmaster**

To disable FlexMaster management of the controller, use the following command:

```
no flexmaster
```

#### **Syntax Description**

```
no flexmaster
```

Disable FlexMaster management of the controller

#### **Defaults**

None

#### **Example**

```
ruckus(config-sys) # no flexmaster  
FlexMaster Management has been disabled.
```

#### **northbound**

To enable northbound portal interface support and set the northbound portal password, use the following command:

```
northbound password WORD
```

#### **Defaults**

Disabled

#### **Example**

```
ruckus(config-sys) # northbound password pass123  
The northbound portal interface settings have been updated.
```

#### **no northbound**

To disable northbound portal interface support, use the following command:

```
no northbound
```

#### **Example**

```
ruckus(config-sys) # no northbound  
Northbound portal interface has been disabled.
```

## SNMPv2 Commands

Use the following commands to configure SNMPv2 settings. To use these commands, you must first enter the **config-sys-snmpv2** context.

### snmpv2

To configure the SNMPv2 settings, use the following command:

#### snmpv2

Executing this command enters the config-sys-snmpv2 context.

### Syntax Description

#### snmpv2

Configure the SNMPv2 settings

#### abort

Exits the config-sys-snmpv2 context without saving changes.

#### end

Saves changes, and then exits the config-sys-snmpv2 context.

#### exit

Saves changes, and then exits the config-sys-snmpv2 context.

#### quit

Exits the config-sys-snmpv2 context without saving changes.

#### no access-v3

Disables special MIB node for customer's kt.

#### access-v3

Enables special MIB node for customer's kt.

#### contact WORD

Enables SNMPV2 agent and sets the system contact.

#### location WORD

Enables SNMPV2 agent and sets the system location.

#### ro-community WORD

Enables SNMPV2 agent and sets the RO community name.

#### rw-community WORD

Enables SNMPV2 agent and sets the RW community name.

#### show

Displays SNMPV2 agent and SNMP trap settings.

### Defaults

SNMP Agent:

Status= Enabled

Contact= [https://support.ruckuswireless.com/contact\\_us](https://support.ruckuswireless.com/contact_us)

Location= 350 West Java Dr. Sunnyvale, CA 94089 US

## Configuring Controller Settings

### Configure System Commands

RO Community= public

RW Community= private

SNMP Trap:

Format= Version2

Status= Disabled

Support-access-V3:

Status= Disabled

### Example

```
ruckus (config-sys) # snmpv2  
ruckus (config-sys-snmpv2) #
```

### *contact*

To enable SNMPv2 agent and set the system contact, use the following command:

**contact WORD**

### *location*

To enable SNMPv2 agent and set the system location, use the following command:

**location WORD**

### *ro-community*

To set the read-only (RO) community name, use the following command:

**ro-community WORD**

### Syntax Description

#### **ro-community**

Configure the read-only community name

**WORD**

Set the read-only community name to this value

### Defaults

public

### Example

```
ruckus (config-sys-snmpv2) # ro-community private-123  
The command was executed successfully
```

## **rw-community**

To set the read-write (RW) community name, use the following command:

**rw-community WORD**

This command must be entered from within the snmp-agent context.

### **Syntax Description**

#### **rw-community**

Configure the read-write community name

#### **WORD**

Set the read-write community name to this value

### **Defaults**

private

### **Example**

```
ruckus(config-sys-snmpv2)# rw-community private-123  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **show**

To display SNMPv2 agent and SNMP trap settings, use the show command.

### **Example**

```
ruckus(config-sys-snmpv2)# show  
SNMP Agent:  
  Status= Enabled  
  Contact= https://support.ruckuswireless.com/contact_us  
  Location= 350 West Java Dr. Sunnyvale, CA 94089 US  
  RO Community= public  
  RW Community= private  
  
SNMP Trap:  
  Format= Version2  
  Status= Disabled  
  
Support-access-V3:  
  Status= Disabled
```

## **snmpv2-ap**

To enable SNMP AP notification, use the following command:

**snmpv2-ap**

### **Example**

```
ruckus(config-sys)# snmpv2-ap  
The SNMP v2 agent settings have been updated.  
ruckus(config-sys) #
```

## Configuring Controller Settings

### Configure System Commands

#### **no snmpv2-ap**

To disable SNMP AP notification, use the following command:

```
no snmpv2-ap
```

#### Example

```
ruckus(config-sys)# no snmpv2-ap
The SNMP v2 agent settings have been updated.
ruckus(config-sys)#

```

## SNMPv3 Commands

Use the following commands to configure SNMPv3 settings. To use these commands, you must first enter the **config-sys-snmpv3** context.

### **snmpv3**

To configure the SNMPv3 settings, use the following command:

**snmpv3**

Executing this command enters the config-sys-snmpv3 context.

### Syntax Description

**snmpv3**

Configure the SNMPv3 settings

**abort**

Exits the config-sys-snmpv3 context without saving changes.

**end**

Saves changes, and then exits the config-sys-snmpv3 context.

**exit**

Saves changes, and then exits the config-sys-snmpv3 context.

**quit**

Exits the config-sys-snmpv3 context without saving changes.

**ro-user WORD**

Contains commands that can be executed from within the context.

**ro-user WORD MD5 WORD**

Contains commands that can be executed from within the context.

**ro-user WORD MD5 WORD DES WORD**

Sets the privacy phrase of DES for SNMPV3.

**ro-user WORD MD5 WORD AES WORD**

Sets the privacy phrase of AES for SNMPV3.

**ro-user WORD MD5 WORD None**

Sets the privacy to None for SNMPV3.

**ro-user WORD SHA WORD**

Contains commands that can be executed from within the context.

**ro-user WORD SHA WORD DES WORD**

Sets the privacy phrase of DES for SNMPV3.

**ro-user WORD SHA WORD AES WORD**

Sets the privacy phrase of AES for SNMPV3.

**ro-user WORD SHA WORD; None**

Sets the privacy to None for SNMPV3.

**rw-user WORD**

Contains commands that can be executed from within the context.

## Configuring Controller Settings

### Configure System Commands

**rw-user WORD MD5 WORD**

Contains commands that can be executed from within the context.

**rw-user WORD MD5 WORD DES WORD**

Sets the privacy phrase of DES for SNMPV3.

**rw-user WORD MD5 WORD AES WORD**

Sets the privacy phrase of AES for SNMPV3.

**rw-user WORD MD5 WORD None**

Sets the privacy to None for SNMPV3.

**rw-user WORD SHA WORD**

Contains commands that can be executed from within the context.

**rw-user WORD SHA WORD DES WORD**

Sets the privacy phrase of DES for SNMPV3.

**rw-user WORD SHA WORD AES WORD**

Sets the privacy phrase of AES for SNMPV3.

**rw-user WORD SHA WORD None**

Sets the privacy to None for SNMPV3.

**show**

Displays SNMPV3 agent and SNMP trap settings.

## Defaults

SNMPV3 Agent:

Status= Disabled

Ro:

User=

Authentication Type= MD5

Authentication Pass Phrase=

Privacy Type= DES

Privacy Phrase=

Rw:

User=

Authentication Type= MD5

Authentication Pass Phrase=

Privacy Type= DES

Privacy Phrase=

SNMP Trap:

Format= Version3

Status= Disabled

## **snmp-trap-format**

To set the SNMP trap format to SNMPV2 or SNMPV3, use the following command:

```
snmp-trap-format [ SNMPv2 | SNMPv3 ]
```

### **Syntax Description**

#### **snmp-trap-format**

Set the SNMP trap format

```
[ SNMPv2 | SNMPv3 ]
```

Set to either SNMPv2 or SNMPv3

### **Defaults**

SNMPv2

### **Example**

```
ruckus(config-sys) # snmp-trap-format SNMPV2  
The SNMP trap settings have been updated.
```

## **snmpv2-trap**

To enable the SNMPv2 trap and set the IP address of the trap server, use the following command:

```
snmpv2-trap NUMBER IP/IPv6-ADDR
```

### **Syntax Description**

#### **snmpv2-trap**

Enable the SNMPv2 trap and set the trap server's IP address

**NUMBER**

Assign the trap receiver ID (1-4)

**IP/IPv6-ADDR**

Set the trap receiver IP address

### **Defaults**

None

### **Example**

```
ruckus(config-sys) # snmpv2-trap 1 192.168.10.22  
The SNMP trap settings have been updated.
```

## **snmpv3-trap**

To enable and configure the SNMPv3 trap parameters, use the following command:

```
snmpv3-trap user_name snmp_trap_server_ip [ MD5 | SHA ] auth_pass_phrase [ DES privacy_phrase | AES privacy_phrase | None ]
```

## Configuring Controller Settings

### Configure System Commands

#### Syntax Description

##### **snmpv3-trap**

Enable the SNMPv3 trap and configure the trap parameters

##### *user\_name*

Trap user name

##### *snmp\_trap\_server\_ip*

Trap server IP address

##### [ **MD5** | **SHA** ]

Authentication method

##### *auth\_pass\_phrase*

Authentication passphrase

##### [ **DES privacy\_phrase** | **AES privacy\_phrase** | **None** ]

Privacy method and privacy phrase

#### Defaults

None

#### Example

```
ruckus(config-sys)#snmpv3-trap test1234 192.168.0.22 MD5 test1234 DES test4321
The command was executed successfully.
```

#### ***no snmp-trap-ap***

To disable SNMP trap server configuration for AP, use the following command:

```
no snmp-trap-ap
```

#### Example

```
ruckus(config-sys)#no snmp-trap-ap
The SNMP AP trap settings have been updated.
```

## Syslog Settings Commands

Use the **syslog** commands to configure the controller's syslog notification settings. To run these commands, you must first enter the **config-sys** context.

### **syslog**

To enable syslog notifications and enter the config-sys-syslog context, use the following command:

**syslog**

#### **Example**

```
ruckus(config-sys)# syslog  
ruckus(config-sys-syslog)#[/pre]
```

### **no syslog**

To disable syslog notification, use the following command:

**no syslog**

#### **Syntax Description**

**no syslog**

Disable syslog notification

#### **Defaults**

Disabled.

#### **Example**

```
ruckus(config-sys)# no syslog  
The syslog settings have been updated.  
ruckus(config-sys)#[/pre]
```

### **server**

To set the syslog server address, use the following command:

**server IP-ADDR**

#### **Syntax Description**

**server**

Set the syslog server IP address.

**IPADDR**

Send syslog notifications to this IP address.

## Configuring Controller Settings

### Configure System Commands

#### Defaults

Disabled.

#### Example

```
ruckus(config-sys-syslog)# server 172.17.16.2
The syslog settings have been updated.
ruckus(config-sys-syslog)#+
```

## **type**

To set the syslog server type, use the following command:

**type <LOG TYPE>**

### **Syntax Description**

all: Sets remote syslog type to all.

client: Sets remote syslog type to client info.

flowlevel: Sets remote syslog type to flowlevel.

### **Example**

```
ruckus(config-sys-syslog) # type all  
The syslog settings have been updated.  
ruckus(config-sys-syslog) #
```

## **facility**

To set the facility name, use the following command:

**facility FACILITY NAME**

### **Syntax Description**

**facility FACILITY NAME**

Sets the syslog facility name (local0 - local7, or keep)

### **Defaults**

Disabled.

## **priority**

To set the syslog priority level, use the following command:

**priority PRIORITY LEVEL**

### **Syntax Description**

**priority PRIORITY LEVEL**

Sets the syslog priority level (emerg, alert, crit, err, warning, notice, info, debug).

### **Defaults**

Disabled.

## **ap-facility**

To set the AP syslog facility name, use the following command:

## Configuring Controller Settings

### Configure System Commands

**ap-facility** FACILITY-NAME

#### Syntax Description

**ap-facility** FACILITY-NAME

Sets the AP syslog facility name (local0 - local7, or keep).

#### Defaults

Disabled.

#### ap-priority

To set the AP syslog priority level, use the following command:

**ap-priority** PRIORITY LEVEL

#### Syntax Description

**ap-priority** PRIORITY LEVEL

Sets the AP syslog priority level (emerg, alert, crit, err, warning, notice, info, debug).

IPADDR

Send syslog notifications to this IP address.

#### Defaults

Disabled.

#### Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# syslog
ruckus(config-sys-syslog)# server 192.168.3.10
The syslog settings have been updated.
ruckus(config-sys-syslog)# facility local0
The syslog settings have been updated.
ruckus(config-sys-syslog)# priority emerg
The syslog settings have been updated.
ruckus(config-sys-syslog)# ap-facility local0
The syslog settings have been updated.
ruckus(config-sys-syslog)# ap-priority emerg
The syslog settings have been updated.
ruckus(config-sys-syslog)# end
The syslog settings have been updated.
Your changes have been saved.
ruckus(config-sys) #
```

#### no syslog-ap

To disable external syslog server configuration for AP, use the following command:

**no syslog-ap**

**Example**

```
ruckus(config-sys)#no syslog-ap  
The AP syslog settings have been updated.
```

## Management Access Control List Commands

Use the following commands to create or configure management ACLs and enter the **config-sys-mgmt-acl** or **config-sys-mgmt-acl-ipv6** contexts. These commands must be used from the **config-sys** context.

### **mgmt-acl**

To create or configure a management ACL, use the following command:

**mgmt-acl WORD**

#### Syntax Description

**mgmt-acl**  
Create or configure a management ACL  
**WORD**  
Create or configure this management ACL

#### Defaults

None.

#### Usage Guidelines

Executing this command enters the **config-mgmt-acl** context.

#### Example

```
ruckus(config-sys)# mgmt-acl mac11
The management ACL 'mac11' has been created. To save the Management ACL, type 'end' or 'exit'.
ruckus(config-mgmt-acl)#
```

### **no mgmt-acl**

To delete a management ACL for IPv4, use the following command:

**no mgmt-acl WORD**

### **mgmt-acl-ipv6**

To create or configure an IPv6 management ACL, use the following command:

**mgmt-acl-ipv6 WORD**

Executing this command enters the config-mgmt-acl-ipv6 context.

#### Syntax Description

**mgmt-acl-ipv6**  
Create or configure a management ACL  
**WORD**  
Create or configure this management ACL

## Defaults

None.

## Example

```
ruckus(config-sys) # mgmt-acl-ipv6 mac11  
The management ACL 'mac11' has been created. To save the Management ACL, type 'end' or 'exit'.  
ruckus(config-mgmt-acl-ipv6) #
```

## **no mgmt-acl-ipv6**

To delete a management ACL for IPv6, use the following command:

```
no mgmt-acl-ipv6 WORD
```

## **exit**

Saves changes, and then exits the config-mgmt-acl context.

## **end**

Saves changes, and then exits the config-mgmt-acl context.

## **quit**

Exits the config-mgmt-acl context without saving changes.

## **abort**

Exits the config-mgmt-acl context without saving changes.

## **name**

To set the management ACL name, use the following command:

```
name WORD
```

## **restrict-type**

To set the management ACL restriction type, use the following command:

```
restrict-type [ single ip-addr IP-ADDR | range ip-range IP-ADDR IP-ADDR | subnet ip-subnet IP-ADDR IP-SUBNET ]
```

## Syntax Description

### **restrict-type**

Set the management ACL restriction type (single/range).

#### **single ip-addr**

Set management ACL restriction type to single.

**range**

Sets the management ACL restriction type to range.

**ip-range**

Sets the IP address range for management ACL. Use a space ( ) to separate addresses.

**subnet ip-subnet**

Sets the subnet for management ACL IP address. Use a space ( ) to separate IP address and Netmask (128.0.0.0 to 255.255.255.252).

**restrict-type single ip-addr**

To set the management ACL restriction type to a single IP address, use the following command:

**restrict-type single ip-addr *ip\_address***

**Syntax Description**

**restrict-type single ip-addr**

Set the management ACL restriction type to a single IP address

*ip\_address*

Set to this IP address only

**Example**

```
ruckus(config-mgmt-acl)# restrict-type single ip-addr 192.168.110.22  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

**restrict-type subnet ip-subnet**

To set the management ACL restriction type to certain subnets, use the following command:

**restrict-type subnet ip-subnet *IP-SUBNET* *IP-SUBNET***

**Syntax Description**

**restrict-type subnet ip-subnet**

Set the management ACL restriction type to a single IP address

*IP-SUBNET*

Set to this subnet

**Example**

```
ruckus(config-mgmt-acl)#restrict-type subnet ip-subnet 172.30.110.26 255.255.254.0  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

**restrict-type range ip-range**

To set the management ACL restriction type to an IP address range, use the following command:

**restrict-type range ip-range *ip\_address* *ip\_address***

### Syntax Description

#### **restrict-type range ip-range**

Set the management ACL restriction type to a single IP address

#### *ip\_address ip\_address*

**Set to this IP address range. The first *ip\_address* is for the startui**

### Example

```
ruckus(config-mgmt-acl)#restrict-type range ip-range 172.30.110.28 172.30.110.39  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

### show

To display management ACL settings, use the show command.

## QoS Commands

Use the following commands to configure QoS settings on the controller. These commands must be executed from the **config-sys** context.

### no qos

To disable QoS on the controller, use the following command:

#### **no qos**

### Syntax Description

#### **no qos**

Disable QoS on the controller

### Defaults

None.

### Example

```
ruckus(config-sys)# no qos  
Changes are saved!  
System QoS function has been disabled.
```

### qos

To enable and configure Quality of Service settings on the controller, use the following command:

#### **qos**

### Usage Guidelines

Executing this command enters the **config-sys-qos** context. The following commands can be executed from within the **qos** context.

## Example

```
ruckus (config-sys) # qos  
ruckus (config-sys-qos) #
```

### **heuristics video inter-packet-gap**

Use the following command to set the QoS heuristics video inter-packet gap minimum/maximum values:

```
heuristics video inter-packet-gap min NUMBER max NUMBER
```

### **heuristics video packet-length**

Use the following command to set the heuristics video packet-length values:

```
heuristics video packet-length min NUMBER max NUMBER
```

### **heuristics voice inter-packet-gap**

Use the following command to set the heuristics voice inter-packet-gap values:

```
heuristics voice inter-packet-gap min NUMBER max NUMBER
```

### **heuristics voice packet-length**

Use the following command to set the heuristics voice packet-length values:

```
heuristics voice packet-length min NUMBER max NUMBER
```

### **heuristics classification video packet-octet-count**

Use the following command to set the heuristics classification video packet-octet-count value:

```
heuristics classification video packet-octet-count NUMBER
```

### **heuristics classification voice packet-octet-count**

Use the following command to set the heuristics classification voice packet-octet-count value:

```
heuristics classification voice packet-octet-count NUMBER
```

### **heuristics no-classification video packet-octet-count**

Use the following command to set the heuristics no-classification video packet-octet-count value

```
heuristics no-classification video packet-octet-count NUMBER
```

### **heuristics no-classification voice packet-octet-count**

Use the following command to set the heuristics no-classification voice packet-octet-count value

```
heuristics no-classification voice packet-octet-count NUMBER
```

## ***tos classification video***

Use the following command to set the TOS classification video value:

**tos classification video WORD**

## ***tos classification voice***

Use the following command to set the TOS classification voice value:

**tos classification voice WORD**

## ***tos classification data***

Use the following command to set the TOS classification data value:

**tos classification data WORD**

## ***tos classification background***

Use the following command to set the TOS classification background value:

**tos classification background WORD**

## ***show***

Use the following command to display the system QoS settings:

**show**

## **Example**

```
ruckus(config-sys)# qos
ruckus(config-sys-qos)# show
System QoS:
Tos DATA TUNNEL = 0xA0
Tos CTRL TUNNEL = 0xA0
Tos Classification-Voice = 0xE0 0xC0 0xB8
Tos Classification-Video = 0xA0 0x80
Tos Classification-Data = 0x0
Tos Classification-Background = 0x0
Tx fail threshold = 50
heuristics inter-packet-gap Video = 0 65
heuristics inter-packet-gap Voice = 15 275
heuristics packet-length Video = 1000 1518
heuristics packet-length Voice = 70 400
heuristics classification Video = 50000
heuristics classification Voice = 600
heuristics no classification Video = 500000
heuristics no classification Voice = 10000

ruckus(config-sys-qos)#

```

## ***tunnel-mtu***

To set the tunnel MTU, use the following command:

**tunnel-mtu NUMBER**

## **Configuring Controller Settings**

### Configure System Commands

#### **Syntax Description**

##### **tunnel-mtu**

Set the tunnel MTU

#### **Defaults**

None.

#### **Example**

```
ruckus(config-sys) # tunnel-mtu 1500  
The Tunnel MTU settings have been updated.  
ruckus(config-sys) #
```

## **lwapp-mgmt-qlen-threshold**

To set the LWAPP MGMT queue length threshold to avoid too many messages delayed in the queue, use the following command:

```
lwapp-mgmt-qlen-threshold <NUMBER> <NUMBER>
```

#### **Syntax Description**

##### **lwapp-mgmt-qlen-threshold**

Set the LWAPP management queue threshold

<NUMBER>: Enter the LWAPP MGMT queue length threshold to drop AUTH frames (0~1000, 0 means disabled).

<NUMBER>: Enter the LWAPP MGMT queue length threshold to resume processing AUTH frames (0~1000 and can't bigger than the drop threshold).

#### **Defaults**

Drop: 100

Resume: 25

#### **Example**

```
ruckus(config-sys) # lwapp-mgmt-qlen-threshold 100 25  
The LWAPP MGMT queue length threshold settings have been updated.  
ruckus(config-sys) #
```

## **bonjour**

To enable bonjour service, use the following command:

```
bonjour
```

#### **Defaults**

Disabled.

### **Example**

```
ruckus(config-sys) # bonjour  
The bonjour service settings have been updated.  
ruckus(config-sys) #
```

## **no bonjour**

To disable bonjour service, use the following command:

**no bonjour**

## **telnetd**

To enable the telnet server, use the following command:

**telnetd**

### **Syntax Description**

**telnetd**

Enable the telnet server

### **Defaults**

None.

### **Example**

```
ruckus(config-sys) # telnetd  
The telnet server settings have been updated.  
ruckus(config-sys) #
```

## **no telnetd**

To disable the telnet server, use the following command:

**telnetd**

### **Syntax Description**

**no telnetd**

Disable the telnet server

### **Defaults**

None.

## Configuring Controller Settings

### Configure System Commands

#### Example

```
ruckus(config-sys)# no telnetd  
The telnet server settings have been updated.  
ruckus(config-sys)#[/pre]
```

## static-route

To create and configure static route settings, use the following command:

**static-route WORD**

#### Syntax Description

**static-route**

Create and configure a static route

**name WORD**

Set the name of the static route

**subnet IP-SUBNET**

Set the subnet for the destination network. Use a slash (/) to separate IP address and subnet

**gateway GATEWAY-ADDR**

Set the gateway address

**show**

Show a list of all static routes

#### Defaults

None.

#### Example

```
ruckus(config-sys)# static-route route1  
The static route 'route1' has been created. To save the static route, type 'end' or 'exit'.  
ruckus(config-static-route)# subnet 192.168.11.1/24  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-static-route)# gateway 192.168.11.1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-static-route)# show  
Static Route:  
ID=  
Name= route1  
IP subnet= 192.168.11.1/24  
IP gateway= 192.168.11.1  
ruckus(config-static-route)#[/pre]
```

## no static-route

To delete a static route, use the following command:

**no static-route**

## static-route-ipv6

To create and configure IPv6 static route settings, use the following command:

**static-route-ipv6 WORD**

### Syntax Description

**static-route-ipv6**

Create and configure a static route

**name WORD**

Set the name of the static route

**prefix IPv6-PREFIX**

Set the subnet for the destination network. Use a slash (/) to separate IP address and prefix length

**gateway GATEWAY-ADDR**

Set the gateway address

**show**

Show a list of all static routes

### Defaults

None.

### Example

```
ruckus(config-sys)# static-route route1
The static route 'route1' has been created. To save the static route, type 'end' or 'exit'.
ruckus(config-static-route)# subnet 192.168.11.1/24
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-static-route)# gateway 192.168.11.1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-static-route)# show
Static Route:
ID=
Name= route1
IP subnet= 192.168.11.1/24
IP gateway= 192.168.11.1

ruckus(config-static-route) #
```

## no static-route-ipv6

To delete an IPv6 static route, use the following command:

**no static-route-ipv6 WORD**

## snmp-trap

To set the SNMP trap format, use the following command:

**snmp-trap [SNPv2 | SNMPv3]**

## Syntax Description

### **snmp-trap**

Enable SNMP trap notifications

### **SNMPv2**

Set SNMP trap format to SNMPv2

### **SNMPv3**

Set SNMP trap format to SNMPv3

## Example

```
ruckus(config-sys)# snmp-trap SNMPv2  
The SNMP trap settings have been updated.  
ruckus(config-sys)#[/pre]
```

## no snmp-trap

To disable the SNMP trap notifications, use the following command:

### **no snmp-trap NUMBER**

## Syntax Description

### **no snmp-trap**

Disables SNMP trap notification by index

## Example

```
ruckus(config-sys)# no snmp-trap 1  
The SNMP trap settings have been updated.[/pre]
```

## no snmpv2-trap

To disable the SNMP trap notifications, use the following command:

### **no snmp-trap NUMBER**

## Syntax Description

### **no snmpv2-trap**

Disables SNMP trap notification by index

## Example

```
ruckus(config-sys)# no snmpv2-trap 1  
The SNMP trap settings have been updated.[/pre]
```

## no snmpv3-trap

To disable the SNMPv3 trap notification, use the following command:

**no snmpv3-trap NUMBER**

### Syntax Description

**no snmpv3-trap**

Disables SNMP trap notification by index

### Example

```
ruckus(config-sys) # no snmpv3-trap 1  
The SNMP trap settings have been updated.
```

## no snmpv2

To disable the SNMPv2 agent, use the following command:

**no snmpv2**

### Syntax Description

**no snmpv2**

Disables the SNMPv2 agent

### Example

```
ruckus(config-sys) # no snmpv2  
The SNMP v2 agent settings have been updated.
```

## no snmpv3

To disable the SNMPv3 agent, use the following command:

**no snmpv3**

### Syntax Description

**no snmpv3**

Disables the SNMPv3 agent

### Example

```
ruckus(config-sys) # no snmpv3  
The SNMP v3 agent settings have been updated.
```

## login-warning

To configure the login warning message, use the following command:

**login-warning**

## Configuring Controller Settings

### Configure System Commands

#### Syntax Description

##### **login-warning**

Configure the login warning message.

##### **abort**

Exits the login-warning context without saving changes.

##### **end**

Saves changes, and then exits the login-warning context.

##### **exit**

Saves changes, and then exits the login-warning context.

##### **quit**

Exits the login-warning context without saving changes.

##### **content WORD**

Customize login warning content.

#### Example

```
ruckus(config-sys)# login-warning
ruckus(config-sys-login-warning)# content "Warning, you are logging into equipment belonging to ruckus,
if you are not an authorized user please logout immediately."
The login warning settings have been updated.
ruckus(config-sys-login-warning)# end
The login warning settings have been updated.
Your changes have been saved.
ruckus(config-sys)#[/pre]
```

## no login-warning

To disable the login warning message, use the following command:

##### **no login-warning**

## event-log-level

To configure the event log level, use the following command:

##### **event-log-level EVENT LOG LEVEL**

#### Syntax Description

##### **event-log-level**

Enter the syslog event log level 1-3 (1:Critical Events Only, 2:Warning and Critical Events, 3>Show More).

#### Defaults

2: Warning and Critical Events

#### Example

```
ruckus# config
You have all rights in this mode.[/pre]
```

```
ruckus(config)# sys
ruckus(config-sys)# syslog
ruckus(config-sys-syslog)# event-log-level 1
The syslog settings have been updated.
ruckus(config-sys-syslog)#[/pre]
```

## **support-entitle**

Use the following command to manually download entitlement file:

**support-entitle**

### *Example*

```
ruckus(config-sys)# support-entitle
Your Support service has been successfully activated for this ZoneDirector. You may proceed with
firmware upgrade.
ruckus(config-sys)#[/pre]
```

## **URL-Filtering-License-Renew**

To synchronize the URL Filtering License from the Ruckus server, use the following command:

**URL-Filtering-License-Renew**

### *Example*

```
ruckus(config-sys)# URL-Filtering-License-Renew
OK
ruckus(config-sys)#[/pre]
```

## **session-stats-resv**

To enable session statistics recording, use the following command:

**session-stats-resv**

### *Defaults*

Disabled

### *Example*

```
ruckus(config-sys)# session-stats-resv
The session statistics function has been enabled.
ruckus(config-sys)#[/pre]
```

## **no session-stats-resv**

Use the following command to disable recording of session statistics:

**no session-stats-resv**

## Configuring Controller Settings

### Configure System Commands

#### **Example**

```
ruckus(config-sys)# no session-stats-resv  
The session statistics function has been disabled.  
ruckus(config-sys)#[/pre>
```

## arc-data-transmission

To enable ARC data transmission, use the following command:

**arc-data-transmission**

### **Example**

```
ruckus(config-sys)# arc-data-transmission  
The ARC data transmission has been enabled.  
ruckus(config-sys)#[/pre]
```

## no arc-data-transmission

To disable ARC (application recognition and control) data transmission, use the following command:

**no arc-data-transmission**

### *Example*

```
ruckus(config-sys)# no arc-data-transmission  
The ARC data transmission has been disabled.  
ruckus(config-sys)#+
```

## session-limit-unauth-stats

To enable recording of Layer 2 unauthorized session statistics, use the following command:

**session-limit-unauth-stats**

### *Defaults*

Enabled

### *Example*

```
ruckus(config-sys)# session-limit-unauth-stats  
The limited unauthorized session statistics function has been enabled.  
ruckus(config-sys)#+
```

## no session-limit-unauth-stats

To disable recording of Layer 2 unauthorized session statistics, use the following command:

**no session-limit-unauth-stats**

## eapol-no-retry

To disable retransmission of EAPOL-key (message 3/4 and group key), use the following command:

**eapol-no-retry**

### *Example*

```
ruckus(config-sys)# eapol-no-retry  
Eapol-key retry has been disabled  
ruckus(config-sys)#[/pre]
```

## no eapol-no-retry

To enable retransmission of EAPOL-key, use the following command:

**no eapol-no-retry**

### *Example*

```
ruckus(config-sys) # no eapol-no-retry  
Eapol-key retry has been enabled  
ruckus(config-sys) #
```

## shared-username-control-enable

To enable the checking function of the number of online stations sharing the same user account, use the following command:

**shared-username-control-enable**

### *Example*

```
ruckus(config-sys) # shared-username-control-enable  
Enable the checking function of the number of online stations shared the same user account.  
ruckus(config-sys) #
```

## no shared-username-control-enable

To disable the checking function of the number of online stations sharomg the same user account, use the following command:

**no shared-username-control-enable**

### *Example*

```
ruckus(config-sys) # no shared-username-control  
Disable the checking function of the number of online stations shared the same user account.  
ruckus(config-sys) #
```

## show

Use the following command to display system configuration information:

**show**

### *Example*

```
ruckus(config-sys) # show  
Country Code:  
    Code= United States  
  
Identity:  
    Name= ZoneDirector  
  
Session Statistics:  
    Enable= false  
    Limited Unauthorized Session= true  
  
ARC Data Transmission:  
    Enable= true
```

```
NTP:  
    Status= Enabled  
    Address= ntp.ruckuswireless.com  
    Timezone= GMT  
  
Log:  
    Status= Disabled  
    Address=  
    Facility=  
    Priority=  
    AP Facility=  
    AP Priority=  
    event log level= 1  
  
Tunnel MTU:  
    Tunnel MTU= 1500  
  
Bonjour Service:  
    Status= Enabled  
  
Telnet Server:  
    Status= Disabled  
  
FTP Server:  
    Status= Enabled  
    Anonymous Status= Disabled  
  
FlexMaster:  
    Status= Disabled  
    Address=  
    Interval= 15  
  
login warning:  
    Status= Disabled  
    content= "Warning, you are logging into device for authorized user only. If you are not an authorized user, please click Quit; otherwise click Continue to login."  
  
IWAAPP:  
    MGMT queue length threshold to drop AUTH frame = 100  
    MGMT queue length threshold to resume processing AUTH frame = 25  
  
EAPoL Key no Retry:  
    Status= Disabled  
  
ruckus(config-sys) #
```

## show support-entitle

To display the content of the entitlement file, use the following command:

**show support-entitle**

### *Example*

```
ruckus(config-sys)# show support-entitle
Serial Number: SN1150
Services purchased: 904
Date to Start :Thu Oct 16 00:00:00 2014
Date to End: Wed Jan 14 23:59:00 2015

Number of APs: licensed
Status: active
Detailed: Support service activated
ruckus(config-sys)#[/pre]
```

## show URL-Filtering-License

To display the current URL Filtering License information, use the following command:

**show URL-Filtering-License**

### *Example*

```
ruckus(config-sys)# show url-filtering-license
ID: 1
Name: URL Filtering Temporal License
Number of APs: 128
Generated by: URL Filtering Temporal license by Ruckus
Serial number/Unique ID: un9418490011251569244593778
Date to Start :Tue Sep 24 16:23:48 2019

Date to End: Mon Dec 23 15:23:48 2019

Status: active
Detailed: This license is available for 54 days.
ruckus(config-sys)#[/pre]
```

## show shared-username-control

To display the web authentication username control setting, use the following command:

**show shared-username-control**

### *Example*

```
ruckus(config-sys)# show shared-username-control
Disabled the checking function of the number of online stations shared the same user account.
ruckus(config-sys)#[/pre]
```

# Configure UPNP Settings

Use the following commands to enable or disable Universal Plug and Play:

## upnp

**upnp**

### Syntax Description

**upnp**

Enable UPnP

### Defaults

Enabled.

### Example

```
ruckus(config)# upnp  
UPnP Service is enabled  
/bin/upnp enable  
ruckus(config)#+
```

## no upnp

**no upnp**

### Syntax Description

**no upnp**

Enable UPnP

### Defaults

Enabled.

### Example

```
ruckus(config)# no upnp  
UPnP Service is disabled  
/bin/upnp disable  
ruckus(config)#+
```

# Configure Zero-IT Settings

To configure Zero-IT settings, use the following commands.

## zero-it

To configure Zero-IT settings, use the following command:

```
zero-it [ local | name WORD ]
```

## zero-it-auth-server

To configure Zero-IT settings, use the following command:

```
zero-it-auth-server [ local | name WORD ]
```

### Syntax Description

#### zero-it-auth-server

Set Zero-IT authentication server

##### local

Set the Zero-IT authentication server to local database

##### name

Set the Zero-IT authentication server to an external AAA server

##### WORD

Name of AAA server

### Defaults

None.

### Example

```
ruckus(config)# zero-it-auth-server name radius
The Authentication Server of Zero IT Activation has been updated.
ruckus(config) #
```

# Configure Dynamic PSK Expiration

The following section lists commands for configuring Dynamic Pre-Shared Keys.

## dynamic-psk-expiration

To set DPSK expiration, use the following command:

**dynamic-psk-expiration TIME**

### Syntax Description

**dynamic-psk-expiration**

Set DPSK expiration

**TIME**

Set DPSK expiration to this time limit (one-day, one-week, two-weeks, one-month, two-months, three-months, half-a-year, one-year, two-years)

**unlimited**

Set DPSKs to never expire

### Defaults

None.

### Example

```
ruckus(config)# dynamic-psk-expiration unlimited  
The Dynamic psk expiration value has been updated.  
ruckus(config) #
```

# Configure WLAN Settings Commands

Use the **config-wlan** commands to configure the WLAN settings, including the WLAN's description, SSID, and its security settings. To run these commands, you must first enter the **config-wlan** context.

## wlan

To create a WLAN or configure an existing WLAN, use the following command:

**wlan <WORD>/<NAME>**

Executing this command enters the config-wlan context.

### Syntax Description

**wlan**

Configure a WLAN

**<WORD>/<NAME>**

Name of the WLAN service

### Defaults

None.

### Example

```
ruckus(config)# wlan ruckus2
The WLAN service 'ruckus2' has been created. To save the WLAN service, type 'end' or 'exit'.
ruckus(config-wlan) #
```

## no wlan

To delete a WLAN service by name, use the following command:

**no wlan<WORD>**

### Example

```
ruckus(config)# no wlan wlantemp
The WLAN service 'wlantemp' has been deleted.
ruckus(config) #
```

## abort

Exits the config-wlan context without saving changes.

## end

Saves changes, and then exits the config-wlan context.

## exit

Saves changes, and then exits the config-wlan context.

## quit

Exits the config-wlan context without saving changes.

## description

To set the WLAN service description, use the following command:

**description WORD**

### Syntax Description

#### **description**

Configure the WLAN description

#### **WORD**

Set the WLAN description this value

### Defaults

None.

### Example

```
ruckus(config-wlan)# description ruckustestwlan2
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## called-station-id-type

To set the called station ID type to, use the following command:

**called-station-id-type [ wlan-bssid | ap-mac ]**

### Syntax Description

#### **wlan-bssid**

Set the called station ID type to 'BSSID:SSID'

#### **ap-mac**

Set the called station ID type to 'APMAC:SSID'

### Defaults

wlan-bssid

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Example

```
ruckus(config-wlan)# called-station-id-type wlan-bssid  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## ssid

To set the WLAN service's SSID or network name, use the following command:

```
ssid SSID
```

#### Syntax Description

**ssid**

Configure the WLAN service's SSID

**SSID**

Set the SSID to this value

#### Defaults

None.

#### Example

```
ruckus(config-wlan)# ssid ruckus2  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan) #
```

## beacon-interval

To set the beacon interval for mesh links, use the following command:

```
beacon-interval NUMBER
```

#### Syntax Description

**beacon-interval**

Set the beacon interval for the WLAN

**NUMBER**

Enter the beacon interval (100~1000 TUs)

#### Defaults

100

#### Example

```
ruckus(config-wlan)# beacon-interval 100  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan) #
```

## wlan-bind

To set the radio for WLAN bind, use the following command:

**wlan-bind <RADIO>**

### Syntax

<RADIO>: [all | 2.g | 5g]

### Defaults

all

### Example

```
ruckus(config-wlan)# wlan-bind all
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## mgmt-tx-rate

To set the transmit rate for management frames, use the following command:

**mgmt-tx-rate RATE**

### Syntax Description

**mgmt-tx-rate**

Set the max transmit rate for management frames

**RATE**

Set the transmit rate (in Mbps).

### Defaults

2

### Example

```
ruckus(config-wlan)# mgmt-tx-rate 2
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## name

To set the name of the WLAN, use the following command:

**name NAME**

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Syntax Description

##### **name**

Set the WLAN name

##### **NAME**

Set to this name

#### Defaults

None.

#### Example

```
ruckus(config-wlan)# name ruckus2  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

#### type

To configure the WLAN type, use the following command:

```
type [ standard-usage | guest-access | hotspot WORD | hs20 WORD | autonomous ]
```

#### Syntax Description

##### **type**

Set the WLAN type

##### **standard-usage**

Set the WLAN type to standard usage

##### **guest-access**

Set the WLAN type to guest access

##### **hotspot WORD**

Set the WLAN type to Hotspot using the hotspot service specified

##### **hs20 WORD**

Set the WLAN type to Hotspot 2.0 using the HS2.0 operator specified

##### **autonomous**

Set the WLAN type to Autonomous.

#### Defaults

Standard usage

#### Example

```
ruckus(config-wlan)# type standard-usage  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **type standard-usage**

To set the WLAN type to “Standard Usage”, use the following command:

**type standard-usage**

**type standard**

## **type guest-access**

To set the WLAN type to “Guest Access”, use the following command:

**type guest-access WORD**

### **Example**

```
ruckus(config-wlan)# type guest-access guestpolicy1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## **type hotspot**

To set the WLAN type to “Hotspot”, use the following command:

**type hotspot**

## **type hs20**

To set the WLAN type to “Hotspot 2.0”, use the following command:

**type hs20<WORD>**

### **Syntax Description**

**type hs20:** set WLAN type to Hotspot 2.0

**<WORD>:** set Hotspot 2.0 Operator name

### **Example**

```
ruckus(config-wlan)# type hs20 operator1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## **type autonomous**

To set the WLAN type to “Autonomous”, use the following command:

**type autonomous**

## **open**

To set the authentication method to 'open', use the following command:

**open [none|owe|wpa2|wpa3|wpa23-mixed|wpa-mixed|wep-64|wep-128] passphrase <WORD> algorithm <WORD>]**

## Configuring Controller Settings

Configure WLAN Settings Commands

### Syntax Description

- none: Sets the authentication method to 'open' and encryption method to 'none'.
- owe: Sets the authentication method to 'open', encryption method to 'OWE', algorithm to 'AES', and pmf to 'required'.
- wpa2: Sets the authentication method to 'open' and encryption method to 'WPA2'.
- wpa3: Sets the authentication method to 'open' and encryption method to 'WPA3'.
- wpa23-mixed: Sets the encryption method to 'WPA2/WPA3 Mixed'.
- wpa-mixed: Sets the encryption method to 'WPA/WPA2 Mixed'.
- AES: Sets the algorithm to AES.
- auto: Sets the algorithm to auto.
- key: Sets the WEP-64 or WEP-128 key.

### Defaults

None.

### Example

```
ruckus(config)# wlan wlan2
The WLAN service 'wlan2' has been created. To save the WLAN service, type 'end' or 'exit'.
ruckus(config-wlan)# open none
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)# end
The WLAN service 'wlan2' has been updated and saved.
Your changes have been saved.
ruckus(config)#

```

### open owe

To set the authentication method to 'open', encryption method to 'OWE', algorithm to 'AES', and pmf to 'required', use the following command:

**open owe**

### Example

```
ruckus(config-wlan)# open owe
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

### open wpa2

To set the authentication method to 'open' and encryption method to 'WPA2', use the following command:

**open wpa2 passphrase WORD algorithm [aes|auto]**

### Example

```
ruckus(config-wlan)# open wpa2 passphrase pass1234 algorithm aes
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## **open wpa3**

To set the encryption method to WPA3, use the following command:

```
open wpa3 passphrase <PASSPHRASE> algorithm aes
```

### **Example**

```
ruckus(config-wlan)# open wpa3 passphrase pass1234 algorithm aes  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#

```

## **open wpa23-mixed**

To set the encryption method to 'WPA2/WPA3 Mixed', use the following command:

```
open wpa23-mixed psk-passphrase <PASSPHRASE> sae-passphrase <PASSPHRASE> algorithm AES
```

### **Example**

```
ruckus(config-wlan)# open wpa23-mixed psk-passphrase pass1234 sae pass5678 algorithm aes  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#

```

## **open wpa-mixed**

To set the encryption method to 'WPA/WPA2 Mixed', use the following command:

```
open wpa-mixed passphrase <PASSPHRASE> sae-passphrase <PASSPHRASE> algorithm [AES | AUTO]
```

### **Example**

```
ruckus(config-wlan)# open wpa-mixed passphrase pass1234 algorithm AES  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#

```

## **open wep-64**

To set the encryption method to 'WEP-64', use the following command:

```
open wep-64 key <WEP64-KEY> key-id <NUMBER>
```

### **Example**

```
ruckus(config-wlan)# open wep-64 key BA3777C135 key-id 1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#

```

## **open wep-128**

To set the encryption method to 'WEP-128', use the following command:

```
open wep-128 key <WEP128-KEY> key-id <NUMBER>
```

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Example

```
ruckus(config-wlan)# open wep-128 key 252e3634733c22372b41272f34 key-id 1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## zero-it-activation

To enable Zero-IT activation, use the following command:

**zero-it-activation**

**zero-it**

#### Syntax Description

**zero-it-activation**

Enable Zero-IT activation

**zero-it**

Enable Zero-IT activation

#### Defaults

Disabled.

#### Example

```
ruckus(config-wlan)# zero-it-activation  
The command was executed successfully. To save the changes, type 'end' or 'exit'.[/pre]
```

## no zero-it-activation

To disable Zero-IT activation, use the following command:

**no zero-it-activation**

**no zero-it**

#### Syntax Description

**no zero-it-activation**

Disable Zero-IT activation

**no zero-it**

Disable Zero-IT activation

#### Defaults

Disabled.

## Example

```
ruckus(config-wlan)# no zero-it
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## mac none

To set the authentication method to 'MAC Address' and encryption method to 'none', use the following command:

```
mac none auth-server WORD
```

## Syntax Description

```
mac
      Set the authentication method to 'MAC Address'
none
      Set the encryption method to 'none'
auth-server WORD
      Set the authorization server address to WORD
```

## Defaults

None.

## Example

```
ruckus(config-wlan)# mac none auth-server Ruckus-Auth-01
The command was executed successfully.
ruckus(config-wlan)#

```

## mac owe

To set the authentication to MAC address and encryption method to 'OWE', use the following command:

```
mac owe auth-server <WORD>
```

## Example

```
ruckus(config-wlan)# mac owe auth-server radius1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## mac wpa2

To set the authentication method to 'MAC Address', encryption method to 'WPA2', and algorithm to 'AES', use the following command:

```
mac wpa2 passphrasePASSPHRASE algorith AES auth-server WORD
```

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Syntax Description

##### **mac wpa2**

Set the authentication method to 'MAC Address' and encryption method to 'WPA2'

##### **passphrase PASSPHRASE**

Set the WPA2 passphrase to PASSPHRASE

##### **algorithm AES**

Set the encryption algorithm to 'AES'

##### **auth-server WORD**

Set the authorization server address to WORD

#### Defaults

None.

#### Example

```
ruckus(config-wlan)# mac wpa2 passphrase 12345678 algorithm AES auth-server Ruckus-Auth-01
The command was executed successfully.
ruckus(config-wlan) #
```

## mac wpa3

To set the encryption method to WPA3, use the following command:

```
mac wpa3 passphrase <PASSPHRASE> algorithm AES auth-server <WORD>
```

#### Defaults

None

#### Example

```
ruckus(config-wlan)# mac wpa3 passphrase passpharse algorithm AES auth-server 192.168.40.3
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan) #
```

## mac wpa23-mixed

To set the encryption method to 'WPA2/WPA3 Mixed', use the following command:

```
mac wpa23-mixed psk-passphrase <PASSPHRASE> sae-passphrase <PASSPHRASE> algorithm AES auth-server <WORD>
```

#### Defaults

None

#### Example

```
ruckus(config-wlan)# mac wpa23-mixed psk-passphrase password123 sae-passphrase password123 algorithm AES
auth-server 192.168.40.3
```

```
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan) #
```

## mac wpa-mixed

To set the authentication method to 'MAC Address', encryption method to WPA-Mixed, and algorithm to AES, use the following command:

```
mac wpa-mixed passphrase <PASSPHRASE> algorithm AES auth-server <WORD>
```

### Syntax Description

**mac wpa-mixed**

Set the authentication method to 'MAC Address' and encryption method to 'WPA-Mixed'

**passphrase PASSPHRASE**

Set the WPA2 passphrase to PASSPHRASE

**algorithm AES**

Set the encryption algorithm to 'AES'

**auth-server WORD**

Set the authorization server to this auth server

### Defaults

None.

### Example

```
ruckus(config-wlan) # mac wpa-mixed passphrase pass1234 algorithm AES auth-server radius  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan) #
```

## mac wep-64

To set the authentication method to 'MAC Address', encryption method to 'WEP-64', key index, and WEP key, use the following command:

```
mac wep-64 key {KEY} key-id {} KEY key-id KEY-ID auth-server WORD
```

### Syntax Description

**mac**

Set the authentication method to MAC address

**wep-64**

Set the encryption method to WEP 64-bit

**key KEY**

Set the WEP key to KEY

**key-id KEY-ID**

Set the WEP key ID to KEY-ID

**auth-server WORD**

Set the authorization server address to WORD

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Defaults

None.

#### Example

```
ruckus(config-wlan)# mac wep-64 key 15791BD8F2 key-id 2 auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan)#[/pre]
```

## mac wep-128

To set the authentication method to 'MAC Address', encryption method to 'WEP-128', key index, and WEP key, use the following command:

```
mac wep-128 KEY key-id KEY-ID auth-server WORD
```

#### Syntax Description

**mac**

Set the authentication method to MAC address

**wep-128**

Set the encryption method to WEP 128-bit

**key KEY**

Set the WEP key to KEY

**key-id KEY-ID**

Set the WEP key ID to KEY-ID

**auth-server WORD**

Set the authorization server address to WORD

#### Defaults

None.

#### Example

```
ruckus(config-wlan)# mac wep-128 key 15715791BD8F212345691BD8F2 key-id 2 auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan)#[/pre]
```

## auth-server

To set the authentication server, use the following command:

**auth-server <WORD>**

### Syntax Description

**auth-server WORD**

Set the authorization server address to WORD

**local**

Set the authorization server address to *local database*

### Defaults

None.

### Example

```
ruckus(config-wlan)# auth-server radius1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## shared wep-64

To set the encryption method to WEP-64, use the following command:

**shared wep-64 key <WEP64-KEY> key-id <NUMBER>**

### Example

```
ruckus(config-wlan)# shared wep-64 key 0011223344 key-id 1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## shared wep-128

To set the encryption method to WEP-128, use the following command:

**shared wep-128 key <WEP128-KEY> key-id <NUMBER>**

### Example

```
ruckus(config-wlan)# shared wep-128 key 2e6a5f5e7d4b46392174756338 key-id 1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## dot1x eap-type EAP-SIM auth-server

To set the authentication method to 'EAP-SIM', use the following command:

**dot1x eap-type EAP-SIM auth-server [ local | name WORD ]**

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Syntax Description

##### **dot1x**

Set the authentication method to '802.11x'

##### **eap-type**

Set the EAP type

##### **EAP-SIM**

Set the authentication method to EAP-SIM

##### **auth-server**

Set authentication server

##### **local**

Set the authentication server to 'local database'

##### **name**

Set the auth server

##### **WORD**

Name of the auth server

#### Defaults

None.

#### Example

```
ruckus(config-wlan)# dot1x eap-type EAP-SIM auth-server local  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## dot1x eap-type PEAP auth-server

To set the authentication method to 'PEAP', use the following command:

```
dot1x eap-type PEAP auth-server [ local | name WORD ]
```

#### Syntax Description

##### **dot1x**

Set the authentication method to '802.11x'

##### **eap-type**

Set the EAP type

##### **PEAP**

Set the authentication method to PEAP

##### **auth-server**

Set authentication server

##### **local**

Set the authentication server to 'local database'

##### **name**

Set the auth server

**WORD**

Name of the auth server

### **Defaults**

None.

### **Example**

```
ruckus(config-wlan)# dot1x eap-type PEAP auth-server local  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **dot1x wpa2**

To set the authentication method to '802.1x EAP', encryption method to 'WPA2', and algorithm to 'AES', use the following command:

```
dot1x wpa2algorithm AES auth-server[ local | name <WORD> ]
```

### **Syntax Description**

**dot1x**

Set the authentication method to '802.11x'

**wpa2**

Set the encryption method to WPA2

**algorithm AES**

Set the algorithm to AES

**auth-server**

Set authentication server

**local**

Set the authentication server to 'local database'

**name**

Set the auth server

<WORD>

Name of the auth server

### **Defaults**

None.

### **Example**

```
ruckus(config-wlan)# dot1x wpa2 algorithm AES auth-server Ruckus-RADIUS  
The command was executed successfully.  
ruckus(config-wlan) #
```

## Configuring Controller Settings

### Configure WLAN Settings Commands

## dot1x wpa2 algorithm auto auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WPA2', and algorithm to 'Auto', use the following command:

```
dot1x wpa2 algorithm auto auth-server [ local | name WORD ]
```

### Syntax Description

#### dot1x

Set the authentication method to '802.11x'

#### wpa2

Set the encryption method to WPA2

#### algorithm auto

Set the algorithm to auto

#### auth-server

Set authentication server

#### local

Set the authentication server to 'local database'

#### name

Set the auth server

#### WORD

Name of the auth server

### Defaults

None.

### Example

```
ruckus(config-wlan)# dot1x wpa2 algorithm auto auth-server Ruckus-Auth-01
The command was executed successfully.
ruckus(config-wlan) #
```

## dot1x wpa-mixed algorithm AES auth-server

To set the authentication method to 802.1x EAP, encryption method to WPA-Mixed, and encryption method to AES, use the following command:

```
dot1x wpa-mixed algorithm AES auth-server [ local | name WORD ]
```

### Syntax Description

#### dot1x

Set the authentication method to '802.11x'

#### wpa-mixed

Set the encryption method to WPA-Mixed

**algorithm AES**  
Set the algorithm to AES

**auth-server**  
Set authentication server

**local**  
Set the authentication server to 'local database'

**name**  
Set the auth server

**WORD**  
Name of the auth server

### Defaults

None.

### Example

```
ruckus(config-wlan)# dot1x wpa-mixed algorithm AES auth-server local  
The command was executed successfully.  
ruckus(config-wlan)#+
```

## dot1x wpa-mixed algorithm auto auth-server

To set the authentication method to 802.1x EAP, encryption method to WPA-Mixed, and encryption method to Auto, use the following command:

```
dot1x wpa-mixed algorithm auto auth-server [ local | name WORD ]
```

### Syntax Description

**dot1x**  
Set the authentication method to '802.11x'

**wpa-mixed**  
Set the encryption method to WPA-Mixed

**algorithm auto**  
Set the algorithm to Auto

**local**  
Set the authentication server to 'local database'

**name**  
Set the auth server

**WORD**  
Name of the auth server

### Defaults

None.

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Example

```
ruckus(config-wlan)# dot1x wpa-mixed algorithm AES auth-server local  
The command was executed successfully.  
ruckus(config-wlan)#[/pre>
```

## dot1x authentication encryption wep-64 auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WEP-64', key index, and WEP key, use the following command:

```
dot1x authentication encryption wep-64 auth-server auth server
```

#### Syntax Description

##### dot1x authentication

Set the authentication method to '802.11x'

##### encryption wep-64

Set the encryption method to WEP 64-bit

##### auth-server auth server

Set the auth server to *auth server*

#### Defaults

None.

#### Example

```
ruckus(config-wlan)# dot1x authentication encryption wep-64 auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan)#[/pre>
```

## dot1x wep-128 auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WEP-128', key index, and WEP key, use the following command:

```
dot1x wep-128 auth-server [ local | name WORD]
```

#### Syntax Description

##### dot1x

Set the authentication method to '802.11x'

##### wep-128

Set the encryption method to WEP 128-bit

##### auth-server[ local | name WORD]

Set the auth server to local or to the named server

#### Defaults

None.

## Example

```
ruckus(config-wlan)# dot1x authentication encryption wep-128 auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan)#+
```

## dot1x none

To set the encryption as none and authentication server to 'Local Database' or the named server, use the following command:

```
dot1x none auth-server [ local | name <WORD> ]
```

### Syntax Description

#### **dot1x none**

Set the authentication method to '802.1x' and encryption to none.

#### [ auth-server local | name WORD ]

Set the auth server to local or to the named server.

### Defaults

None.

## Example

```
ruckus(config-wlan)# dot1x none auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan)#+
```

## dot1x-mac

To set the authentication method to '802.1X EAP + MAC Address', use the following command:

```
dot1x-mac none <WORD> [auth-server name <WORD>]
```

### Syntax Description

#### **dot1x-mac none**

Set the authentication method to '802.1X + MAC Address' and encryption to none

#### **auth-server name WORD**

Set the auth server to the named server

### Defaults

None.

## Example

```
ruckus(config-wlan)# dot1x-mac none auth-server name radius1  
The command was executed successfully.  
ruckus(config-wlan)#+
```

## Configuring Controller Settings

Configure WLAN Settings Commands

## dot1x wpa3

To set the authentication method to 802.1X and the encryption method to WPA3, use the following command:

```
dot1x wpa3 algorithm AES-GCMP-256 auth-server name<WORD>
```

### Defaults

None

### Example

```
ruckus(config-wlan)# ruckus(config-wlan)# dot1x wpa3 algorithm AES-GCMP-256 auth-server name radius1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## bgscan

To enable background scanning on the WLAN, use the following command:

```
bgscan
```

### Example

```
ruckus(config-wlan)# bgscan  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## no bgscan

To disable background scanning on the WLAN, use the following command:

```
no bgscan
```

### Example

```
ruckus(config-wlan)# no bgscan  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## ft-roaming

To enable FT Roaming, use the following command:

```
ft-roaming
```

### Example

```
ruckus(config-wlan)# ft-roaming  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## no ft-roaming

To disable FT Roaming, use the following command:

**no ft-roaming**

## rrm-neigh-report

To enable 802.11k Neighbor-list report, use the following command:

**rrm-neigh-report**

### *Example*

```
ruckus(config-wlan)# rrm-neigh-report
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## no rrm-neigh-report

To isable 802.11k Neighbor-list report, use the following command:

**no rrm-neigh-report**

## https-redirection

To enable HTTPS redirection, use the following command:

**https-redirection**

## no https-redirection

To disable HTTPS redirection, use the following command:

**no https-redirection**

## client-flow-log

To enable logging of client flow data to external syslog, use the following command:

**client-flow-log**

### *Example*

```
ruckus(config-wlan)# client-flow-log
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## no client-flow-log

To disable logging of client flow data to external syslog, use the following command:

**no client-flow-log**

## **Configuring Controller Settings**

### Configure WLAN Settings Commands

#### **Example**

```
ruckus(config-wlan)# no client-flow-log  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **client-connect-log**

To enable logging of client connect data, use the following command:

### **client-connect-log**

#### **Defaults**

Disabled

#### **Example**

```
ruckus(config-wlan)# client-connect-log  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **no client-connect-log**

To disable logging of client connection data, use the following command:

### **client-connect-log**

#### **Defaults**

Disabled

#### **Example**

```
ruckus(config-wlan)# no client-connect-log  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **bypasscna**

Use the following command to bypass Apple Captive Network Assistance (CNA) on iOS and OS X devices.

### **bypasscna**

#### **Example**

```
ruckus(config-wlan)# bypasscna  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **no bypasscna**

To disable the bypass Apple CNA feature, use the following command:

**no bypasscna**

### Example

```
ruckus(config-wlan)# no bypasscna
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## client-isolation

To enable client isolation (per-AP or across APs), use the following command:

```
client-isolation [ isolation-on-ap | isolation-on-subnet ] [ enable | disable ]
```

### Syntax Description

#### client-isolation

Enable client isolation for this WLAN.

#### isolation-on-ap

Enable client isolation per AP.

#### isolation-on-subnet

Enable client isolation across APs.

### Example

```
ruckus(config-wlan)# client-isolation isolation-on-ap enable
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## whitelist

To apply a client isolation whitelist to this WLAN, use the following command:

```
whitelist name WORD
```

## no whitelist

To disable the whitelist for this WLAN, use the following command:

```
no whitelist
```

## load-balancing

To enable load balancing for this WLAN, use the following command:

```
load-balancing
```

### Defaults

Disabled

## **Configuring Controller Settings**

Configure WLAN Settings Commands

### **Example**

```
ruckus(config-wlan)# load-balancing  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **no load-balancing**

To disable load balancing for this WLAN, use the following command:

**no load-balancing**

### **Example**

```
ruckus(config-wlan)# no load-balancing  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **band-balancing**

To enable band balancing for this WLAN, use the following command:

**band-balancing**

### **Defaults**

Enabled.

### **Example**

```
ruckus(config-wlan)# band-balancing  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **no band-balancing**

To disable band balancing for this WLAN, use the following command:

**no band-balancing**

## **send-eap-failure**

To enable send EAP failure messages, use the following command:

**send-eap-failure**

### **Defaults**

Disabled

### **Example**

```
ruckus(config-wlan)# send-eap-failure  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **no send-eap-failure**

To disable send EAP failure messages, use the following command:

```
no send-eap-failure
```

### **Example**

```
ruckus(config-wlan)# no send-eap-failure  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **pap-authenticator**

To enable RADIUS message authenticator in PAP requests, use the following command:

```
pap-authenticator
```

### **Example**

```
ruckus(config-wlan)# pap-authenticator  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **no pap-authenticator**

To disable RADIUS message authenticator in PAP requests, use the following command:

```
no pap-authenticator
```

### **Example**

```
ruckus(config-wlan)# no pap-authenticator  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **nasid-type**

To set the NAS ID type, use the following command:

```
nasid-type [ wlan-bssid | mac-addr | user-define WORD ]
```

### **Syntax Description**

**nasid-type**

Set the NAS ID type

## Configuring Controller Settings

Configure WLAN Settings Commands

### wlan-bssid

Set NAS ID type WLAN-BSSID (default)

### mac-addr

Set NAS ID type to Controller MAC Address

### user-define WORD

Set NAD ID type to a user-defined string

## Defaults

WLAN-BSSID

## Example

```
ruckus(config-wlan)# nasid-type wlan-bssid  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## priority low

To set the WLAN priority to low, use the following command:

**priority low**

## priority high

To set the WLAN priority to high, use the following command:

**priority high**

## web-auth

To enable Web authentication, use the following command:

**web-auth [ local | name WORD ]**

## Syntax Description

### web-auth

Enable Web authentication

### local

Use local database as auth server

### name

Specify an external auth server

### WORD

The AAA server to use for Web authentication

## Defaults

None

## Example

```
ruckus# config  
ruckus(config)# wlan wlan-123  
ruckus(config-wlan)# web-auth Ruckus-RADIUS  
The command was executed successfully.  
ruckus(config-wlan)#+
```

## no web-auth

To disable Web authentication, use the following command:

**no web-auth**

## Syntax Description

**no web-auth**

Disable Web authentication

## Defaults

None.

## Example

```
ruckus# config  
ruckus(config)# wlan wlan-123  
ruckus(config-wlan)# no web-auth  
The command was executed successfully.
```

## grace-period

To enable and set a maximum time (in minutes) for which users must re-authenticate after disconnecting, use the following command:

**grace-period NUMBER**

## Syntax Description

**grace-period**

Enables and Sets a maximum time (in minutes) for which users must re-authenticate after disconnecting.

## Defaults

Disabled.

## Example

```
ruckus(config-wlan)# grace-period 20  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## Configuring Controller Settings

### Configure WLAN Settings Commands

## no grace-period

To disable the grace period, use the following command:

**no grace-period NUMBER**

### Syntax Description

**no grace-period**

Disables the grace period timeout.

### Defaults

Disabled.

### Example

```
ruckus(config-wlan)# no grace-period  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## acct-server

To set the accounting server, use the following command:

**acct-server WORD**

### Syntax Description

**acct-server**

Configure the AAA server

**WORD**

Set the AAA server to this address

### Defaults

None.

### Example

```
ruckus# config  
ruckus(config)# wlan wlan-123  
ruckus(config-wlan)# acct-server Ruckus-Acct-01  
The command was executed successfully.
```

## acct-server interim-update

To configure the interim update frequency (in minutes) of the AAA server, use the following command:

**acct-server WORD interim-update NUMBER**

## Syntax Description

### acct-server

Configure the interim update frequency of the AAA server

### interim-update{minutes}

Set the update frequency to this value (in minutes)

## Defaults

5 (minutes)

## Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan)# acct-server Ruckus-Acct-01 interim-update 5
The command was executed successfully.
```

## no acct-server

To disable the AAA server, use the following command:

### no acct-server

## Syntax Description

### no acct-server

Disable AAA server authentication

## Defaults

None.

## Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan)# no acct-server
The command was executed successfully.
```

## inactivity-timeout

To set the inactivity timeout to the specified number in minutes, use the following command:

### inactivity-timeout NUMBER

## Syntax Description

### inactivity-timeout

Enable and set the inactivity timeout

## **Configuring Controller Settings**

### Configure WLAN Settings Commands

**NUMBER**

Set the inactivity timeout in minutes (1-500 min.)

#### **Defaults**

5

#### **Example**

```
ruckus(config-wlan)# inactivity-timeout 15  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **web-auth-timeout**

To enable and set the web authentication timeout time to the specified number in minutes, use the following command:

**web-auth-timeout NUMBER**

#### **Syntax Description**

**web-auth-timeout**

Enable and set the web authentication timeout

**NUMBER**

Set the inactivity timeout in minutes

#### **Defaults**

5

#### **Example**

```
ruckus(config-wlan)# web-auth-timeout 15  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **vlan**

To set the VLAN ID for the WLAN, use the following command:

**vlan NUMBER**

#### **Syntax Description**

**vlan**

Enable VLAN

**NUMBER**

Set the VLAN ID to this value

## Defaults

1

## Example

```
ruckus(config-wlan)# vlan 123  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## dynamic-vlan

To enable dynamic VLAN, use the following command:

**dynamic-vlan**

### Syntax Description

**dynamic-vlan**

Enable dynamic VLAN

### Usage Guidelines

Dynamic VLAN can be enabled or disabled in the following two conditions: 1) The authentication method is '802.1X/EAP' or 'MAC Address', Encryption method is WPA, WPA2, WPA mixed, or none. 2) Authentication method is 'Open', Encryption method is WPA, WPA2 (Algorithm may not be Auto), enable Zero-IT Activation, enable Dynamic PSK.

## Example

```
ruckus(config-wlan)# dynamic-vlan  
The command was executed successfully. To save the changes, type 'end' or 'exit'
```

## no dynamic-vlan

To disable dynamic VLAN, use the following command:

**no dynamic-vlan**

### Syntax Description

**no dynamic-vlan**

Disable dynamic VLAN

## Defaults

Disabled.

## Example

```
ruckus(config-wlan)# no dynamic-vlan  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## Configuring Controller Settings

Configure WLAN Settings Commands

## mcast-filter

To enable multicast filter for the WLAN, use the following command:

**mcast-filter**

## no mcast-filter

To disable multicast filter for the WLAN, use the following command:

**no mcast-filter**

## hide-ssid

To hide an SSID from wireless users, use the following command. Wireless users who know the SSID will still be able to connect to the WLAN service.

**hide-ssid**

### Syntax Description

**hide-ssid**

Hide SSID from wireless users

### Defaults

Disabled

### Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan)# hide-ssid
The command was executed successfully.
```

## no hide-ssid

To unhide or broadcast an SSID to wireless users, use the following command:

**no hide-ssid**

### Syntax Description

**no hide-ssid**

Broadcast SSID to wireless users

### Defaults

Disabled

### Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan)# no hide-ssid
The command was executed successfully
```

## ofdm-only

To enable support of OFDM rates only, use the following command:

**ofdm-only**

## no ofdm-only

To disable OFDM only rates, use the following command:

**no ofdm-only**

## admission-control

To enable Call Admission Control, use the following command:

**admission-control**

## no admission-control

To disable Call Admissino Control, use the following command:

**no admission-control**

## transient-client-management

To enable transient client management, use the following command:

**transient-client-management**

### Defaults

Disabled.

### Example

```
ruckus(config-wlan)# transient-client-management
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## no transient-client-management

To disable transient client management, use the following command:

**no transient-client-management**

## **Configuring Controller Settings**

### Configure WLAN Settings Commands

#### **Defaults**

Disabled.

#### **Example**

```
ruckus(config-wlan)# no transient-client-management  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **join-wait-time**

To set the time to wait on join requests (1-60 seconds, 5 by default), use the following command:

```
join-wait-time <NUMBER>[/pre]
```

#### **Defaults**

5

#### **Example**

```
ruckus(config-wlan)# transient-client-management  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)# join-wait-time 5  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **join-wait-threshold**

To set the number of join requests to wait (1-50 seconds, 5 by default), use the following command:

```
join-wait-threshold <NUMBER>[/pre]
```

#### **Defaults**

5

#### **Example**

```
ruckus(config-wlan)# join-wait-threshold 5  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **join-expire-time**

To set the join expire time (1-300 seconds, 300 by default), use the following command:

```
join-expire-time <NUMBER>[/pre]
```

#### **Defaults**

300

## Example

```
ruckus(config-wlan)# join-expire-time 300
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## min-client-rssi

To set the minimum client RSSI threshold (-90 to -60 dBm, -85 by default), use the following command:

**min-client-rssi <NUMBER>**

### Defaults

-85

## Example

```
ruckus(config-wlan)# min-client-rssi -85
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## bss-minrate

To set the minimum BSS transmission rate of the WLAN (in Mbps), use the following command:

**bss-minrate NUMBER**

### Syntax Description

#### **bss-minrate**

Set the minimum BSS transmission rate in Mbps.

#### **NUMBER**

Minimum BSS transmission rate

### Defaults

None.

## Example

```
ruckus(config-wlan)# bss-minrate 2
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## no bss-minrate

To disable the minimum BSS transmission rate for the WLAN, use the following command:

**no bss-minrate**

## dtim-period

To set the DTIM period of the WLAN, use the following command:

**dtim-period NUMBER**

### Syntax Description

**dtim-period**

Sets the DTIM period of the WLAN (1-255).

**NUMBER**

DTIM period.

### Defaults

1

### Example

```
ruckus(config-wlan)# dtim-period 5
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#End
```

## no dtim-period

To set the DTIM period of the WLAN to 1 (default), use the following command:

**no dtim-period**

### Syntax Description

**no dtim-period**

Set the DTIM period to 1.

### Defaults

1

### Example

```
ruckus(config-wlan)# no dtim-period  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## Configuring Controller Settings

### Configure WLAN Settings Commands

## directed-threshold

To set the Directed MC/BC threshold of the WLAN (0-128), use the following command:

**directed-threshold NUMBER**

### Syntax Description

#### **directed-threshold**

Set the Directed MC/BC threshold of the WLAN.

#### *NUMBER*

Directed threshold (0-128)

### Defaults

5

### Example

```
ruckus(config-wlan)# directed-threshold 5
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## no directed-threshold

To set the Directed MC/BC threshold of the WLAN to 5 (default), use the following command:

**no directed-threshold**

### Syntax Description

**no directed-threshold**

Sets the Directed Multicast/Broadcast threshold to 5.

### Defaults

5

### Example

```
ruckus(config-wlan)# no directed-threshold  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## tunnel-mode

To enable tunnel mode, use the following command:

**tunnel-mode**

### Syntax Description

**tunnel-mode**

Enable tunnel mode

### Defaults

Disabled.

### Example

```
ruckus# config  
ruckus(config)# wlan wlan-123  
ruckus(config-wlan)# tunnel-mode  
The command was executed successfully.
```

## no tunnel-mode

To disable the tunnel mode, use the following command:

**no tunnel-mode**

## **Configuring Controller Settings**

### Configure WLAN Settings Commands

#### **Syntax Description**

##### **no tunnel-mode**

Disable the tunnel mode

#### **Defaults**

Disabled.

#### **Example**

```
ruckus# config  
ruckus(config)# wlan wlan-123  
ruckus(config-wlan-wlan-123)# no tunnel-mode  
The command was executed successfully.
```

## **dhcp-relay**

To set the DHCP relay server to the specified address (tunneled WLANs only), use the following command:

##### **dhcp-relay WORD**

## **no dhcp-relay**

To disable DHCP relay, use the following command:

##### **no dhcp-relay**

## **smart-roam**

To enable and set SmartRoam with the specified roam factor (1-10), use the following command:

##### **smart-roam NUMBER/EMPTY**

## **no smart-roam**

To disable the SmartRoam feature, use the following command:

##### **no smart-roam**

## **force-dhcp**

To enable the Force DHCP option, use the following command:

##### **force-dhcp**

#### **Defaults**

Disabled

### **Example**

```
ruckus(config-wlan)# force-dhcp  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **force-dhcp-timeout**

To disconnect the client if it does not obtain valid IP address within the specified timeout period (in seconds), use the following command:

**force-dhcp-timeout NUMBER**

### **Defaults**

10 seconds

### **Example**

```
ruckus(config-wlan)# force-dhcp-timeout 10  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## **no force-dhcp**

To disable the Force DHCP option, use the following command:

**no force-dhcp**

## Configuring DHCP Option 82 Sub-Option Settings

Use the following commands to enable DHCP Option 82 and configure sub-option settings for a WLAN.

Execute this command from within the *config-wlan* context to enter the *config-wlan-option82* context and configure option 82 sub-option settings.

### Example

```
ruckus (config-wlan) # option82
Sets the DHCP option82 with default value.
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus (config-wlan-option82) #
```

### option82

To enable DHCP option 82 and enter the config-wlan-option82 context, use the following command:

**option82**

### Defaults

Disabled

### Syntax Description

#### **subopt1**

Enables and sets the DHCP option 82 sub-option1.

#### **subopt1 disable**

Disables the DHCP option 82 sub-option1.

#### **subopt1 rks-circuitid**

sets the DHCP option 82 sub-option1 is RKS\_CircuitID.

#### **subopt1 ap-mac-hex**

sets the DHCP option 82 sub-option1 is AP-MAC.

#### **subopt1 ap-mac-hex-essid**

sets the DHCP option 82 sub-option1 is AP-MAC and ESSID.

#### **subopt2**

Enables and sets the DHCP option 82 sub-option2.

#### **subopt2 disable**

Disables the DHCP option 82 sub-option2.

#### **subopt2 client-mac-hex**

sets the DHCP option 82 sub-option2 is Client-Mac.

#### **subopt2 client-mac-hex-essid**

sets the DHCP option 82 sub-option2 is Client-Mac and Essid.

#### **subopt2 ap-mac-hex**

sets the DHCP option 82 sub-option2 is AP-MAC.

**subopt2 ap-mac-hex-essid**  
sets the DHCP option 82 sub-option2 is AP-MAC and ESSID.

**subopt2 cuid**  
Sets the DHCP option 82 sub-option2 is CUID.

**subopt150**  
Enables and sets the DHCP option 82 sub-option150.

**subopt150 disable**  
Disables the DHCP option 82 sub-option150.

**subopt150 vlan-id**  
sets the DHCP option 82 sub-option150 is Vlan ID.

**subopt151**  
Enables and sets the DHCP option 82 sub-option151.

**subopt151 disable**  
Disables the DHCP option 82 sub-option151.

**subopt151 area-name WORD/NAME**  
Sets the DHCP option 82 sub-option151's Area Name.

**subopt151 essid**  
Sets the DHCP option 82 sub-option151 is Essid.

## **no option82**

To disable DHCP option 82, use the following command:

**no option82**

## **sta-info-extraction**

To enable station information extraction (client fingerprinting), use the following command:

**sta-info-extraction**

### **Defaults**

Enabled

## **no sta-info-extraction**

To disable station information extraction (client fingerprinting), use the following command:

**no sta-info-extraction**

## **max-clients**

To set the maximum number of clients for a specific WLAN, use the following command:

**max-clients NUMBER**

## Configuring Controller Settings

### Configure WLAN Settings Commands

#### Syntax Description

##### **max-clients**

Configure the maximum number of clients that the WLAN can support

##### **NUMBER**

Set the maximum clients to this value

#### Defaults

100

#### Example

```
ruckus(config-wlan)# max-clients 100
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## 802dot11d

To enable 802.11d for the WLAN, use the following command:

### **802dot11d**

#### Defaults

Enabled

## no 802dot11d

To disable 802.11d for the WLAN, use the following command:

### **no 802dot11d**

## arc

Use the following command to enable Application Recognition & Control:

### **arc**

#### Defaults

Disabled

#### Example

```
ruckus(config-wlan)# arc
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## no arc

Use the following command to disable Application Recognition and Control:

**no arc**

## apply-arc-policy

Use the following command to apply an application policy to the WLAN:

**apply-arc-policy WORD**

### Defaults

None

### Example

```
ruckus(config-wlan)# apply-arc-policy facebook
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## no apply-arc-policy

Use the following command to disable an application policy for the WLAN:

**no apply-arc-policy**

### Defaults

None

### Example

```
ruckus(config-wlan)# no apply-arc-policy
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## url-filtering

To enable URL Filtering for the WLAN, use the following command:

**url-filtering**

### Defaults

Disabled

### Example

```
ruckus(config-wlan)# url-filtering
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## Configuring Controller Settings

### Configure WLAN Settings Commands

## no url-filtering

To disable URL Filtering for the WLAN, use the following command:

**no url-filtering**

### Defaults

Disabled

### Example

```
ruckus(config-wlan)# no url-filtering
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## url-filtering-profile

Use the following command to apply a URL filtering profile to the WLAN:

**url-filtering-profile WORD**

### Defaults

None

### Example

```
ruckus(config-wlan)# url-filtering-profile filter1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## auto-proxy

To enable auto-proxy and set the location of the wpad.dat file, use the following command:

**auto-proxy [wpad-saved-on-zd | wpad-saved-on-external-server] url WORD**

### Syntax Description

**auto-proxy**

Enable auto-proxy and specify the location of the wpad.dat file

**wpad-saved-on-ZD**

WPAD.DAT file is saved on ZoneDirector

**wpad-saved-on-external-server**

WPAD.DAT file is saved on an external server

**url**

Specify the WPAD URL configured on DHCP/DNS server

**WORD**

Auto-proxy path and file name

## Defaults

None.

## Example

```
ruckus(config-wlan)# auto-proxy wpad-saved-on-zd url 192.168.0.2/wpad.dat
The file has been loaded into ZoneDirector successfully,Please use 'import' to apply it
ruckus(config-wlan)#+
```

## no auto-proxy

To disable auto-proxy, use the following command:

```
no auto-proxy
```

## pmk-cache

To set the PMK cache time to the specified number in minutes (1~720 minutes), use the following command:

```
pmk-cache timeout NUMBER
```

## Defaults

720 minutes

## no pmk-cache

To disable PMK cache, use the following command:

```
no pmk-cache
```

## pmk-cache-for-reconnect

To apply PMK cache when client reconnects (default), use the following command:

```
pmk-cache-for-reconnect
```

## no pmk-cache-for-reconnect

To disable application of PMK caching when client reconnects, use the following command:

```
no pmk-cache-for-reconnect
```

## Defaults

Enabled

## **Configuring Controller Settings**

Configure WLAN Settings Commands

### **Usage Guidelines**

When “no pmk-cache-for-reconnect” is set, the controller attempts to look up PMK cache for roaming clients only, so every client reconnection requires a full reauthentication. A graceful roaming (disconnect before connecting to the roam-to AP) is not regarded as roaming from the controller’s perspective.

## **sae-anti-clogging-threshold**

To set the SAE anti\_clogging\_threshold to the specified number, use the following command:

**sae-anti-clogging-threshold<NUMBER>**

### **Defaults**

None

### **Example**

```
ruckus(config-wlan)# sae-anti-clogging-threshold 10
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#

```

## **roaming-acct-interim-update**

To enable accounting interim-updates when a client roams, use the following command:

**roaming-acct-interim-update**

### **Defaults**

Disabled.

### **Usage Guidelines**

When “roaming-acct-interim-update” is set, all traffic and session-id data from the original session is carried over to the new session.

## **no roaming-acct-interim-update**

To disable accounting interim updates when a client roams (default: disabled), use the following command:

**no roaming-acct-interim-update**

## **show**

To display WLAN settings, use the following command:

**show**

### **Defaults**

None

### Example

```
ruckus(config-wlan)# show
WLAN Service:
ID:
:
NAME = wlantest
Tx. Rate of Management Frame(2.4GHz) = 2.0Mbps
Tx. Rate of Management Frame(5GHz) = 6.0Mbps
Beacon Interval = 100ms
SSID = wlantest
Description =
Type = Standard Usage
Authentication = open
Encryption = wpa3
Algorithm = aes
Passphrase = password123
SAE anti-clogging-threshold = 10
FT Roaming = Disabled
802.11k Neighbor report = Disabled
Web Authentication = Disabled
Authentication Server = Disabled
Accounting Server = Disabled
Called-Station-Id type = wlan-bssid
Tunnel Mode = Disabled
DHCP relay = Disabled
Background Scanning = Enabled
Max. Clients = 100
Isolation per AP = Disabled
Isolation across AP = Disabled
Zero-IT Activation = Disabled
Priority = High
Load Balancing = Disabled
Band Balancing = Disabled
Dynamic PSK = Disabled
Rate Limiting Uplink = Disabled
PerSSID Rate Limiting Uplink = 0
Rate Limiting Downlink = Disabled
PerSSID Rate Limiting Downlink = 0
Auto-Proxy configuration:
    Status = Disabled
Inactivity Timeout:
    Status = Enabled
    Timeout = 5 Minutes
VLAN-ID = 1
Dynamic VLAN = Disabled
Closed System = Disabled
Https Redirection = Disabled
OFDM-Only State = Disabled
Multicast Filter State = Disabled
802.11d State = Disabled
Force DHCP State = Disabled
Force DHCP Timeout = 10
DHCP Option82:
    Status = Disabled
    Option82 sub-Option1 = Disabled
    Option82 sub-Option2 = Disabled
    Option82 sub-Option150 = Disabled
    Option82 sub-Option151 = Disabled
Ignore unauthorized client statistic = Disabled
STA Info Extraction State = Enabled
BSS Minrate = Disabled
DTIM period = 1
Directed MC/BC Threshold = 5
Call Admission Control State = Disabled
PMK Cache Timeout= 720 minutes
PMK Cache for Reconnect= Enabled
NAS-ID Type= wlan-bssid
Roaming Acct-Interim-Update= Disabled
PAP Message Authenticator = Enabled
Send EAP-Failure = Disabled
```

## Configuring Controller Settings

### Configure WLAN Settings Commands

```
L2/MAC = No ACLS
L3/L4/IP Address = No ACLS
L3/L4/IPv6 Address = No ACLS
Precedence = Default
Proxy ARP = Disabled
Device Policy = No ACLS
Vlan Pool = No Pools
Role based Access Control Policy = Disabled
SmartRoam = Disabled Roam-factor = 1
White List = No ACLS
URL Filtering = Enabled
Application Recognition & Control = Disabled
Client Flow Data Logging = Disabled
Wlan Bind = all
Client Connection Data = Disabled
Transient Client Management = Disabled
80211w-pmf = Required
```

```
ruckus (config-wlan) #
```

# Configure Dynamic PSK Commands

Use the following commands to enable and configure Ruckus Dynamic Pre-Shared Key functionality for the WLAN.

## dynamic-psk enable

To enable internal Dynamic Pre-Shared Keys, use the following command:

**dynamic-psk enable**

### Syntax Description

**dynamic-psk enable**

Enable internal Dynamic PSK

### Defaults

Disabled

### Example

```
ruckus(config-wlan)# dynamic-psk enable  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## dynamic-psk external

To enable external Dynamic Pre-Shared Keys, use the following command:

**dynamic-psk external auth-server <WORD>**

### Syntax Description

**dynamic-psk external**

Enable external Dynamic PSK

**auth-server <WORD>**

Specify authentication server

### Defaults

Disabled

### Example

```
ruckus(config-wlan)# dynamic-psk external auth-server RADIUS  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#+
```

## dynamic-psk passphrase-len

To set the Dynamic Pre-Shared Key passphrase length, use the following command:

**dynamic-psk passphrase-len NUMBER**

## dynamic-psk type

To sets the type of dynamic PSK (secure or mobile-friendly), use the following command:

**dynamic-psk type [mobile-friendly|secure]**

### Syntax Description

**dynamic-psk type**

Set the DPSK type

**mobile-friendly**

Set the DPSK type to mobile-friendly

**secure**

Set the DPSK type to secure

### Defaults

Secure

### Example

```
ruckus(config-wlan)# dynamic-psk type mobile-friendly  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## no dynamic-psk

To disable Dynamic Pre-Shared Keys on the WLAN, use the following command:

**no dynamic-psk**

## limit-dpsk

To enable Dynamic PSK limits and set the max number of devices per user, use the following command:

**limit-dpsk NUMBER**

## no limit-dpsk

To disable Dynamic PSK limits, use the following command:

**no limit-dpsk**

## shared-dpsk

To enable Shared Dynamic PSK and set the number of devices that can share one unbound DPSK (2-4000), use the following command:

**shared-dpsk <NUMBER>**

## no shared-dpsk

To disable Shared Dynamic PSK, use the following command:

**no shared-dpsk**

## dynamic-psk-expiration

To set the WLAN Dynamic PSK expiration, use the following command:

**dynamic-psk-expiration [ length | start-point ] WORD**

### Syntax Description

#### **dynamic-psk-expiration**

Sets the DPSK expiration.

#### **length**

Sets the DPSK expiration length.

#### **unlimited**

Sets wlan dynamic psk expiration to unlimited.

#### **one-day**

Sets wlan dynamic psk expiration to one day.

#### **one-week**

Sets wlan dynamic psk expiration to one week.

#### **two-weeks**

Sets wlan dynamic psk expiration to two weeks.

#### **one-month**

Sets wlan dynamic psk expiration to one month.

#### **two-months**

Sets wlan dynamic psk expiration to two months.

#### **three-months**

Sets wlan dynamic psk expiration to three months.

#### **half-a-year**

Sets wlan dynamic psk expiration to half a year.

#### **one-year**

Sets wlan dynamic psk expiration to one year.

#### **two-years**

Sets wlan dynamic psk expiration to two years.

**start-point**

Sets the DPSK validity start-point.

**first-use**

The D-PSK expiration will be calculated from when it is first used.

**creation-time**

The D-PSK expiration will be calculated from when it is created.

**Example**

```
ruckus(config-wlan)# dynamic-psk-expiration start-point first-use  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)# dynamic-psk-expiration length one-week  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## no l2acl

To disable Layer 2 Access Control Lists, use the following command:

**no l2acl**

## no role-based-access-ctrl

To disable role based access control policy service, use the following command:

**no role-based-access-ctrl**

## no l3acl

To disable Layer 3/4 ACLs, use the following command:

**no l3acl**

## no l3acl-ipv6

To disable Layer 3/4 IPv6 ACLs, use the following command:

**no l3acl-ipv6**

## no vlanpool

To disable the VLAN pool for this WLAN, use the following command:

**no vlanpool**

## no dvcpcy

To disable device policy for this WLAN, use the following command:

**no dvcpcy**

## rate-limit

To set the rate limiting for the WLAN, use the following command:

**rate-limit uplink NUMBER downlink NUMBER**

### Syntax Description

**rate-limit**

Set the rate limit

**uplink**

Set the uplink rate limit

**downlink**

Set the downlink rate limit

**NUMBER**

Set the rate limiting to the value specified.

### Defaults

None.

### Example

```
ruckus(config-wlan)# rate-limit uplink 20 downlink 20
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan)#+
```

## no rate-limit

To disable the rate limit, use the following command:

**no rate-limit**

### Syntax Description

**no rate-limit**

Disable rate limiting for the WLAN

### Defaults

Disabled.

### Example

```
ruckus(config-wlan)# no rate-limit
The command was executed successfully. To save the changes, type 'end' or 'exit'.+#
```

## vlanpool

To configure a VLAN pool with the specified name, use the following command:

**vlanpool WORD**

## no mac-addr-format

Sets MAC auth username and password to format aabbccddeeff.

## mac-addr-format

Sets MAC auth username and password to one of the following formats:

**mac-addr-format aa-bb-cc-dd-ee-ff**

Sets MAC auth username and password to format aa-bb-cc-dd-ee-ff.

**mac-addr-format aa:bb:cc:dd:ee:ff**

Sets MAC auth username and password to format aa:bb:cc:dd:ee:ff.

**mac-addr-format AABBCCDDEEFF**

Sets MAC auth username and password to format AABBCCDDEEFF.

**mac-addr-format AA-BB-CC-DD-EE-FF**

Sets MAC auth username and password to format AA-BB-CC-DD-EE-FF.

**mac-addr-format AA:BB:CC:DD:EE:FF**

Sets MAC auth username and password to format AA:BB:CC:DD:EE:FF.

## acl dvcpolicy

To apply a Device Policy to the WLAN, use the following command:

**acl dvcpolicy WORD**

## acl precedence

To apply a Precedence Policy to the WLAN, use the following command:

**acl precedence WORD**

## acl role-based-access-ctrl

To enable Role based Access Control Policy on the WLAN, use the following command:

**acl role-based-access-ctrl**

### Defaults

Disabled

### Example

```
ruckus(config-wlan)# acl role-based-access-ctrl  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlan)#[/pre]
```

## **qos classification**

To enable Quality of Service classification, use the following command:

**qos classification**

## **no qos classification**

To disable Quality of Service classification, use the following command:

**no qos classification**

## **qos heuristics-udp**

To enable QoS heuristics for UDP traffic, use the following command:

**qos heuristics-udp**

## **no qos heuristics-udp**

To disable QoS heuristics for UDP traffic, use the following command:

**no qos heuristics-udp**

## **qos directed-multicast**

To enable QoS directed multicast, use the following command:

**qos directed-multicast**

## **no qos directed-multicast**

To disable QoS directed multicast, use the following command:

**no qos directed-multicast**

## **qos igmp-snooping**

To disable QoS directed multicast, use the following command:

**qos igmp-snooping**

## **no qos igmp-snooping**

To disable QoS IGMP snooping, use the following command:

**no qos igmp-snooping**

## **qos mld-snooping**

To enable QoS MLD snooping, use the following command:

**no qos mld-snooping**

## **no qos mld-snooping**

To disable QoS MLD snooping, use the following command:

**no qos mld-snooping**

## **qos tos-classification**

To enable QoS TOS classification, use the following command:

**qos tos-classification**

## **no qos tos-classification**

To disable QoS TOS classification, use the following command:

**no qos tos-classification**

## **qos priority high**

To set QoS priority to 'high', use the following command:

**qos priority high**

## **qos priority low**

To set QoS priority to 'low', use the following command:

**qos priority low**

## **qos directed-threshold**

To set the QoS directed threshold, use the following command:

**qos directed-threshold NUMBER**

## **disable-dgaf**

To disable Downstream Group-Address Frame Forwarding, use the following command (Hotspot 2.0 WLAN only):

**disable-dgaf**

## **no disable-dgaf**

To enable Downstream Group-Address Frame Forwarding, use the following command (Hotspot 2.0 WLAN only):

**no disable-dgaf**

## proxy-arp

To enable Proxy ARP service for the WLAN, use the following command:

**proxy-arp**

## no proxy-arp

To disable Proxy ARP service for the WLAN, use the following command:

**no proxy-arp**

## 80211w-pmf

To enable 802.11w PM, use the following command:

**80211w-pmf**

## no 80211w-pmf

To disable 802.11w PMF, use the following command:

**no 80211w-pmf**

## ignor-unauth-stats

To enable ignoring unauthorized client statistics, use the following command:

**ignor-unauth-stats**

## no ignor-unauth-stats

To disable ignoring unauthorized client statistics, use the following command:

**no ignor-unauth-stats**

## show

To display the WLAN settings, use the following command:

**show**

### Syntax Description

**show**

Display WLAN settings

### Defaults

None.

## Configuring Controller Settings

Configure Dynamic PSK Commands

### Example

```
ruckus(config)# wlan ruckus1
The WLAN service 'ruckus1' has been loaded. To save the WLAN service, type 'end' or 'exit'.
ruckus(config-wlan)# show
WLAN Service:
ID:
1:
NAME = Ruckus-Wireless-1
Tx. Rate of Management Frame(2.4GHz) = 2.0Mbps
Tx. Rate of Management Frame(5GHz) = 6.0Mbps
Beacon Interval = 100ms
SSID = Ruckus-Wireless-1
Description = Ruckus-Wireless-1
Type = Standard Usage
Authentication = open
Encryption = wpa
Algorithm = aes
Passphrase = password
FT Roaming = Disabled
802.11k Neighbor report = Disabled
Web Authentication = Disabled
Authentication Server = Disabled
Accounting Server = Disabled
Called-Station-Id type = wlan-bssid
Tunnel Mode = Disabled
DHCP relay = Disabled
Max. Clients = 100
Isolation per AP = Disabled
Isolation across AP = Disabled
Zero-IT Activation = Enabled
Load Balancing = Disabled
Band Balancing = Disabled
Dynamic PSK = Enabled
Dynamic PSK Passphrase Length =
Limit Dynamic PSK = Disabled
Auto-Proxy configuration:
    Status = Disabled
Inactivity Timeout:
    Status = Disabled
VLAN-ID = 1
Dynamic VLAN = Disabled
Closed System = Disabled
OFDM-Only State = Disabled
Multicast Filter State = Disabled
802.11d State = Disabled
Force DHCP State = Disabled
Force DHCP Timeout = 0
DHCP Option82:
    Status = Disabled
    Option82 sub-Option1 = Disabled
    Option82 sub-Option2 = Disabled
    Option82 sub-Option150 = Disabled
    Option82 sub-Option151 = Disabled
Ignore unauthorized client statistic = Disabled
STA Info Extraction State = Enabled
BSS Minrate = Disabled
Call Admission Control State = Disabled
PMK Cache Timeout= 720 minutes
PMK Cache for Reconnect= Enabled
NAS-ID Type= wlan-bssid
Roaming Acct-Interim-Update= Disabled
PAP Message Authenticator = Enabled
Send EAP-Failure = Disabled
L2/MAC = No ACLS
L3/L4/IP Address = No ACLS
L3/L4/IPv6 Address = No ACLS
Precedence = No ACLS
Proxy ARP = Disabled
Device Policy = No ACLS
Role based Access Control Policy = Disabled
```

```
SmartRoam = Disabled Roam-factor = 1
White List = No ACLS
Application Visibility = disabled
Apply Policy Group = No_Denys
```

```
ruckus(config)#
```

# Configure WLAN Group Commands

Use the wlan-group commands to configure the settings of a particular WLAN group.

## wlan-group

To create a new WLAN group or update an existing WLAN group, use the following command:

**wlan-group WORD**

### Syntax Description

**wlan-group**

Configure the WLAN group

**WORD**

Name of the WLAN group

### Defaults

Default.

### Example

```
ruckus# config
ruckus(config)# wlan-group wlangroup2
The WLAN group 'wlangroup2' has been created. To save the WLAN group, type 'end' or 'exit'.
ruckus(config-wlangrp) #
```

## no wlan-group

To delete a WLAN group from the list, use the following command:

**no wlan-group WORD**

### Syntax Description

**no wlan-group**

Delete the WLAN group

**WORD**

Name of the WLAN group

### Defaults

None.

### Example

```
ruckus(config)# no wlan-group wlan-grp-01
The WLAN group 'wlan-grp-01' has been removed.
ruckus(config) #
```

## abort

To exit the wlan-group context without saving changes, use the abort command. Enter this command from within the context of the WLAN group that you are configuring.

**abort**

### Syntax Description

**abort**

Exit the WLAN group without saving changes

### Defaults

None.

### Example

```
ruckus# config
ruckus(config)# wlan-group wlangroup2
The WLAN group 'wlangroup2' has been created. To save the WLAN group, type 'end' or 'exit'.
ruckus(config-wlangrp)# abort
No changes have been saved.
ruckus(config)#+
```

## end

To save changes to the WLAN group settings and exit the wlan-group context, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

**end**

### Syntax Description

**end**

Save changes, and then exit the WLAN group

### Defaults

None.

### Example

```
ruckus# config
ruckus(config)# wlan-group wlangroup2
The WLAN group 'wlangroup2' has been created. To save the WLAN group, type 'end' or 'exit'.
ruckus(config-wlangrp)# end
The WLAN group 'wlangroup2' has been updated.
Your changes have been saved.
ruckus(config)#+
```

## exit

To save changes to the WLAN group settings and exit the wlan-group context, use the exit command. Enter this command from within the context of the WLAN group that you are configuring.

**exit**

### Syntax Description

**exit**

Save changes, and then exit the WLAN group

### Defaults

None.

### Example

```
ruckus# config
ruckus(config)# wlan-group wlangroup2
The WLAN group entry 'wlangroup2' has been loaded. To save the WLAN group, type 'end' or 'exit'.
ruckus(config-wlangrp)# exit
The WLAN group 'wlangroup2' has been updated.
Your changes have been saved.
ruckus(config)#+
```

## quit

To exit the wlan-group context without saving changes, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

**quit**

### Syntax Description

**quit**

Exit the WLAN group without saving changes

### Defaults

None.

### Example

```
ruckus# config
ruckus(config)# wlan-group wlangroup2
The WLAN group entry 'wlangroup2' has been loaded. To save the WLAN group, type 'end' or 'exit'.
ruckus(config-wlangrp)# quit
No changes have been saved.
ruckus(config)#+
```

## name

To set the WLAN group name, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

**name WORD**

### Syntax Description

**name**

Configure the WLAN group name

**WORD**

Set the WLAN group name to this value

### Defaults

None.

### Example

```
ruckus# config
ruckus(config)# wlan-group wlangroup2
The WLAN group entry 'wlangroup2' has been loaded. To save the WLAN group, type 'end' or 'exit'.
ruckus(config-wlangrp)# name wlangroup2
ruckus(config-wlangrp)# show
WLAN Group:
ID:
 2:
  Name= wlangroup2
  Description=
  WLAN Service:

ruckus(config-wlangrp) #
```

## description

To set the WLAN group description, use the following command. Enter this command from within the context of the WLAN group that you are configuring. Multiple word text must be enclosed in quotes.

**description WORD**

### Syntax Description

**description**

Configure the WLAN group description

**WORD**

Set the WLAN group description to this value

### Defaults

None.

## Configuring Controller Settings

### Configure WLAN Group Commands

#### Example

```
ruckus# config
ruckus(config)# wlan-group wlangroup2
ruckus(config-wlangrp)# description "WLAN Group 2"
ruckus(config-wlangrp)# show
WLAN Group:
ID:
 2:
  Name= wlangroup2
  Description= WLAN Group 2
  WLAN Service:
ruckus(config-wlangrp) #
```

## wlan

To add a WLAN service to the WLAN group, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

**wlan WORD**

#### Syntax Description

**wlan**

Add a WLAN to the WLAN group

**WORD**

Name of the WLAN to be added

#### Defaults

None.

#### Example

```
rruckus(config-wlangrp)# wlan ruckus1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlangrp)# show
WLAN Group:
ID:
  :
  Name= wlangroup1
  Description=
  WLAN Service:
    WLAN1:
      NAME= ruckus1
      VLAN=
ruckus(config-wlangrp) #
```

## no wlan

To remove a WLAN service from the WLAN group, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

**no wlan WORD**

## Syntax Description

### **no wlan**

Delete an existing WLAN service from the WLAN group

### **WORD**

Name of the WLAN to be removed

## Defaults

None.

## Example

```
ruckus(config-wlangrp)# no wlan ruckus1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlangrp)#[/pre]
```

## wlan vlan override none

To add a WLAN service to the WLAN group and set the VLAN tag to 'No Change', use the following command. Enter this command from within the context of the WLAN group that you are configuring.

### **wlan WORD vlan override none**

## Syntax Description

### **wlan WORD**

Add the WLAN to the WLAN group

### **vlan override none**

Set the VLAN tag to No Change

## Defaults

None.

## Example

```
ruckus(config-wlangrp)# wlan ruckus1 vlan override none  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlangrp)#[/pre]
```

## wlan vlan override tag

To add a WLAN service to the WLAN group and set the VLAN tag to the specified VLAN ID, use the following command:

### **wlan NAME vlan override tag NUMBER**

## Syntax Description

### **wlan NAME**

Add the NAME to the WLAN group

**vlan override tag NUMBER**

Set the VLAN tag of NAME to the specified NUMBER

**Defaults**

None.

**Example**

```
ruckus(config-wlangrp)# wlan ruckus1 vlan override tag 12  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-wlangrp) #
```

**show**

To display WLAN group settings, use the following command:

```
show
```

**Defaults**

```
ruckus(config-wlangrp)# show
```

WLAN Group:

ID:

1:

Name= Default

Description= Default WLANs for Access Points

WLAN Service:

WLAN1:

NAME= Ruckus1

VLAN=

```
ruckus(config-wlangrp) #
```

# Configure Role Commands

Use the role commands to configure user roles on the controller. To run these commands, you must first enter the **config-role** context.

## role

To create a new role or modify an existing role, use the following command:

**role WORD**

### Syntax Description

**role**  
Create or modify a user role  
**WORD**  
Name of role

### Defaults

None.

### Example

```
ruckus(config)# role role1
The role entry 'role1' has been created
ruckus(config-role)#+
```

## no role

To delete a role entry from the list, use the following command:

**no role WORD**

### Syntax Description

**no role**  
Delete a user role  
**WORD**  
Name of role

### Defaults

None.

### Example

```
ruckus(config)# no role role1
The Role 'role1' has been deleted.
ruckus(config)#+
```

## abort

To exit the config-role context without saving changes, use the abort command. Enter this command from within the context of the role that you are configuring.

**abort**

### Syntax Description

**abort**

Exit the role without saving changes

### Defaults

None.

### Example

```
ruckus(config-role)# abort  
No changes have been saved.  
ruckus(config)#
```

## end

To save changes, and then exit the config-role context, use the following command:

**end**

### Syntax Description

**end**

Save changes, and then exit the context

### Defaults

None.

### Example

```
ruckus(config-role)# end  
The Role entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#
```

## exit

To save changes, and then exit the config-role context, use the following command:

**exit**

## Syntax Description

### exit

Save changes, and then exit the context

## Defaults

None.

## Example

```
ruckus(config-role)# exit  
The Role entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#
```

## quit

To exit the config-role context without saving changes, use the quit command. Enter this command from within the context of the role that you are configuring.

### quit

## Syntax Description

### quit

Exit the role without saving changes

## Defaults

None.

## Example

```
ruckus(config-role)# quit  
No changes have been saved.  
ruckus(config)#
```

## name

To set the name of a user role, use the following command:

### name WORD

## Syntax Description

### name

Set the name of a user role

### WORD

Set to this role

## **Configuring Controller Settings**

### Configure Role Commands

#### **Defaults**

None.

#### **Example**

```
ruckus(config-role)# name guest33  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **description**

To set the description for a user role, use the following command:

**description WORD**

#### **Syntax Description**

**description**

Set the description of a user role

**WORD**

Set to this description

#### **Defaults**

None.

#### **Example**

```
ruckus(config-role)# description testforCLI  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **group-attributes**

To set the group attributes of a user role, use the following command:

**group-attributes WORD**

#### **Syntax Description**

**group-attributes**

Set the attributes of a user role

**WORD**

Set to this attribute

#### **Defaults**

None.

## Example

```
ruckus(config-role)# group-attributes ruckus1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## wlan-allowed

To set the WLANs to which a user role will have access, use the following command:

```
wlan-allowed [ all | specify-wlan ]
```

### Syntax Description

#### wlan-allowed

Set the WLANs to which a role will have access

##### all

Grant access to all WLANs

##### specify-wlan

Grant access to a specific WLAN

### Defaults

None.

## Example

```
ruckus(config-role)# wlan-allowed all
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-role)# wlan-allowed specify-wlan
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## specify-wlan-access

To add a particular WLAN to the list of WLANs that a user role can access, use the following command:

```
specify-wlan-access wlan_ssid
```

### Syntax Description

#### specify-wlan-access

Add access to a WLAN by a user role

##### wlan\_ssid

Add access to this WLAN

### Defaults

None.

## Configuring Controller Settings

### Configure Role Commands

#### Example

```
ruckus(config-role)# specify-wlan-access joejoe98  
The wlan 'joejoe98' has been added to the Role.
```

## no specify-wlan-access

To remove a particular WLAN from the list of WLANs that a user role can access, use the following command:

```
no specify-wlan-access WORD/SSID
```

#### Syntax Description

**no specify-wlan-access**

Remove access to a WLAN by a user role

WORD/SSID

Remove access to this WLAN

#### Defaults

None.

#### Example

```
ruckus(config-role)# no specify-wlan-access joejoe98  
The wlan 'joejoe98' has been removed from the Role.
```

## guest-pass-generation

To add guest pass generation privileges to a user role, use the following command:

```
guest-pass-generation
```

#### Syntax Description

**guest-pass-generation**

Add guest pass generation privileges to a user role

#### Defaults

None.

#### Example

```
ruckus(config-role)# guest-pass-generation  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## no guest-pass-generation

To remove guest pass generation privileges from a user role, use the following command:

**no guest-pass-generation**

### Syntax Description

**no guest-pass-generation**

Remove guest pass generation privileges from a user role

### Defaults

None.

### Example

```
ruckus(config-role)# no guest-pass-generation  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## admin

To add ZoneDirector administration privileges to a user role, use the following command:

**admin [ super | operator | monitoring ]**

### Syntax Description

**admin**

Add ZoneDirector administration privileges to a user role

**super**

Sets to Super (Perform all configuration and management tasks)

**operator**

Sets to Operator (Change settings affecting single AP's only)

**monitoring**

Sets to Monitoring (Monitoring and viewing operation status only)

### Defaults

None.

### Example

```
ruckus(config-role)# admin super  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## no admin

To remove ZoneDirector administration privileges from a user role, use the following command:

**no admin**

## Configuring Controller Settings

### Configure Role Commands

#### Syntax Description

##### **no admin**

Remove ZoneDirector administration privileges from a user role

#### Defaults

None.

#### Example

```
ruckus(config-role)# no admin  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## access-ctrl

Enables access control policy.

#### Defaults

Disabled

#### Example

```
ruckus(config)# role role1  
The Role entry 'role1' has been created.  
ruckus(config-role)# access-ctrl  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-role)# show  
Role:  
  ID:  
  :  
    Name= role1  
    Description=  
    Group Attributes=  
    Guest Pass Generation= Disallowed  
    ZoneDirector Administration:  
      Status= Disallowed  
    Allow All WLANs:  
      Mode= Allow Specify WLAN access  
      Access Control Policy= Allowed  
    Allow All OS Types:  
      Mode= Allow all OS types to access  
      VLAN = Any  
      Rate Limiting Uplink = Disabled  
      Rate Limiting Downlink = Disabled  
  
ruckus(config-role) #
```

## no access-ctrl

Disables access control policy.

##### **no access-ctrl**

## dvc-type-allowed

To allow all or specify device type access, use the following command:

**os-type-allowed [all|specify]**

### Example

```
ruckus(config-role)# dvc-type-allowed all  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-role)#[/pre]
```

## specify-dvc-policy

To add the specified device policy into the role entry, use the following command:

**specify-dvc-policy <WORD>**

### Example

```
ruckus(config-role)# specify-dvc-policy 0  
ruckus(config-role)#[/pre]
```

## vlan

Sets the VLAN ID to the specified ID number or "none"

**vlan NUMBER**

## rate-limit uplink

Sets the rate limiting of uplink.

**rate-limit uplink NUMBER**

## rate-limit uplink downlink

Sets the rate limiting of downlink.

**rate-limit uplink NUMBER downlink NUMBER**

## no rate-limit

Sets rate limiting to Disable.

**no rate-limit**

## apply-arc-policy

To configure an ARC policy with the specified name, use the following command:

**apply-arc-policy<WORD>**

### Syntax Description

**apply-arc-policy**

Configures an Application Recognition and Control policy with the specified name.

**WORD**

Name of the ARC policy.

### Defaults

None.

### Example

```
ruckus(config-role)# apply-arc-policy Facebook
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-role)#[/pre]
```

## no apply-arc-policy

To disable ARC policy, use the following command:

**no apply-arc-policy**

### *Example*

```
ruckus(config-role)# no apply-arc-policy  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-role)#+
```

## url-filtering

To configure URL Filtering with the specified name, use the following command:

**url-filtering WORD**

### *Defaults*

None

### *Example*

```
ruckus(config-role)# url-filtering filter1  
Sorry, Please Enable 'Access Control Policy' firstly, then try again.  
ruckus(config-role)#+
```

## no url-filtering

To disable URL filtering, use the following command:

**no url-filtering**

### *Defaults*

None

### *Example*

```
ruckus(config-role)# no url-filtering  
Sorry, Please Enable 'Access Control Policy' firstly, then try again.  
ruckus(config-role)#+
```

## show

To display the settings of a role, use the following command:

**show**

## Configuring Controller Settings

### Configure Role Commands

#### Syntax Description

**show**

Display the settings of a role

#### Defaults

None.

#### Example

```
ruckus(config-role)# show
Role:
  ID:
  :
    Name= role1
    Description=
    Group Attributes=
    Guest Pass Generation= Disallowed
    ZoneDirector Administration:
      Status= Disallowed
    Allow All WLANs:
      Mode= Allow Specify WLAN access
      Access Control Policy= Disallowed

ruckus(config-role)#

```

# Configure VLAN Pool Commands

Use the `vlan-pool` commands to create and configure a VLAN pool. Running these commands enters the `config-vlan-pool` context from within the `config` context.

## vlan-pool

To create a new VLAN pool or modify an existing pool, and enter the config-vlan-pool context, use the following command:

**vlan-pool WORD**

### Syntax Description

**abort**

Exits the config-vlanpool context without saving changes.

**end**

Saves changes, and then exits the config-vlanpool context.

**exit**

Saves changes, and then exits the config-vlanpool context.

**quit**

Exits the config-vlanpool context without saving changes.

**name WORD**

Sets the vlan pool entry name.

**description WORD**

Sets the vlan pool entry description.

**vlan**

Adds or deletes vlans from the vlan pool.

**vlan add WORD**

Add the vlan to the specified pool.

**vlan delete WORD**

Delete the vlan from the specified pool.

**vlan show**

**option NUMBER**

Set the option 1 'Mac Hash' 2 'Round-Robin' 3 'Least-Used' to the specified pool.

**show**

Displays pool settings.

### Example

```
ruckus(config)# vlan-pool vlan-pool-1
The vlan pool entry 'vlan-pool-1' has been created.
ruckus(config-vlanpool)# description "vlan pool for printers"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-vlanpool)# option 1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-vlanpool)# vlan add 10
ruckus(config-vlanpool)# vlan add 20
```

## Configuring Controller Settings

### Configure VLAN Pool Commands

```
ruckus(config-vlanpool)# vlan add 30
ruckus(config-vlanpool)# vlan add 50-56
ruckus(config-vlanpool)# show
VLAN Pool:
ID:
:
Name = vlan-pool-1
Description = vlan pool for printers
Option = 1
VLANSET = 10,20,30,50-56

ruckus(config-vlanpool)# end
The vlan pool entry has saved successfully.
Your changes have been saved.
ruckus(config)#

```

## no vlan-pool

To delete a VLAN pool, use the following command:

**no vlan-pool WORD**

### Example

```
ruckus(config)# no vlan-pool vlan-pool-1
The vlan pool 'vlan-pool-1' has been deleted.
ruckus(config)#

```

# Configure User Commands

Use the user commands to configure a user's name, password, and role. To run these commands, you must first enter the **config-user** context.

## user

To create a user or modify an existing user and enter the config-user context, use the following command:

**user WORD**

### Syntax Description

**user**  
Create or modify a user entry  
**WORD**  
Name of the user

### Defaults

None.

### Example

```
ruckus(config)# user johndoe1
The User entry 'johndoe1' has been created.
ruckus(config-user)#+
```

## no user

To delete a user record, use the following command:

**no user WORD**

### Syntax Description

**user**  
Create or modify a user entry  
**WORD**  
Name of the user

### Defaults

None.

### Example

```
ruckus(config)# no user johndoe1
The User 'johndoe1' has been deleted.
ruckus(config)#+
```

## abort

To exit the config-user context without saving changes, use the abort command. Enter this command from within the context of the user that you are configuring.

**abort**

### Syntax Description

**abort**

Exit the user settings without saving changes

### Defaults

None.

### Example

```
ruckus(config-user)# abort  
No changes have been saved.  
ruckus(config)#
```

## end

To save changes, and then exit the config-user context, use the following command (you must first set a password before exiting):

**end**

### Syntax Description

**end**

Save changes, and then exit the context

### Defaults

None.

### Example

```
ruckus(config-user)# end  
The User entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#
```

## exit

To save changes, and then exit the config-user context, use the following command (you must first set a password before exiting):

**exit**

## Syntax Description

### **exit**

Save changes, and then exit the context

## Defaults

None.

## Example

```
ruckus(config-user)# exit  
The User entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#[/pre]
```

## quit

To exit the config-user context without saving changes, use the quit command. Enter this command from within the context of the user that you are configuring.

### **quit**

## Syntax Description

### **quit**

Exit the user settings without saving changes

## Defaults

None.

## Example

```
ruckus(config-role)# quit  
No changes have been saved.  
ruckus(config)#[/pre]
```

## user-name

To set the name of a user, use the following command:

### **user-name WORD**

## Syntax Description

### **user-name**

Set the name of a user

### **WORD**

Set to this user name

## **Configuring Controller Settings**

### Configure User Commands

#### **Defaults**

None.

#### **Example**

```
ruckus(config-user)# user-name joel  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **full-name**

To set the full name of a user, use the following command:

**full-name WORD**

#### **Syntax Description**

**full-name**

Set the full name of a user

**WORD**

Set to this full name

#### **Defaults**

None.

#### **Example**

```
ruckus(config-user)# full-name joeblow  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## **password**

To set the password of a user, use the following command:

**password WORD**

#### **Syntax Description**

**password**

Set the password of a user

**WORD**

Set to this password

#### **Defaults**

None.

## Example

```
ruckus(config-user)# password 12345678  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## role

To assign a role to a user, use the following command:

```
role WORD
```

## Syntax Description

**role**

Assign a role to a user.

**WORD**

The name of the role to be assigned to the user.

## Defaults

Default

## Example

```
ruckus(config-user)# role guest  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## show

To display the settings of a user, use the following command:

```
show
```

## Syntax Description

**show**

Show user settings

## Defaults

None.

## Example

```
ruckus(config-user)# show  
User:  
ID:  
:  
User Name= Joe  
Full Name= Joe Blow  
Password= *****  
Role= Default
```

## **Configuring Controller Settings**

### Configure User Commands

```
ruckus(config-user) #
```

# Configure Guest Access Commands

Use the guest-access commands to configure guest access services. To run these commands, you must first enter the **config-guest-access** context.

## guest-access

To create/configure a Guest Access service and enter the config-guest-access context, use the following command:

**guest-access WORD**

### *Example*

```
ruckus(config)# guest-access guestpolicy1  
The Guest Access entry 'guestpolicy1' has been created.  
ruckus(config-guest-access) #
```

## no guest-access

To delete a Guest Access service, use the following command:

**no guest-access**

### *Example*

```
ruckus(config)# no guest-access guest1  
The Guest Access 'guest1' has been deleted.  
ruckus(config) #
```

## abort

To exit the config-guest-access context without saving changes, use the abort command.

**abort**

## end

To save changes, and then exit the config-guest-access context, use the following command:

**end**

## exit

To save changes, and then exit the config-guest-access context, use the following command:

**exit**

## quit

To exit the config-guest-access context without saving changes, use the quit command.

**quit**

## guest-access-force-https-redirection

Enables guest access force HTTPS redirection.

### Syntax

**guest-access-force-https-redirection**

### Command Default

Disabled

### Examples

```
ruckus(config)# guest-access-force-https-redirection  
The command was executed successfully.  
ruckus(config)#
```

## **no guest-access-force-https-redirection**

Disables guest access force HTTPS redirection.

### **Syntax**

**no guest-access-force-https-redirection**

### **Command Default**

Disabled.

### **Examples**

```
ruckus(config)# no guest-access-force-https-redirection
The command was executed successfully.
ruckus(config) #
```

## guest-access-guestpass-effective

To set the guest pass effective date to begin from the creation time or from first use, use the following command:

**guest-access-guestpass-effective [now|first-use-expired <NUMBER>]**

### Syntax Description

**now**

Sets Effective from the creation time.

**first-use-expired <NUMBER>**

Effective from first use, Expire new guest passes if not used within xx days.

### Example

```
ruckus (config-guest-access) # guest-access-guestpass-effective first-use-expired 10  
The command was executed successfully.  
ruckus (config-guest-access) #
```

## name

To set the name of the guest access policy, use the following command:

**name WORD**

## self-service

To enable guest pass self-registration, use the following command:

**self-service**

## no self-service

To disable guest pass self-registration, use the following command:

**no self-service**

## guestpass-duration

To set the guest pass duration, use the following command:

**guestpass-duration [ hour | day | week ] NUMBER**

## guestpass-reauth

To set the guest pass reauthorization timeout, use the following command:

**guestpass-reauth [ hour | day | week ] NUMBER**

## no guestpass-reauth

To disable guest pass reauthorization timeout, use the following command:

**no guestpass-reauth**

## guestpass-share-number

To set the limit on how many devices can share one guest pass, use the following command (valid values: [0, 10] and 0 means unlimited):

**guestpass-share-number NUMBER**

## guestpass-sponsor

To enable guest pass sponsor approval, use the following command:

**guestpass-sponsor**

## no guestpass-sponsor

To disable guest pass sponsor approval, use the following command:

**no guestpass-sponsor**

## guestpass-sponsor-auth-server

Sets the authentication server to 'Local Database' or to a specified AAA server name, use the following command:

**guestpass-sponsor-auth-server [ local | name WORD ]**

## guestpass-sponsor-number

To set the number of sponsors that can be used for this guest pass service (valid values: [1,5]), use the following command:

**guestpass-sponsor-number NUMBER**

## guestpass-notification

To set the notification method for delivering guest passes, use the following command:

**guestpass-notification NUMBER**

### Syntax Description

**1**

Device Screen

**2**

Mobile

**3**

Email

4

Mobile and Email

## guestpass-terms-and-conditions

To enable and set the terms and conditions, use the following command:

**guestpass-terms-and-conditions WORD**

## no guestpass-terms-and-conditions

To disable the terms and conditions, use the following command:

**no guestpass-terms-and-conditions**

## onboarding

To configure onboarding portal options, use the following command:

**onboarding [key-and-zeroit|zeroit]**

### Syntax Description

#### onboarding

Enable onboarding portal.

#### key-and-zeroit

Enables guest pass and zero-it activation.

#### zeroit

Enables zero-it activation only.

### Defaults

Enabled, Guest Pass and Zero-IT.

### Example

```
ruckus(config-guest-access)# onboarding key-and-zeroit
The command was executed successfully.
ruckus(config-guest-access) #
```

## no onboarding

To disable the onboarding portal, use the following command:

**no onboarding**

## no authentication

To disable guest access authentication, use the following command:

## **no authentication**

### **Syntax Description**

#### **no authentication**

Disable guest access authentication

### **Defaults**

Enabled.

### **Example**

```
ruckus(config-guest-access)# no authentication  
The command was executed successfully.
```

## **authentication guest-pass-and-social-login**

To enable guest pass and social media login authentication for this guest access service, use the following command:

#### **authentication guest-pass-and-social-login**

### **Syntax Description**

#### **authentication guest-pass-and-social-login**

Enable guest pass and social media authentication.

### **Example**

```
ruckus(config-guest-access)# authentication guest-pass-and-social-login  
The command was executed successfully.  
ruckus(config-guest-access) #
```

## authentication only-social-login

To enable social media login only for this guest access service, use the following command:

**authentication only-social-login**

### Syntax Description

**authentication only-social-login**

Enable social media authentication only.

### Example

```
ruckus(config-guest-access)# authentication only-social-login  
The command was executed successfully.  
ruckus(config-guest-access)#+
```

## no term-of-use

To hide the Terms of Use text on the guest pass access page, use the following command:

**no term-of-use**

### Syntax Description

**no term-of-use**

Hide Terms of Use

### Defaults

Disabled.

### Example

```
ruckus(config-guest-access)# no term-of-use  
The command was executed successfully.
```

## term-of-use

To display and specify the Terms of Use text on the guest pass access page, use the following command:

**term-of-use WORD**

### Syntax Description

**term-of-use**

Display Terms of Use

**WORD**

Display this text as content of Terms of Use on Guest Pass access page

## Defaults

Disabled.

## Example

```
ruckus(config-guest-access)# term-of-use test.guest  
The command was executed successfully.
```

## redirect

To set the URL to which to redirect a guest user after passing authentication, use the following command:

```
redirect [ original | url WORD ]
```

## Syntax Description

### redirect

Set the URL to which the guest user will be redirected

### original

Redirect user to the original page that he intended to visit

### url WORD

Redirect user to a different URL. Specify the URL in WORD.

## Defaults

original

## Example

```
ruckus(config-guest-access)# redirect url http://www.ruckuswireless.com  
The command was executed successfully.
```

## welcome-text

To configure the text to display on the guest access user login page, use the following command:

```
welcome-text WORD
```

## Syntax Description

### welcome-text

Configure the welcome message

### WORD

Use this as the welcome message

## Defaults

Welcome to the Guest Access login page.

## Configuring Controller Settings

### Configure Guest Access Commands

#### **Example**

```
ruckus(config-guest-access)# welcome-text "Welcome to the Guest Access Login Page."  
The command was executed successfully.  
ruckus(config-guest-access)#[/pre>
```

## walled-garden

### Syntax

```
walled-garden <INDEX> <WORD>
```

### Command Default

None.

### Parameters

#### <INDEX>

Enter a number (1-35) for this walled garden entry.

#### <WORD>

Enter the URL to be added to the walled garden rules.

### Examples

```
ruckus(config-guest-access)# walled-garden 1 www.google.com
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-guest-access)#

```

## no walled-garden

### Syntax

**no walled-garden <INDEX>**

### Command Default

None.

### Parameters

<INDEX>

Enter a number (1-35) for this walled garden entry.

### Examples

```
ruckus(config-guest-access)# no walled-garden 1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-guest-access)#

```

## social-media-login

To set the social media login, use the following command:

**social-media-login WORD**

### Syntax

<WORD>: Specify the social media login type:

- google <WORD> <WORD>: Sets the social media login to Google/Google+
- linkedin <WORD> <WORD>: Sets the social media login to LinkedIn
- microsoft <NUMBER> <WORD> <WORD>: Sets the social media login to Microsoft
- wechat <WORD> <WORD> <WORD> <WORD>: Sets the social media loging to WeChat.

### Example

```
ruckus(config-guest-access)# social-media-login linkedin 1234456 test1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-guest-access)#

```

## ***social-media-login delete-social-media***

To delete the social media, use the following command:

**social-media-login delete-social-media <NUMBER>**

### **Syntax Description**

**<NUMBER>**

Delete the social media, google:3 linkdin:4 microsoft:5 wechat:6

### **Example**

```
ruckus(config-guest-access)# social-media-login delete-social-media 3  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-guest-access) #
```

## ***social-media-login google***

To set the social media login to Google/Google+, use the following command:

**social-media-login google WORD WORD**

## ***social-media-login hds***

To set the social media login host domain list, use the following command:

**social-media-login hds <WORD>**

## ***social-media-login no hds***

To clear the social media login host domain list, use the following command:

**social-media-login no hds**

## ***social-media-login linkedin***

To set the social media login to LinkedIn, use the following command

**social-media-login linkedin WORD WORD**

## ***social-media-login microsoft***

To sets the social media login to Microsoft, use the following command:

**social-media-login microsoft NUMBERWORD WORD**

## ***social-media-login wechat***

To sets the social media login to WeChat, use the following command:

**social-media-login wechat WORDWORD WORDWORD**

## Configuring Controller Settings

### Configure Guest Access Commands

#### ***social-media-login wechat force-follow***

To set the WeChat social media WLAN to force follow , use the following command:

```
social-media-login wechat WORDWORD WORDWORD force-follow WORD
```

#### **show**

To display the guest access policy settings, use the following command:

```
show
```

#### **Syntax Description**

```
show
```

Display the guest access settings

#### **Example**

```
ruckus(config-guest-access) # show
Guest Access:
  Name = guest1
  Onboarding Portal:
    Disabled
  Authentication:
    Mode = Use Guest Pass and Social login authentication
  Effective time:
    Countdown-by-issued = false
    Effective Period      = 7 Days
  Title = Welcome to Guest WiFi !
  Terms of Use:
    Status = Disabled
  Redirection:
    Mode = To the URL that the user intends to visit
  Self Service Registration:
    Status          = Disabled
Wall Garden:

  Restricted Subnet Access:
    Rules:
      1:
        Description=
        Type= Deny
        Source Address= Any
        Destination Address= local
        Source Port= Any
        Destination Port= Any
        Protocol= Any
      2:
        Description=
        Type= Deny
        Source Address= Any
        Destination Address= 10.0.0.0/8
        Source Port= Any
        Destination Port= Any
        Protocol= Any
      3:
        Description=
        Type= Deny
        Source Address= Any
        Destination Address= 172.16.0.0/12
        Source Port= Any
        Destination Port= Any
        Protocol= Any
      4:
```

```
Description=
Type= Deny
Source Address= Any
Destination Address= 192.168.0.0/16
Source Port= Any
Destination Port= Any
Protocol= Any

Restricted IPv6 Access:
Rules:
1:
Description=
Type= Deny
Source Address= Any
Destination Address= local
Source Port= Any
Destination Port= Any
Protocol= Any
ICMPv6 Type= Any

ruckus(config-guest-access) #
```

## web-portal-force-https-redirection

Enables web portal force HTTPS redirection.

### Syntax

**web-portal-force-https-redirection**

### Command Default

Disabled.

### Examples

```
ruckus(config)# web-portal-force-https-redirection  
The command was executed successfully.  
ruckus(config)#[/pre]
```

# no web-portal-force-https-redirection

Disables web portal force HTTPS redirection.

## Syntax

**no web-portal-force-https-redirection**

## Command Default

Disabled.

## Examples

```
ruckus(config)# no web-portal-force-https-redirection
The command was executed successfully.
ruckus(config)#+
```

## portal-auth-force-dns-server

Enables portal authentication WLAN (Hotspot Service, Guest Access and Web Authentication) force DNS server.

### Syntax

```
portal-auth-force-dns-server <IP/IPv6-ADDR1 [IP/IPv6-ADDR2]>
```

### Command Default

Disabled

### Examples

```
ruckus(config)# portal-auth-force-dns-server 192.168.40.10
The command was executed successfully.
ruckus(config)#
```

## no portal\_auth-force-dns-server

Disable portal authentication WLAN (Hotspot Service, Guest Access and Web Authentication) force DNS server.

### Syntax

**no portal\_auth-force-dns-server**

### Command Default

Disabled

### Examples

```
ruckus(config)# no portal_auth-force-dns-server  
The command was executed successfully.  
ruckus(config)#
```

## guest-access-auth-server

Sets the authentication server to 'Local Database' or to a specified AAA server.

### Syntax

```
guest-access-auth-server { local | name <WORD> }
```

### Command Default

None

### Parameters

**local**

Sets the authentication server to 'Local Database'.

**name <WORD>**

Sets the authentication server to specified AAA server name.

### Examples

```
ruckus(config)# guest-access-auth-server name radius1
The command was executed successfully.
ruckus(config)#+
```

# Configuring Guest Access Restriction Rules

Use the following commands to configure restricted access rules for a guest policy. To use these commands, you must enter the **config-guest-restrict-access** context from within the **config-guest-access** context.

## no restrict-access-order

To delete a restrict access order, use the following command:

**no restrict-access-order NUMBER**

### Syntax Description

**no restrict-access-order**

Delete a restrict access order

**NUMBER**

Delete this order ID

### Example

```
ruckus(config-guest-access)# no restrict-access-order 4
The Restricted Subnet Access entry has been removed from the Guest Access.
ruckus(config-guest-access)#[/pre]
```

## Configuring Controller Settings

### Configuring Guest Access Restriction Rules

## restrict-access-order

To create a new restrict access order or modify an existing restrict access order, use the following command:

**restrict-access-order NUMBER**

This command enters the config-guest-restrict-access context. The following commands are available from within this context:

### Syntax Description

**help**

Shows available commands

**history**

Shows a list of previously run commands.

**abort**

Exits the config-guest-restrict-access context without saving changes.

**end**

Saves changes, and then exits the config-guest-restrict-access context.

**exit**

Saves changes, and then exits the config-guest-restrict-access context.

**quit**

Exits the config-guest-restrict-access context without saving changes.

**order NUMBER**

Sets the guest access rule order.

**description WORD**

Sets the guest access rule description.

**type [ allow | deny ]**

Sets the guest access rule type to allow or deny.

**destination [ address ADDR | port NUMBER/WORD**

Sets the destination address/port of a guest access rule.

**protocol NUMBER/WORD**

Sets the protocol of a guest access rule.

**show**

Displays restricted subnet access settings.

## show

To display guest access restriction settings, use the following command:

**show**

### Syntax Description

**show**

Display guest access restriction settings

## Defaults

None.

## order

To configure the guest access rule order, use the following command:

**order NUMBER**

### Syntax Description

**order**

Set the order of a guest access rule

**NUMBER**

Assign the rule this order

### Example

```
ruckus (config-guest-restrict-access) # order 3  
The command was executed successfully.
```

## description

To set the description of a guest access rule, use the following command:

**description WORD**

### Syntax Description

**description**

Set the description of a guest access rule

**WORD**

Set this as description

### Defaults

None.

### Example

```
ruckus (config-guest-restrict-access) # description guestd3  
The command was executed successfully.
```

## type allow

To set the guest access rule type to 'allow', use the following command:

**type allow**

## Configuring Controller Settings

### Configuring Guest Access Restriction Rules

#### Syntax Description

##### **type**

Set the guest access rule type

##### **allow**

Set the rule type to 'allow'

#### Defaults

Deny.

#### Example

```
ruckus(config-guest-restrict-access)# type allow  
The command was executed successfully.
```

#### type deny

To set the guest access rule type to 'deny', use the following command:

##### **type deny**

#### Syntax Description

##### **type**

Set the guest access rule type

##### **deny**

Set the rule type to 'deny'

#### Defaults

Deny.

#### Example

```
ruckus(config-guest-restrict-access)# type deny  
The command was executed successfully.
```

#### destination address

To set the destination address of the rule, use the following command:

##### **destination address IP-ADDR/WORD**

#### Syntax Description

##### **destination address**

Set the destination address of the rule

##### **IP-ADDR/WORD**

Set the destination to this IP address

## Defaults

Any.

## Example

```
ruckus(config-guest-restrict-access)# destination address 192.168.0.20/24  
The command was executed successfully.
```

## destination port

To set the destination port of the rule, use the following command:

**destination port** NUMBER/WORD

## Syntax Description

**destination port**

Set the destination port of the rule

NUMBER/WORD

Set the destination to this port number

## Defaults

Any.

## Example

```
ruckus(config-guest-restrict-access)# destination port 562  
The command was executed successfully.
```

## protocol

To set the protocol for the rule, use the following command:

**protocol** NUMBER/WORD

## Syntax Description

**protocol**

Set the protocol for the rule

NUMBER/WORD

Set to this protocol

## Defaults

Any.

## **Configuring Controller Settings**

### **Configuring Guest Access Restriction Rules**

#### ***Example***

```
ruckus(config-guest-restrict-access)# protocol 69  
The command was executed successfully.
```

# IPv6 Guest Restrict Access Commands

Use the IPv6 guest restrict access commands to configure IPv6 restrict access rules. To run these commands, you must first enter the **config-ipv6-guest-restrict-access** context.

## no restrict-access-order-ipv6

To delete a restrict access order, use the following command:

**no restrict-access-order-ipv6 NUMBER**

### Syntax Description

**no restrict-access-order-ipv6**

Delete a restrict access order

**NUMBER**

Delete this order ID

### Defaults

None.

### Example

```
ruckus(config-guest-access)# no restrict-access-order-ipv6 2
The IPv6 Restricted Subnet Access entry has been removed from the Guest Access.
ruckus(config-guest-access) #
```

## restrict-access-order-ipv6

To create a new restrict access order or modify an existing restrict access order, use the following command:

**restrict-access-order-ipv6 NUMBER**

This command enters the **config-ipv6-guest-restrict-access** context. The following commands are available from within this context:

### Syntax Description

**help**

Shows available commands

**history**

Shows a list of previously run commands.

**abort**

Exits the config-guest-restrict-access context without saving changes.

**end**

Saves changes, and then exits the config-guest-restrict-access context.

**exit**

Saves changes, and then exits the config-guest-restrict-access context.

## Configuring Controller Settings

### IPv6 Guest Restrict Access Commands

#### **quit**

Exits the config-guest-restrict-access context without saving changes.

#### **order NUMBER**

Sets the guest access rule order.

#### **description WORD**

Sets the guest access rule description.

#### **type [ allow | deny ]**

Sets the guest access rule type to allow or deny.

#### **destination [address IPv6-ADDR | port NUMBER/WORD]**

Sets the destination address/port of a guest access rule.

#### **protocol NUMBER/WORD**

Sets the protocol of a guest access rule.

#### **icmpv6-type**

Sets the ICMPv6 type of a Guest Access rule.

#### **show**

Displays restricted subnet access settings.

## Example

```
ruckus (config-guest-access) # restrict-access-order-ipv6 2
ruckus (config-ipv6-guest-restrict-access) # type allow
The command was executed successfully.
ruckus (config-ipv6-guest-restrict-access) # show
    Description=
    Type= Allow
    Destination Address= Any
    Destination Port= Any
    Protocol= Any
    ICMPv6 Type= Any
ruckus (config-ipv6-guest-restrict-access) # end
The IPv6 Restricted Subnet Access entry has been added to the Guest Access.
Your changes have been saved.
ruckus (config-guest-access) #
```

## show

To display guest access restriction settings, use the following command:

#### **show**

## Syntax Description

#### **show**

Display guest access restriction settings

## Example

```
ruckus (config-ipv6-guest-restrict-access) # show
    Description=
    Type= Allow
    Destination Address= Any
    Destination Port= Any
```

```
Protocol= Any
ICMPv6 Type= Any
ruckus (config-ipv6-guest-restrict-access) #
```

## order

To configure the guest access rule order, use the following command:

```
order NUMBER
```

### Syntax Description

**order**

Set the order of a guest access rule

**NUMBER**

Assign the rule this order

### Defaults

None.

### Example

```
ruckus (config-ipv6-guest-restrict-access) # order 3
The command was executed successfully.
```

## description

To set the description of a guest access rule, use the following command:

```
description WORD
```

### Syntax Description

**description**

Set the description of a guest access rule

**WORD**

Set this as description

### Defaults

None.

### Example

```
ruckus (config-ipv6-guest-restrict-access) # description guestd3
The command was executed successfully.
```

## type allow

To set the guest access rule type to 'allow', use the following command:

**type allow**

### Syntax Description

**type**

Set the guest access rule type

**allow**

Set the rule type to 'allow'

### Defaults

Deny.

### Example

```
ruckus (config-ipv6-guest-restrict-access) # type allow  
The command was executed successfully.
```

## type deny

To set the guest access rule type to 'deny', use the following command:

**type deny**

### Syntax Description

**type**

Set the guest access rule type

**deny**

Set the rule type to 'deny'

### Defaults

Deny.

### Example

```
ruckus (config-ipv6-guest-restrict-access) # type deny  
The command was executed successfully.
```

## destination address

To set the destination address of the rule, use the following command:

**destination address IP-ADDR/WORD**

## Syntax Description

### **destination address**

Set the destination address of the rule

### **IP-ADDR/WORD**

Set the destination to this IP address

## Defaults

None.

## Example

```
ruckus(config-ipv6-guest-restrict-access)# destination address fe80::/64
The command was executed successfully.
ruckus(config-ipv6-guest-restrict-access) #
```

## destination port

To set the destination port of the rule, use the following command:

### **destination port NUMBER/WORD**

## Syntax Description

### **destination port**

Set the destination port of the rule

### **NUMBER/WORD**

Set the destination to this port number

## Defaults

None.

## Example

```
ruckus(config-ipv6-guest-restrict-access)# destination port 562
The command was executed successfully.
```

## protocol

To set the protocol for the rule, use the following command:

### **protocol NUMBER/WORD**

## Syntax Description

### **protocol**

Set the protocol for the rule

## **Configuring Controller Settings**

### IPv6 Guest Restrict Access Commands

NUMBER/WORD

Set to this protocol

#### **Defaults**

None.

#### **Example**

```
ruckus (config-ipv6-guest-restrict-access)# protocol 69  
The command was executed successfully.
```

## **icmpv6-type**

To set the ICMPv6 type of a Guest Access rule, use the following command:

```
icmpv6-type [ any | number NUMBER ]
```

#### **Defaults**

Any.

#### **Example**

```
ruckus (config-ipv6-guest-restrict-access)# icmpv6-type any  
The command was executed successfully.  
ruckus (config-ipv6-guest-restrict-access) #
```

# Configure Hotspot Commands

Use the hotspot commands to configure the controller's hotspot settings. To run these commands, you must first enter the **config-hotspot** context.

## hotspot

To create a new hotspot or edit an existing entry and enter the config-hotspot context, use the following command:

**hotspot WORD**

### Syntax Description

**hotspot**  
Create or edit a hotspot service  
**WORD**  
Name of hotspot service

### Defaults

None.

### Example

```
ruckus(config)# hotspot hotspot1
The Hotspot entry 'hotspot1' has been loaded. To save the Hotspot entry, type end or exit.
ruckus(config-hotspot) #
```

## no hotspot

To delete a hotspot record from the list, use the following command:

**no hotspot WORD**

### Syntax Description

**hotspot**  
Create or edit a hotspot service  
**WORD**  
Name of hotspot service

### Defaults

None.

### Example

```
ruckus(config)# hotspot hotspot1
The Hotspot entry 'hotspot1' has been loaded. To save the Hotspot entry, type end or exit.
ruckus(config-hotspot) #
```

## abort

To exit the config-hotspot context without saving changes, use the abort command.

**abort**

### Syntax Description

**abort**

Exit the hotspot settings without saving changes

### Defaults

None.

### Example

```
ruckus(config-hotspot)# abort  
No changes have been saved.  
ruckus(config)#[/pre]
```

## end

To save changes, and then exit the config-hotspot context, use the following command:

**end**

### Syntax Description

**end**

Save changes, and then exit the context

### Defaults

None.

### Example

```
ruckus(config-hotspot)# end  
The login page url can't be empty.  
ruckus(config-hotspot)# end  
The Hotspot entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#[/pre]
```

## exit

To save changes, and then exit the config-hotspot context, use the following command:

**exit**

## Syntax Description

### exit

Save changes, and then exit the context

## Defaults

None.

## Example

```
ruckus(config-hotspot)# exit  
The login page url can't be empty  
ruckus(config-hotspot)# exit  
The Hotspot entry has saved successfully.  
Your changes have been saved.
```

## quit

To exit the config-hotspot context without saving changes, use the quit command.

### quit

## Syntax Description

### quit

Exit the hotspot settings without saving changes

## Defaults

None.

## Example

```
ruckus(config-hotspot)# quit  
No changes have been saved.  
ruckus(config)#
```

## show

To display the current hotspot settings, use the following command:

### show

## Syntax Description

### show

Display the current hotspot settings

## Defaults

None.

## Configuring Controller Settings

### Configure Hotspot Commands

#### Example

```
ruckus(config-hotspot)# show
Hotspot:
ID:
1:
Name= h1
Login Page Url= http://172.18.110.122
Start Page= redirect to the URL that the user intends to visit.
Session Timeout= Disabled
Idle Timeout= Enabled
Timeout= 60 Minutes
Authentication Server= Local Database
Accounting Server= Disabled
Location ID=
Location Name=
Walled Garden 1=
Walled Garden 2=
Walled Garden 3=
Walled Garden 4=
Walled Garden 5=
Rules:
Order= 1
Description= h1_order1
Type= Deny
Destination Address= 192.168.20.20/24
Destination Port= 920
Protocol= 58
```

## name

To set the hotspot name, use the following command

```
name WORD
```

#### Syntax Description

**name**

Set the hotspot name

**WORD**

Set to this name

#### Defaults

None.

#### Example

```
ruckus(config-hotspot)# name ruckus1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## smartclient

Use the following command to enable WISPr smart client support

```
smartclient [ secure https ] [ secure http ] [ wispr-only secure https ] [ wispr-only secure-http ] [ info ]
```

## Syntax Description

### **smartclient**

Enable WISPr smartclient support.

### **secure https**

Enables WISPr smart client support with HTTPS security.

### **secure http**

Enables WISPr smart client support with no security.

### **wispr-only secure https**

Enables only WISPr smart client support with HTTPS security.

### **wispr-only secure http**

Enables only WISPr smart client support with no security.

### **info**

Sets the instruction to guide user to login by Smart Client application.

## Defaults

None.

## Example

```
ruckus(config-hotspot)# smartclient secure https  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-hotspot)#[/pre]
```

## no smartclient

To disable WISPr Smart Client support, use the following command:

### **no smartclient**

## login-page

To set the URL of the hotspot login, use the following command:

### **login-page [ original | WORD ]**

## Syntax Description

### **login-page**

Set the URL of the hotspot login

### **WORD**

Set to this URL

### **original**

Redirect to the URL that the user intends to visit

## Configuring Controller Settings

### Configure Hotspot Commands

#### Defaults

None.

#### Example

```
ruckus(config-hotspot)# login-page http://ruckuswireless.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## start-page

To set the URL or page to which the user will be redirected after logging into the hotspot, use the following command:

```
start-page [ original | url WORD ]
```

#### Syntax Description

##### start-page

Set the URL or page to which the user will be redirected after logging into the hotspot

##### original

Redirect user to the original page he or she intended to visit

##### url WORD

Redirect user to another page. Set the URL of the page in WORD.

#### Defaults

original

#### Example

```
ruckus(config-hotspot)# start-page url http://www.ruckuswireless.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## no session-timeout

To disable the session timeout for hotspot usage, use the following command:

```
no session-timeout
```

#### Syntax Description

##### no session-timeout

Disable the session timeout for hotspot usage

#### Defaults

None.

## Example

```
ruckus(config-hotspot)# no session-timeout  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## session-timeout

To enable and set the session timeout for hotspot usage, use the following command:

```
session-timeout minutes
```

### Syntax Description

**session-timeout**

Disable the session timeout for hotspot usage

*minutes*

Set the session timeout to this value (in minutes)

### Defaults

1440 minutes

## Example

```
ruckus(config-hotspot)# session-timeout 20  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## no grace-period

To disable the grace period (idle timeout) for hotspot users, use the following command:

```
no grace-period
```

### Syntax Description

**no grace-period**

Disable the idle timeout for hotspot users

### Defaults

None.

## Example

```
ruckus(config-hotspot)# no grace-period  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## grace-period

To enable and set the grace period (idle timeout) for hotspot users, use the following command:

## Configuring Controller Settings

### Configure Hotspot Commands

**grace-period** *minutes*

#### grace-period

Set the idle timeout for hotspot users

*minutes*

Set the idle timeout to this value (in minutes)

### Defaults

60 minutes

### Example

```
ruckus(config-hotspot)# grace-period 20  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## auth-server local

To use ZoneDirector as the authentication server for hotspot users, use the following command:

**auth-server local**

### Syntax Description

#### auth-server

Set an authentication server for hotspot users

#### local

Use ZoneDirector as the authentication server

### Defaults

local

### Example

```
ruckus(config-hotspot)# auth-server local  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## auth-server name

To use an external server for authenticating hotspot users, use the following command:

**auth-server name WORD**

## Syntax Description

### **auth-server name**

Set an external authentication server for hotspot users

#### **WORD**

Use this server as the authentication server

## Defaults

None.

## Example

```
ruckus(config-hotspot)# auth-server name radius1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-hotspot)#[/pre]
```

## auth-server name no-mac-bypass

To disable MAC authentication bypass (no redirection), use the following command:

```
auth-server name WORD no-mac-bypass
```

## auth-server name mac-bypass

To enable MAC authentication bypass (no redirection) and use password as authentication password, use the following command:

```
auth-server name WORD mac-bypass [ mac | password WORD ]
```

## Syntax Description

### **auth-server name**

Set an external authentication server for hotspot users

#### **WORD**

Authentication server name

### **mac-bypass**

Enable MAC auth bypass

#### **mac**

Enables MAC authentication bypass (no redirection) and use device MAC address as authentication password.

#### **password WORD**

Enables MAC authentication bypass (no redirection) and use password as authentication password.

#### **mac-in-dot1x**

Use device MAC address as authentication password and enable to send username and password in 802.1X format of 00-10-A4-23-19-C0 (by default 0010a42319c0).

#### **password-in-dot1x WORD**

Use password as authentication password and enable to send username and password in 802.1X format of 00-10-A4-23-19-C0 (by default 0010a42319c0).

## Defaults

None.

## Example

```
ruckus(config-hotspot)# auth-server name radius1 mac-bypass mac  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-hotspot)#

```

## auth-server name mac-bypass mac-addr-format

To set MAC auth username and password to one of the following formats, use the following command:

```
auth-server name WORD mac-bypass mac-addr-format [ FORMAT ]
```

## Syntax Description

### auth-server name

Set an external authentication server for hotspot users

### WORD

Authentication server name

### mac-bypass

Enable MAC auth bypass

### mac-addr-format

Enable MAC authentication bypass (no redirection) and use device MAC address as authentication password.

### [FORMAT ]

Set the MAC address format.

### aabbccddeeff

Set the MAC address format to aabbccddeeff.

### aa-bb-cc-dd-ee-ff

Set the MAC address format to aa-bb-cc-dd-ee-ff.

### aa:bb:cc:dd:ee:ff

Set the MAC address format to aa:bb:cc:dd:ee:ff.

### AABBCCDDEEFF

Set the MAC address format to AABBCCDDEEFF.

### AA-BB-CC-DD-EE-FF

Set the MAC address format to AA-BB-CC-DD-EE-FF.

### AA:BB:CC:DD:EE:FF

Set the MAC address format to AA:BB:CC:DD:EE:FF.

## acct-server

To enable the accounting server for hotspot usage, use the following command:

```
acct-server WORD
```

## Syntax Description

### **acct-server**

Enable the accounting server for hotspot usage

#### **WORD**

Name of the AAA server

## Defaults

None.

## Example

```
ruckus(config-hotspot)# acct-server "RADIUS Accounting"  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-hotspot)#[/pre]
```

## no acct-server

To disable the accounting server for hotspot usage, use the following command:

### **no acct-server**

## Syntax Description

### **no acct-server**

Disable the accounting server for hotspot usage

## Defaults

None.

## Example

```
ruckus(config-hotspot)# no acct-server  
The command was executed successfully. To save the changes, type 'end' or 'exit'.[/pre]
```

## acct-server interim-update

To enable and set the accounting server for hotspot usage, use the following command:

### **acct-server WORD interim-update NUMBER**

## Syntax Description

### **no acct-server**

Enable and set the accounting server for hotspot usage

#### **WORD**

Set to this accounting server

## Configuring Controller Settings

### Configure Hotspot Commands

#### **interim-update**

Set the interim update interval

#### **NUMBER**

Set to this interval (in minutes)

#### **Defaults**

5 minutes

#### **Example**

```
ruckus(config-hotspot)# acct-server asd interim-update 10
The AAA server 'asd' could not be found. Please check the spelling, and then try again.
ruckus(config-hotspot)# acct-server acctl interim-update 20
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## client-isolation

To enable wireless client isolation (on AP or across APs), use the following command:

```
client-isolation [ isolation-on-ap | isolation-across-ap ] [ enable | disable ]
```

#### **Syntax Description**

##### **client-isolation**

Enable client isolation.

##### **isolation-on-ap**

Enable client isolation per AP.

##### **isolation-on-subnet**

Enable spoof guarding and across AP client isolation using whitelist.

#### **Defaults**

Disabled

#### **Example**

```
ruckus(config-hotspot)# client-isolation isolation-on-ap enable
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-hotspot)# client-isolation isolation-on-subnet enable
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-hotspot) #
```

## whitelist

To apply a client isolation whitelist to this Hotspot, use the following command:

```
whitelist name WORD
```

## location-id

To set the location ID of the hotspot, use the following command:

**location-id** *location-id*

### Syntax Description

**location-id**

Set the location ID of the hotspot

*location-id*

Set to this location ID

### Defaults

None.

### Example

```
ruckus(config-hotspot)# location-id us  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## location-name

To set the location name of the hotspot, use the following command:

**location-name** *location-name*

### Syntax Description

**location-name**

Set the location name of the hotspot

*location-name*

Set to this location name

### Defaults

None.

### Example

```
ruckus(config-hotspot)# location-name shenzhen  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## walled-garden

To set a hotspot “walled garden” URL, use the following command:

**walled-garden** INDEX WORD

## Configuring Controller Settings

### Configure Hotspot Commands

#### Syntax Description

##### walled-garden

Create a walled garden rule

##### INDEX

Enter walled garden URL index. (1~35)

##### WORD

Destination URL

#### Defaults

None.

#### Example

```
ruckus(config-hotspot)# walled-garden 1 www.ruckuswireless.com
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-hotspot) #
```

#### no walled-garden

To delete a walled garden URL, use the following command

##### no walled-garden INDEX

#### Syntax Description

##### walled-garden

Delete a walled garden rule

##### INDEX

Enter walled garden URL index. (1~35)

#### Defaults

None.

#### Example

```
ruckus(config-hotspot)# no walled-garden 1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-hotspot) #
```

# Configuring Hotspot Restricted Access Rules

The following commands are used to create and modify Hotspot restricted access rules. Use the restrict-access-order command from the config-hotspot context to enter the config-hotspot-restrict-access context.

## restrict-access-order

To create a new restrict access order or modify an existing restrict access order, use the following command:

**restrict-access-order NUMBER**

### Syntax Description

#### **restrict-access-order**

Add a restrict access order

#### **NUMBER**

Add this order ID

#### **order NUMBER**

Sets the hotspot rule order.

#### **description WORD**

Sets the hotspot rule description.

#### **type allow**

Sets the hotspot rule type to 'allow'.

#### **type deny**

Sets the hotspot rule type to 'deny'.

#### **destination address IP-ADDR/WORD**

Sets the destination address of a hotspot rule.

#### **destination port NUMBER/WORD**

Sets the destination port of a hotspot rule.

#### **protocol NUMBER/WORD**

Sets the protocol of a hotspot rule.

#### **show**

Displays the policy rule.

### Defaults

None.

### Example

```
ruckus (config-hotspot)# restrict-access-order 1
ruckus (config-hotspot-restrict-access)#
ruckus (config-hotspot-restrict-access)# show
    Description=
    Type= Deny
    Destination Address= Any
    Destination Port= Any
```

## Configuring Controller Settings

### Configuring Hotspot Restricted Access Rules

```
Protocol= Any  
ruckus (config-hotspot-restrict-access) #
```

## no restrict-access-order

To delete a restrict access order, use the following command:

```
no restrict-access-order NUMBER
```

### Syntax Description

**no restrict-access-order**

Delete a restrict access order

**NUMBER**

Delete this order ID

### Defaults

None.

### Example

```
ruckus (config-hotspot) # no restrict-access-order 1  
The rule '1' has been removed from the Hotspot.
```

## restrict-access-order-ipv6

To create a new IPv6 restrict access order or modify an existing restrict access order, use the following command:

```
restrict-access-order-ipv6 NUMBER
```

### Syntax Description

**restrict-access-order-ipv6**

Add a restrict access order

**NUMBER**

Add this order ID

**order NUMBER**

Sets the hotspot rule order.

**description WORD**

Sets the hotspot rule description.

**type allow**

Sets the hotspot rule type to 'allow'.

**type deny**

Sets the hotspot rule type to 'deny'.

**destination address IP-ADDR/WORD**

Sets the destination address of a hotspot rule.

**destination port NUMBER/WORD**  
Sets the destination port of a hotspot rule.

**protocol NUMBER/WORD**  
Sets the protocol of a hotspot rule.

**icmpv6 type [any|number NUMBER]**  
Sets the icmpv6 type of a hotspot rule.

**show**  
Displays the policy rule.

## Defaults

None.

## Example

```
ruckus (config-hotspot)# restrict-access-order-ipv6 1
ruckus (config-hotspot-restrict-access)#
ruckus (config-hotspot-restrict-access-ipv6) # show
    Description=
    Type= Deny
    Destination Address= Any
    Destination Port= Any
    Protocol= Any
    ICMPv6 Type= Any
ruckus (config-hotspot-restrict-access-ipv6) #
```

## no restrict-access-order-ipv6

To delete a restrict access order, use the following command:

**no restrict-access-order-ipv6 order\_id**

## Syntax Description

**no restrict-access-order**  
Delete a restrict access order

**order\_id**  
Delete this order ID

## Defaults

None.

## Example

```
ruckus (config-hotspot) # no restrict-access-order-ipv6 1
The rule '1' has been removed from the Hotspot.
```

## **Configuring Controller Settings**

### Configuring Hotspot Restricted Access Rules

## **icmpv6-type**

To set the ICMPv6 type, use the following command:

```
icmpv6-type [any | number NUMBER]
```

### **Defaults**

Any.

### **Example**

```
ruckus(config-hotspot-restrict-access-ipv6)# icmpv6-type any  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-hotspot-restrict-access-ipv6)#+
```

# Hotspot Access Restriction Commands

Use the hotspot-restrict-access commands to configure network segments to which hotspot access will be blocked. To run these commands, you must first enter the **config-hotspot-restrict-access** context.

The same commands are available for IPv6 networks from the **config-hotspot-restrict-access-ipv6** context.

## end

To save changes, and then exit the config-hotspot-restrict-access context, use the following command:

**end**

### Syntax Description

**end**

Save changes, and then exit the context

### Defaults

None.

### Example

```
ruckus (config-hotspot-restrict-access) # end  
ruckus (config-hotspot) #
```

## exit

To save changes, and then exit the config-hotspot-restrict-access context, use the following command:

**exit**

### Syntax Description

**exit**

Save changes, and then exit the context

### Defaults

None.

### Example

```
ruckus (config-hotspot-restrict-access) # exit  
ruckus (config-hotspot) #
```

## show

To display hotspot access restriction settings, use the following command:

## Configuring Controller Settings

### Hotspot Access Restriction Commands

**show**

#### Syntax Description

**show**

Display the hotspot access restriction settings

#### Defaults

None.

## order

To configure the hotspot access rule order, use the following command:

**order NUMBER**

#### Syntax Description

**order**

Set the order of a hotspot access rule

**NUMBER**

Assign the rule this order

#### Defaults

None.

#### Example

```
ruckus(config-hotspot-restrict-access)# order 1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## description

To set the description of a hotspot access rule, use the following command:

**description WORD**

#### Syntax Description

**description**

Set the description of a hotspot access rule

**WORD**

Set this as description

#### Defaults

None.

## Example

```
ruckus(config-hotspot-restrict-access)# description h1_order1  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## type allow

To set the hotspot access rule type to 'allow', use the following command:

```
type allow
```

### Syntax Description

**type**  
Set the hotspot access rule type  
**allow**  
Set the rule type to 'allow'

### Defaults

None.

## Example

```
ruckus(config-hotspot-restrict-access)# type allow  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## type deny

To set the hotspot access rule type to 'deny', use the following command:

```
type deny
```

### Syntax Description

**type**  
Set the hotspot access rule type  
**deny**  
Set the rule type to 'deny'

### Defaults

None.

## Example

```
ruckus(config-hotspot-restrict-access)# type deny  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## destination address

To set the destination address of the rule, use the following command:

**destination address IP-ADDR/WORD**

### Syntax Description

**destination address**

Set the destination address of the rule

**IP-ADDR/WORD**

Set the destination to this IP address

### Defaults

None.

### Example

```
ruckus(config-hotspot-restrict-access)# destination address 192.168.20.20/24  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## destination port

To set the destination port of the rule, use the following command:

**destination port NUMBER/WORD**

### Syntax Description

**destination port**

Set the destination port of the rule

**NUMBER/WORD**

Set the destination to this port number

### Defaults

None.

### Example

```
ruckus(config-hotspot-restrict-access)# destination port 920  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## protocol

To set the protocol for the rule, use the following command:

**protocol NUMBER/WORD**

## Syntax Description

### **protocol**

Set the protocol for the rule

### **NUMBER/WORD**

Set to this protocol

## Defaults

None.

## Example

```
ruckus(config-hotspot-restrict-access)# protocol 58  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## intrusion-prevention

To enable temporary blocking of Hotspot clients with repeated authentication attempts, use the following command:

### **intrusion-prevention**

## Defaults

Disabled.

## Example

```
ruckus(config-hotspot)# intrusion-prevention  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-hotspot)#

```

## no intrusion-prevention

To disable temporary blocking of Hotspot clients with repeated authentication failure, use the following command:

### **no intrusion-prevention**

## Example

```
ruckus(config-hotspot)# no intrusion-prevention  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-hotspot)#

```

# Configure Hotspot 2.0 Commands

Use the **hs20op** and **hs20sp** commands to configure the controller's Hotspot 2.0 operator and service provider settings. To run these commands, you must first enter the **config-hs20op** or **config-hs20sp** context.

To deploy a Hotspot 2.0 service, you must configure the following:

- A Hotspot 2.0 Operator entry
- A Hotspot 2.0 Service Provider entry
- A WLAN with Hotspot 2.0 service enabled

## hs20op

Use the following command to configure a Hotspot 2.0 Operator entry:

**hs20op WORD**

### Syntax Description

**hs20op**

Create or configure a Hotspot 2.0 Operator entry

**WORD**

The name of the Hotspot 2.0 Operator entry.

### Example

```
ruckus(config)# hs20op operator1
The Hotspot (2.0) operator entry 'operator1' has been created.
ruckus(config-hs20op)# end
The Hotspot (2.0) operator entry has saved successfully.
Your changes have been saved.
ruckus(config)#[/pre]
```

## no hs20op

Use the following command to delete a Hotspot 2.0 Operator entry:

**no hs20op WORD**

### Example

```
ruckus(config)# no hs20op operator1
The Hotspot (2.0) oeprator 'operator1' has been deleted.
ruckus(config)#[/pre]
```

## Configure Hotspot 2.0 Operator Settings

The following commands can be used to configure Hotspot 2.0 Operator entry settings. To execute these commands, you must first create or edit a Hotspot 2.0 Operator entry using the `hs20op` command and entering the `config-hs20op` context.

### Syntax Description

#### **help**

Shows available commands.

#### **history**

Shows a list of previously run commands.

#### **abort**

Exits the config-hs20op context without saving changes.

#### **end**

Saves changes, and then exits the config-hs20op context.

#### **exit**

Saves changes, and then exits the config-hs20op context.

#### **quit**

Exits the config-hs20op context without saving changes.

#### **no internet-option**

Disables with connectivity to internet.

#### **no hessid**

Sets the HESSID to empty.

#### **no service-provider WORD NUMBER**

Deletes a service provider from the Hotspot (2.0) operator.

#### **no venue-group-type**

Sets both venue group and venue type to unspecified.

#### **no friendly-name LANGUAGE**

Disable the friendly name for the specified language.

#### **no asra**

Disables additional step required for access.

#### **no asra terms**

Disables ASRA Type: Acceptance of terms and conditions.

#### **no asra enrollment**

Disables ASRA Type: On-line enrollment supported.

#### **no asra http-https**

Disables ASRA Type: http/https redirection.

#### **no asra dns**

Disables ASRA Type: DNS redirection.

#### **no asra http-https-url**

Sets the redirect URL of http/https redirection to empty.

**no wan-metrics sym**

Disables Symmetric Link.

**no custm-conn-cap NUMBER**

Deletes a Connection Capability entry.

**no adv-gas dos-detect**

Disables the GAS DOS detection.

**no hs-caps operating-class-indication**

Disables the operating class indication.

**name WORD**

Sets the hotspot(2.0) operator entry name.

**description WORD**

Sets the hotspot(2.0) operator entry description.

**internet-option**

Enables with connectivity to internet.

**hessid MAC**

Sets the HESSID.

**hessid-use-bssid**

Sets the HESSID to use BSSID.

**service-provider WORD**

Adds a service provider to the Hotspot (2.0) operator.

**venue-group-type unspecified**

Sets the venue group to unspecified

**venue-group-type assembly**

Sets the venue group to assembly

**venue-group-type assembly unspecified**

Sets the venue type to unspecified

**venue-group-type assembly arena**

Sets the venue type to arena

**venue-group-type assembly stadium**

Sets the venue type to stadium

**venue-group-type assembly passenger-terminal**

Sets the venue type to passenger terminal

**venue-group-type assembly amphitheater**

Sets the venue type to amphitheater

**venue-group-type assembly amusement-park**

Sets the venue type to amusement park

**venue-group-type assembly place-worship**

Sets the venue type to place of worship

**venue-group-type assembly convention-center**

Sets the venue type to convention center

**venue-group-type assembly library**

Sets the venue type to library

**venue-group-type assembly museum**

Sets the venue type to museum

**venue-group-type assembly restaurant**

Sets the venue type to restaurant

**venue-group-type assembly theater**

Sets the venue type to theater

**venue-group-type assembly bar**

Sets the venue type to bar

**venue-group-type assembly coffee-shop**

Sets the venue type to coffee shop

**venue-group-type assembly zoo-or-aquarium**

Sets the venue type to zoo or aquarium

**venue-group-type assembly emergency-coordination-center**

Sets the venue type to emergency coordination center

**venue-group-type business**

Sets the venue group to business

**venue-group-type business unspecified**

Sets the venue type to unspecified

**venue-group-type business doctor-or-dentist-office**

Sets the venue type to doctor or dentist office

**venue-group-type business bank**

Sets the venue type to bank

**venue-group-type business fire-station**

Sets the venue type to fire station

**venue-group-type business police-station**

Sets the venue type to police station

**venue-group-type business post-office**

Sets the venue type to post office

**venue-group-type business professional-office**

Sets the venue type to professional office

**venue-group-type business research-and-development-facility**

Sets the venue type to research and development facility

**venue-group-type business attorney-office**

Sets the venue type to attorney office

**venue-group-type educational**

Sets the venue group to educational

**venue-group-type educational unspecified**

Sets the venue type to unspecified

## **Configuring Controller Settings**

### Configure Hotspot 2.0 Commands

**venue-group-type educational school-primary**  
Sets the venue type to school primary

**venue-group-type educational school-secondary**  
Sets the venue type to school secondary

**venue-group-type educational university-or-college**  
Sets the venue type to university or college

**venue-group-type factory-industrial**  
Sets the venue group to factory industrial

**venue-group-type factory-industrial unspecified**  
Sets the venue type to unspecified

**venue-group-type factory-industrial factory**  
Sets the venue type to factory

**venue-group-type institutional**  
Sets the venue group to institutional

**venue-group-type institutional unspecified**  
Sets the venue type to unspecified

**venue-group-type institutional hospital**  
Sets the venue type to hospital

**venue-group-type institutional long-term-care-facility**  
Sets the venue type to long term care facility

**venue-group-type institutional alcohol-and-drug-reHabilitation-center**  
Sets the venue type to alcohol and drug reHabilitation center

**venue-group-type institutional group-home**  
Sets the venue type to group home

**venue-group-type institutional prison-or-jail**  
Sets the venue type to prison or jail

**venue-group-type mercantile**  
Sets the venue group to mercantile

**venue-group-type mercantile unspecified**  
Sets the venue type to unspecified

**venue-group-type mercantile retail-store**  
Sets the venue type to retail store

**venue-group-type mercantile grocery-market**  
Sets the venue type to grocery market

**venue-group-type mercantile automotive-service-station**  
Sets the venue type to automotive service station

**venue-group-type mercantile shopping-mall**  
Sets the venue type to shopping mall

**venue-group-type mercantile gas-station**  
Sets the venue type to gas station

**venue-group-type residential**

Sets the venue group to residential

**venue-group-type residential unspecified**

Sets the venue type to unspecified

**venue-group-type residential private-residence**

Sets the venue type to private residence

**venue-group-type residential hotel-or-motel**

Sets the venue type to hotel or motel

**venue-group-type residential dormitory**

Sets the venue type to dormitory

**venue-group-type residential boarding-house**

Sets the venue type to boarding house

**venue-group-type storage**

Sets the venue group to storage

**venue-group-type storage unspecified**

Sets the venue type to unspecified

**venue-group-type utility-miscellaneous**

Sets the venue group to utility miscellaneous

**venue-group-type utility-miscellaneous unspecified**

Sets the venue type to unspecified

**venue-group-type vehicular**

Sets the venue group to vehicular

**venue-group-type vehicular unspecified**

Sets the venue type to unspecified

**venue-group-type vehicular automobile-or-truck**

Sets the venue type to automobile or truck

**venue-group-type vehicular airplane**

Sets the venue type to airplane

**venue-group-type vehicular bus**

Sets the venue type to bus

**venue-group-type vehicular ferry**

Sets the venue type to ferry

**venue-group-type vehicular ship-or-boat**

Sets the venue type to ship or boat

**venue-group-type vehicular train**

Sets the venue type to train

**venue-group-type vehicular motor-bike**

Sets the venue type to motor bike

**venue-group-type outdoor**

Sets the venue group to outdoor

## Configuring Controller Settings

### Configure Hotspot 2.0 Commands

#### **venue-group-type outdoor unspecified**

Sets the venue type to unspecified

#### **venue-group-type outdoor muni-mesh-network**

Sets the venue type to muni mesh network

#### **venue-group-type outdoor city-park**

Sets the venue type to city park

#### **venue-group-type outdoor rest-area**

Sets the venue type to rest area

#### **venue-group-type outdoor traffic-control**

Sets the venue type to traffic control

#### **venue-group-type outdoor bus-stop**

Sets the venue type to bus stop

#### **venue-group-type outdoor kiosk**

Sets the venue type to kiosk

#### **friendly-name LANGUAGE WORD**

Sets the friendly name for the specified language.

#### **asra**

Enables additional step required for access.

#### **asra terms**

Enables ASRA Type: Acceptance of terms and conditions.

#### **asra enrollment**

Enables ASRA Type: On-line enrollment supported.

#### **asra http-https**

Enables ASRA Type: http/https redirection.

#### **asra http-https urlWORD**

Sets the redirect URL of http/https redirection.

#### **asra dns**

Enables ASRA Type: DNS redirection.

#### **accs-net-type private**

Sets the access network type to Private network.

#### **accs-net-type private-with-guest**

Sets the access network type to Private network with guest access.

#### **accs-net-type chargeable-public**

Sets the access network type to Chargeable public network.

#### **accs-net-type free-public**

Sets the access network type to Free public network.

#### **accs-net-type personal-device**

Sets the access network type to Personal device network.

#### **accs-net-type test-or-experimental**

Sets the access network type to Test or experimental.

**accs-net-type wildcard**

Sets the access network type to Wildcard.

**ip-addr-type ipv4 not-avail**

Sets the IPv4 Address Type to not available.

**ip-addr-type ipv4 public**

Sets the IPv4 Address Type to public address.

**ip-addr-type ipv4 port-restricted**

Sets the IPv4 Address Type to port-restricted address.

**ip-addr-type ipv4 single-nated**

Sets the IPv4 Address Type to single NATed private address.

**ip-addr-type ipv4 double-nated**

Sets the IPv4 Address Type to double NATed private address.

**ip-addr-type ipv4 port-single**

Sets the IPv4 Address Type to port-restricted address and single NATed private address.

**ip-addr-type ipv4 port-double**

Sets the IPv4 Address Type to port-restricted address and double NATed private address.

**ip-addr-type ipv4 unknown**

Sets the IPv4 Address Type to unknown.

**ip-addr-type ipv6 not-avail**

Sets the IPv6 Address Type to not available.

**ip-addr-type ipv6 avail**

Sets the IPv6 Address Type to available.

**ip-addr-type ipv6 unknown**

Sets the IPv6 Address Type to unknown.

**wan-metrics sym**

Enables Symmetric Link.

**wan-metrics link-stat up**

Sets Link Status to Link UP.

**wan-metrics link-stat down**

Sets Link Status to Link Down.

**wan-metrics link-stat test**

Sets Link Status to Link in Test State.

**wan-metrics downlink-load NUMBER**

Sets WAN downlink load.

**wan-metrics downlink-speed NUMBER**

Sets WAN downlink speed.

**wan-metrics uplink-load NUMBER**

Sets WAN uplink load.

**wan-metrics uplink-speed NUMBER**

Sets WAN uplink speed.

## **Configuring Controller Settings**

### Configure Hotspot 2.0 Commands

**wan-metrics lmd NUMBER**  
Sets Load Measurement Duration.

**conn-cap icmp closed**  
Sets the ICMP Connection Capability Status to closed

**conn-cap icmp open**  
Sets the ICMP Connection Capability Status to open

**conn-cap icmp unknown**  
Sets the ICMP Connection Capability Status to unknown

**conn-cap ftp closed**  
Sets the FTP Connection Capability Status to closed

**conn-cap ftp open**  
Sets the FTP Connection Capability Status to open

**conn-cap ftp unknown**  
Sets the FTP Connection Capability Status to unknown

**conn-cap ssh closed**  
Sets the SSH Connection Capability Status to closed

**conn-cap ssh open**  
Sets the SSH Connection Capability Status to open

**conn-cap ssh unknown**  
Sets the SSH Connection Capability Status to unknown

**conn-cap http closed**  
Sets the HTTP Connection Capability Status to closed

**conn-cap http open**  
Sets the HTTP Connection Capability Status to open

**conn-cap http unknown**  
Sets the HTTP Connection Capability Status to unknown

**conn-cap tls-vpn closed**  
Sets the TLS VPN Connection Capability Status to closed

**conn-cap tls-vpn open**  
Sets the TLS VPN Connection Capability Status to open

**conn-cap tls-vpn unknown**  
Sets the TLS VPN Connection Capability Status to unknown

**conn-cap pptp-vpn closed**  
Sets the PPTP VPN Connection Capability Status to closed

**conn-cap pptp-vpn open**  
Sets the PPTP VPN Connection Capability Status to open

**conn-cap pptp-vpn unknown**  
Sets the PPTP VPN Connection Capability Status to unknown

**conn-cap voip-tcp closed**  
Sets the VoIP(TCP) Connection Capability Status to closed

**conn-cap voip-tcp open**  
Sets the VoIP(TCP) Connection Capability Status to open

**conn-cap voip-tcp unknown**  
Sets the VoIP(TCP) Connection Capability Status to unknown

**conn-cap ikev2 closed**  
Sets the IKEv2 Connection Capability Status to closoed

**conn-cap ikev2 open**  
Sets the IKEv2 Connection Capability Status to open

**conn-cap ikev2 unknown**  
Sets the IKEv2 Connection Capability Status to unknown

**conn-cap voip-udp closed**  
Sets the VoIP(UDP) Connection Capability Status to closed

**conn-cap voip-udp open**  
Sets the VoIP(UDP) Connection Capability Status to open

**conn-cap voip-udp unknown**  
Sets the VoIP(UDP) Connection Capability Status to unknown

**conn-cap ipsec-vpn closed**  
Sets the IPSec VPN Connection Capability Status to closoed

**conn-cap ipsec-vpn open**  
Sets the IPSec VPN Connection Capability Status to open

**conn-cap ipsec-vpn unknown**  
Sets the IPSec VPN Connection Capability Status to unknown

**conn-cap esp closed**  
Sets the ESP Connection Capability Status to closoed

**conn-cap esp open**  
Sets the ESP Connection Capability Status to open

**conn-cap esp unknown**  
Sets the ESP Connection Capability Status to unknown

**custm-conn-cap NUMBER ip-proto NUMBER port NUMBERstatus closed**  
Sets Status to closed.

**custm-conn-cap NUMBER ip-proto NUMBER port NUMBERstatus closed description WORD**  
Sets the description of Connection Capability entry.

**custm-conn-cap NUMBER ip-proto NUMBER port NUMBERstatus open**  
Sets Status to open.

**custm-conn-cap NUMBER ip-proto NUMBER port NUMBERstatus open description WORD**  
Sets the description of Connection Capability entry.

**custm-conn-cap NUMBER ip-proto NUMBER port NUMBERstatus unknown**  
Sets Status to unknown.

**custm-conn-cap NUMBER ip-proto NUMBER port NUMBERstatus unknown description WORD**  
Sets the description of Connection Capability entry.

## Configuring Controller Settings

### Configure Hotspot 2.0 Commands

```
adv-gas cb-delay NUMBER
    Sets the GAS Comeback Delay.

adv-gas rsp-limit NUMBER
    Sets the GAS query response length limit.

adv-gas rsp-buf-time NUMBER
    Sets the GAS query response buffering time.

adv-gas dos-detect
    Enables the GAS DOS detection.

adv-gas dos-maxreq NUMBER
    Set the GAS DOS detection maximum request number.

hs-caps operating-class-indication 2.4
    Sets the operating class indication to 2.4 GHz.

hs-caps operating-class-indication 5
    Sets the operating class indication to 5 GHz.

hs-caps operating-class-indication dual-band
    Sets the operating class indication to 2.4/5 GHz.

show
    Displays hotspot 2.0 operator settings.
```

## hs20sp

Use the following command to configure a Hotspot 2.0 Service Provider entry:

```
hs20sp WORD
```

### Example

```
ruckus(config)# hs20sp serviceprovider1
The Hotspot (2.0) service provider entry 'serviceprovider1' has been created.

ruckus(config-hs20sp)# end
The Hotspot (2.0) service provider entry has saved successfully.

Your changes have been saved.

ruckus(config)#
```

## no hs20sp

Use the following command to delete a Hotspot 2.0 Service Provider entry:

```
no hs20sp WORD
```

### Example

```
ruckus(config)# no hs20sp provider1
The Hotspot (2.0) service provider 'provider1' has been deleted.

ruckus(config)#
```

## Configure Hotspot 2.0 Service Provider Settings

The following commands can be used to configure Hotspot 2.0 Service Provider entry settings. To execute these commands, you must first create or edit a Hotspot 2.0 Service Provider entry using the **hs20sp** command and entering the **config-hs20sp** context.

### Syntax Description

#### **help**

Shows available commands.

#### **history**

Shows a list of previously run commands.

#### **abort**

Exits the config-hs20sp context without saving changes.

#### **end**

Saves changes, and then exits the config-hs20sp context.

#### **exit**

Saves changes, and then exits the config-hs20sp context.

#### **quit**

Exits the config-hs20sp context without saving changes.

#### **no nai-realm NUMBER**

Deletes a NAI Realm entry.

#### **no domain-name NUMBER**

Deletes a domain name entry.

#### **no roam-consortium NUMBER**

Deletes a roaming consortium entry.

#### **no anqp-3gpp-info NUMBER**

Deletes a 3GPP cellular network information entry.

#### **name WORD**

Sets the hotspot(2.0) service provider entry name.

#### **description WORD**

Sets the hotspot(2.0) service provider entry description.

#### **nai-realm NUMBER**

Creates a new NAI Realm entry or modifies an existing entry.

#### **domain-name NUMBER**

Creates a new domain name entry or modifies an existing entry.

#### **domain-nameNUMBER name WORD**

Sets the domain name of a domain name entry.

#### **roam-consortium NUMBER**

Creates a new roaming consortium entry or modifies an existing entry.

#### **roam-consortiumNUMBER org-id HEX**

Sets the organization ID of a roaming consortium entry.

## Configuring Controller Settings

### Configure Hotspot 2.0 Commands

```
roam-consortiumNUMBER org-id HEX name WORD
Sets the name of a roaming consortium entry.

anqp-3gpp-info NUMBER
Creates a 3GPP cellular network information entry or modifies an existing entry list.

anqp-3gpp-info NUMBER mcc NUMBER
Sets the MCC of 3GPP cellular network information entry.

anqp-3gpp-info NUMBER mcc NUMBER mnc NUMBER
Sets the MNC of 3GPP cellular network information entry.

anqp-3gpp-info NUMBER mcc NUMBER mnc NUMBER name WORD
Sets the name of 3GPP cellular network information entry.

show
Displays hotspot 2.0 service provider settings.
```

## nai-realm

To create, a new NAI Realm entry or modifies an existing entry, use the following command:

```
nai-realm NUMBER
```

This command enters the config-hs20sp-nai-realm context. The following commands can be executed from within this context.

### Syntax Description

```
name
Sets the name of the NAI Realm entry.

encoding
Sets the encoding of the NAI Realm entry.

eap-method NUMBER
Sets the EAP method #X of the NAI Realm entry. (X:1~4)

no
Contains commands that can be executed from within the context.

show
Displays NAI Realm settings.
```

### Example

```
ruckus (config-hs20sp) # nai-realm 1
ruckus (config-hs20sp-nai-realm) # name realm1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus (config-hs20sp-nai-realm) # show
    Name= realm1
    Encoding= RFC-4282
    EAP Method #1= N/A
    EAP Method #2= N/A
    EAP Method #3= N/A
    EAP Method #4= N/A
ruckus (config-hs20sp-nai-realm) # end
To save the changes, type 'end' or 'exit'.
ruckus (config-hs20sp) # end
The Hotspot (2.0) service provider entry has saved successfully.
```

```
Your changes have been saved.  
ruckus(config)#
```

## name

Use the following command to set the name of the NAI Realm entry:

```
name WORD
```

## encoding

Use the following command to set the encoding of the NAI Realm entry:

```
encoding [ rfc-4282 | utf-8 ]
```

## eap-method

Use the following command to set the EAP method of the NAI Realm entry:

```
eap-method NUMBER
```

## eap-method eap-mthd

Use the following command to set the EAP method of the NAI Realm entry:

```
eap-method NUMBER eap-mthd [N/A | NAME ]
```

### Syntax Description

#### N/A

Sets the EAP method of the NAI Realm entry to N/A.

#### MD5-Challenge

Sets the EAP method of the NAI Realm entry to MD5-Challenge.

#### EAP-TLS

Sets the EAP method of the NAI Realm entry to EAP-TLS.

#### EAP-CISCO

Sets the EAP method of the NAI Realm entry to EAP-Cisco.

#### EAP-SIM

Sets the EAP method of the NAI Realm entry to EAP-SIM.

#### EAP-TTLS

Sets the EAP method of the NAI Realm entry to EAP-TTLS.

#### PEAP

Sets the EAP method of the NAI Realm entry to PEAP.

#### MSCHAP-V2

Sets the EAP method of the NAI Realm entry to EAP-MSCHAP-V2.

#### EAP-AKA

Sets the EAP method of the NAI Realm entry to EAP-AKA.

**EAP-AKA-Prime**

Sets the EAP method of the NAI Realm entry to EAP-AKA'.

**Reserved**

Sets the EAP method of the NAI Realm entry to Reserved.

**Example**

```
ruckus (config-hs20sp-nai-realm) # eap-method 1 eap-mthd EAP-TLS  
The command was executed successfully. To save the changes, type 'end' or 'exit'  
ruckus (config-hs20sp-nai-realm) #
```

## eap-method auth-info

To set the Auth Info of the EAP method, use the following command:

**eap-method NUMBER auth-info NUMBER**

### Syntax Description

**auth-id**

Sets the auth info ID of the auth info.

**auth-id expanded-EAP-method**

Sets the Auth Info of the EAP method to expanded-EAP-method.

**auth-id expanded-EAP-method vndr-id NUMBER**

Sets the vendor ID of the auth info.

**auth-id expanded-EAP-method vndr-id NUMBER NUMBER**

Sets the vendor type of the auth info.

**auth-id nonEAP-inner-auth**

Sets the Auth Info of the EAP method to Non-EAP Inner Authentication Type.

**auth-id nonEAP-inner-auth auth-type**

Sets the auth info type of the auth info.

**nonEAP-inner-auth auth-type Reserved**

Sets the Non-EAP Inner Authentication Type to Reserved.

**auth-id nonEAP-inner-auth auth-type PAP**

Sets the Non-EAP Inner Authentication Type to PAP.

**auth-id nonEAP-inner-auth auth-type CHAP**

Sets the Non-EAP Inner Authentication Type to CHAP.

**auth-id nonEAP-inner-auth auth-type MSCHAP**

Sets the Non-EAP Inner Authentication Type to MSCHAP.

**auth-id nonEAP-inner-auth auth-type MSCHAPV2**

Sets the Non-EAP Inner Authentication Type to MSCHAPV2.

**auth-id inner-auth-EAP-mthd**

Sets the Auth Info of the EAP method to Inner Authentication EAP Method Type.

**auth-id inner-auth-EAP-mthd auth-type**

Sets the auth info type of the auth info.

**auth-id inner-auth-EAP-mthd auth-type EAP-TLS**

Sets the Inner Authentication EAP Method Type to EAP-TLS.

**auth-id inner-auth-EAP-mthd auth-type EAP-SIM**

Sets the Inner Authentication EAP Method Type to EAP-SIM.

**auth-id inner-auth-EAP-mthd auth-type EAP-TTLS**

Sets the Inner Authentication EAP Method Type to EAP-TTLS.

**auth-id inner-auth-EAP-mthd auth-type EAP-AKA**

Sets the Inner Authentication EAP Method Type to EAP-AKA.

**auth-id inner-auth-EAP-mthd auth-type EAP-AKA-Prime**

Sets the Inner Authentication EAP Method Type to EAP-AKA'.

**auth-id exp-inner-EAP-mthd**

Sets the Auth Info of the EAP method to expanded-inner-EAP-method.

**auth-id inner-EAP-mthd vndr-id NUMBER**

Sets the vendor ID of the auth info.

**auth-id exep-inner-EAP-mthd vndr-id NUMBER vndr-type NUMBER**

Sets the vendor type of the auth info.

**auth-id credential-type**

Sets the Auth Info of the EAP method to Credential Type.

**auth-id credential-type auth-type**

Sets the auth info type of the auth info.

**auth-id credential-type auth-type SIM**

Sets the Credential Type to SIM.

**auth-id credential-type auth-type USIM**

Sets the Credential Type to USIM.

**auth-id credential-type auth-type NFC-secure-elem**

Sets the Credential Type to NFC Secure Element.

**auth-id credential-type auth-type hardware-token**

Sets the Credential Type to Hardware Token.

**auth-id credential-type auth-type softoken**

Sets the Credential Type to Softoken.

**auth-id credential-type auth-type certificate**

Sets the Credential Type to Certificate.

**auth-id credential-type auth-type**

**auth-id credential-type auth-type username-password**

Sets the Credential Type to username/password.

**auth-id credential-type auth-type none**

Sets the Credential Type to none.

**auth-id credential-type auth-type reserved**

Sets the Credential Type to Reserved.

**auth-id tunnel-EAP-mthd-crdn-type**

Sets the Auth Info of the EAP method to Tunneled EAP Method Credential Type.

**auth-id tunnel-EAP-mthd-crdn-type auth-type**

Sets the auth info type of the auth info.

**auth-id tunnel-EAP-mthd-crdn-type auth-type SIM**

Sets the Tunneled EAP Method Credential Type to SIM.

**auth-id tunnel-EAP-mthd-crdn-type auth-type USIM**

Sets the Tunneled EAP Method Credential Type to USIM.

**auth-id tunnel-EAP-mthd-crdn-type auth-type NFC-secure-elem**

Sets the Tunneled EAP Method Credential Type to NFC Secure Element.

**auth-id tunnel-EAP-mthd-crdn-type auth-type hardware-token**

Sets the Tunneled EAP Method Credential Type to Hardware Token.

**auth-id tunnel-EAP-mthd-crdn-type auth-type softtoken**

Sets the Tunneled EAP Method Credential Type to Softtoken.

**auth-id tunnel-EAP-mthd-crdn-type auth-type certificate**

Sets the Tunneled EAP Method Credential Type to Certificate.

**auth-id tunnel-EAP-mthd-crdn-type auth-type username-password**

Sets the Tunneled EAP Method Credential Type to username/password.

**auth-id tunnel-EAP-mthd-crdn-type auth-type reserved**

Sets the Tunneled EAP Method Credential Type to Reserved.

**auth-id tunnel-EAP-mthd-crdn-type auth-type anonymous**

Sets the Tunneled EAP Method Credential Type to Anonymous.

**no eap-method NUMBER**

Sets the EAP method #X of the NAI Realm entry. (X:1~4)

**no eap-method NUMBER auth-info NUMBER**

Disable the Auth Info of the EAP method

**show**

Displays NAI Realm settings.

# Configure Mesh Commands

Use the mesh commands to configure the controller's mesh networking settings. To run these commands, you must first enter the **config-mesh** context.

## mesh

Use the mesh command to enter the config-mesh context and configure the mesh-related settings.

**mesh**

### Syntax Description

**mesh**

Configure mesh settings

### Defaults

none

### Example

```
ruckus(config)# mesh  
ruckus(config-mesh) #
```

## abort

To exit the config-mesh context without saving changes, use the abort command.

## end

To save changes, and then exit the config-mesh context, use the end command.

## exit

To save changes, and then exit the config-mesh context, use the exit command.

## quit

To exit the config-mesh context without saving changes, use the quit command.

## show

To display the current mesh settings, use the following command from within the *config-mesh* context:

**show**

## Configuring Controller Settings

### Configure Mesh Commands

#### Syntax Description

**show**

Display the current mesh settings

#### Example

```
ruckus(config-mesh)# show
Mesh Settings:
  Mesh Status= Enabled
  Mesh Name(ESSID)= Mesh-951608000220
  Mesh Passphrase= bzj9Y0kEpkxOPzPXYKqLrJHZSAAnbtfaTm7Ebh6qps24PPcc5MtCiijGGwFZBG
  Mesh Radio Option= 5G
  Mesh Uplink Selection Algorithm = default(static)
  Mesh Hop Detection:
    Status= Disabled
  Mesh Downlinks Detection:
    Status= Disabled
  Tx. Rate of Management Frame= 2Mbps
  Beacon Interval= 200ms
  Zero-Touch-Mesh status= Enabled
Zero Touch Mesh Pre-Approved Serial Number List:
serial number = 921802014959, approved = 0, time = 0, id = 1
serial number = 441e981cf0d0, approved = 0, time = 0, id = 2
serial number = 4f1e681cf3f0, approved = 0, time = 0, id = 3
serial number = c41e781bd7c0, approved = 0, time = 0, id = 4
ruckus(config-mesh) #
```

## ssid

To set the SSID of the mesh network, use the following command:

**ssid WORD/SSID**

#### Syntax Description

**ssid**

Set the SSID of the mesh network

**WORD/SSID**

Set to this SSID

#### Defaults

None.

#### Example

```
ruckus(config-mesh)# ssid rks_mesh
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## passphrase

To set the passphrase that allows access to the mesh network, use the following command:

**passphrase WORD**

## Syntax Description

### **passphrase**

Set the passphrase that allows access to the mesh network

### **WORD**

Set to this passphrase

## Defaults

None.

## Example

```
ruckus(config-mesh)# passphrase test123456
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## hops-warn-threshold

To enable and configure the mesh hop threshold, use the following command:

### **hops-warn-threshold NUMBER**

## Syntax Description

### **hops-warn-threshold**

Set the mesh hop threshold (max hops)

### **NUMBER**

Set to this threshold value

## Defaults

5

## Example

```
ruckus(config-mesh)# hops-warn-threshold 6
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## no detect-hops

To disable the mesh hop threshold, use the following command:

### **no detect-hops**

## Syntax Description

### **no detect-hops**

Disable the mesh hop threshold

## Defaults

None.

## Example

```
ruckus(config-mesh)# no detect-hops  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## fan-out-threshold

To enable and configure the mesh downlink threshold, use the following command:

**fan-out-threshold NUMBER**

### Syntax Description

**fan-out-threshold**

Set the mesh downlink threshold (max downlinks)

**NUMBER**

Set to this threshold value

## Defaults

5

## Example

```
ruckus(config-mesh)# fan-out-threshold 8  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## no detect-fanout

To disable the mesh downlink threshold, use the following command:

**no detect-fanout**

### Syntax Description

**no detect-fanout**

Disable the mesh downlink threshold

## Example

```
ruckus(config-mesh)# no detect-fanout  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## beacon-interval

To set the beacon interval for mesh links, use the following command:

**beacon-interval NUMBER**

### Syntax Description

**beacon-interval**

Set the beacon interval for mesh links

**NUMBER**

Enter the beacon interval (100~1000 TUs)

### Defaults

200

### Example

```
ruckus(config-mesh)# beacon-interval 200  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-mesh)#+
```

## mgmt-tx-rate

To set the transmit rate for management frames, use the following command:

**mgmt-tx-rate RATE**

### Syntax Description

**mgmt-tx-rate**

Set the max transmit rate for management frames

**RATE**

Set the transmit rate (in Mbps).

### Defaults

2

### Example

```
ruckus(config-mesh)# mgmt-tx-rate 2  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-mesh)#+
```

## mesh-uplink-selection static

Sets static on mesh uplinks, the default is static.

**mesh-uplink selection static**

## Syntax Description

### **mesh-uplink-selection**

Set the mesh uplink selection method.

#### **static**

Set mesh uplink selection to static.

## Defaults

Static

## Example

```
ruckus(config-mesh)# mesh-uplink-selection static  
Nothing changed  
ruckus(config-mesh)#+
```

## mesh-uplink-selection dynamic

Sets dynamic on mesh uplinks.

### **mesh-uplink selection dynamic**

## Syntax Description

### **mesh-uplink-selection**

Set the mesh uplink selection method.

#### **dynamic**

Set mesh uplink selection to dynamic.

## Defaults

Static

## Example

```
ruckus(config-mesh)# mesh-uplink-selection dynamic  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-mesh)#+
```

## mesh-radio-option

To set the mesh radio, use the following command:

```
mesh-radio-option <2.4G | 5G>
```

### Options

2.4G: Sets mesh radio type to 2.4 GHz.

5G: Sets mesh radio type to 5 GHz.

### Defaults

5G

### Example

```
ruckus(config-mesh)# mesh-radio-option 5G
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-mesh)#+
```

## Configuring Controller Settings

### Configure Mesh Commands

## zero-touch-mesh

To enable zero touch mesh, use the following command:

**zero-touch-mesh**

### Defaults

Disabled

### Example

```
ruckus(config-mesh)# zero-touch-mesh  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-mesh)#+
```

## no zero-touch-mesh

To disable zero touch mesh, use the following command:

**no zero-touch-mesh**

### **Defaults**

Disabled

### **Example**

```
ruckus(config-mesh)# no zero-touch-mesh
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-mesh)#+
```

## Configuring Controller Settings

### Configure Mesh Commands

## zt-mesh-serial

To add one or more zero-touch mesh pre-approved serial numbers, use the following command:

```
zt-mesh-serial[<SERIAL_1> <SERIAL_2> <...> <SERIAL_n>]
```

### Syntax Description

zt-mesh-serial: Add zero-touch mesh pre-approved serial number.

<SERIAL\_1>... : Serial number to be added to Zero Touch Mesh pre-approved list.

#### NOTE

The `zt-mesh-serial` command only submits these serial numbers to a system memory buffer. It does not save them to the pre-approved AP list. If you enter the `exit` or `end` command, these serial numbers will be saved to the pre-approved serial list and deleted from the system memory buffer. If you enter the `quit` or `abort` command, these serial numbers will be discarded and deleted from the system memory buffer.

### Example

```
ruckus(config-mesh)# zt-mesh-serial 111122223333 222233334444 333344445555 444455556666
Add all serial numbers to zt-mesh pre-approved list submit ok!
ruckus(config-mesh)# end
Add 111122223333 to zt-mesh pre-approved list execute success!
Add 222233334444 to zt-mesh pre-approved list execute success!
Add 333344445555 to zt-mesh pre-approved list execute success!
Add 444455556666 to zt-mesh pre-approved list execute success!
Your changes have been saved.
ruckus(config)#

```

## no zt-mesh-serial

To delete a zero-touch mesh pre-approved serial number, use the following command:

**no zt-mesh-serial [<SIGNAL\_1> <SIGNAL\_2> <...> <SIGNAL\_n>]**

### Syntax Description

no zt-mesh-serial: Delete zero-touch mesh pre-approved serial number.

<SIGNAL\_1>... : Serial number to be removed from Zero Touch Mesh pre-approved list.

#### NOTE

The no zt-mesh-serial command only submits these serial numbers to a system memory buffer. It does not remove them from the pre-approved AP list. If you enter the exit or end command, these serial numbers will be removed from the pre-approved serial list and deleted from the system memory buffer. If you enter the quit or abort command, these serial numbers will be discarded and deleted from the system memory buffer.

### Example

```
ruckus(config-mesh)# no zt-mesh-serial 111122223333 222233334444 333344445555 444455556666
Delete all serial numbers from zt-mesh pre-approved list submit ok!
ruckus(config-mesh)# end
Delete 111122223333 from zt-mesh pre-approved list execute success!
Delete 222233334444 from zt-mesh pre-approved list execute success!
Delete 333344445555 from zt-mesh pre-approved list execute success!
Delete 444455556666 from zt-mesh pre-approved list execute success!
Your changes have been saved.
ruckus(config)#

```

# Configure Alarm Commands

Use the alarm commands to configure the controller's alarm notification settings. To run these commands, you must first enter the **config-alarm** context.

## alarm

To enter the config-alarm context, use the following command.

**alarm**

### Defaults

Disabled

### Example

```
ruckus(config)# alarm  
ruckus(config-alarm) #
```

## no alarm

To disable alarm settings, use the following command:

**no alarm**

### Example

```
ruckus(config)# no alarm  
The Alarm settings have been updated.  
ruckus(config) #
```

## abort

To exit the config-alarm context without saving changes, use the abort command.

**abort**

## end

To save changes, and then exit the config-alarm context, use the following command:

**end**

### Example

```
ruckus(config-alarm)# end  
The Alarm settings have been updated.  
Your changes have been saved.  
ruckus(config) #
```

## exit

To save changes, and then exit the config-alarm context, use the following command:

**exit**

### Example

```
ruckus(config-alarm)# exit  
The Alarm settings have been updated.  
Your changes have been saved.
```

## quit

To exit the config-alarm context without saving changes, use the quit command.

**quit**

### Example

```
ruckus(config-alarm)# quit  
No changes have been saved.  
ruckus(config)#
```

## e-mail

To set the email address to which alarm notifications will be sent, use the following command:

**e-mail WORD**

### Syntax Description

**e-mail**

Set the email address to which alarm notifications will be sent

**WORD**

Send alarm notifications to this email address

### Defaults

None.

### Example

```
ruckus(config-alarm)# e-mail joe@163.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## show

To display the current alarm settings, use the following command:

**show**

## Configuring Controller Settings

### Configure Alarm Commands

#### **Example**

```
ruckus(config-alarm)# show  
Alarm:  
  Status= Enabled  
  Email Address= test@hotmail.com  
  
ruckus(config-alarm) #
```

# Configure Alarm-Event Settings

Use the alarm-event commands to configure which events will trigger ZoneDirector email alerts. Entering this command enters the **config-alarm-event** context.

## alarm-event

To enter the config-alarm-event context and configure email alarm notifications for specific event types, use the following command:

**alarm-event**

## event

To enable email alarm notifications for a specific alarm event, use the following command:

**event WORD**

### Syntax Description

**event all**

Enable email alarms for all event types

**rogue-ap-detected**

Enable email notification when Rogue AP detected

**rogue-device-detected**

Enable email notification when Ad hoc network detected

**ap-lost-contacted**

AP lost contact

**ssid-spoofing-ap-detected**

SSID spoofing AP detected

**mac-spoofing-ap-detected**

MAC spoofing AP detected

**user-blocked-ap-detected**

User blocked AP detected

**rogue-dhcp-server-detected**

Rogue DHCP server detected

**temporary-license-expired**

Temporary license has expired

**temporary-license-will-expire**

Temporary license will expire

**lan-rogue-ap-detected**

LAN Rogue AP detected

**radius-server-unreachable**

RADIUS server unreachable

## Configuring Controller Settings

### Configure Alarm-Event Settings

#### **ap-has-hardware-problem**

AP hardware problem detected

#### **uplink-ap-lost**

Mesh AP uplink connection lost

#### **incomplete-primary/secondary-ip-settings**

AP fails to maintain primary/secondary ZD IP address settings

#### **smart-redundancy-state-changed**

Smart Redundancy device status change detected

#### **smart-redundancy-active-connected**

Smart Redundancy device active device connected

#### **smart-redundancy-standby-connected**

Smart Redundancy standby device connected

#### **smart-redundancy-active-disconnected**

Smart Redundancy active device disconnected

#### **smart-redundancy-standby-disconnected**

Smart Redundancy standby device disconnected

#### **entitlement-download-fail**

Failure to download the Support Entitlement file from the Ruckus Entitlement server

#### **license-download-fail**

Failure to download the URL License file from the Ruckus License Server.

#### **test-alarm ap-lose-connection**

Test AP connection lost alarm event

#### **show**

Show alarm settings

## Defaults

All enabled

## Example

```
ruckus(config)# alarm-event
ruckus(config-alarm-event)# event all
ruckus(config-alarm-event)# show
Alarm Events Notify By Email:
  MSG_rogue_AP_detected=          enabled
  MSG_ad_hoc_network_detected=    enabled
  MSG_AP_lost=                   enabled
  MSG_SSID_spoofing_AP_detected=  enabled
  MSG_MAC_spoofing_AP_detected=   enabled
  MSG_admin_rogue_dhcp_server=    enabled
  MSG_admin_templic_expired=     enabled
  MSG_admin_templic_oneday=       enabled
  MSG_same_network_spoofing_AP_detected=  enabled
  MSG_RADIUS_service_outage=     enabled
  MSG_AP_hardware_problem=       enabled
  MSG_AP_no_mesh_uplink=         enabled
  MSG_AP_keep_no_AC_cfg=        enabled
  MSG_cltr_change_to_active=    enabled
  MSG_cltr_active_connected=    enabled
```

```
MSG_cltr_standby_connected=          enabled
MSG_cltr_active_disconnected=        enabled
MSG_cltr_standby_disconnected=       enabled
MSG_user_blocked_AP_detected=        enabled
MSG_Entityment_file_download_fail=   enabled
ruckus(config-alarm-event) #
```

## no event

To disable email alarm notifications for specific event types, use the following command:

```
no event event_name
```

### Syntax Description

#### no event

Disable email alarms for this event type

#### all

Disable email alarms for all event types

#### rogue-ap-detected

Rogue AP detected

#### rogue-device-detectedq

Ad hoc network detected

#### ap-lost-contacted

AP lost contact

#### ssid-spoofing-ap-detected

SSID spoofing AP detected

#### mac-spoofing-ap-detected

MAC spoofing AP detected

#### user-blocked-ap-detected

User blocked AP detected

#### rogue-dhcp-server-detected

Rogue DHCP server detected

#### temporary-license-expired

Temporary license has expired

#### temporary-license-will-expire

Temporary license will expire

#### lan-rogue-ap-detected

LAN Rogue AP detected

#### radius-server-unreachable

RADIUS server unreachable

#### ap-has-hardware-problem

AP hardware problem detected

#### uplink-ap-lost

Mesh AP uplink connection lost

## Configuring Controller Settings

### Configure Alarm-Event Settings

#### **incomplete-primary/secondary-ip-settings**

AP fails to maintain primary/secondary ZD IP address settings

#### **smart-redundancy-state-changed**

Smart Redundancy device status change detected

#### **smart-redundancy-active-connected**

Smart Redundancy device active device connected

#### **smart-redundancy-standby-connected**

Smart Redundancy standby device connected

#### **smart-redundancy-active-disconnected**

Smart Redundancy active device disconnected

#### **smart-redundancy-standby-disconnected**

Smart Redundancy standby device disconnected

#### **entitlement-download-fail**

Failure to download the Support Entitlement file from the Ruckus Entitlement server

## Example

```
ruckus (config-alarm-event) # no event aaa-server-unreachable
ruckus (config-alarm-event) # show
Alarm Events Notify By Email:
  MSG_rogue_AP_detected=           enabled
  MSG_ad_hoc_network_detected=     enabled
  MSG_AP_lost=                     enabled
  MSG_SSID_spoofing_AP_detected=   enabled
  MSG_MAC_spoofing_AP_detected=    enabled
  MSG_admin_rogue_dhcp_server=     enabled
  MSG_admin_templic_expired=       enabled
  MSG_admin_templic_oneday=        enabled
  MSG_same_network_spoofing_AP_detected= enabled
  MSG_RADIÙS_service_outage=      disabled
  MSG_AP_hardware_problem=        enabled
  MSG_AP_no_mesh_uplink=          enabled
  MSG_AP_keep_no_AC_cfg=          enabled
  MSG_cltr_change_to_active=      enabled
  MSG_cltr_active_connected=      enabled
  MSG_cltr_standby_connected=     enabled
  MSG_cltr_active_disconnected=   enabled
  MSG_cltr_standby_disconnected=  enabled
  MSG_user_blocked_AP_detected=   enabled
  MSG_Entitlement_file_download_fail= enabled

ruckus (config-alarm-event) #
```

# Configure Services Commands

Use the services commands to configure miscellaneous service settings, such as automatic power and channel selection settings, ChannelFly, background scanning, rogue AP and rogue DHCP server detection, etc. To run these commands, you must first enter the **config-services** context.

## abort

To exit the config-services context without saving changes, use the abort command.

**abort**

### Syntax Description

**abort**

Exit the service settings without saving changes

## Example

```
ruckus (config-services) # abort  
No changes have been saved.  
ruckus (config) #
```

## end

To save changes, and then exit the config-services context, use the following command:

**end**

### Syntax Description

**end**

Save changes, and then exit the context

## Example

```
ruckus (config-services) # end  
Your changes have been saved.  
ruckus (config) #
```

## exit

To save changes, and then exit the config-services context, use the following command:

**exit**

### Syntax Description

**exit**

Save changes, and then exit the context

## **Configuring Controller Settings**

### Configure Services Commands

#### **Example**

```
ruckus(config-services)# exit  
Your changes have been saved.  
ruckus(config)#
```

## **quit**

To exit the config-services context without saving changes, use the quit command.

**quit**

#### **Syntax Description**

**quit**

Exit the service settings without saving changes

#### **Example**

```
ruckus(config-services)# quit  
No changes have been saved.  
ruckus(config)#
```

## **auto-channel-background-scanning**

To configure auto channel background scanning settings, and enter the *ruckus(config-auto-channel-background-scanning)* context, use the following command:

**auto-channel-background-scanning**

#### **Example**

```
ruckus(config-services)# auto-channel-background-scanning  
ruckus(config-auto-channel-background-scanning) #
```

## **radio-2.4**

To enable auto channel background scanning on the 2.4 GHz radio, use the following command:

**radio-2.4**

### **Defaults**

Enabled.

#### **Example**

```
ruckus(config-auto-channel-background-scanning) # radio-2.4  
The command was executed successfully.  
ruckus(config-auto-channel-background-scanning) #
```

## **no radio-2.4**

To disable auto channel background scanning on the 2.4 GHz radio, use the following command:

**no radio-2.4**

### **Defaults**

Enabled.

### **Example**

```
ruckus (config-auto-channel-background-scanning) # no radio-2.4  
The command was executed successfully.  
ruckus (config-auto-channel-background-scanning) #
```

## **radio-5**

To enable auto channel background scanning on the 5 GHz radio, use the following command:

**radio-5**

### **Defaults**

Enabled.

### **Example**

```
ruckus (config-auto-channel-background-scanning) # radio-5  
The command was executed successfully.  
ruckus (config-auto-channel-background-scanning) #
```

## **no radio-5**

To disable auto channel background scanning on the 5 GHz radio, use the following command:

**no radio-5**

### **Defaults**

Enabled.

### **Example**

```
ruckus (config-auto-channel-background-scanning) # no radio-5  
The command was executed successfully.  
ruckus (config-auto-channel-background-scanning) #
```

## **off-period**

To set the off period hours for auto channel background scanning, use the following command:

**off-period <NUMBER><NUMBER>**

## **Configuring Controller Settings**

### Configure Services Commands

#### **Defaults**

Disabled.

#### **Example**

```
ruckus(config-auto-channel-background-scanning)# off-period 23  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-auto-channel-background-scanning)#+
```

#### **no off-period**

To disable the off period for auto channel background scanning, use the following command:

#### **no off-period**

#### **Defaults**

Disabled.

#### **Example**

```
ruckus(config-auto-channel-background-scanning)# no off-period  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-auto-channel-background-scanning)#+
```

#### **clients**

To set the max number of associated clients per AP above which auto channel selection will not function, use the following command:

#### **clients<NUMBER>**

#### **Defaults**

Disabled.

#### **Example**

```
ruckus(config-auto-channel-background-scanning)# clients 100  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-auto-channel-background-scanning)#+
```

#### **interval**

To set the auto channel selection interval (in minutes), use the following command:

#### **interval <NUMBER>**

#### **Defaults**

10 minutes.

## Example

```
ruckus(config-auto-channel-background-scanning)# interval 10  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-auto-channel-background-scanning)#+
```

## threshold

To set threshold auto channel background scanning threshold (low|medium|high), use the following command:

```
threshold [low | medium | high]
```

## Defaults

Medium.

## Example

```
ruckus(config-auto-channel-background-scanning)# threshold low  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-auto-channel-background-scanning)#+
```

## simulate

To simulate auto channel selection with the current settings, use the following command:

```
simulate
```

## Example

```
ruckus(config-auto-channel-background-scanning)# simulate  
#####2.4G channel plan#####  
AP MAC      NB   Client  NB_Client  Rogue  Channel  Changed  New_Channel  New_NB  New_NB_Client  
New_Rogue  
#####5G channel plan#####  
AP MAC      NB   Client  NB_Client  Rogue  Channel  Changed  New_Channel  New_NB  New_NB_Client  
New_Rogue  
d4:c1:9e:35:c9:40  0     1       0        0      40      No       NA        0       0          0  
ruckus(config-auto-channel-background-scanning)#+
```

## deploy

To deploy auto channel background scanning with the current settings, use the following command:

```
deploy
```

## Example

```
ruckus(config-auto-channel-background-scanning)# deploy  
ruckus(config-auto-channel-background-scanning)#+
```

## show

To display auto channel background scanning settings, use the following command:

## Configuring Controller Settings

### Configure Services Commands

**show**

#### Example

```
ruckus(config-auto-channel-background-scanning)# show
 2.4GHZ radio status= Enabled
 5GHZ radio status= Enabled
 Off period hours = Disabled
 Interval = 1000 minutes
ruckus(config-auto-channel-background-scanning) #
```

## auto-adjust-ap-channel radio-2.4

To enable automatically adjusting the AP 2.4 GHz radio channel when interference is detected, use the following command:

**auto-adjust-ap-channel radio-2.4**

#### Syntax Description

**auto-adjust-ap-channel**

Enable the auto adjustment of the AP radio channel.

**radio-2.4**

Enable the auto adjustment of the AP radio channel on the 2.4 GHz radio.

#### Defaults

Enabled.

#### Example

```
ruckus(config-services)# auto-adjust-ap-channel radio-2.4
The command was executed successfully.
ruckus(config-services) #
```

## no auto-adjust-ap-power radio-2.4

To disable automatically adjusting AP 2.4 GHz radio channel when interference is detected, use the following command:

**no auto-adjust-ap-power radio-2.4**

#### Syntax Description

**no auto-adjust-ap-power**

Disable the auto adjustment of the AP radio power.

**radio-2.4**

Disable the auto adjustment of the AP radio power on the 2.4 GHz radio.

#### Defaults

Disabled.

## Example

```
ruckus(config-services)# no auto-adjust-ap-power radio-2.4  
The command was executed successfully.
```

## auto-adjust-ap-power radio-5

To enable automatically adjusting AP 5 GHz radio power when interference is detected, use the following command:

```
auto-adjust-ap-power radio-5
```

## Syntax Description

### auto-adjust-ap-power

Enable the auto adjustment of the AP radio power.

### radio-2.4

Enable the auto adjustment of the AP radio power on the 5 GHz radio.

## Defaults

Disabled.

## Example

```
ruckus(config-services)# auto-adjust-ap-power radio-5  
The command was executed successfully.
```

## no auto-adjust-ap-power radio-5

To disable automatically adjusting AP 5 GHz radio channel when interference is detected, use the following command:

```
no auto-adjust-ap-power radio-5
```

## Syntax Description

### no auto-adjust-ap-power

Disable the auto adjustment of the AP radio power.

### radio-5

Disable the auto adjustment of the AP radio power on the 5 GHz radio.

## Defaults

Enabled.

## Example

```
ruckus(config-services)# no auto-adjust-ap-power radio-5  
The command was executed successfully.
```

## auto-adjust-ap-channel radio-2.4

To enable automatically adjusting the AP 2.4 GHz radio channel when interference is detected, use the following command:

**auto-adjust-ap-channel radio-2.4**

### Syntax Description

**auto-adjust-ap-channel**

Enable the auto adjustment of the AP radio channel.

**radio-2.4**

Enable the auto adjustment of the AP radio channel on the 2.4 GHz radio.

### Defaults

Enabled.

### Example

```
ruckus(config-services)# auto-adjust-ap-channel radio-2.4  
The command was executed successfully.  
ruckus(config-services) #
```

## no auto-adjust-ap-channel radio-2.4

To disable automatically adjusting the AP 2.4 GHz radio channel when interference is detected, use the following command:

**no auto-adjust-ap-channel radio-2.4**

### Syntax Description

**no auto-adjust-ap-channel**

Disable the auto adjustment of the AP radio channel.

**radio-2.4**

Disable the auto adjustment of the AP radio channel on the 2.4 GHz radio.

### Defaults

Enabled.

### Example

```
ruckus(config-services)# no auto-adjust-ap-channel radio-2.4  
The command was executed successfully.  
ruckus(config-services) #
```

## auto-adjust-ap-channel radio-5

To enable automatically adjusting the AP 5 GHz radio channel when interference is detected, use the following command:

**auto-adjust-ap-channel radio-5**

## Syntax Description

### **auto-adjust-ap-channel**

Enable the auto adjustment of the AP radio channel.

### **radio-5**

Enable the auto adjustment of the AP radio channel on the 5 GHz radio.

## Defaults

Enabled.

## Example

```
ruckus(config-services)# auto-adjust-ap-channel radio-5  
The command was executed successfully.  
ruckus(config-services) #
```

## **no auto-adjust-ap-channel radio-5**

To disable automatically adjusting the AP 5 GHz radio channel when interference is detected, use the following command:

```
no auto-adjust-ap-channel radio-5
```

## Syntax Description

### **no auto-adjust-ap-channel**

Disable the auto adjustment of the AP radio channel.

### **radio-5**

Disable the auto adjustment of the AP radio channel on the 5 GHz radio.

## Defaults

Enabled.

## Example

```
ruckus(config-services)# no auto-adjust-ap-channel radio-5  
The command was executed successfully.  
ruckus(config-services) #
```

## raps

To enable the Radar Avoidance Pre-Scanning (RAPS) feature on supported access points (SC-8800-S, 7782, 7781, etc.), use the following command:

```
raps
```

## **no raps**

To disable the Radar Avoidance Pre-Scanning (RAPS) feature on supported access points (SC-8800-S, 7782, 7781, etc.), use the following command:

**no raps**

## channelfly

To enable ChannelFly channel management, use the following command:

**channelfly [ radio-2.4-mtbc | radio-5-mtbc ] NUMBER**

### Syntax Description

**channelfly**

Enable ChannelFly automatic adjustment of theAP radio channel

**radio-2.4**

Enable ChannelFly on the 2.4 GHz radio

**radio-5**

Enable ChannelFly on the 5 GHz radio

**mtbc**

Set the mean time between channel changes

**NUMBER**

Number in minutes (1~1440) to set as mean time between channel change

### Defaults

Enabled for both 2.4 and 5 GHz radios

MTBC: 100

### Example

Enable ChannelFly channel management for 2.4G radios

```
ruckus(config-services)# channelfly radio-2.4 100  
The command was executed successfully.  
ruckus(config-services) #
```

Enable ChannelFly channel management for 5 G radios

```
ruckus(config-services)# channelfly radio-2.4-mtbc 100  
The command was executed successfully.  
ruckus(config-services) #
```

## no channelfly

To disable ChannelFly channel management, use the following command:

**no channelfly [ radio-2.4 | radio-5 ]**

### Syntax Description

**no channelfly**

Disable ChannelFly automatic adjustment of theAP radio channel

#### **radio-2.4**

Disable ChannelFly on the 2.4 GHz radio

#### **radio-5**

Disable ChannelFly on the 5 GHz radio

#### **Defaults**

None.

#### **Example**

```
ruckus(config-services)# no channelfly radio-2.4  
The command was executed successfully.  
ruckus(config-services)# no channelfly radio-5  
The command was executed successfully.  
ruckus(config-services) #
```

## **background-scan**

To enable background scanning and configure the scan interval, use the following command:

```
background-scan [ radio-2.4-interval | radio-5-interval ] <NUMBER>
```

#### **Syntax Description**

##### **background-scan**

Enable background scanning and configure the scan interval

##### **radio-2.4-interval <NUMBER>**

Configure background scanning interval for the 2.4 GHz radio

##### **radio-5-interval <NUMBER>**

Configure background scanning interval for the 5 GHz radio

##### **low-threshold <NUMBER>**

Set the min threshold of switch channel in 2.4 GHz radio (Range: 0 ~ 2000)

#### **Defaults**

20 seconds

#### **Example**

```
ruckus(config-services)# background-scan radio-2.4-interval 6  
The command was executed successfully.
```

## **background-scan low-threshold**

To set the min threshold of switch channel in 2.4GHz radio (Range: 0 ~ 2000), use the following command:

```
background-scan low-threshold <NUMBER>
```

### **Example**

```
ruckus(config-services)# background-scan low-threshold 100  
The command was executed successfully.  
ruckus(config-services) #
```

## **no background-scan**

To disable background scanning on the 2.4GHz radio, use the following command:

```
no background-scan [ radio-2.4-interval | radio-5 ]
```

### **Syntax Description**

**no background-scan**

Disable background scanning

**radio-2.4**

Disable background scanning on the 2.4GHz radio

**radio-5**

Disable background scanning on the 5GHz radio

### **Defaults**

None

### **Example**

```
ruckus(config-services)# no background-scan radio-2.4  
The command was executed successfully.  
ruckus(config-services)# no background-scan radio-5  
The command was executed successfully.
```

## aeroscout-detection

To enable detection of AeroScout RFID Tags by APs that are managed by ZoneDirector, use the following command:

**aeroscout-detection**

### Syntax Description

**aeroscout-detection**

Enable detection of AeroScout RFID Tags by APs

### Defaults

Disabled

### Example

```
ruckus(config-services)# aeroscout-detection  
The command was executed successfully.
```

## no aeroscout-detection

To disable detection of AeroScout RFID Tags by APs that are managed by ZoneDirector, use the following command:

**no aeroscout-detection**

### Syntax Description

**no aeroscout-detection**

Disable detection of AeroScout RFID Tags by APs

### Defaults

Disabled

### Example

```
ruckus(config-services)# no aeroscout-detection  
The command was executed successfully.
```

## ekahau

To enable and set Ekahau Blink support with ERC IP and port, use the following command:

**ekahau ERC IP ERC Port**

### Defaults

Disabled

## Configuring Controller Settings

Configure Services Commands

### Example

```
ruckus(config-services)# ekahau 10.10.10.1 500
The command was executed successfully.
ruckus(config-services)# show
Services:
    Automatically adjust ap radio power= Disabled
    Automatically adjust ap channel= Enabled
    Channelfly works on 2.4GHz radio:
        Status= Disabled
    Channelfly works on 5GHz radio:
        Status= Disabled
    Run a background scan on 2.4GHz radio:
        Status= Enabled
        Time= 2000 seconds
    Run a background scan on 5GHz radio:
        Status= Enabled
        Time= 2000 seconds
    AeroScout RFID tag detection= Disabled
    Tunnel encryption for tunneled traffic= Disabled
    Block multicast traffic from network to tunnel= Block non well-known
    Block broadcast traffic from network to tunnel except ARP and DHCP= Disabled
    Tunnel Proxy ARP of tunnel WLAN:
        status= Disabled
        ageing time= 0
    Packet Inspection Filter(PIF) uplink process= Disabled
    Packet Inspection Filter(PIF) rate limit:
        status= Disabled
    RAPS= Enabled
    EKHAU settings:
        status= Enabled
        ERC IP= 10.10.10.1
        ERC port= 500
ruckus(config-services) #
```

## no ekahau

To disable Ekahau Blink support, use the following command:

**no ekahau**

### Defaults

Disabled

### Example

```
ruckus(config-services)# no ekahau
The command was executed successfully.
ruckus(config-services) #
```

## tun-encrypt

To enable tunnel encryption for tunneled traffic, use the following command:

**tun-encrypt**

### Defaults

Disabled

### **Example**

```
ruckus(config-services)# tun-encrypt  
The command was executed successfully.
```

## **no tun-encrypt**

To disable tunnel encryption for tunneled traffic, use the following command:

```
no tun-encrypt
```

### **Defaults**

Disabled

### **Example**

```
ruckus(config-services)# no tun-encrypt  
The command was executed successfully.
```

## tun-block-mcast all

To enable multicast blocking for tunneled traffic, use the following command:

**tun-block-mcast all**

### Defaults

Disabled

### Example

```
ruckus(config-services)# tun-block-mcast all  
The command was executed successfully.  
ruckus(config-services) #
```

## tun-block-mcast non-well-known

To enable multicast blocking for non-well-known tunneled traffic, use the following command:

**tun-block-mcast non-well-known**

### Defaults

Disabled

### Example

```
ruckus(config-services)# tun-block-mcast non-well-known  
The command was executed successfully.  
ruckus(config-services) #
```

## no tun-block-mcast

To disable blocking multicast traffic from network to tunnel, use the following command:

**no tun-block-mcast**

## tun-block-bcast

To enable broadcast blocking for tunneled traffic, use the following command:

**tun-block-bcast**

### Defaults

Disabled

### Example

```
ruckus(config-services)# tun-block-bcast  
The command was executed successfully.  
ruckus(config-services) #
```

## no tun-block-bcast

To disable blocking broadcast traffic from network to tunnel except ARP and DHCP, use the following command:

**no tun-block-bcast**

## tun-proxy-arp

To enable proxy ARP service for tunneled traffic, use the following command:

**tun-proxy-arp NUMBER**

### Defaults

Disabled

### Example

```
ruckus(config-services)# tun-proxy-arp 1000  
The command was executed successfully.  
ruckus(config-services) #
```

## no tun-proxy-arp

To disable Proxy ARP for the tunneled WLAN, use the following command:

**no tun-proxy-arp**

## tun-ip-ageing

To set ageing time for IP/IPv6 table, use the following command:

**tun-ip-ageing NUMBER**

## pif

To enable Packet Inspection Filter and set rate limiting threshold, use the following command:

**pif [uplink-proc | rate-limit NUMBER ]**

### Syntax Description

**pif**

Enable Packet Inspection Filter

**uplink-proc**

Enable uplink process of Packet Inspection Filter

**rate-limit**

Enable and set Broadcast Neighbor Discovery Packets (ARP and ICMPv6 Neighbor Solicit) rate limit threshold.

**NUMBER**

Rate limiting threshold for PIF feature.

## Configuring Controller Settings

Configure Services Commands

### Example

```
ruckus(config-services)# pif uplink-proc
The command was executed successfully.
ruckus(config-services)# pif rate-limit 1000
The command was executed successfully.
ruckus(config-services)# show
Services:
    Automatically adjust ap radio power= Disabled
    Automatically adjust ap channel= Enabled
    ChannelFly works on 2.4GHz radio:
        Status= Disabled
    ChannelFly works on 5GHz radio:
        Status= Disabled
    Run a background scan on 2.4GHz radio:
        Status= Enabled
        Time= 20 seconds
    Run a background scan on 5GHz radio:
        Status= Enabled
        Time= 20 seconds
    AeroScout RFID tag detection= Disabled
    Tunnel encryption for tunneled traffic= Enabled
    Block multicast traffic from network to tunnel= Disabled
    Block broadcast traffic from network to tunnel except ARP and DHCP= Disabled
    Tunnel Proxy ARP of tunnel WLAN:
        status= Disabled
    Packet Inspection Filter(PIF) uplink process= Enabled
    Packet Inspection Filter(PIF) rate limit:
        status= Enabled
        rate limit= 1000
ruckus(config-services) #
```

### no pif

To disable uplink process of packet inspection filter or disables Broadcast Neighbor Discovery Packets (ARP and ICMPv6 Neighbor Solicit), use the following command:

```
no pif [uplink-proc | rate-limit ]
```

### Example

```
ruckus(config-services)# no pif uplink-proc
The command was executed successfully.
ruckus(config-services)# no pif rate-limit
The command was executed successfully.
ruckus(config-services) #
```

### show

To display the current service settings, use the following command:

```
show
```

### Syntax Description

```
show
```

Display the current service settings

## Defaults

None.

## Example

```
ruckus(config-services)# show  
Services:  
    Automatically adjust ap radio power= Disabled  
    Automatically adjust ap channel= Enabled  
    Channelfly works on 2.4GHz radio:  
        Status= Disabled  
    Channelfly works on 5GHz radio:  
        Status= Disabled  
    Run a background scan on 2.4GHz radio:  
        Status= Enabled  
        Time= 2000 seconds  
    Run a background scan on 5GHz radio:  
        Status= Enabled  
        Time= 2000 seconds  
    AeroScout RFID tag detection= Disabled  
    Tunnel encryption for tunneled traffic= Disabled  
    Block multicast traffic from network to tunnel= Block non well-known  
    Block broadcast traffic from network to tunnel except ARP and DHCP= Disabled  
    Tunnel Proxy ARP of tunnel WLAN:  
        status= Disabled  
        ageing time= 0  
    Packet Inspection Filter(PIF) uplink process= Disabled  
    Packet Inspection Filter(PIF) rate limit:  
        status= Disabled  
ruckus(config-services)#[/pre>
```

# Configure WIPS Commands

Use the wips commands to configure Wireless Intrusion Prevention settings. To run these commands, you must first enter the **config-wips** context.

## wips

Use the following command to enter the config-wips context and configure WIPS settings:

**wips**

### Syntax Description

**help**

Shows available commands

**history**

Shows a list of previously run commands

**end**

Saves changes, and the exits the config-wips context

**exit**

Saves changes, and the exits the config-wips context

**no WORD**

Disable WIPS services

**protect-excessive-wireless-request**

Enables protecting the wireless network against excessive wireless requests

**temp-block-auth-failed-client time NUMBER**

Temporarily block wireless clients with repeated authentication failures for the specified time (in seconds)

**rogue-report [ all ] | [ malicious ssid-spoofing | same-network | user-blocked | mac-spoofing ]**

Enables report rogue devices in ZD event log.

**all**

Report all rogue devices.

**malicious [ ssid-spoofing | same-network | user-blocked | mac-spoofing ]**

Report particular malicious type.

**malicious-report**

Enables protecting the network from malicious rogue access points

**rogue-dhcp-detection**

Enables rogue DHCP server detection

**show**

Displays the WIPS settings

### Example

```
ruckus(config)# wips
ruckus(config-wips)# show
Protect my wireless network against excessive wireless requests= Disabled
Temporarily block wireless clients with repeated authentication failures:
```

```
Status= Enabled
Time= 30 seconds
Report rogue devices in ZD event log= Enabled
Protect the network from malicious rogue access points= Disabled
Rogue DHCP server detection= Enabled
ruckus(config-wips)# temp-block-auth-failed-client time 30
The command was executed successfully.
ruckus(config-wips)# rogue-report all
The command was executed successfully.
ruckus(config-wips)# rogue-report malicious same-network
The command was executed successfully.
ruckus(config-wips)# rogue-dhcp-detection
The command was executed successfully.
ruckus(config-wips)# no rogue-dhcp-detection
The command was executed successfully.
ruckus(config-wips)# no rogue-report
The command was executed successfully.
ruckus(config-wips)# show
Protect my wireless network against excessive wireless requests= Disabled
Temporarily block wireless clients with repeated authentication failures:
  Status= Enabled
  Time= 30 seconds
Report rogue devices in ZD event log= Disabled
Protect the network from malicious rogue access points= Disabled
Rogue DHCP server detection= Disabled
ruckus(config-wips)#[/pre]
```

# Configure Email Server Commands

Use the email-server commands to configure email server settings. To run these commands, you must first enter the **config-email-server** context.

## email-server

Use the following command to enter the **config-email-server** context and configure email server settings:

**email-server**

### Syntax Description

**help**

Shows available commands.

**history**

Shows a list of previously run commands.

**abort**

Exits the config-email-server context without saving changes.

**end**

Saves changes, and exits the config-email-server context.

**exit**

Saves changes, and exits the config-email-server context.

**quit**

Exits the config-email-server context without saving changes.

**enable**

Enables the E-Mail server.

**from WORD**

Sets the E-Mail from for email server.

**smtp-server-name WORD**

Sets the smtp server name for email server.

**smtp-server-port NUMBER**

Sets the smtp server port for email server.

**smtp-auth-name WORD**

Sets the smtp authentication user name for email server.

**smtp-auth-password WORD**

Sets the smtp authentication password for email server.

**smtp-wait-time**

Sets the smtp server wait time (in seconds).

**tls-smtp-encryption tls**

Enables TLS of smtp encryption for email server.

**tls-smtp-encryption starttls**

Enables starttls in the TLS of smtp encryption for email server.

**no enable**

Disables the email server setting.

**no tls-smtp-encryption tls**

Disables TLS of smtp encryption for email server.

**no tls-smtp-encryption starttls**

Disables starttls in the TLS of smtp encryption for email server.

**show**

Shows email server settings.

## Example

```
ruckus(config)# email-server
ruckus(config-email-server)# enable
ruckus(config-email-server)# from example@example.com
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-email-server)# smtp-server-name smtp.example.com
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-email-server)# smtp-server-port 587
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-email-server)# smtp-auth-name johndoe
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-email-server)# smtp-auth-password password
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-email-server)# tls-smtp-encryption tls
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-email-server)# tls-smtp-encryption starttls
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-email-server)# show
Email Server:
  Status= Enabled
  E-mail From = example@example.com
  SMTP Server Name= smtp.example.com
  SMTP Server Port= 587
  SMTP Authentication Username= johndoe
  SMTP Authentication Password= *****
  SMTP Encryption Options:
    TLS= Enabled
    STARTTLS= Enabled

ruckus(config-email-server)# end
The Email server settings have been updated.
Your changes have been saved.
ruckus(config)#

```

## from

To set the sender from address for email alarms, use the following command:

**from WORD**

## Syntax Description

**from**

Set the email address from which alarm notifications will be sent

**WORD**

Send alarm notifications from this email address

## **Configuring Controller Settings**

### Configure Email Server Commands

#### **Defaults**

None.

#### **Example**

```
ruckus(config-email-server)# from test1@gmail.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-email-server)#[/pre]
```

## **enable**

To enable the email server, use the following command:

**enable**

#### **Example**

```
ruckus(config-email-server)# enable  
ruckus(config-email-server)#[/pre]
```

## **no enable**

To disable the email server, use the following command:

**no enable**

#### **Example**

```
ruckus(config-email-server)# no enable  
ruckus(config-email-server)# show  
Email Server:  
    Status= Disabled  
ruckus(config-email-server)#[/pre]
```

## **smtp-server-name**

To set the SMTP server that ZoneDirector uses to send alarm notifications, use the following command:

**smtp-server-name WORD**

#### **Syntax Description**

**smtp-server-name**

Set the SMTP server that ZoneDirector uses to send alarm notifications

**WORD**

Set to this SMTP server name

#### **Defaults**

None.

## Example

```
ruckus(config-email-server)# smtp-server-name smtp.163.com  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## smtp-server-port

To set the SMTP server port that ZoneDirector uses to send alarm notifications, use the following command:

```
smtp-server-port NUMBER
```

### Syntax Description

**smtp-server-port**

Set the SMTP server port that ZoneDirector uses to send alarm notifications

**NUMBER**

Set to this SMTP server port

### Defaults

587

## Example

```
ruckus(config-email-server)# smtp-server-port 25  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## smtp-auth-name

To set the user name that ZoneDirector uses to authenticate with the SMTP server, use the following command:

```
smtp_auth_name WORD
```

### Syntax Description

**smtp\_auth\_name**

Set the user name that ZoneDirector uses to authenticate with the SMTP server

**WORD**

Set to this user name

### Defaults

None.

## Example

```
ruckus(config-email-server)# smtp-auth-name joe  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## smtp-auth-password

To set the password that ZoneDirector uses to authenticate with the SMTP server, use the following command:

**smtp-auth-password WORD**

### Syntax Description

**smtp-auth-password**

Set the password that ZoneDirector uses to authenticate with the SMTP server

**WORD**

Set to this password

### Defaults

None.

### Example

```
ruckus(config-email-server)# smtp-auth-password 123456
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## smtp-wait-time

To set the SMTP server wait time (in seconds), use following command:

**smtp-wait-time NUMBER**

### Example

```
ruckus(config-email-server)# smtp-wait-time 10
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-alarm) #
```

## tls-smtp-encryption

To enable TLS for SMTP encryption of email notifications, use the following command:

**tls-smtp-encryption [ tls | starttls ]**

### Syntax Description

**tls-smtp-encryption**

Enable SMTP encryption of email notifications

**tls**

Enable TLS encryption for email notifications

**starttls**

Enable STARTTLS encryption for email notifications

## Defaults

None.

## Example

```
ruckus(config-email-server)# tls-smtp-encryption tls  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

## no tls-smtp-encryption

To disable TLS for SMTP encryption of alarm notifications, use the following command:

```
no tls-smtp-encryption [ tls | starttls ]
```

## Syntax Description

### no tls-smtp-encryption

Disable SMTP encryption of alarm notifications

#### tls

Disable TLS encryption

#### starttls

Disable STARTTLS encryption

## Defaults

None.

## Example

```
ruckus(config-email-server)# no tls-smtp-encryption tls  
The command was executed successfully. To save the changes, type 'end' or 'exit'.
```

# Configure SMS Server Commands

Use the sms-server commands to configure SMS server settings. To run these commands, you must first enter the **config-sms-server** context.

## sms-server

Use the following command to enter the **config-sms-server** context and configure SMS server settings:

**sms-server**

### Syntax Description

**help**

Shows available commands.

**history**

Shows a list of previously run commands.

**abort**

Exits the config-sms-server context without saving changes.

**end**

Saves changes, and the exits the config-sms-server context.

**exit**

Saves changes, and the exits the config-sms-server context.

**quit**

Exits the config-sms-server context without saving changes.

**twilio**

Configures SMS server settings for twilio. Enters ruckus(config-sms-server-twilio)#[/]

**clickatell**

Configures SMS server settings for clickatell. Enters ruckus(config-sms-server-clickatell)#[/]

**account-sid WORD**

Sets the account sid for twilio of sms server

**auth-token WORD**

Sets the auth token for twilio of sms server

**from-phonenumbers WORD**

Sets the from phonenumbers for twilio of sms server

**country-code [no-default-and-ask-user-to-input|default <country code default value> | default <country code default value> allow-change | default <country code default value> disallow-change ]**

Sets the country code, default country code and whether to allow user input to change the country code from the default.

**user-name WORD**

Sets the user name for clickatell of sms server

**password WORD**

Sets the password for clickatell of sms server

**api-id WORD**

Sets the api id for clickatell of sms server

### **show**

Displays the SMS server settings.

### **customized**

Configures SMS server settings for customized server. Enters ruckus(config-sms-server-customized) #

#### **url <WORD> <WORD>**

Sets the URL for customized sms server

#### **post <WORD>**

Sets the post for customized sms server

### **Example**

```
ruckus(config)# sms-server
ruckus(config-sms-server)# twilio
ruckus(config-sms-server-twilio)# account-sid abcdef123
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-sms-server-twilio)# auth-token word1234
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-sms-server-twilio)# country-code default +1 allow-change
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-sms-server-twilio)# from-phononenumber 6661231234
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-sms-server-twilio)# end
The SMS server settings have been updated.
Your changes have been saved.
ruckus(config-sms-server)# show
SMS Server:
  Server Type= twilio
    Account SID= abcdef123
    Auth Token= word1234
    From PhoneNumber= 6661231234
    Country Code= Use default +1 and allow user to change

ruckus(config-sms-server)# end
The SMS server settings have been updated.
Your changes have been saved.
ruckus(config) #
```

### **no sms-server**

To disable SMS server settings, use the following command:

#### **no sms-server**

### **Example**

```
ruckus(config)# no sms-server
The SMS server settings have been updated.
ruckus(config) #
```

### **country-code**

Use the following command to configure SMS server country code settings:

**country-code [no-default-and-ask-user-to-input|default<WORD> + <NUMBER> [allow-change|disallow change]]**

## Configuring Controller Settings

### Configure SMS Server Commands

#### Example

```
ruckus(config-sms-server-twilio)# country-code default +1 allow-change
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-sms-server-twilio)# end
The SMS server settings have been updated.
Your changes have been saved.
ruckus(config-sms-server)# show
SMS Server:
  Server Type= twilio
    Account SID= test123
    Auth Token= test123
    From PhoneNumber= 1112223344
    Country Code= Use default +1 and allow user to change

ruckus(config-sms-server) #
```

# Configure mDNS (Bonjour) Commands

Use the following commands to configure mDNS (Bonjour Gateway) service.

## **mdnsproxy**

Use the following command to enable mDNS proxy (Bonjour Gateway) service:

**mdnsproxy [ zd | ap ]**

## **no mdnsproxy**

Use the following command to disable mDNS proxy (Bonjour Gateway) service:

**no mdnsproxy [zd | ap ]**

## **mdnsproxyrule**

Use the following command to create a new Bonjour Gateway rule or modify an existing rule, and enter the config-mdnsproxyrule context:

**mdnsproxyrule ID**

## **no mdnsproxyrule**

Use the following command to delete a Bonjour Gateway rule:

**no mdnsproxyrule ID**

## Configuring Controller Settings

### Configure Bonjour Policy

# Configure Bonjour Policy

The following commands can be used from within the **config-bonjourpolicy** context to configure the Bonjour policy.

## bonjour-policy

To create or edit a Bonjour policy, use the following command:

**bonjour-policy WORD**

### Syntax Description

**help**

Shows available commands

**history**

Shows a list of previously run commands

**no mdnsproxyrule**

Delete mDNSproxy rule

**mdnsproxyrule ID**

Add/update mDNSproxy rules

**note NOTE**

Rule comments

**end**

Save the current rule and quit

**exit**

Save the current rule and quit

**abort**

Discard the current rule and quit

**quit**

Discard the current rule and quit

### Example

```
ruckus(config)# bonjour-policy bonjour1
ruckus(config-bonjourpolicy)# note bonjourpolicy1
ruckus(config-bonjourpolicy)# end
Your changes have been saved.
ruckus(config)# show bonjour-policy
bonjour-policy:
    ID: 1
    Name: bonjour1
    Description: bonjourpolicy1
    rule:
ruckus(config)#

```

## no bonjour-policy

To delete a Bonjour policy, use the following command:

**no bonjour-policy WORD**

## Configuring Controller Settings

### Configure Bonjour Policy

## Configure mDNS Proxy Rules

The following commands can be used from within the **config-mdnsproxyrule** context to configure the Bonjour Gateway bridge service rule.

### Syntax Description

#### help

Shows available commands

#### history

Shows a list of previously run commands

#### service Service-Name

Service name in ? list, or new bonjour rule

#### from-vlan VLAN-From

VLAN from

#### to-vlan VLAN-to

VLAN to

#### note NOTE

Rule comments

#### show

Show the current edited rule

#### end

Save the current rule and quit

#### abort

Discard the current rule and quit

#### quit

Discard the current rule and quit

### Example

```
ruckus(config-bonjourpolicy)# mdnsproxyrule 1
ruckus(config-policyrule)# service AirDisk
ruckus(config-policyrule)# from-vlan 220
ruckus(config-policyrule)# to-vlan 1
ruckus(config-policyrule)# note "share printer to vlan1"
ruckus(config-policyrule)# end
ruckus(config-bonjourpolicy)# end
ruckus(config)# show bonjour-policy
bonjour-policy:
    ID: 1
    Name: bonjour1
    Description: bonjourpolicy1
    rule:
        1:
            mdnsservice: AirDisk
            from_vlan: br0.220
            to_vlan: br0
            Notes: share printer to vlan1
ruckus(config)#

```

# Configure Bonjour Fencing Policy

To create a Bonjour Fencing policy and enter the **config-bonjourfencing** context, use the following command:

**bonjour-fencing <NAME>**

## Syntax Description

### **bonjour-fencing**

Configure a Bonjour Fencing policy.

#### **NAME**

Set the name of the fencing policy.

no <ID>	Delete fencing rules
show	Show the current edited bonjour fence
description	Sets the bonjour fence description.
fencerule <ID>	Add/Update fence rules
end	Save current rule and quit
exit	Save current rule and quit
abort	Discard current rule and quit
quit	Discard current rule and quit

## Defaults

None.

## Example

```
ruckus(config)# bonjour-fencing fence1
ruckus(config-bonjourfencing)#
  help          Shows available commands.
  history       Shows a list of previously run commands.
  no <ID>      Delete fencing rules
  show          Show the current edited bonjour fence
  description <WORD> Sets the bonjour fence description.
  fencerule <ID> Add/Update fence rules
  end          Save current rule and quit
  exit          Save current rule and quit
  abort         Discard current rule and quit
  quit         Discard current rule and quit
ruckus(config-bonjourfencing)#
```

## **Configuring Controller Settings**

### Configure Bonjour Fencing Policy

## **show**

To display Bonjour Fencing settings, use the following command:

**show**

### **Example**

```
ruckus(config-bonjourfencing) # show  
bonjour-fence:  
    ID:  
        Name: bonjourfence1  
        Description:  
        rule:  
ruckus(config-bonjourfencing) #
```

## description

To set the Precedence Policy rule description, use the following command:

**description**

### *Example*

```
ruckus(config-prece-rule)# description "Default precedence policy"  
The command was executed successfully. To save the changes, type 'end' or 'exit'.  
ruckus(config-prece-rule)#[/pre]
```

## fencerule

To add or update Bonjour fencing rules, use the following command:

**fencerule <ID>**

### *Example*

```
ruckus(config-bonjourfencing)# fencerule 1  
ruckus(config-fencerule)#+
```

## source-type

To set the fence rule to wired or wireless, use the following command:

**source-type <TYPE>**

### *Example*

```
ruckus(config-fencerule)# source-type Wireless  
ruckus(config-fencerule)#{
```

## device-mac

To set the device MAC address, use the following command:

**device-mac <MAC>**

### **Example**

```
ruckus (config-fencerule)# device-mac  
<MAC>           Enter device mac (for example, XX:XX:XX:XX:XX,XX:XX:XX:XX:XX)  
ruckus (config-fencerule)#+
```

## anchor-ap

To set the anchor AP, use the following command:

**anchor-ap <MAC>**

### *Example*

```
ruckus(config-fencerule)# anchor-ap 01:02:03:04:05:06  
ruckus(config-fencerule)#{
```

## service

To set the service to be fenced, use the following command:

```
service <Service-Name>
```

### Options

The following services can be selected:

```
AirDisk|AirPlay|AirPort Management|AirPrint|AirTunes|Apple File Sharing|Apple  
Mobile Devices (Allows Sync with iTunes over Wi-Fi)|Apple TV|iCloud  
Sync|iTunes Remote|iTunes Sharing|Open Directory Master|Optical Disk  
Sharing|Ruckus Controller|Screen Sharing|Secure File Sharing|Secure Shell  
(SSH)|World Wide Web (HTTP)|World Wide Web SSL (HTTPS)|Workgroup  
Manager|Xgrid|GoogleChromeCast|
```

### Example

```
ruckus(config-fencerule)# service AirDisk  
ruckus(config-fencerule) #
```

## fencing-range

To set the fencing range, use the following command:

**fencing-range <RANGE>**

### Options

Same AP

1-Hop AP Neighbors

### Example

```
ruckus(config-fencerule)# fencing-range Same AP  
ruckus(config-fencerule)#{
```



# Using Debug Commands

---

• Debug Commands Overview.....	561
• General Debug Commands.....	561
• Show Commands.....	568
• Accessing a Remote AP CLI.....	575
• Working with Debug Logs and Log Settings.....	577
• Remote Troubleshooting.....	585
• AP Core Dump Collection.....	587
• Script Execution.....	589

## Debug Commands Overview

This section describes the commands that you can use to debug ZoneDirector and connected APs, and to configure debug log settings.

From the privileged commands context, type **debug** to enter the debug context. To show a list of commands available from within the debug context, type **help** or **?**.

## General Debug Commands

The following section describes general debug commands can be executed from within the debug context.

### help

Shows available commands.

### list-all

List all available commands.

### history

Shows a list of previously run commands.

### quit

Exits the debug context.

### fw\_upgrade

To upgrade the controller's firmware, use the following command:

**fw\_upgrade protocol://server ip|server name/path/image name [ -f ]**

**fw\_upgrade OPTIONS**

## Using Debug Commands

### General Debug Commands

#### Syntax Description

##### **fw\_upgrade**

Upgrade the controller's firmware

##### *protocol*

Protocol for image transfer (FTP, TFTP, HTTP, KERMIT)

##### OPTIONS

###### **-p**

protocol

###### **-s**

server IP address or name

###### **-n**

image name with path on the server

###### **-f**

non-verbose mode

###### **-h**

fw\_upgrade help message

#### Defaults

None.

#### Example

```
ruckus(debug) # fw_upgrade -p tftp -s 192.168.0.14 -n zd-upgrade.img
-----
** Starting CLI Upgrade  **

Protocol : tftp
Server IP : 192.168.0.14
Image Name: zd-upgrade.img

-----
** Checking if memory is sufficient **

.
----->Sufficient memory to perform upgrade
-----
** Downloading ZD image **

.....
...
```

#### restore

To restore the controller's configuration, use the following command:

```
restore [ all | failover | policy ]
```

#### restore all

To reestablish everything, use the following command:

**restore all IP-ADDR FILE-NAME**

## restore failover

To restore everything, except system name and IP address settings, use the following command:

**restore failover IP-ADDR FILE-NAME**

## restore policy

To restore only WLAN settings, access control list, roles, and users, use the following command:

**restore policy IP-ADDR FILE-NAME**

## delete-station

To deauthorize the station with the specified MAC address, use the following command.

**delete-station MAC**

### Syntax Description

**delete-station**

Delete the station with the specified MAC address

**MAC**

The MAC address of the station that will be deleted

### Defaults

None.

### Example

```
ruckus# debug
ruckus(debug)# delete-station 00:10:77:01:00:01
The command was executed successfully.
```

## restart-ap

To restart the device with the specified MAC address, use the restart ap command.

**restart-ap MAC**

### Syntax Description

**restart-ap**

Restart the device with the specified MAC address

**MAC**

The MAC address of the device to be restarted

## Using Debug Commands

### General Debug Commands

#### Defaults

None.

#### Example

```
ruckus# debug
ruckus(debug)# restart-ap 00:13:92:EA:43:01
The command was executed successfully.
```

## wlaninfo

Configures and enables debugging of WLAN service settings. Enter wlaninfo without arguments to see all options.

**wlaninfo OPTIONS**

#### Syntax Description

##### wlaninfo

Enable logging of WLAN info

##### OPTIONS

Configure WLAN debug information options

#### Defaults

None.

#### Example

```
ruckus(debug)# wlaninfo -W -x
WLAN svc "Rhastahl1" (id=1):
  WLAN ID = 0, ref_cnt = 7
  SSID = "Rhastahl1" enabled
  Apply to 11a and 11g/b radios
  Closed system = No, Privacy = Enabled, ACL enabled Guest-WLAN = No
  WISPr-WLAN = No
  Access Policy = 0/0, Web Auth = No, grace period = 0 (0 means disable), max clients = 100
  WMM = enabled priority = 0 uplink = DISABLE downlink = DISABLE
  Cipher = Clear Text Local bridging = Enabled, DHCP relay = Disabled, vlan = 1, dvlan = Disabled,
  bgscan = Enabled
  Proxy ARP = Disabled (IE:Disabled)
  wep key index = 0, wep key len = 0
  PAP message authenticator = Enabled, EAP-Failure = Disabled
  Device Policy = 0, Precedence = 1
  Smart Roam = Disabled Roam-factor = 1
  Hotspot2.0--WLAN = No (id=0)
  Num of VAP deployed: 6
    VAP: 04:4f:aa:0c:b1:0c, number of stations = 0
    VAP: 04:4f:aa:0c:b1:08, number of stations = 0
    VAP: c0:c5:20:3b:91:fc, number of stations = 1
    VAP: c0:c5:20:3b:91:f8, number of stations = 0
    VAP: c4:10:8a:1f:d1:fc, number of stations = 1
    VAP: c4:10:8a:1f:d1:f8, number of stations = 0
  ACL 1 (System): default=Allowed system-wide=yes
  Auth Policy:
    Auth Algorithms:RSN/PSK RSN/Dynamic PSK
    Auth Server Type: None
    WPA Version: WPA2
    WPA Auth and Key Management: WPA PSK
    WPA PSK Pass Phrase:password
```

```

WPA PSK Prev Pass Phrase:
WPA PSK Pass Phrase (Hex):
    31306173 68613130
WPA PSK:
    6aa94bac df5346ac ecc7d38f a14a6dbf
    7ba6f6f8 df2a4943 b23c9655 ac4f33de
WPA Prev PSK:
    00000000 00000000 00000000 00000000
    00000000 00000000 00000000 00000000
GTK life time = 28800 seconds, GTK Life size = 2000 Kpkts
GMK life time = 86400 seconds, Strict Rekey = No
WPA Group Cipher Suites:0x00000010
    CCMP
WPA Pairwise Cipher Suites:0x00000010
    CCMP
NASID Type: = wlan-bssid
PMK Cache Time: = 43200
PMK Cache for Reconnect: = enabled
Roaming Acct-Inerim-Update: = disabled
Called-Station-Id-type: 0
Classification: enabled
UDP Heuristic Classification: enabled
Directed Multicast: enabled
IGMP Snooping: enabled
MLD Snooping: disabled
ToS Classification: enabled
Dot1p Classification: disabled
Multicast Filter: disabled
Directed Threshold: 5
Priority: Voice:0 Video:2 Data:4 Background:6
Force DHCP: disabled Timeout:10

*** Total WLAN Entries: 1 ***
ruckus(debug)#

```

## save\_debug\_info

Saves debug information.

**save\_debug\_info IP-ADDR FILE-NAME**

### Syntax Description

**save\_debug\_info**

Save debug log file

**IP-ADDR**

The destination IP address

**FILE-NAME**

The destination file name

### Defaults

None.

### Example

```

ruckus(debug)# save_debug_info 192.168.11.26 log.log
Creating debug info file ...
Done
Sending debug info file to "log.log@192.168.11.26" ...

```

## Using Debug Commands

### General Debug Commands

```
...  
ruckus (debug) #
```

## save-config

Upload the configuration file to the designated TFTP site.

```
save-config IP-ADDR FILE-NAME
```

### Syntax Description

#### save-config

Upload the configuration file

IP-ADDR

The destination IP address

FILE-NAME

The destination file name

### Defaults

None.

### Example

```
ruckus (debug) # save-config 192.168.11.26 config.log  
Creating backup config file  
Done  
Uploading backup config file  
...  
ruckus (debug) #
```

## emfd-malloc-stats

Show uclibc malloc statistics.

### Example

```
ruckus (debug) # emfd-malloc-stats  
===== [pid=350] Sat Feb 15 15:58:42 2014  
total bytes allocated          =    2691072  
total bytes in use            =    2471920  
total bytes freed             =    219152  
total allocated mmap space   =    311296  
number of free chunks         =       18  
number of fastbin blocks     =        0  
space in freed fastbin blocks =        0  
bin[ 1]: chunk_num=      1, list_len=      1, alloc_bytes=      4152, min_chunk[1]=      4152,  
max_chunk[1]=      4152  
bin[ 3]: chunk_num=      3, list_len=      3, alloc_bytes=       72, min_chunk[1]=       24,  
max_chunk[1]=       24  
bin[ 4]: chunk_num=      1, list_len=      1, alloc_bytes=       32, min_chunk[1]=       32,  
max_chunk[1]=       32  
bin[ 5]: chunk_num=      4, list_len=      4, alloc_bytes=      160, min_chunk[1]=      40,  
max_chunk[1]=      40  
bin[ 6]: chunk_num=      1, list_len=      1, alloc_bytes=       48, min_chunk[1]=       48,  
max_chunk[1]=       48
```

```

bin[10]: chunk_num=      1, list_len=      1, alloc_bytes=      80, min_chunk[1]=      80,
max_chunk[1]=      80
bin[14]: chunk_num=      1, list_len=      1, alloc_bytes=     112, min_chunk[1]=     112,
max_chunk[1]=     112
bin[45]: chunk_num=      1, list_len=      1, alloc_bytes=    2928, min_chunk[1]=    2928,
max_chunk[1]=    2928
bin[49]: chunk_num=      1, list_len=      1, alloc_bytes=   5168, min_chunk[1]=   5168,
max_chunk[1]=   5168
bin[51]: chunk_num=      2, list_len=      2, alloc_bytes=  14952, min_chunk[1]=  7248,
max_chunk[2]=  7704
bin[52]: chunk_num=      1, list_len=      1, alloc_bytes=   8208, min_chunk[1]=   8208,
max_chunk[1]=  8208
ruckus (debug) #

```

## speedflex

To enable SpeedFlex on APs, use the following command:

**speedflex**

### Defaults

Enabled.

### Example

```

ruckus (debug) # speedflex
The System SpeedFlex has been enabled.
ruckus (debug) #

```

## no speedflex

To disable SpeedFlex on APs, use the following command:

**no speedflex**

### Defaults

Enabled.

### Example

```

ruckus (debug) # no speedflex
The System SpeedFlex has been disabled.
ruckus (debug) #

```

## Using Debug Commands

Show Commands

# Show Commands

This section describes the show commands available within the debug context.

## show ap

To display AP information for all APs, use the following command:

**show ap**

### Syntax Description

**show ap**

Display a list of all approved APs.

### Example

```
ruckus(debug) # show ap
AP:
ID:
1:
MAC Address= 44:1e:94:1b:f0:d0
Model= r510
Approved= Yes
Device Name= RuckusAP
Description=
Location=
GPS=
CERT = Normal
Bonjour-policy=
Bonjour-fencing=
Group Name= System Default
Channel Range:
A/N= 36,40,44,48,149,153,157,161 (Disallowed= )
B/G/N= 1,2,3,4,5,6,7,8,9,10,11 (Disallowed= )
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
Tx. Power= Auto
WLAN Group Name= Default
Call Admission Control= OFF
Protection Mode= Auto
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
Tx. Power= Auto
WLAN Group Name= Default
Call Admission Control= OFF
Protection Mode= 2
Override global ap-model port configuration= No
Network Setting:
Protocol mode= Use Parent Setting
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.0.10
Netmask= 255.255.255.0
Gateway= 192.168.0.1
Primary DNS Server=
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
```

```

IPv6 Type= Auto Configuration
IPv6 Address= ::461e:98ff:fe1b:f0d0
IPv6 Prefix Length= 64
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
    Mode= Use Parent Setting
    max hops= Use Parent Setting
LLDP:
    Status = Use Parent Setting
LAN Port:
    0:
        Interface= eth0
        Dot1x= None
        LogicalLink= Up
        PhysicalLink= Up 10Mbps full
        Label= 10/100/1000 PoE LAN1
    1:
        Interface= eth1
        Dot1x= None
        LogicalLink= Down
        PhysicalLink= Down
        Label= 10/100/1000 LAN2
    2:
        MAC Address= d4:c2:9e:35:c9:50
        Model= r610
        Approved= Yes
        Device Name= RuckusAP
        Description=
        Location=
        GPS=
        CERT = Normal
        Bonjour-policy=
        Bonjour-fencing=
        Group Name= System Default
        Channel Range:
            A/N= 36,40,44,48,149,153,157,161 (Disallowed= )
            B/G/N= 1,2,3,4,5,6,7,8,9,10,11 (Disallowed= )
Radio a/n:
    Channelization= Auto
    Channel= Auto
    WLAN Services enabled= Yes
    Tx. Power= Auto
    WLAN Group Name= Default
    Call Admission Control= OFF
    Protection Mode= Auto
Radio b/g/n:
    Channelization= Auto
    Channel= Auto
    WLAN Services enabled= Yes
    Tx. Power= Auto
    WLAN Group Name= Default
    Call Admission Control= OFF
    Protection Mode= 2
Override global ap-model port configuration= No
Network Setting:
    Protocol mode= Use Parent Setting
    Device IP Settings= Keep AP's Setting
    IP Type= DHCP
    IP Address= 192.168.0.3
    Netmask= 255.255.255.0
    Gateway= 192.168.0.1
    Primary DNS Server=
    Secondary DNS Server=

    Device IPv6 Settings= Keep AP's Setting
    IPv6 Type= Auto Configuration
    IPv6 Address= ::d6c1:9eff:fe35:c950
    IPv6 Prefix Length= 64
    IPv6 Gateway=

```

## Using Debug Commands

Show Commands

```
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
  Mode= Use Parent Setting
  max hops= Use Parent Setting
LLDP:
  Status = Use Parent Setting
LAN Port:
  0:
    Interface= eth0
    Dot1x= None
    LogicalLink= Up
    PhysicalLink= Up 1000Mbps full
    Label= 10/100/1000 PoE LAN1
  1:
    Interface= eth1
    Dot1x= None
    LogicalLink= Down
    PhysicalLink= Down
    Label= 10/100/1000 LAN2
PoE Mode= Auto
802.3af PoE Tx. chain= 2

ruckus(debug) #
```

## show station

Displays a list of all connected stations (or clients).

**show station**

### Syntax Description

**show station**

Show all connected stations

### Defaults

None.

### Example

```
ruckus(debug) # show station
Clients List:
Client:
  MAC Address= 6c:62:6d:1b:e3:00
  User Name=
  IP Address= 192.168.11.11
  IPv6 Address=
  Access Point= 04:4f:aa:0c:b1:00
  WLAN= Ruckus1
  Channel= 1
  Signal (dB)= 53

Client:
  MAC Address= 00:22:fb:ad:1b:2e
  User Name=
  IP Address= 192.168.11.7
  IPv6 Address=
  Access Point= 04:4f:aa:0c:b1:00
  WLAN= Ruckus1
  Channel= 165
```

```
Signal (dB) = 42
ruckus(debug) #
```

## show logs

Displays a list of debug log components.

**show logs**

### Syntax Description

**show logs**

Display debug log components

### Defaults

None.

### Example

```
ruckus(debug) # show logs
Debug Logs:
  All= Enabled
  Sys-mgmt= Enabled
  Mesh= Enabled
  Web-auth= Enabled
  Rf-mgmt= Enabled
  Radius= Enabled
  Hotspot-srv= Enabled
  Aps= Enabled
  Net-mgmt= Enabled
  802.1x= Enabled
  Web-svr= Enabled
  802.11= Enabled
  Dvlan= Enabled
  Smart-redundancy= Enabled
  Debug logs of specified MAC address:
    Status= Disabled
ruckus(debug) #
```

## show tls

Displays TLS support status.

**show tls**

### Example

```
ruckus(debug) # show tls
  TLS= Support TLS 1.0 and TLS 1.1
ruckus(debug) #
```

## show speedflex

To display SpeedFlex enabled status, use the following command:

## Using Debug Commands

Show Commands

**show speedflex**

### Example

```
ruckus(debug) # show speedflex
  SpeedFlex= Enabled
ruckus(debug) #
```

## show remote-troubleshooting

To display remote troubleshooting status, use the following command:

**show remote-troubleshooting**

### Example

```
ruckus(debug) # show remote-troubleshooting
Ruckus CA troubleshooting is stopped!
The server addr is: None

ruckus(debug) #
```

## ps

To display information about all processes that are running, use the following command:

**ps**

### Example

```
ruckus(debug) # ps
  PID PPID USER          VSZ STAT COMMAND
    1     0 root           1184 S      init
    2     0 root            0 SW   [kthreadd]
    3     2 root            0 SW   [ksoftirqd/0]
    5     2 root            0 SW< [kworker/0:0H]
    7     2 root            0 SW   [rcu_sched]
    8     2 root            0 SW   [rcu_bh]
    9     2 root            0 SW   [migration/0]
   10    2 root            0 SW   [watchdog/0]
   11    2 root            0 SW   [watchdog/1]
   12    2 root            0 SW   [migration/1]
   13    2 root            0 SW   [ksoftirqd/1]
   15    2 root            0 SW< [kworker/1:0H]
   16    2 root            0 SW< [khelper]
   17    2 root            0 SW   [irq/202-msmdata]
   18    2 root            0 SW< [writeback]
   19    2 root            0 SW< [bioset]
   20    2 root            0 SW< [crypto]
   21    2 root            0 SW< [kblockd]
   22    2 root            0 SW   [khubd]
   23    2 root            0 SW   [kswapd0]
   24    2 root            0 SW   [kworker/1:1]
   25    2 root            0 SW   [fsnotify_mark]
   26    2 root            0 SW   [kworker/u4:1]
   30    2 root            0 SW   [spi32766]
   39    2 root            0 SW< [ipv6_addrconf]
   53    2 root            0 SW< [deferwq]
   54    2 root            0 SW   [kworker/u4:2]
   55    2 root            0 SW   [ubi bgt0d]
   62    1 root           1172 S   /bin/sh /usr/sbin/pad.sh
```

```

65   62 root      720 S  /usr/sbin/pad
68   1 root      5764 S < /usr/sbin/rsmd start
70   1 root      5740 S < watchdog
79   2 root      0 SW  [ubi_bgt1d]
81   2 root      0 SW  [ubi_bgt2d]
83   2 root      0 SW  [ubifs_bgt2_01]
245  68 root      5808 S < /usr/sbin/timer start
261  2 root      0 SW< [gmac_workqueue]
262  2 root      0 SW< [nss_data_plane_]
263  2 root      0 SW< [nss_freq_queue]
264  2 root      0 SW< [coredump_wait]
329  1 root      8444 S  /usr/sbin/tcsd
394  2 root      0 SW< [alloc_task_wque]
395  2 root      0 SW< [alloc_task_wque]
416  1 root      5900 S  eved
444  1 root      1172 S  klogd -c 4
498  1 root      2668 S  /usr/bin/mosquitto -c /tmp/mosquitto.conf
501  1 root      2676 S  /usr/bin/matrix
512  1 root      5764 S  rksmcast
541  1 root      2792 S  /usr/sbin/dropbear -e /var/run/-login -I 900 -p
588  68 root      5836 S < /usr/sbin/rfwd start
630  2 root      0 SW< [uif-630]
636  1 root      17960 S /usr/sbin/apmgr -r start
640  1 root      9712 S /usr/sbin/election
651  3147 root    1168 S sleep 300
652  1 root      5760 S /usr/sbin/wrad
659  1 root      6000 S /usr/sbin/mdnsfence -p /tmp/mdnsfence.pid -b
669  1 root      5736 S hs20d
699  1 root      5924 S /usr/sbin/channelfly -i wifi0 -q
710  1 root      2912 S hostapd -B -g/var/run/hostapd-global -P/var/run
714  1 root      5868 S /usr/sbin/channelfly -i wifi1 -q
716  1 root      6248 S ztmd -s
727  1 root      5996 S /usr/sbin/rfmd -S
729  1 root      7784 S /usr/sbin/wipind
735  1 root      7400 S cpd
806  1 root      6176 S /usr/sbin/avpd -D
822  1 root      19300 S /usr/sbin/uf_agent
846  1 root      7116 S /usr/sbin/statd -D
853  1 root      33796 S /usr/sbin/qm_dpi -D -n 1
862  1 root      5744 S dbdc
867  1 root      5736 S /usr/sbin/PoEMgr
899  1 root      5740 S rfloop_radiod -b -m 2
901  1 root      3032 S /bin/wd_feeder
1700 1 root      6652 S /tmp/var/run/-login
1705 1 root      1168 S sleep 1000d
1877 1 root      5720 S snmpget -p /var/run/snmpget.pid1 -i 1
1897 1 root      5724 S snmpwalk -p /var/run/snmpwalk.pid1 -i 1
1943  3269 root    1168 S sleep 20
1957  2488 root    1168 S sleep 21
1977  68 root      0 Z < [rsmd_func]
1978  68 root      0 Z < [rsmd_func]
1979  68 root      0 Z < [rsmd_func]
1980  68 root      0 Z < [rsmd_func]
1988  65 root      720 S /usr/sbin/pad
1989  1988 root    1172 S sh -c /bin/ps -aux
1990  1989 root    1176 R /bin/ps -aux
2032  1 root      1176 S /bin/sh /bin/tsyslogd.sh
2034  2032 root    3940 S /bin/tsyslogd -r -h -n --rotate=21
2036  1 root      980 S /usr/sbin/in.tftpd -l -s /etc/airespider-images
2088  1 root      1172 S /bin/sh /bin/tacmon.sh
2092  2088 root    3688 S /bin/tacmon -i 30 -r 15
2117  1 root      4384 S /bin/emf_repo_flashsync monitor 15
2118  1 root      3072 S ttymlogd
2166  1 root      1124 S < clusterD
2167  1 root      26348 S stamgr -d3 -t0
2169  1 root      11996 S apmgr_zd -r start
2230  1 root      7168 S upnpd
2296  1 root      10432 S getstatd
2297  1 root      41668 S emfd
2298  1 root      5340 S N sqldited
2300  1 root      10488 S rhttps
2488  1 root      1184 S /bin/sh /usr/sbin/bonjour_mon.sh

```

## Using Debug Commands

Show Commands

```
2882      1 root      1188 S    /sbin/udhcpc -b -i br0 --pidfile=/var/run/udhcp
3145      1 root      2496 S    /usr/sbin/vsftpd /etc/vsftpd2.conf
3147      1 root      1176 S    /bin/sh /bin/ftpdMon.sh
3269      1 root      1176 S    /bin/sh /usr/sbin/pubnub_mon.sh un9418490011251
3277 3269 root      8380 S    /usr/sbin/pubnubd un9418490011251572982362879
3395      2 root      0 SW     [kworker/0:1]
3450      1 root      2580 S    radsecproxy
3474      1 root      1172 S    /sbin/udhcpc -i br0 --pidfile=/var/run/udhcpc.p
3535      1 root      23988 S   /bin/webs
3757      1 root      2376 S <  /usr/sbin/zapd
3758      1 root      5876 S    lldpd -C d4:c1:9e:35:c9:40 -S Ruckus R610 Multi
3763 3758 root      5888 S    lldpd -C d4:c1:9e:35:c9:40 -S Ruckus R610 Multi
3845      1 root      14740 S   /usr/bin/stainfod
4256      1 root      1416 S    mdnsd
4301 2488 root      744 S    /usr/sbin/dns-sd -R Ruckus-Unleashed _ruckus-un
5266      65 root     724 S    /usr/sbin/pad
5290      1 root      3092 S    empty -f -L /tmp/empty/icx_01.tmp -i /tmp/empty
5292 5290 root      2860 S    dbclient -y super@192.168.0.8
14982     2 root      0 SW     [kworker/1:2]
26640     541 root    2864 R    /usr/sbin/dropbear -e /var/run/-login -I 900 -p
26651 26640 root    1176 S    /bin/sh /var/run/-login
26652 26651 root    5588 S    /bin/login
26693 26652 root    10952 S   ruckus_cli2 -p VTCeYiFPy6&rw
27890     2 root      0 SW     [kworker/0:0]
ruckus(debug) #
```

# Accessing a Remote AP CLI

The following command is used to access the command line interface of a connected AP and execute AP CLI commands from the controller CLI. Configuration changes made through the AP CLI may be overwritten by controller settings if the AP is restarted or reconnects to the controller.

## remote\_ap\_cli

Use the **remote\_ap\_cli** command to access an AP remotely and execute AP CLI commands.

```
remote_ap_cli [ -q ] { -a ap_mac | -A } "cmd arg1 arg2 .."
```

### Syntax Description

#### remote\_ap\_cli

Execute CLI commands in a remote AP

#### -q

Do not display results

#### -a

Specify AP by MAC address

#### ap\_mac

The AP's MAC address

#### -A

All connected APs

#### cmd

AP CLI command

#### arg

AP CLI command argument

### Example

```
ruckus(debug)# remote_ap_cli -A "get director"
---- Command 'rkscli -c "get director "' executed at c0:c5:20:3b:91:f0
----- ZoneDirector Info -----
Primary Controller : n/a
Secondary Controller : n/a
DHCP Opt43 Code : 3

The information of the most recent Zone Director:
[1] 192.168.40.100

AP is under management of ZoneDirector: 192.168.40.100 / c0:c5:20:18:97:c1,
Currently AP is in state: RUN
OK
---- Command 'rkscli -c "get director "' executed at c4:10:8a:1f:d1:f0
----- ZoneDirector Info -----
Primary Controller : n/a
Secondary Controller : n/a
DHCP Opt43 Code : 3

The information of the most recent Zone Director:
[1] 192.168.40.100

AP is under management of ZoneDirector: 192.168.40.100 / c0:c5:20:18:97:c1,
Currently AP is in state: RUN
```

## Using Debug Commands

### Accessing a Remote AP CLI

```
OK
---- Command Execution Summary:
    success: 2
    failure: 0
    total: 2
ruckus (debug) #
```

# Working with Debug Logs and Log Settings

This section describes the commands that you can use to configure and review ZoneDirector debug logs.

## logs all

Enables debug logs of all debug components.

### Syntax Description

**logs all**  
Enable logging of all debug components

### Usage Guidelines

Running this command can place considerable load on the system. If your ZoneDirector is already under load, running this command could potentially cause errors resulting in a reboot. In general, only use this command when working with Ruckus support to troubleshoot an issue.

### Example

```
ruckus(debug) # logs all
The command was executed successfully.
ruckus(debug) # show logs
Debug Logs:
  All= Enabled
  Sys-mgmt= Enabled
  Mesh= Enabled
  Web-auth= Enabled
  Rf-mgmt= Enabled
  Radius= Enabled
  Hotspot-srv= Enabled
  Aps= Enabled
  Net-mgmt= Enabled
  802.1x= Enabled
  Web-svr= Enabled
  802.11= Enabled
  Dvlan= Enabled
  Smart-redundancy= Enabled
  Client-association= Enabled
  Debug logs of specified MAC address:
    Status= Disabled
ruckus(debug) #
```

## no logs all

Disables debug logs of all debug components.

### Syntax Description

**no logs**  
Disable debug logs  
**all**  
Disable all log components

## Using Debug Commands

### Working with Debug Logs and Log Settings

#### Example

```
ruckus(debug) # no logs all  
The command was executed successfully.  
ruckus(debug) #
```

## logs comp sys-mgmt

Enables debug logs of system management components.

#### Syntax Description

```
logs  
    Enable debug logs  
  
comp sys-mgmt  
    Component system management
```

#### Example

```
ruckus(debug) # logs comp sys-mgmt  
The command was executed successfully.  
ruckus(debug) # show logs  
Debug Logs:  
    All= Disabled  
    Sys-mgmt= Enabled  
    Mesh= Disabled  
    Web-auth= Disabled  
    Rf-mgmt= Disabled  
    Radius= Disabled  
    Hotspot-srv= Disabled  
    Aps= Disabled  
    Net-mgmt= Disabled  
    802.1x= Disabled  
    Web-svr= Disabled  
    802.11= Disabled  
    Dvlan= Disabled  
    Smart-redundancy= Disabled  
    Client-associations= Disabled  
    Debug logs of specified MAC address:  
        Status= Disabled  
ruckus(debug) #
```

## no logs comp sys-mgmt

Disables debug logs of system management components.

## logs comp mesh

Enables debug logs of mesh components.

## no logs comp mesh

Disables debug logs of mesh components.

## **logs comp web-auth**

Enables debug logs of web authentication components.

## **no logs comp web-auth**

Disables debug logs of web authentication components.

## **logs comp rf-mgmt**

Enables debug logs of RF management components.

## **no logs comp rf-mgmt**

Disables debug logs of RF management components.

## **logs comp radius**

Enables debug logs of radius components.

## **no logs comp radius**

Disables debug logs of radius components.

## **logs comp hotspot-srv**

Enables debug logs of hotspot services components.

## **no logs comp hotspot-srv**

Disables debug logs of hotspot services components.

## **logs comp aps**

Enables debug logs of AP components.

## **no logs comp aps**

Disables debug logs of access points components.

## **logs comp net-mgmt**

Enables debug logs of network management components.

## **Using Debug Commands**

Working with Debug Logs and Log Settings

### **no logs comp net-mgmt**

Disables debug logs of network management components.

### **logs comp 802.1x**

Enables debug logs of 802.1x components.

### **no logs comp 802.1x**

Disables debug logs of 802.1x components.

### **logs comp web-svr**

Enables debug logs of web server components.

### **no logs comp web-svr**

Disables debug logs of web server components.

### **logs comp 802.11**

Enables debug logs of 802.11 components.

### **no logs comp 802.11**

Disables debug logs of 802.11 components.

### **logs comp dvlan**

Enables debug logs of dynamic VLAN components.

### **no logs comp dvlan**

Disables debug logs of dynamic vlan components.

### **logs comp smart-redundancy**

Enable Smart Redundancy component debug logs.

### **no logs comp smart-redundancy**

Disable Smart Redundancy component debug logs.

## logs comp bonjour-gateway

Enable Bonjour Gateway debug logs.

## no logs comp bonjour-gateway

Disable Bonjour Gateway debug logs.

## logs comp mdnsd

Enable bonjour mdnsd debug logs.

## no logs comp mdnsd

Disable bonjour mdnsd debug logs.

## logs comp client-association

Enable client association debug logs.

## no logs comp client-association

Disable client association debug logs.

## logs mac

Enables and sets filter running logs based on specified mac address.

**logs mac MAC**

### Syntax Description

**logs**

Enable debug logs

**mac**

Filter logs by specific MAC address

**MAC**

The MAC address of the device to be filtered

### Example

```
ruckus(debug) # logs mac 04:4f:aa:0c:b1:00
The command was executed successfully.
ruckus(debug) #
```

## Using Debug Commands

### Working with Debug Logs and Log Settings

## no logs mac

Disables MAC address filtering on running logs.

### Syntax Description

**no logs**

Disable debug logs

**mac**

Filter by MAC address

### Example

```
ruckus(debug) # no logs mac  
The command was executed successfully.  
ruckus(debug) #
```

## logs play

Starts displaying logs on console.

### Syntax Description

**logs**

Enable debug logs

**play**

Start log play

### Usage Guidelines



#### CAUTION

Running this command can place considerable load on the system. If your ZoneDirector is already under load, running this command could potentially cause errors resulting in a reboot. In general, only use this command when working with Ruckus support to troubleshoot an issue.

### Example

```
ruckus(debug) # logs play  
ruckus(debug) # [Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job[user auth attempt_hash_autoexpire] at 1329285210...  
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at 1329285210...Done  
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job[station auth attempt_hash_autoexpire] at 1329285210...  
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at 1329285210...Done  
[Feb 15 05:53:33] [STAMgr] [debug] acsrvc_thread():ACSRVC rcv AP 04:4f:aa:0c:b1:00, IP= 192.168.11.6,  
IPv6=f00::1  
...  
...  
ruckus(debug) # no logs play  
ruckus(debug) #
```

## no logs play

Stops displaying logs on console.

### Syntax Description

<b>no logs</b>	Disable debug logs
<b>play</b>	Stop log play

### Example

```
rruckus(debug) # logs play
ruckus(debug) # [Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job[user auth
attempt_hash_autoexpire] at 1329285210...
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at 1329285210...Done
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job[station auth attempt_hash_autoexpire] at
1329285210...
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at 1329285210...Done
[Feb 15 05:53:33] [STAMgr] [debug] acsrvc_thread():ACSRVC rcv AP 04:4f:aa:0c:b1:00, IP= 192.168.11.6,
IPv6=fc00::1
...
...
ruckus(debug) # no logs play
ruckus(debug) #
```

## logs winbind

To set Winbind debug level (1-10),, use the following command:

**logs winbind <WINBIND>**

### Defaults

None

### Example

```
ruckus(debug) # logs winbind 10
killall: winbindd: no process killed
ruckus(debug) #
```

## support-tls

To set the TLS support version, use the following command:

**support-tls<VER>**

### Defaults

1.0-1.1

## Using Debug Commands

### Working with Debug Logs and Log Settings

#### **Example**

```
ruckus(debug) # support-tls 1.0-1.1
Already support TLSv1.0 and TLSv1.1.
ruckus(debug) #
```

## no support-tls

To disable TLS support, use the following command:

```
no support-tls<VER>
```

# Remote Troubleshooting

This section describes remote troubleshooting commands.

## remote-troubleshooting server

To set the remote troubleshooting server IP address, use the following command:

**remote-troubleshooting server IP-ADDR**

## remote-troubleshooting start

Enables remote troubleshooting.

### Syntax Description

**remote-troubleshooting**  
    Remote troubleshooting  
**start**  
    Start remote troubleshooting

### Defaults

None.

### Example

```
ruckus (debug) # remote-troubleshooting start
ruckus (debug) #
```

## remote-troubleshooting stop

Disables remote troubleshooting.

### Syntax Description

**remote-troubleshooting**  
    Remote troubleshooting  
**stop**  
    Stop remote troubleshooting

### Defaults

None.

**Example**

```
ruckus (debug) # remote-troubleshooting stop  
ruckus (debug) #
```

## **radius-stats-wlan**

Show web-auth WLAN radius statistics bins.

## **radius-stats-authsvr**

Show web-auth WLAN radius statistics bins.

# AP Core Dump Collection

This section lists the AP core dump commands.

## collect\_ap\_coredump

Enable AP core dump collection.

**collect\_ap\_coredump [ all | MAC ]**

### Syntax Description

**collect\_ap\_coredump**

Collect AP core dump

**all**

Collect core dump from all connected APs

**MAC**

Specific AP MAC address

### Defaults

None.

### Example

```
ruckus(debug) # collect_ap_coredump all
---- Command 'apmgrinfo --coredump y' executed at 04:4f:aa:0c:b1:00
start reporting coredump to ZD!
---- Command 'apmgrinfo --coredump y' executed at 00:24:82:3f:14:60
start reporting coredump to ZD!
---- Command Execution Summary:
      success: 2
      failure: 0
      total: 2
rm: cannot remove '/etc/airespider-images/firmwares/ap-dump/*': No such file or directory
sh: codump_server: not found
start collecting AP's coredump !
ok
ruckus(debug) #
```

## no collect\_ap\_coredump

Disable AP core dump collection.

### Syntax Description

**no collect\_ap\_coredump**

Stop collecting AP core dump

### Defaults

None.

**Example**

```
ruckus(debug) # no collect_ap_coredump all
---- Command 'apmgrinfo --coredump n' executed at 04:4f:aa:0c:b1:00
stop reporting coredump to ZD!
---- Command 'apmgrinfo --coredump n' executed at 00:24:82:3f:14:60
stop reporting coredump to ZD!
---- Command Execution Summary:
      success: 2
      failure: 0
      total: 2
rm: cannot remove '/etc/airespider-images/firmwares/ap-dump/*': No such file or directory
stop collecting AP's coredump !
ok
ruckus(debug) #
```

# Script Execution

This section lists the commands that can be executed from the **script** context. The script context must be entered from the debug context.

## script

Enters the script context from the debug context. You must first enter the script context before executing a script.

**script**

### Syntax Description

**script**

Enter the script context

### Defaults

None.

### Example

```
ruckus(debug) # script
ruckus(script) #
```

## quit

Exit the script context.

**quit**

### Syntax Description

**quit**

Exit the script context

### Defaults

None.

### Example

```
ruckus(script) # quit
ruckus(debug) #
```

## list

List all available scripts.

**list**

### Syntax Description

#### list

List all available scripts

### Defaults

None.

### Example

```
ruckus(script)# list -a  
Index          Scripts  
 1             .version.sh  
ruckus(script)#+
```

## del

Deletes a script.

## info

Display script help file

#### info

### Syntax Description

#### info

Display script information

### Defaults

None.

### Example

```
ruckus(script)# info  
info <file>  
ruckus(script)#+
```

## exec

Execute script.

**exec** *file* {parameter}

### Syntax Description

#### exec

Execlute the script

## Defaults

None.

## Example

```
ruckus(script)# exec
exec <file> {parameter}
ruckus(script)#+
```



© 2022 CommScope, Inc. All rights reserved.  
350 West Java Dr., Sunnyvale, CA 94089 USA  
<https://www.commscope.com>