

The screenshot displays the EnGenius ESR9850 router's web interface. On the left, a dark blue sidebar contains a menu with items: System, Wizard, Internet, Wireless, Firewall, **Advanced** (highlighted with a red box), and Tools. The main content area has a brown header with the title 'Wireless Network Broadband Router' and a dropdown menu set to 'AP Router Mode'. Below the header is a navigation bar with tabs: **NAT** (circled in red), Port map., Port fw., Port tri., ALG, UPnP, QoS, and Routing. The NAT section contains a descriptive paragraph about Network Address Translation. Below this, the 'NAT' status is set to 'Enable'. Further down, the 'Network Turbine' section is highlighted with a red box, showing the 'Disable' radio button selected. An 'Apply' button is located at the bottom right of the configuration area.

After upgrading the firmware v2.0.2, [it is recommended to disable Network Turbine](#) by selecting **Advanced**, and then choosing **NAT**, and you can click **Disable Network Turbine** as shown above and then click **Apply**. Network Turbine will only benefit NAT performance when the internet speed is higher than 50Mbps.