


Package contents

- Wireless N-Router
- Quick Start Guide
- Ethernet cable
- Power Adapter


Minimum Requirements

- Broadband Internet Service (Kabel or DSL Modem)
- Internet Browser (Internet Explorer, Safari, Firefox, Chrome)
- Computer with Wireless 2.4 GHz or 5 GHz Adapter (IEEE 802.11a/b/g/n)


1. Unplug your cable or DSL modem and remove the power adapter.
2. Plug one end of the included gray Ethernet cable into the blue port labeled WAN on the back of your router.




Plug the other end of the cable into the Ethernet port of your modem.




3. Reconnect the power adapter to your cable or DSL modem and plug into wall outlet.



4. Connect the power adapter to your router and plug into wall outlet. Wait for 2 minutes.



5. The preset Wi-Fi Name and Password are located on the bottom of your router.





Wi-Fi Name (SSID)	e.g. EnGenius
Wi-Fi Password	e.g. 123456789


6. Open the wireless utility settings on your PC, Mac, or mobile device and connect to your network (Wi-Fi Name).

7. Open a Web browser on a mobile device or computer. Type "Engeniusrouter" into a web browser. Follow the Wizard from here on.



 **PC** - located at lower right portion of your screen in sys tray

 **Mac** - located at top right portion of your screen on menu bar

 **Mobile Device** - iPhone shown