

# Cloudpath Enrollment System Integration with Ruckus WLAN Controllers Configuration Guide, 5.4

Supporting Cloudpath Software Release 5.4

# Copyright, Trademark and Proprietary Rights Information

© 2019 ARRIS Enterprises LLC. All rights reserved.

No part of this content may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from ARRIS International plc and/or its affiliates ("ARRIS"). ARRIS reserves the right to revise or change this content from time to time without obligation on the part of ARRIS to provide notification of such revision or change.

## Export Restrictions

These products and associated technical data (in print or electronic form) may be subject to export control laws of the United States of America. It is your responsibility to determine the applicable regulations and to comply with them. The following notice is applicable for all products or technology subject to export control:

*These items are controlled by the U.S. Government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations.*

## Disclaimer

THIS CONTENT AND ASSOCIATED PRODUCTS OR SERVICES ("MATERIALS"), ARE PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, ARRIS DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, NON-INFRINGEMENT, FREEDOM FROM COMPUTER VIRUS, AND WARRANTIES ARISING FROM COURSE OF DEALING OR COURSE OF PERFORMANCE. ARRIS does not represent or warrant that the functions described or contained in the Materials will be uninterrupted or error-free, that defects will be corrected, or are free of viruses or other harmful components. ARRIS does not make any warranties or representations regarding the use of the Materials in terms of their completeness, correctness, accuracy, adequacy, usefulness, timeliness, reliability or otherwise. As a condition of your use of the Materials, you warrant to ARRIS that you will not make use thereof for any purpose that is unlawful or prohibited by their associated terms of use.

## Limitation of Liability

IN NO EVENT SHALL ARRIS, ARRIS AFFILIATES, OR THEIR OFFICERS, DIRECTORS, EMPLOYEES, AGENTS, SUPPLIERS, LICENSORS AND THIRD PARTY PARTNERS, BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER, EVEN IF ARRIS HAS BEEN PREVIOUSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, WHETHER IN AN ACTION UNDER CONTRACT, TORT, OR ANY OTHER THEORY ARISING FROM YOUR ACCESS TO, OR USE OF, THE MATERIALS. Because some jurisdictions do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of liability for consequential or incidental damages, some of the above limitations may not apply to you.

## Trademarks

ARRIS, the ARRIS logo, Ruckus, Ruckus Wireless, Ruckus Networks, Ruckus logo, the Big Dog design, BeamFlex, ChannelFly, Edgelron, FastIron, HyperEdge, ICX, IronPoint, OPENG, SmartCell, Unleashed, Xclaim, ZoneFlex are trademarks of ARRIS International plc and/or its affiliates. Wi-Fi Alliance, Wi-Fi, the Wi-Fi logo, the Wi-Fi CERTIFIED logo, Wi-Fi Protected Access (WPA), the Wi-Fi Protected Setup logo, and WMM are registered trademarks of Wi-Fi Alliance. Wi-Fi Protected Setup™, Wi-Fi Multimedia™, and WPA2™ are trademarks of Wi-Fi Alliance. All other trademarks are the property of their respective owners.

# Contents

---

<b>Configuring the Ruckus Wireless Controllers.....</b>	<b>4</b>
<b>Setting up Cloudpath as an AAA Authentication Server.....</b>	<b>4</b>
<b>Creating AAA Accounting Server (Optional).....</b>	<b>7</b>
<b>Running Authentication Test.....</b>	<b>8</b>
ZoneDirector.....	8
SmartZone.....	8
Unleashed.....	9
Possible Results from Authentication Test.....	9
<b>Creating Hotspot Services.....</b>	<b>10</b>
<b>Setting Up the Walled Garden.....</b>	<b>15</b>
<b>Creating the Onboarding SSID.....</b>	<b>18</b>
Enabling Bypass CNA on ZoneDirector.....	22
Enabling Bypass CNA on Unleashed.....	23
<b>Creating the Secure SSID.....</b>	<b>24</b>

# Configuring the Ruckus Wireless Controllers

This document describes how to configure the Ruckus ZoneDirector, SmartZone, and Unleashed controllers to integrate with the Cloudpath system, and includes the following steps:

- Set up Cloudpath as an AAA Authentication Server
- Create AAA Accounting Server (Optional)
- Create Hotspot Services
- Set Up the Walled Garden
- Create the Onboarding SSID
- Create the Secure SSID

## NOTE

The screen shots and corresponding instructions in this manual are based on the following Ruckus Controller versions:

- ZoneDirector 10.1.1
- Virtual SmartZone 3.6.0 (High Scale)
- Unleashed 200.6

If you are using different versions of any controller, please consult your controller documentation because you may encounter some differences in the user interface.

## Setting up Cloudpath as an AAA Authentication Server

Create an AAA authentication server for the Cloudpath onboard RADIUS server. The following images show this configuration on the Ruckus ZoneDirector, SmartZone, and Unleashed controllers.

On ZoneDirector, go to **Services & Profiles > AAA Servers**. On SmartZone, go to **Services & Profiles > Authentication**. On Unleashed, go to **Admin & Services > Services > AAA Servers > Authentication Servers**.

FIGURE 1 Create AAA Authentication Server on ZoneDirector

**Create New**

Name	<input type="text" value="R-AOnboard"/>
Type	<input type="radio"/> Active Directory <input type="radio"/> LDAP <input checked="" type="radio"/> RADIUS <input type="radio"/> RADIUS Accounting <input type="radio"/> TACACS+
Encryption	<input type="checkbox"/> TLS
Auth Method	<input checked="" type="radio"/> PAP <input type="radio"/> CHAP
Backup RADIUS	<input type="checkbox"/> Enable Backup RADIUS support
IP Address*	<input type="text" value="192.168.5.73"/>
Port*	<input type="text" value="1812"/>
Shared Secret*	<input type="text" value="*****"/>
Confirm Secret*	<input type="text" value="*****"/>
Retry Policy	
Request Timeout*	<input type="text" value="3"/> seconds
Max Number of Retries*	<input type="text" value="2"/> times

FIGURE 2 Create AAA Authentication Server on SmartZone

**Create AAA Server**

**General Options**

Name: Lab AAA Auth

Description:

Type:  RADIUS  Active Directory  LDAP

Backup RADIUS:  Enable Secondary Server

**Primary Server**

IP Address: 72.18.151.56

Port: 1812

Shared Secret: .....

Confirm Secret: .....

**User Role Mapping**

OK Cancel

FIGURE 3 Create AAA Authentication Server on Unleashed

**Create New**

Name

Type  Active Directory  RADIUS  RADIUS Accounting

Encryption  TLS

Auth Method  PAP  CHAP

Backup RADIUS  Enable Backup RADIUS support

IP Address\*

Port\*

Shared Secret\*

Confirm Secret\*

Retry Policy

Request Timeout\*  seconds

Max Number of Retries\*  times

Enter the following values for the **Authentication** Server:

1. Name
2. Type = RADIUS
3. Auth Method (not applicable for SmartZone) = PAP
4. IP address = The IP address of the Cloudpath ES.
5. Port = 1812
6. Shared Secret = This must match the shared secret for the Cloudpath ES onboard RADIUS server. (**Configuration > RADIUS Server**).
7. Leave the default values for the remaining fields.

## Creating AAA Accounting Server (Optional)

Use the same process to create the AAA Accounting Server.

### NOTE

To navigate to the correct screen on Ruckus SmartZone, go to **Services & Profiles > Accounting**.

Enter the following values for the **Accounting** Server:

1. Name
2. Type = RADIUS ACCOUNTING.
3. IP address = The IP address of the Cloudpath ES.

4. Port = 1813

**NOTE**

The Authentication server uses port 1812. The Accounting server uses port 1813.

5. Shared Secret = This must match the shared secret for the Cloudpath ES onboard RADIUS server. (**Configuration > RADIUS Server**)
6. Leave the default values for the remaining fields.

## Running Authentication Test

You can test the connection between the controller and the Cloudpath ES RADIUS server.

Follow the instructions for the applicable controller. For the possible results, see [Possible Results from Authentication Test](#).

## ZoneDirector

At the bottom of the AAA server page, there is a section called "Test Authentication/Accounting Servers Settings." The Test Against field should be Local Database, as shown below. Enter a test User Name and Password, then click the **Test** button.

**FIGURE 4** Authentication Test on ZoneDirector

The screenshot shows a web form titled "Test Authentication/Accounting Servers Settings". Below the title is a descriptive paragraph: "You may test your authentication server settings by providing a user name and password here. Groups to which the user belongs will be returned and you can use them to configure the role." The form contains the following elements: a "Test Against" dropdown menu with "Local Database" selected; a "Username" text input field; a "Password" text input field with a "Show Password" button next to it; and a "Test" button in the bottom right corner.

## SmartZone

When you save a configuration for an AAA Authentication server in SmartZone, you can click the **Test AAA** tab at the top of the screen, select the server from the drop-down list, enter your credentials, then click the **Test** button.



FIGURE 5 Authentication Test on SmartZone

Test AAA Servers

\* Name: Jeff AAA Auth vSZ

\* Protocol:  PAP  CHAP

\* User Name: bob

\* Password: ....  
 Show password

Test Cancel

## Unleashed

Enter the test credentials on the Test Authentication Servers Settings tab, then click the **Test** button.

FIGURE 6 Authentication Test on Unleashed

Authentication Servers Test Authentication Servers Settings

You may test your authentication server settings by providing a user name and password here. Groups to which the user belongs will be returned and you can use them to configure the role.

Test Against Anna43Unleashed

User Name

Password Show Password

Test

## Possible Results from Authentication Test

If you run the authentication test, you receive one of these responses:

- Failed! Connection timed out
- Failed! Invalid username and password

## Creating Hotspot Services

- Authentication Failed

The only one of these responses that means that connectivity was established is:

Failed! Invalid username or password

# Creating Hotspot Services

You can configure the Hotspot Service on the ZoneDirector, SmartZone, or Unleashed controllers.

1. Navigate to: For ZoneDirector, go to **Services & Profiles > Hotspot Services**. For SmartZone, go to **Services & Profiles > Hotspots & Portals > Hotspot WISPr**. For Unleashed, go to **Admin & Services > Services > Hotspot Services**, then use both the **General** tab and the **Authentication** tab, as instructed later in this section.

2. Name the Hotspot Service.

**FIGURE 7** Create Hotspot Service on ZoneDirector

### Create New

Name	Lab Hotspot Services
<b>Redirection</b>	
WISPr Smart Client Support	<input checked="" type="radio"/> None <input type="radio"/> Enabled <input type="radio"/> Only WISPr Smart Client allowed
Login Page*	Redirect unauthenticated user to <input type="text" value="https://training.cloudpath.net/e"/> for authentication.
Start Page	After user is authenticated, <input checked="" type="radio"/> redirect to the URL that the user intends to visit. <input type="radio"/> redirect to the following URL: <input type="text"/>
<b>User Session</b>	
Session Timeout	<input type="checkbox"/> Terminate user session after <input type="text" value="1440"/> minutes
Grace Period	<input type="checkbox"/> Allow users to reconnect without re-authentication for <input type="text" value="30"/> minutes
<b>Authentication/Accounting Servers</b>	
Authentication Server	Jeff AAA Auth <input checked="" type="checkbox"/> Enable MAC authentication bypass(no redirection). <input checked="" type="radio"/> Use device MAC address as authentication password. <input type="radio"/> Use <input type="text"/> as authentication password. MAC Address Format <input type="text" value="AA:BB:CC:DD:EE:FF"/>
Accounting Server	Jeff AAA acct <input type="text" value="5"/> Send Interim-Update every <input type="text" value="5"/> minutes
<b>Wireless Client Isolation</b>	
<input type="checkbox"/> Isolate wireless client traffic from other clients on the same AP. <input type="checkbox"/> Isolate wireless client traffic from all hosts on the same VLAN/subnet. <input type="text" value="No WhiteList"/> <small>(Requires whitelist for gateway and other allowed hosts.)</small>	
<input type="checkbox"/> Location Information <input type="checkbox"/> Walled Garden <input type="checkbox"/> Restricted Subnet Access <input type="checkbox"/> Advanced Options	
<input type="button" value="OK"/> <input type="button" value="Cancel"/>	

FIGURE 8 Create Hotspot WISPr on SmartZone

**Create Hotspot Portal**

**General Options**

Portal Name: Lab Hotspot Services  
Portal Description:

**Redirection**

Smart Client Support:  None  Enable  Only Smart Client Allowed

Logon URL:  Internal  External

Redirect unauthenticated user to the URL for authentication: https://training.cloudpath.net/enroll/TrainingTest/Produc

Redirected MAC Format: AA:BB:CC:DD:EE:FF

Start Page: After user is authenticated,  
 Redirect to the URL that user intends to visit.  Redirect to the following URL:

HTTPS Redirect:  If enabled, the AP will try to redirect HTTPS requests to the hotspot portal

**User Session**

Session Timeout: 1440 Minutes (2-14400)  
Grace Period: 60 Minutes (1-14399)

**Location Information**

Location ID: (example: isocc=us,cc=1,ac=408,network=ACMEWISP\_NewarkAirport)  
Location Name: (example: ACMEWISP,Gate\_14\_Terminal\_C\_of\_Newark\_Airport)

**Walled Garden**

OK Cancel

FIGURE 9 Create Hotspot Service on Unleashed - General Tab

## Create New ✕

General

Authentication

WalledGarden

Policy

**Name**

**Redirection**

**WISPr Smart Client Support**  None  Enabled  Only WISPr Smart Client allowed

**Login Page** Redirect unauthenticated user to  for authentication.

**Start Page** After user is authenticated,

redirect to the URL that the user intends to visit.

redirect to the following URL:

**User Session**

**Session Timeout** (Requires whitelist for gateway and other allowed hosts.)

Terminate user session after  minutes

**Grace Period**  Allow users to reconnect without re-authentication for  minutes

**Intrusion Prevention**  Temporarily block Hotspot clients with repeated authentication attempts.

OK

Cancel

**FIGURE 10** Create Hotspot Service on Unleashed - Authentication Tab

The screenshot displays the 'Authentication' configuration tab for a hotspot service. It is divided into three main sections:

- Authentication/Accounting Servers:**
  - Authentication Server:** A dropdown menu is set to 'Anna43Unleashed' with a 'Create New' button next to it.
  - Options:**
    - Enable MAC authentication bypass(no redirection).
    - Use device MAC address as authentication password.
    - Use [ ] as authentication password.
  - MAC Address Format:** A dropdown menu is set to 'AA:BB:CC:DD:EE:FF'.
  - Accounting Server:** A dropdown menu is set to 'Anna43UnleashedACCT' with a 'Create New' button next to it.
  - Send Interim-Update every:** A text input field contains '10' followed by 'minutes'.
- Wireless Client Isolation:**
  - Isolate wireless client traffic from other clients on the same AP.
  - Isolate wireless client traffic from all hosts on the same VLAN/subnet.
  - No WhiteList:** A dropdown menu is set to 'No WhiteList' with a 'Create New' button next to it.
  - (Requires whitelist for gateway and other allowed hosts.)
- Location Information:**
  - Location ID:** An empty text input field with a hint: (e.g. isocc=us,cc=1,ac=408,network=ACMEWISP\_NewarkAirport)
  - Location Name:** An empty text input field with a hint: (e.g. ACMEWISP,Gate\_14\_Terminal\_C\_of\_Newark\_Airport)

At the bottom right of the window, there are two buttons: 'OK' and 'Cancel'.

3. Point the unauthenticated user to the **Cloudpath Enrollment Portal URL**, which can be found on the **Cloudpath Admin UI Configuration > Workflows** page, in the **Workflows** table.
4. Check **Redirect to the URL that the user intends to visit**.
5. Select the **Cloudpath RADIUS Authentication Server**. Applicable only for ZoneDirector and Unleashed (**Authentication** tab) in this screen.
6. Select **Enable MAC authentication bypass (no redirection)**. Applicable only for ZoneDirector and Unleashed (**Authentication** tab) in this screen. Selecting this field allows users with registered MAC addresses to be transparently authorized without having to log in.
7. For MAC Address Format (which appears when you select **Enable MAC authentication bypass (no redirection)** in the preceding step, it is recommended that you select the following option from the drop-down list: AA:BB:CC:DD:EE:FF
8. Select the **Cloudpath RADIUS Accounting Server**. Applicable only for ZoneDirector and Unleashed (**Authentication** tab).
9. Leave the defaults for the remaining settings. Click **OK**.


# Setting Up the Walled Garden

Perform the following steps to add a walled garden configuration to your existing Hotspot Services configuration:

1. Navigate to: For ZoneDirector, go to **Services & Profiles > Hotspot Services**. For SmartZone, go to **Services & Profiles > Hotspots & Portals > Hotspot WISPr**. For Unleashed, go to **Admin & Services > Services > Hotspot Services**.

- For ZoneDirector and SmartZone, use the **edit** function on the existing Hotspot Services configuration, then scroll to the **Walled Garden** section and expand this section. For Unleashed, click the **WalledGarden** on the existing Hotspot Services configuration.

**FIGURE 11** Walled Garden Configuration for ZoneDirector



**FIGURE 12** Walled Garden Configuration for SmartZone






FIGURE 13 Walled Garden Configuration for Unleashed

**Edit** ✕

General Authentication **WalledGarden** Policy

Unauthenticated users are allowed to access the following destinations:  
(e.g. \*.mydomain.com, mydomain.com, \*.mydomain.\*, 192.168.1.1:80, 192.168.1.1/24 or 192.168.1.1:80/24)

<input type="checkbox"/>	Order	Destination Address	Action
<input type="checkbox"/>	1	192.168.5.42	Save Cancel

[Create New](#) ⊞ Advanced Options Delete

**OK** Cancel

3. Include the DNS or IP address of the Cloudpath system, then click **OK**.
4. Optionally, there are some domains that you can add to the walled garden on all controllers to:
  - Prevent the Apple CNA mini-browser from appearing on Apple devices.
  - Avoid being blocked or slowed when attempting to download the Cloudpath wizard.

**NOTE**

There will still be about a 15-to-20-second delay when the full application is 33 percent complete (about 40 MB) in its download.

The recommended destinations to add for the walled garden are:

```

*.ggpht.com
*.play.googleapis.com
*.googleapis.com
*.play.google.com
android.clients.google.com
*.gvt1.com
connectivitycheck.android.com
connectivitycheck.google.com
*.gstatic.com
*.clients3.google.com
*.thawte.com

```

**NOTE**

The \*.thawte.com destination is the OCSP URL of the SSL certificate of the Cloudpath server. This URL can be found by clicking the *lock* icon in your web browser and viewing the details of your certificate.

5. If you are still experiencing issues, you can try adding the following destinations to the walled garden:

```
*.clients.google.com  
*.l.google.com  
*.googleusercontent.com  
*.appengine.google.com  
*.cloud.google.com  
*.android.com  
*.cloudfront.net  
*.akamaihd.net  
172.217.0.0/16  
216.58.0.0/16
```

## Creating the Onboarding SSID

To configure the onboarding SSID, navigate to: For ZoneDirector and SmartZone, go to the Wireless LANS section of the controller UI; for Unleashed, go to **Wifi Networks** to create the WLAN.

1. Name the SSID.

2. Type=Hotspot Service (WISPr).

**FIGURE 14** Onboarding SSID Configuration on ZoneDirector

**Create WLAN**

**General Options**

Name: Lab Onboard SSID

ESSID: Lab Onboard SSID

Description:

**WLAN Usages**

Type:

- Standard Usage (For most regular wireless network usages.)
- Guest Access (Guest access policies and access control will be applied.)
- Hotspot Service (WISPr)
- Hotspot 2.0
- Autonomous
- Social Media
- WeChat

**Authentication Options**

Method:  Open  802.1x EAP  MAC Address  802.1x EAP + MAC Address

Fast BSS Transition:  Enable 802.11r FT Roaming (Recommended to enable 802.11k Neighbor-list Report for assistant.)

**Encryption Options**

Method:  WPA2  WPA-Mixed  WEP-64 (40 bit)  WEP-128 (104 bit)  None

**Options**

Hotspot Services: Lab Hotspot Services

Priority:  High  Low

**Advanced Options**

FIGURE 15 Onboarding SSID Configuration on SmartZone

### Create WLAN Configuration

**General Options**

Name:

SSID:

Description:

Zone:

WLAN Group:  + Create

**Authentication Options**

Authentication Type:  Standard usage (for most regular wireless networks)  Hotspot (HSP)  Guest Access  Web Authentication

Hotspot 2.0 Access  Hotspot 2.0 Onboarding  WPA-Chat

Method:  Open  802.1X EAP  MAC Address  802.1X RADIUS

MAC Authentication:  Use user-defined text as authentication password (default is device MAC address):

MAC Address Format:

**Encryption Options**

Method:  WPA2  WPA-Mixed  WEP-64 (40 bits)  WEP-128 (104 bits)  None

**Data Plane Options**

Access Network:  Tunnel WLAN traffic through Ruckus GRE

**Hotspot Portal**

Hotspot (HSP) Portal:  + Create

Bypass CNA:  Enable

Authentication Service:  Use the controller as proxy  Use RADIUS-based profile

+ Create

Accounting Service:  Use the controller as proxy

+ Create Send interim update every  Minutes (0-1440)

**Options**

Acct Delay Time:  Enable

Wireless Client Isolation:  Disable  Enable (isolate wireless client traffic from all hosts on the same VLAN/subnet)

Isolation Whitelist:  + Create

(The whitelist requires entries for the subnet gateway and other allowed hosts.)

(The whitelist can only contain wired destinations, wireless clients are not supported on the whitelist.)

Priority:  High  Low

**RADIUS Options**

**Advanced Options**

OK
Cancel

**FIGURE 16** Onboarding SSID Configuration for Unleashed

**Create WLAN** ✕

\* **Name:**

**Usage Type:**

- Standard for most regular wireless network usage
- Guest Access guest access policies and access control will be applied
- Hotspot Service known as WISPr
- Social Media authenticate through social media network
- WeChat

**Hotspot Services:**

Show Advanced Options ▶


3. Authentication Options Method=Open for ZoneDirector, MAC Address for SmartZone. (Not applicable for Unleashed.)
4. The checkbox next to MAC Authentication (SmartZone only) called "Use user defined text as authentication password (default is device MAC address):" can be left unchecked.
5. The MAC Address Format (SmartZone only) recommended selection is: AA:BB:CC:DD:EE:FF. This is the default for most RADIUS servers.
6. Encryption Options Method=None (ZoneDirector and SmartZone).
7. Select the Hotspot Service from the drop-down list that you should already have created in a previous step procedure.
8. Enable the **Bypass CNA** feature as follows, depending on the controller:
  - For SmartZone: Check the box to enable "Bypass CNA," as shown in [Figure 15](#).
  - For ZoneDirector, after you finish configuring the onboarding SSID, refer to [Figure 17](#) on page 22.
  - For Unleashed, after you finish configuring the onboarding SSID, refer to [Figure 19](#) on page 23.
9. Select the Cloudpath RADIUS Authentication Server (SmartZone only).
10. Select the Cloudpath RADIUS Accounting Server (SmartZone only).
11. Leave the defaults for the remaining settings and click **OK** (or **Apply**).

## Enabling Bypass CNA on ZoneDirector

It is recommended to enable the "Bypass Apple CNA Feature," which you can do globally for wireless LANs in ZoneDirector.

1. In the Wireless LANs main screen, click on **Bypass Apple CNA Feature**, as shown in the following figure:

**FIGURE 17** Enabling the Bypass Apple CNA Feature Globally on ZoneDirector




2. In the "Bypass Apple CNA Feature" area of the screen, check the "Hotspot service" box.
3. Click **Apply** to enable the "Bypass Apple CNA Feature" globally on all Wireless LANs that are configured as type "Hotspot Service (WISPr)."

## Enabling Bypass CNA on Unleashed

It is recommended to enable the "Bypass Apple CNA Feature," which you can do globally for wireless LANs in Unleashed.


1. In the WiFi Networks main screen (see figure below), click **Edit**.

**FIGURE 18** Clicking the Edit Button Brings you to Global Configuration



2. In the Global Configuration screen that pops up, click **Bypass Apple CNA Feature**.

**FIGURE 19** Enabling the Bypass Apple CNA Feature Globally on Unleashed



3. In the "Bypass Apple CNA Feature" area of the screen, check the "Hotspot service" box.
4. Click **Apply** to enable the "Bypass Apple CNA Feature" globally on all Wireless LANs that are configured as type "Hotspot Service (WISPr)."

## Creating the Secure SSID

To configure the onboarding SSID, navigate to: For ZoneDirector and SmartZone, go to the Wireless LANS section of the controller UI; for Unleashed, go to **Wifi Networks** to create the WLAN.

1. Name the SSID.
2. Type=Standard Usage.
3. Authentication Option Method=802.1x EAP.
4. Encryption Option Method=WPA2 (not applicable for Unleashed once the 802.1x EAP authentication option method is selected).
5. Encryption Option Algorithm=AES (not applicable for Unleashed once the 802.1x EAP authentication option method is selected).
6. Select the Cloudpath RADIUS authentication server.
7. Select the Cloudpath RADIUS accounting server (required only if you are using Cloudpath onboard RADIUS Accounting and Connection Tracking). **Note:** For ZoneDirector, you need to expand the Advanced Options section of the screen to locate the drop-down selection for the accounting server.



8. Leave the defaults for the remaining settings and click **OK**.

**FIGURE 20** Configure Secure SSID on the ZoneDirector controller

**Create WLAN**

**General Options**

Name: Lab Secure SSID  
 ESSID: Lab Secure SSID  
 Description:

**WLAN Usages**

Type:  Standard Usage (for most regular wireless network usages.)  
 Guest Access (Guest access policies and access control will be applied.)  
 Hotspot Service (WISPr)  
 Hotspot 2.0  
 Autonomous  
 Social Media  
 WeChat

**Authentication Options**

Method:  Open  802.1x EAP  MAC Address  802.1x EAP + MAC Address  
 Fast BSS Transition:  Enable 802.11r FT Roaming (Recommended to enable 802.11k Neighbour List Report for assistant.)

**Encryption Options**

Method:  WPA2  WPA-Mixed  WEP-64 (40 bit)  WEP-128 (104 bit)  None  
 Algorithm:  AES  Auto (TKIP+AES)  
 802.11w MFP:  Disabled  Optional  Required

**Options**

Authentication Server: Jeff AAA Auth Create New  
 Wireless Client Isolation:  Isolate wireless client traffic from other clients on the same AP.  
 Isolate wireless client traffic from all hosts on the same VLAN/subnet.  
 No WhiteList Create New  
 (Requires whitelist for gateway and other allowed hosts.)  
 Zero-IT Activation™:  Enable Zero-IT Activation  
 (WLAN users are provided with wireless configuration installer after they log in.)  
 Priority:  High  Low

**Advanced Options**

OK Cancel

FIGURE 21 Select RADIUS Accounting Server on ZoneDirector

Advanced Options

Accounting Server: Jeff AAA acct Create New Send Interim-Update every 10 minutes

Access Control: L2/MAC No ACLs Create New

L3/4/IP address No ACLs Create New

Device Policy None Create New Precedence Policy Default Create New

Enable Role based Access Control Policy

Application Recognition & Control:  Enable

Call Admission Control:  Enforce CAC on this WLAN when CAC is enabled on the radio

Rate Limiting: Per Station Uplink Disabled Per Station Downlink Disabled

SSID Rate Limiting: UpLink  Enable 0 mbps (0.1~200)

DownLink  Enable 0 mbps (0.1~200)

Per STA rate limiting will not work if SSID rate limiting is enabled.

OK Cancel

FIGURE 22 Configure Secure SSID on the SmartZone controller

**Create WLAN Configuration**

**General Options**

- Name: Lab Secure SSID
- SSID: Lab Secure SSID
- Description:
- Zone: Default
- WLAN Group: Default + Create

**Authentication Options**

- Authentication Type:
  - Standard usage (For most regular wireless networks)
  - Hotspot (WISPr)
  - Guest Access
  - Web Authentication
  - Hotspot 2.0 Access
  - Hotspot 2.0 Onboarding
  - YipeChat
- Method:
  - Open
  - 802.1X EAP
  - MAC Address
  - 802.1X & MAC

**Encryption Options**

- Method:
  - WPA2
  - WPA Mixed
  - WEP-44 (40 bits)
  - WEP-128 (104 bits)
  - None
- Algorithm:
  - AES
  - AUTO
- 802.11r Fast Roaming:
  - Enable 802.11r Fast BSS Transition
  - Disabled
- 802.11r WPA:
  - Disabled
  - Capable
  - Required

**Data Plane Options**

- Access Network:
  - Tunnel WLAN traffic through Ruckus GRE

**Authentication & Accounting Service**

- Authentication Service:
  - Use the controller as proxy
  - Jeff AAA Auth v52 + Create
- Accounting Service:
  - Use the controller as proxy
  - Jeff AAA Acct v52 + Create
  - Send Interim update every: 5 Minutes (0-1440)

**Options**

- Asst Delay Time:
  - Enable
- Wireless Client Isolation:
  - Disable
  - Enable (Isolate wireless client traffic from all hosts on the same VLAN/subnet)
- Isolation Whitelist:
  - Gateway Only (Automatic) + Create
  - (The whitelist requires entries for the subnet gateway and other allowed hosts.)
  - (The whitelist can only contain wired destinations, wireless clients are not supported on the whitelist.)
- Priority:
  - High
  - Low

**RADIUS Options**

**Advanced Options**

OK Cancel

**FIGURE 23** Configure Secure SSID on the Unleashed controller

**Create WLAN** ✕

**Name:**

**Usage Type:**  **Standard** for most regular wireless network usage  
 **Guest Access** guest access policies and access control will be applied  
 **Hotspot Service** known as WISPr  
 **Social Media** authenticate through social media network  
 **WeChat**

**Authentication Method:**  Open  **802.1X EAP**  MAC Address

**Authentication Server:**

**Accounting Server:**

Send Interim-Update every  minutes

Show Advanced Options ▶

The SSIDs are now configured on the wireless LAN controller. When the user connects to the onboarding (open) SSID they are redirected to the Cloudpath web page. When the user successfully completes the enrollment process, they are migrated to the secure SSID.



© 2019 ARRIS Enterprises LLC. All rights reserved.  
Ruckus Wireless, Inc., a wholly owned subsidiary of ARRIS International plc.  
350 West Java Dr., Sunnyvale, CA 94089 USA  
[www.ruckuswireless.com](http://www.ruckuswireless.com)