

OmniVista 3600 Air Manager 8.0



Copyright

© 2014 Alcatel-Lucent. All rights reserved.

Specifications in this manual are subject to change without notice.

Originated in the USA.

AOS-W, Alcatel 4302, Alcatel 4304, Alcatel 4306, Alcatel 4308, Alcatel 4324, Alcatel 4504, Alcatel 4604, Alcatel 4704, Alcatel 6000, OAW-AP41, OAW-AP68, OAW-AP60/61/65, OAW-AP70, OAW-AP80, OAW-AP92/93, OAW-AP105, OAW-AP120/121, OAW-AP124/125, OAW-AP175, OAW-IAP92/93/105, OAW-RAP2, OAW-RAP5, and Omnivista 3600 Air Manager are trademarks of Alcatel-Lucent in the United States and certain other countries.

Any other trademarks appearing in this manual are the property of their respective companies. Includes software from Litech Systems Design. The IF-MAP client library copyright 2011 Infoblox, Inc. All rights reserved. This product includes software developed by Lars Fenneberg et al.

Legal Notice

The use of Alcatel-Lucent switching platforms and software, by all individuals or corporations, to terminate Cisco or Nortel VPN client devices constitutes complete acceptance of liability by that individual or corporation for this action and indemnifies, in full, Alcatel-Lucent from any and all legal actions that might be taken against it with respect to infringement of copyright on behalf of Cisco Systems or Nortel Networks.

Chapter 1 Identifying Hardware Requirements	5
Tested Hardware Platforms	5
Testing Environment Parameters	5
Test Values	6
Conditions that Impact Hardware Sizing	7
Choosing Your RAID Controller	9
RAID Configuration Information	9
Choosing Your Hard Drives	9
SSDs vs 15K SAS	9
Chapter 2 Configuring Your Hardware	10
CPU Configuration	10
Disk Partitioning	10
Filesystem Configuration	10
Chapter 3 Virtualization	11
Virtualization	11
Appendix 4 Sizing a Master Console and Failover Server	12
Master Console	12
Failover Server	12
Contacting Alcatel-Lucent	13

This document provides general guidelines to follow when selecting and configuring hardware. The first part of this chapter describes two OV3600 appliances, and the networking environment in which those appliances were tested and validated. The following sections lists network conditions and OV3600 settings that can cause your server sizing needs to differ from the tested values, and how those settings might impact your choice of hardware.

Please keep in mind that the information presented in this Sizing Guide is intended as a set of guiding principles and not a guarantee of a level of performance on given hardware. If you have questions about how to provision OV3600 appropriately for your network, and certainly if you intend to monitor more than 3,000 devices, please contact Alcatel-Lucent support.

Tested Hardware Platforms

The information provided in this document is based on internal testing scenarios using the hardware platforms described in [Table 1](#), below. These hardware platforms have been tested and verified in the Alcatel-Lucent test networking environment, which is described in detail in "[Testing Environment Parameters](#)" on [page 5](#).

Table 1: *Tested Hardware Platforms*

Model	AW-HW-PRO	AW-HW-ENT
Maximum Devices	1500	4000
CPU	1 x Intel Xeon E5-2640, 2.5 GHz	2 x Intel Xeon E5-2640, 2.5 GHz
Physical Cores	6	12
Passmark Score	9761	14846
RAM	48 GB	80 GB
Disks (RAID10 only)	6 x 146 GB 15k rpm SAS	8 x 146 GB 15k rpm SAS
Storage Capacity	438 GB	584 GB
Maximum Input/Output Operations Per Second (IOPs)	2132	2842

Testing Environment Parameters

The hardware platforms described in "[Tested Hardware Platforms](#)" on [page 5](#) support a network with the following Alcatel-Lucent test values. This testing information is included to give you a clear idea of the type of environment that is recommended for these hardware platforms, and to give you an opportunity to note how your own networking environment may differ from the Alcatel-Lucent testing environment, as any changes from these conditions can have a significant impact hardware performance and requirements. For more information on how these differences can impact your network, see "[Conditions that Impact Hardware Sizing](#)" on [page 7](#).

Aruba uses a PassMark (<http://www.cpubenchmark.net/>) score of OV3600 appliance CPUs to compare the relative processing power between servers. These scores provide for a close comparison, although the score for a CPU model can vary over time as more users contribute benchmark values for that CPU.

To calculate the IOPS delivered by the disk subsystem, Alcatel-Lucent uses the calculator at <http://www.wmarrow.com/strcalc/>. The following values for that calculator most closely approximate the disk workload characteristics of the OV3600.

- RAID Level: RAID 1 and 10
- Stripe size: 1024 KiB
- Number of drives: 8
- Reads %: 20%
- Read cache hit ratio: 95%
- Write cache hit ratio: 65%
- Average I/O size : 8 KiB

Test Values

Scalability is tested based on the following test values. Deviations from these values can impact overall scalability of your OV3600 server.

Table 2: Wireless Scalability Test Values

Category	
AP Interface polling period	10
Device-to-device link period	5
CDP neighbor data polling	30
Ratio of switches/routers to access points	25%
Read ARP polling (hours)	4
Read CDP table for device discovery polling (hours)	4
Read bridge forwarding table polling (hours)	4
Interface Up/Down polling period	10
Ratio of APs to switches	128:1
Ratio of clients to APs	5:1
Ratio of switches/routers to access points	25%
Average port density of switches/routers	36
Read ARP polling period (hours)	8
Read CDP table for device discovery polling period (hours)	8
Read bridge forwarding table polling period (hours)	8
Interface polling period (minutes)	20

Table 3: VisualRF Scalability Test Values

Category	
Average floor plan size (feet)	62,500
Number of access points per floor plan	20
Number of clients per floor plan	100
Number of attenuation grid cells per floor plan	2,500
Number Rogue devices per floor plan	20
OV3600 Synchronization timer (minutes)	15
Rogue location timer (minutes)	30
Location calculation timer (min/max/number of samples)	90/360/3

Conditions that Impact Hardware Sizing

Accurate hardware sizing is almost as much of an art as it is a science, as it requires you to balance the needs of your users and the demands of your existing network infrastructure using a very complex set of interdependent variables. There is no one-size-fits-all approach to hardware sizing that can accurately predict the needs of any individual network. However, as part of a best practice methodology for hardware sizing, Alcatel-Lucent suggests network administrators review the following list of network requirements and variables, all of which that have a significant impact on the load on OV3600, and are all factors to consider when determining hardware requirements.

- **Client Mobility:** How often are your clients roaming? This is largely a function of your environment, but more frequent client roaming increases the OV3600 workload. For example, a typical corporate office has relatively low client mobility, as most people stay at their desks for extended periods of time. In contrast, at a university, thousands of students change classrooms on the hour, producing a flood of association change data for the OV3600 to process. Airports have yet another type of client mobility pattern, with many new, highly mobile clients. These client mobility factors impact the disk write demands and the storage requirements of the OV3600 server.
- **Number Clients Per AP:** The number of clients served by OV3600 has a direct and significant impact on hardware sizing requirement. As a guideline, consider that the Alcatel-Lucent testing environment assumes a client-to-AP ratio of 5:1. If the test networking environment was altered to support twice the clients, the server size would need to double as well.
- **Ratio of New Clients:** OV3600 requires more processing resources to identify new clients than existing clients. If your OV3600 server manages APs in public places like airports or retail spaces, your network will likely have a higher ratio of new clients than the testing environment, will need a server with increased processing power.
- **Wired Switch Percentage:** Switches demand more processing resources from OV3600. The 4,000 device rating for the AW-HW-ENT appliance assumes a distribution of 20% switches and 80% APs. If your network has a higher percentage of switches, consider a server with increased CPU processing power.
- **Trap Rate:** Traps consume processing resources, and trap rates are associated with client mobility. The AW-HW-ENT appliance was tested against a continuous rate of 100 traps/second. If your environment will trigger more traps than the test environment, consider a hardware server with a greater CPU and IOPS capacity.

- **AMON:** AMON allows OV3600 to collect enhanced data from Alcatel-Lucent devices on certain firmware versions. An OV3600 server collecting data using AMON requires more CPU and memory resources than an OV3600 server using SNMP, especially if OV3600 is collecting AppRF and Unified Communication and Collaboration (UCC) data. AppRF can produce a lot of data and increase the OV3600's storage requirements, but an upper bound can be configured to mitigate that problem.
- **SNMP Poll Periods:** The AW-HW-ENT appliance is certified with default polling periods (i.e., 10 minutes for interface polling, 5 minutes for up/down polling). More aggressive or frequent OV3600 polling needs a server with increased CPU and IOPS capacity to handle the increased workload.
- **RAPIDS.** The Rogue AP Intrusion Detection System (RAPIDS) is another feature that can have a major impact the OV3600 server size. Identifying and processing rogue APs consumes CPU and disk resources on the OV3600. If the OV3600 manages an AP that detects many APs in other networks (for example, if your AP is in an open plaza or an atrium in a shopping mall) then that AP will likely identify a large amount of rogue APs, requiring increased server capacity.
- **VisualRF:** The numbers of floor plans and campuses managed and monitored by OV3600 directly impacts the amount of memory used by the VisualRF feature. The OV3600 server may need more memory resources to manage a complex network using VisualRF.
- **Data Retention Periods.** Long retention periods increase the bulk of data the OV3600 has to manage. If your network requires longer data retention periods than the default retention settings, consider a server with a larger disk capacity than the tested devices.
- **Reports.** The type, frequency and scope of reports can have an large impact on the OV3600. The OV3600 RAID controllers are configured for write-back, so they behave like an solid-state drive for writes. Reads, on the other hand, take much more processing resources. Report generation require that a lot of data is read from the disk, which slows the disk subsystem. Internal testing is focused on the steady-state of the OV3600, and does not explicitly factor in report generation and processes like nightly maintenance. Internal testing ensures the steady-state never uses 100% of the server's resources so there is extra processing available when needed. If you will be generating reports frequently, consider a server with a greater IOPS and disk capacity.
- Instant APs: The **Supported Devices** values in [Table 1](#) do not apply to Instant APs unless the following criteria are met.
 - **Device counts are adjusted for virtual controllers**

An Instant AP acting as a virtual controller is managed as two devices; one virtual controller, and one AP. (This is in contrast to Instant APs associated to the Instant virtual controller and standard APs, which are counted as a single device). If your network includes a large number of standalone Instant APs acting as virtual controllers, be aware that this may impact the device count. The **Supported Devices** values in [Table 1](#) assume that these devices are standard APs. If your network includes many Instant virtual controllers, your hardware requirements must take into consideration increased device count.
 - **WAN Link is High Quality.**

The quality of the WAN link has a large impact on Instant networks. Poor WAN link quality increases the amount of time it takes for an Instant AP to download new firmware, causing downloads to take longer. This increases http socket utilization, reducing the ability of other Instant APs to initiate their firmware downloads. Configuration updates are pushed from OV3600 to Instant APs one device at a time, so if an Instant AP on poor quality WAN link is slow to update, that AP acts as a bottleneck, slowing down the configuration push to other devices.
 - **Rogue Polling and VisualRF are disabled**

A single Instant AP cannot accurately detect rogue APs or determine VisualRF location information, as these features typically require triangulation between three or more APs to accurately detect the locations of other

devices on the networks. Best practices are to disable rogue polling and VisualRF in networks with just a single Instant AP per location, to reserve memory and CPU utilization resources for other processes.

Choosing Your RAID Controller

RAID 10 is the only supported RAID configuration for OV3600.



Software RAID and SATA drives are NOT SUPPORTED for any configuration of OV3600.

RAID Configuration Information

For RAID 10:

- Use a dedicated Hardware RAID controller with caching and battery backup or a non volatile (NV) cache.
- Configure the RAID controller for Write-Back caching with battery backup (unless NVcache is selected, in which case Force Write-Back without Battery backup is recommended).
- Enable individual drive caching.
- Ensure that all disks are assigned and configured to a single volume.



Improper RAID configuration can result in drastically reduced server performance. If you have any questions regarding hardware compatibility or selection, contact Alcatel-Lucent support.

Choosing Your Hard Drives

15K SAS drives are the highest performance spinning platter drives available today. Serial ATA and 10K SAS are vastly outperformed by 15K SAS, and should not be used in an OV3600 server.

You will need to select the appropriately sized hard drive to meet your desired storage volume after taking into account RAID 10 reduction on overall storage capacity.

RAID 10 reduces your single volume available drive space by $\frac{1}{2}$ because of the redundancy introduced. An example would be 16x 146GB 15K SAS hard drives in a RAID 10 volume will result in approximately 1.1 TB of storage space [(16*146GB)/ 2].



To ensure hardware capability, purchase server hardware that is certified to be compatible with Red Hat Enterprise Linux 6.2.

SSDs vs 15K SAS

Solid State Drives are becoming more affordable and are being offered as a high performance drive option by many vendors. SSDs offer performance that far outstrips 15K SAS.

OV3600 supports deployment on SSD based storage arrays and can take advantage of the high speed disk access and stellar random write performance. Enterprise grade or high-end consumer grade SSDs are suitable, but avoid low-end consumer grade drives with older controllers. Confirm with your vendor prior to purchasing SSDs that their offerings are appropriate for a 24/7 sustained high random write database server.

In general, RAID 10 is still recommended for SSD deployments to allow for the best overall redundancy and performance. Any parity based RAID (5/6/etc) is not recommended. For additional information, please contact Alcatel-Lucent support.

This section explains sizing information for CPUs, Disk partitions, and file systems, and it includes the following sections:

- "CPU Configuration " on page 10
- "Disk Partitioning" on page 10
- "Filesystem Configuration" on page 10

CPU Configuration

Ensure that Power Management is configured for **Maximum Performance**. By default, most vendors configure BIOS to an eco-friendly setting. Ensure that Memory Operating Mode is configured to **Optimizer Mode**, if available.

Disk Partitioning

OV3600 automatically partitions the disk subsystem upon installation. You can override these values. [Table 4](#) below lists the default partitioning and provides guidance for more advanced scenarios.

Table 4: *Default Partitions*

Default Partitions	Size
boot	100 MB
swap	4 GB
/	Remainder of disk space

Filesystem Configuration

For OV3600, the NOOP File I/O scheduler provides the best random write performance. If you are running OV3600 7.2 or later, OV3600 should automatically manage this setting for you.

To check the currently assigned scheduler (if sda is not your device name, please replace with the correct device name):

```
# cat /sys/block/sda/queue/scheduler
noop anticipatory deadline [cfq] (Sample Output)
```

To configure noop as your preferred scheduler:

```
# echo noop > /sys/block/sda/queue/scheduler
```

And confirm that your change has been applied:

```
# cat /sys/block/sda/queue/scheduler
[noop] anticipatory deadline cfq (Expected Output)
```

Virtualization

OV3600 can run in a virtualized environment. To ensure scalability, use a dedicated processor and memory. You must also ensure that the disk subsystem can maintain the IOPS throughput described in "[Tested Hardware Platforms](#)" on page 5.

Most virtualized environments use a shared disk subsystem assuming that each application will have bursts of I/O without a sustained high I/O throughput. OV3600 requires a continuous sustained high data I/O rate.



NOTE

Alcatel-Lucent recommends a 20% increase buffer for virtual environments. Ensure you allocate enough extra disk space for the OS and swap when partitioning the virtual disk.

Master Console

Table 5: *Master Console Specifications*

Environment Size	CPU Class	Clock Speed (GHz)	CPUs	Total Cores	Memory	Disk Subsystem
Small (2-3 servers)	Intel Xeon E5-2640	2.5	1	6	48GB	6x 146GB 15k RAID 10 (438GB usable disk space)
Large (>3 servers)	Dual Intel Xeon E5-2640	2.5	2	12	80GB	8x 146GB 15k RAID 10 (584GB usable disk space)

Failover Server

The Failover server should be at least as powerful as the most powerful OV3600 server that it monitors to ensure smooth operation in a failover situation.

Contacting Alcatel-Lucent

Please contact your customer service representative or Alcatel-Lucent support if you have questions regarding hardware compatibility or selection.

Table 6: *Contact Information*

Contact Center Online	
Main Site	http://www.alcatel-lucent.com/enterprise
Support Site	https://service.esd.alcatel-lucent.com
Email	esd.support@alcatel-lucent.com
Service & Support Contact Center Telephone	
North America	1-800-995-2696
Latin America	1-877-919-9526
Europe	+800 00200100 (Toll Free) or 1-650-385-2193
Asia Pacific	+65 6240 8484
Worldwide	1-818-878-4507