



### Package Contents

- Access Point
- Power Adapter
- Quick Installation guide
- RJ-45 Ethernet Cable

### Minimum Requirements


- Broadband Internet Service (Cable or DSL Modem)
- Internet Browser (Internet Explorer, Safari, Firefox, Chrome)

### 1. Connecting the Access Point

A. Connect one end of the Ethernet cable into the LAN port of the Access Point and the other end to the Ethernet port on the computer.


B. Connect the Power Adapter to the DC-IN port of the Access Point and plug the other end in to an electrical outlet.

**Note:** The Access Point supports both IEEE 802.3at PoE (Power over Ethernet) or the included power adapter. You may use either one as the power source. DO NOT use both at the same time.




### 2. IP Address Configuration

**A.** Once your computer is on, ensure that your TCP/IP is set to On or Enabled. Open Network Connections and then click Local Area Connection. Select Internet Protocol Version 4 (TCP/IPv4).




**B.** If your PC is already on a network, ensure that you have set it to a Static IP Address on the interface. (Example: 192.168.1.10 and the Subnet Mask address as 255.255.255.0.)






### 3. Access Point Setup

**A.** To configure the Access Point, open a web browser. In the address bar of the web browser, enter 192.168.1.1 and hit enter.



**B.** A login screen will appear. By default, the username of the Access Point is admin and the password is admin. Enter the current username and password of the Access Point and then click Login.



### 4. Switching Modes

**A.** This device can operate in the following modes: Access Point, WDS AP and WDS Bridge.

**B.** Select the Operation Mode under “Network”, “Wireless” tab.

