

# Ruckus ZoneDirector 10.4.1 SNMP Reference Guide

Supporting ZoneDirector 10.4.1

# Copyright, Trademark and Proprietary Rights Information

© 2020 CommScope, Inc. All rights reserved.

No part of this content may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from CommScope, Inc. and/or its affiliates ("CommScope"). CommScope reserves the right to revise or change this content from time to time without obligation on the part of CommScope to provide notification of such revision or change.

## Export Restrictions

These products and associated technical data (in print or electronic form) may be subject to export control laws of the United States of America. It is your responsibility to determine the applicable regulations and to comply with them. The following notice is applicable for all products or technology subject to export control:

*These items are controlled by the U.S. Government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations.*

## Disclaimer

THIS CONTENT AND ASSOCIATED PRODUCTS OR SERVICES ("MATERIALS"), ARE PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, COMMSCOPE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, NON-INFRINGEMENT, FREEDOM FROM COMPUTER VIRUS, AND WARRANTIES ARISING FROM COURSE OF DEALING OR COURSE OF PERFORMANCE. CommScope does not represent or warrant that the functions described or contained in the Materials will be uninterrupted or error-free, that defects will be corrected, or are free of viruses or other harmful components. CommScope does not make any warranties or representations regarding the use of the Materials in terms of their completeness, correctness, accuracy, adequacy, usefulness, timeliness, reliability or otherwise. As a condition of your use of the Materials, you warrant to CommScope that you will not make use thereof for any purpose that is unlawful or prohibited by their associated terms of use.

## Limitation of Liability

IN NO EVENT SHALL COMMSCOPE, COMMSCOPE AFFILIATES, OR THEIR OFFICERS, DIRECTORS, EMPLOYEES, AGENTS, SUPPLIERS, LICENSORS AND THIRD PARTY PARTNERS, BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER, EVEN IF COMMSCOPE HAS BEEN PREVIOUSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, WHETHER IN AN ACTION UNDER CONTRACT, TORT, OR ANY OTHER THEORY ARISING FROM YOUR ACCESS TO, OR USE OF, THE MATERIALS. Because some jurisdictions do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of liability for consequential or incidental damages, some of the above limitations may not apply to you.

## Trademarks

ARRIS, the ARRIS logo, COMMSCOPE, RUCKUS, RUCKUS WIRELESS, the Ruckus logo, the Big Dog design, BEAMFLEX, CHANNELFLY, FASTIRON, ICX, SMARTCELL and UNLEASHED are trademarks of CommScope, Inc. and/or its affiliates. Wi-Fi Alliance, Wi-Fi, the Wi-Fi logo, Wi-Fi Certified, the Wi-Fi CERTIFIED logo, Wi-Fi Protected Access, the Wi-Fi Protected Setup logo, Wi-Fi Protected Setup, Wi-Fi Multimedia and WPA2 and WMM are trademarks or registered trademarks of Wi-Fi Alliance. All other trademarks are the property of their respective owners.

# Contents

---

<b>Preface.....</b>	<b>9</b>
Document Conventions.....	9
Notes, Cautions, and Safety Warnings.....	9
Command Syntax Conventions.....	9
Document Feedback.....	10
RUCKUS Product Documentation Resources.....	10
Online Training Resources.....	10
Contacting RUCKUS Customer Services and Support.....	11
What Support Do I Need?.....	11
Open a Case.....	11
Self-Service Resources.....	11
<b>About This Guide.....</b>	<b>13</b>
Introduction.....	13
Related Documentation.....	13
<b>Standard MIBs.....</b>	<b>15</b>
Standard MIBs That ZoneDirector Supports.....	15
<b>Events and Traps.....</b>	<b>17</b>
Event MIBs Overview.....	17
ZoneDirector Event MIB Group.....	17
ruckusZDEventAPJoinTrap.....	17
ruckusZDEventSSIDSpoofTrap.....	18
ruckusZDEventMACSpoofTrap.....	18
ruckusZDEventRogueAPTrap.....	18
ruckusZDEventAPLostTrap.....	19
ruckusZDEventAPLostHeartbeatTrap.....	19
ruckusZDEventClientAuthFailBlockTrap.....	20
ruckusZDEventAPResetTrap.....	20
ruckusZDEventIPChangeTrap.....	21
ruckusZDEventSystemColdStartTrap.....	21
ruckusZDEventAPChannelChangeTrap.....	22
ruckusZDEventRadiusAuthUnavailableTrap.....	22
ruckusZDEventRadiusAcctUnavailableTrap.....	23
ruckusZDEventClientJoinFailAPBusyTrap.....	23
ruckusZDEventInterferenceADHoc.....	23
ruckusZDEventImageUpgradeFailTrap.....	24
ruckusZDEventHeartbeatTrap.....	24
ruckusZDEventAttackedTrap.....	25
ruckusZDEventSystemWarmStartTrap.....	25
ruckusZDEventInterfereAPTrap.....	26
ruckusZDEventAPSystemColdStartTrap.....	26
ruckusZDEventAPSystemWarmStartTrap.....	27
ruckusZDEventAPSSIDChangedTrap.....	27
ruckusZDEventAPClientExceedValve.....	27
ruckusZDEventAPAvailableStatusTrap.....	28
ruckusZDEventAPWirelessInterfaceFaultTrap.....	28

ruckusZDEventSystemCpuUtilExceedValve.....	29
ruckusZDEventSystemMemUtilExceedValve.....	29
ruckusZDEventSystemBandwidthUtilExceedValve.....	30
ruckusZDEventSystemDropPacketRateExceedValve.....	30
ruckusZDEventAPSyncTimeFail.....	31
ruckusZDEventSystemCpuUtilClrWarn.....	31
ruckusZDEventSystemMemUtilClrwarn.....	31
ruckusZDEventClientJoin.....	32
ruckusZDEventClientJoinFailed.....	32
ruckusZDEventClientJoinFailedAPBusy.....	33
ruckusZDEventClientDisconnect.....	33
ruckusZDEventClientRoamOut.....	34
ruckusZDEventClientRoamIn.....	34
ruckusZDEventClientAuthFailed.....	35
ruckusZDEventClientAuthorizationFailed.....	36
ruckusZDEventAPCPUvalve.....	36
ruckusZDEventAPMEMvalve.....	37
ruckusZDEventAPCPUvalveClrwarn.....	37
ruckusZDEventAPMEMvalveClrwarn.....	37
ruckusZDEventAPNumStaExceedValveClrwarn.....	38
ruckusZDEventDhcpPoolFull.....	38
ruckusZDEventDhcpPoolAbun.....	39
ruckusZDEventSmartRedundancyChangetoActive.....	39
ruckusZDEventSmartRedundancyActiveConnected.....	40
ruckusZDEventSmartRedundancyActiveDisconnected.....	40
ruckusZDEventSmartRedundancyStandbyConnected.....	40
ruckusZDEventSmartRedundancyStandbyDisconnected.....	40
ruckusZDEventLBSAdminEnabled.....	41
ruckusZDEventLBSAdminDisabled.....	41
ruckusZDEventLBSZDLSConnectionUp.....	41
ruckusZDEventLBSZDLSConnectionDown.....	41
ruckusZDEventLBSReceiveCMDFootfall.....	42
ruckusZDEventLBSReceiveCMDCalibration.....	42
Ruckus ZD Event Objects.....	42
ruckusZDEventSerial.....	42
ruckusZDEventNEID.....	43
ruckusZDEventSeverity.....	43
ruckusZDEventType.....	43
ruckusZDEventTime.....	43
ruckusZDEventStatus.....	44
ruckusZDEventTitle.....	44
ruckusZDEventContent.....	44
ruckusZDEventClientMacAddr.....	44
ruckusZDEventAPMacAddr.....	45
ruckusZDEventRogueMacAddr.....	45
ruckusZDEventSSID.....	45
ruckusZDEventChannel.....	45
ruckusZDEventReason.....	46
ruckusZDEventIpAddr.....	46
AP and Client Event MIB Group.....	46

AP/Client Event Traps.....	46
AP/Client Event Objects.....	48
ZD Event Trap Switch Commands.....	48
ruckusZDEventAPJoinTrapSwitchCmd.....	48
ruckusZDEventSSIDSpoofTrapSwitchCmd.....	49
ruckusZDEventMACSpoofTrapSwitchCmd.....	49
ruckusZDEventRogueAPTrapSwitchCmd.....	49
ruckusZDEventAPLostTrapSwitchCmd.....	49
ruckusZDEventAPLostTrapSwitchCmd.....	50
ruckusZDEventAPLostHeartbeatTrapSwitchCmd.....	50
ruckusZDEventClientAuthFailBlockTrapSwitchCmd.....	50
ruckusZDEventAPResetTrapSwitchCmd.....	50
ruckusZDEventIPChangeSwitchCmd.....	51
ruckusZDEventSystemColdStartTrapSwitchCmd.....	51
ruckusZDEventAPChannelChangeTrapSwitchCmd.....	51
ruckusZDEventRadiusAuthUnavailableTrapSwitchCmd.....	51
ruckusZDEventRadiusAcctUnavailableTrapSwitchCmd.....	52
ruckusZDEventClientJoinFailAPBusyTrapSwitchCmd.....	52
ruckusZDEventInterferenceAdHocTrapSwitchCmd.....	52
ruckusZDEventImageUpgradeFailTrapSwitchCmd.....	52
ruckusZDEventHeartbeatTrapSwitchCmd.....	53
ruckusZDEventAttackedTrapSwitchCmd.....	53
ruckusZDEventSystemWarmStartTrapSwitchCmd.....	53
ruckusZDEventInterfereAPTrapSwitchCmd.....	53
ruckusZDEventAPSystemColdStartTrapSwitchCmd.....	54
ruckusZDEventAPSystemWarmStartTrapSwitchCmd.....	54
ruckusZDEventAPSSIDChangedTrapSwitchCmd.....	54
ruckusZDEventAPClientExceedValveTrapSwitchCmd.....	54
ruckusZDEventAPWirelessInterfaceFaultTrapSwitchCmd.....	55
ruckusZDEventSystemCpuUtilExceedValveTrapSwitchCmd.....	55
ruckusZDEventSystemMemUtilExceedValveTrapSwitchCmd.....	55
ruckusZDEventSystemBandwidthUtilExceedValveTrapSwitchCmd.....	55
ruckusZDEventSystemDropPacketRateExceedValveTrapSwitchCmd.....	56
ruckusZDEventAPSyncTimeFailTrapSwitchCmd.....	56
ruckusZDEventSystemCpuUtilClrWarnTrapSwitchCmd.....	56
ruckusZDEventSystemMemUtilClrwarnTrapSwitchCmd.....	56
ruckusZDEventClientJoinTrapSwitchCmd.....	57
ruckusZDEventClientJoinFailedTrapSwitchCmd.....	57
ruckusZDEventClientJoinFailedAPBusyTrapSwitchCmd.....	57
ruckusZDEventClientDisconnectTrapSwitchCmd.....	57
ruckusZDEventClientRoamOutTrapSwitchCmd.....	58
ruckusZDEventClientRoamInTrapSwitchCmd.....	58
ruckusZDEventClientAuthFailedTrapSwitchCmd.....	58
ruckusZDEventClientAuthorizationFailedTrapSwitchC.....	58
ruckusZDEventAPCPUvalveTrapSwitchCmd.....	59
ruckusZDEventAPMEMvalveTrapSwitchCmd.....	59
ruckusZDEventAPCPUvalveClrwarnTrapSwitchCmd.....	59
ruckusZDEventAPMEMvalveClrwarnTrapSwitchCmd.....	59
ruckusZDEventAPNumStaExceedValveClrwarnTrapSwitchCmd.....	60
ruckusZDEventDhcpPoolFullTrapSwitchCmd.....	60

ruckusZDEventDhcpPoolAbunTrapSwitchCmd.....	60
ruckusZDEventSmartRedundancyChangetoActiveTrapSwitchCmd.....	60
ruckusZDEventSmartRedundancyActiveConnectedTrapSwitchCmd.....	61
ruckusZDEventSmartRedundancyActiveDisconnectedTrapSwitchCmd.....	61
ruckusZDEventSmartRedundancyStandbyConnectedTrapSwitchCmd.....	61
ruckusZDEventSmartRedundancyStandbyDisconnectedTrapSwitchCmd.....	61
ruckusZDEventLBSAdminEnabledTrapSwitchCmd.....	62
ruckusZDEventLBSAdminDisabledTrapSwitchCmd.....	62
ruckusZDEventLBSZDLSConnectionUpTrapSwitchCmd.....	62
ruckusZDEventLBSZDLSConnectionUpTrapSwitchCmd.....	62
ruckusZDEventLBSSReceiveCMDFootfallTrapSwitchCmd.....	63
ruckusZDEventLBSSReceiveCMDCalibrationTrapSwitchCmd.....	63
ruckusZDEventALLEventTrapSwitchCmd.....	63
<b>ZoneDirector System MIBs.....</b>	<b>65</b>
ZoneDirector System MIBs Overview.....	65
System Info MIBs.....	65
Expanded System Info MIBs.....	65
System IP Table MIBs.....	67
System Services MIBs.....	67
System Load Balancing Info MIBs.....	69
System Statistics MIBs.....	69
ZD Ethernet Info MIBs.....	70
<b>Ruckus Product MIBs.....</b>	<b>73</b>
Ruckus Product MIBs Overview.....	73
Ruckus Wireless Router Product MIBs.....	73
Ruckus Wireless Adapter Product MIBs.....	73
Ruckus Wireless Metro Product MIBs.....	73
Ruckus Wireless Hotzone Product MIBs.....	74
Ruckus Controller Product MIBs.....	79
<b>ZoneDirector WLAN MIBs.....</b>	<b>81</b>
ZoneDirector WLAN MIBs Overview.....	81
WLAN Info MIBs.....	81
WLAN AP Info MIBs.....	83
WLAN AP Radio Stats MIBs.....	86
WLAN VAP Table MIBs.....	87
WLAN Interface Table MIBs.....	88
WLAN AP Ethernet Status Table MIBs.....	90
WLAN Station Info MIBs.....	90
WLAN Rogue Info MIBs.....	92
<b>ZoneDirector WLAN Configuration MIBs.....</b>	<b>93</b>
ZoneDirector WLAN Configuration MIBs Overview.....	93
WLAN Configuration MIBs.....	93
<b>ZoneDirector AAA Configuration MIBs.....</b>	<b>99</b>
ZoneDirector AAA Configuration MIBs Overview.....	99
<b>ZoneDirector AP Configuration MIBs.....</b>	<b>101</b>
ZoneDirector AP Configuration MIBs Overview.....	101
AP Configuration MIBs.....	101

AP LBS Info MIBs.....	103
<b>Appendix - Changes in This Version.....</b>	<b>105</b>
MIB Changes in 10.4.1.....	105
ZoneDirector SNMP MIB Changes.....	105
ZD Products MIB Changes.....	105
ZD WLAN MIB Changes.....	105



# Preface

• Document Conventions.....	9
• Command Syntax Conventions.....	9
• Document Feedback.....	10
• RUCKUS Product Documentation Resources.....	10
• Online Training Resources.....	10
• Contacting RUCKUS Customer Services and Support.....	11

## Document Conventions

The following table lists the text conventions that are used throughout this guide.

**TABLE 1** Text Conventions

Convention	Description	Example
monospace	Identifies command syntax examples	device (config) # interface ethernet 1/1/6
<b>bold</b>	User interface (UI) components such as screen or page names, keyboard keys, software buttons, and field names	On the <b>Start</b> menu, click <b>All Programs</b> .
<i>italics</i>	Publication titles	Refer to the <i>RUCKUS Small Cell Release Notes</i> for more information.

## Notes, Cautions, and Safety Warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

### NOTE

A NOTE provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

### ATTENTION

An ATTENTION statement indicates some information that you must read before continuing with the current action or task.



### CAUTION

A CAUTION statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



### DANGER

A DANGER statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

## Command Syntax Conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
<b>bold</b> text	Identifies command names, keywords, and command options.

## Preface

Document Feedback

Convention	Description
<i>italic</i> text	Identifies a variable.
[ ]	Syntax components displayed within square brackets are optional.
	Default responses to system prompts are enclosed in square brackets.
{x   y   z}	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
x   y	A vertical bar separates mutually exclusive elements.
<>	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, member[member...].
\	Indicates a “soft” line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

## Document Feedback

RUCKUS is interested in improving its documentation and welcomes your comments and suggestions.

You can email your comments to RUCKUS at [#Ruckus-Docs@commscope.com](mailto:#Ruckus-Docs@commscope.com).

When contacting us, include the following information:

- Document title and release number
- Document part number (on the cover page)
- Page number (if appropriate)

For example:

- RUCKUS SmartZone Upgrade Guide, Release 5.0
- Part number: 800-71850-001 Rev A
- Page 7

## RUCKUS Product Documentation Resources

Visit the RUCKUS website to locate related documentation for your product and additional RUCKUS resources.

Release Notes and other user documentation are available at <https://support.ruckuswireless.com/documents>. You can locate the documentation by product or perform a text search. Access to Release Notes requires an active support contract and a RUCKUS Support Portal user account. Other technical documentation content is available without logging in to the RUCKUS Support Portal.

White papers, data sheets, and other product documentation are available at <https://www.ruckuswireless.com>.

## Online Training Resources

To access a variety of online RUCKUS training modules, including free introductory courses to wireless networking essentials, site surveys, and products, visit the RUCKUS Training Portal at <https://training.ruckuswireless.com>.

# Contacting RUCKUS Customer Services and Support

The Customer Services and Support (CSS) organization is available to provide assistance to customers with active warranties on their RUCKUS products, and customers and partners with active support contracts.

For product support information and details on contacting the Support Team, go directly to the RUCKUS Support Portal using <https://support.ruckuswireless.com>, or go to <https://www.ruckuswireless.com> and select **Support**.

## What Support Do I Need?

Technical issues are usually described in terms of priority (or severity). To determine if you need to call and open a case or access the self-service resources, use the following criteria:

- Priority 1 (P1)—Critical. Network or service is down and business is impacted. No known workaround. Go to the **Open a Case** section.
- Priority 2 (P2)—High. Network or service is impacted, but not down. Business impact may be high. Workaround may be available. Go to the **Open a Case** section.
- Priority 3 (P3)—Medium. Network or service is moderately impacted, but most business remains functional. Go to the **Self-Service Resources** section.
- Priority 4 (P4)—Low. Requests for information, product documentation, or product enhancements. Go to the **Self-Service Resources** section.

## Open a Case

When your entire network is down (P1), or severely impacted (P2), call the appropriate telephone number listed below to get help:

- Continental United States: 1-855-782-5871
- Canada: 1-855-782-5871
- Europe, Middle East, Africa, Central and South America, and Asia Pacific, toll-free numbers are available at <https://support.ruckuswireless.com/contact-us> and Live Chat is also available.
- Worldwide toll number for our support organization. Phone charges will apply: +1-650-265-0903

We suggest that you keep a physical note of the appropriate support number in case you have an entire network outage.

## Self-Service Resources

The RUCKUS Support Portal at <https://support.ruckuswireless.com> offers a number of tools to help you to research and resolve problems with your RUCKUS products, including:

- Technical Documentation—<https://support.ruckuswireless.com/documents>
- Community Forums—<https://forums.ruckuswireless.com/ruckuswireless/categories>
- Knowledge Base Articles—<https://support.ruckuswireless.com/answers>
- Software Downloads and Release Notes—[https://support.ruckuswireless.com/#products\\_grid](https://support.ruckuswireless.com/#products_grid)
- Security Bulletins—<https://support.ruckuswireless.com/security>

Using these resources will help you to resolve some issues, and will provide TAC with additional data from your troubleshooting analysis if you still require assistance through a support case or RMA. If you still require help, open and manage your case at [https://support.ruckuswireless.com/case\\_management](https://support.ruckuswireless.com/case_management).



# About This Guide

---

• <a href="#">Introduction</a>	13
• <a href="#">Related Documentation</a>	13

## Introduction

This *Reference Guide* provides information on the Ruckus ZoneDirector Simple Network Management Protocol (SNMP) Management Information Base objects (MIBs) that ZoneDirector supports.

**NOTE**

For information on how to enable SNMP trap delivery and configure other SNMP settings using the ZoneDirector web interface, refer to the *ZoneDirector User Guide*.

Most user guides and release notes are available in Adobe Acrobat Reader Portable Document Format (PDF) or HTML on the Ruckus Support site:

<https://support.ruckuswireless.com/documents>.

## Related Documentation

In addition to this *Reference Guide*, each ZoneDirector documentation set includes the following:

- *User Guide*: Provides instructions for setup, configuration and management of ZoneDirector and Ruckus access points using the web browser based user interface.
- *Release Notes*: Provide information about the current software release, including new features, enhancements, upgrade information and known issues.
- *Online Help*: Provides instructions for performing tasks using the ZoneDirector web interface. The online help is accessible from the web interface and is searchable.
- *Upgrade Guide*: Provides instructions, product support information, upgrade paths, limitations and related information on upgrading ZoneDirector and its managed access points to the current release.
- *Command Line Interface Reference Guide*: Provides a list of available CLI commands along with their syntax descriptions and usage examples to be used as a reference when administering ZoneDirector via command line.



# Standard MIBs

---

- Standard MIBs That ZoneDirector Supports..... 15

## Standard MIBs That ZoneDirector Supports

ZoneDirector supports standard SNMPv2 MIB objects as defined in RFC 1213.

The following table lists the SNMP standard MIBs that ZoneDirector supports:

Name	OID
system	1.3.6.1.2.1.1
interfaces	1.3.6.1.2.1.2
ip	1.3.6.1.2.1.4
ipAddrTable	1.3.6.1.2.1.4.20
ipRouteTable	1.3.6.1.2.1.4.21
ipForward	1.3.6.1.2.1.4.24
ipv6IpForwarding	1.3.6.1.2.1.4.25
icmp	1.3.6.1.2.1.5
tcp	1.3.6.1.2.1.6
udp	1.3.6.1.2.1.7
snmp	1.3.6.1.2.1.11



# Events and Traps

• Event MIBs Overview.....	17
• ZoneDirector Event MIB Group.....	17
• Ruckus ZD Event Objects.....	42
• AP and Client Event MIB Group.....	46
• ZD Event Trap Switch Commands.....	48

## Event MIBs Overview

This section describes ZoneDirector and AP events and traps that are triggered when an event occurs, along with possible causes for the event and recommended actions to take (if any).

The MIBs described in this section are contained in the RUCKUS-ZD-EVENT-MIB.txt file.

This section is divided into the following subsections:

- [ZoneDirector Event MIB Group](#) on page 17
- [Ruckus ZD Event Objects](#) on page 42
- [AP and Client Event MIB Group](#) on page 46
- [ZD Event Trap Switch Commands](#) on page 48

## ZoneDirector Event MIB Group

The ruckusZDEventTraps MIB tree contains events that trigger SNMP traps to be delivered to an SNMP receiver.

### ruckusZDEventAPJoinTrap

**TABLE 2** ruckusZDEventAPJoinTrap

Name	ruckusZDEventAPJoinTrap
OID	1.3.6.1.4.1.25053.2.2.1.1
Severity	Minor
Status	current
Objects	ruckusZDEventSerial ruckusZDEventNEID ruckusZDEventSeverity ruckusZDEventType ruckusZDEventTime ruckusZDEventStatus ruckusZDEventTitle ruckusZDEventAPMacAddr
Description	Trigger when there is an AP join event. The AP's MAC address is enclosed.
Recommended Actions	None

## Events and Traps

ZoneDirector Event MIB Group

## ruckusZDEventSSIDSpoofTrap

**TABLE 3** ruckusZDEventSSIDSpoofTrap

Name	rickusZDEventSSIDSpoofTrap
OID	1.3.6.1.4.1.25053.2.2.1.2
Severity	Major
Status	current
Objects	rickusZDEventSerial rickusZDEventNEID rickusZDEventSeverity rickusZDEventType rickusZDEventTime rickusZDEventStatus rickusZDEventTitle rickusZDEventSSID
Description	Trigger when a SSID-spoofing rogue AP is detected. The rogue AP's MAC address and SSID are enclosed.
Recommended Actions	Locate the Rogue AP and disconnect it from the network.

## ruckusZDEventMACSpoofTrap

**TABLE 4** ruckusZDEventMACSpoofTrap

Name	rickusZDEventMACSpoofTrap
OID	1.3.6.1.4.1.25053.2.2.1.3
Severity	Major
Status	current
Objects	rickusZDEventSerial, rickusZDEventNEID, rickusZDEventSeverity rickusZDEventType rickusZDEventTime rickusZDEventStatus rickusZDEventTitle rickusZDEventSSID
Description	Trigger when a MAC-spoofing rogue AP is detected. The rogue AP's MAC address and SSID are enclosed.
Recommended Actions	Locate the Rogue AP and disconnect it from the network.

## ruckusZDEventRogueAPTrap

**TABLE 5** ruckusZDEventRogueAPTrap

Name	rickusZDEventRogueAPTrap
OID	1.3.6.1.4.1.25053.2.2.1.4

**TABLE 5** ruckusZDEventRogueAPTrap (continued)

Name	ruckusZDEventRogueAPTrap
Severity	Major
Status	current
Objects	ruckusZDEventSerial, ruckusZEventNEID ruckusZEventSeverity ruckusZEventType ruckusZEventTime ruckusZEventStatus ruckusZEventTitle ruckusZEventSSID
Description	Trigger when a rogue AP is detected. The rogue AP's MAC address and SSID are enclosed.
Recommended Actions	Locate the Rogue AP and disconnect it from the network.

## ruckusZDEventAPLostTrap

**TABLE 6** ruckusZDEventAPLostTrap

Name	ruckusZDEventAPLostTrap
OID	1.3.6.1.4.1.25053.2.2.1.5
Severity	Medium
Status	current
Objects	ruckusZDEventSerial ruckusZEventNEID ruckusZEventSeverity ruckusZEventType ruckusZEventTime ruckusZEventStatus ruckusZEventTitle ruckusZEventAPMacAddr
Description	Trigger when AP lost contact. The AP's MAC address is enclosed.
Recommended Actions	Ensure that the AP's uplink connection (wired or mesh) is available.

## ruckusZDEventAPLostHeartbeatTrap

**TABLE 7** ruckusZDEventAPLostHeartbeatTrap

Name	ruckusZDEventAPLostHeartbeatTrap
OID	1.3.6.1.4.1.25053.2.2.1.6
Severity	Medium
Status	Current
Objects	ruckusZDEventSerial ruckusZEventNEID

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 7** ruckusZDEventAPLostHeartbeatTrap (continued)

Name	rückusZDEventAPLostHeartbeatTrap
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventAPMacAddr
Description	Trigger when AP lost heartbeats. The AP's MAC address is enclosed.
Recommended Actions	Check connection stability between ZD and AP.

## rückusZDEventClientAuthFailBlockTrap

**TABLE 8** ruckusZDEventClientAuthFailBlockTrap

Name	rückusZDEventClientAuthFailBlockTrap
OID	1.3.6.1.4.1.25053.2.2.1.7
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventClientMacAddr rückusZDEventAPMacAddr rückusZDEventSSID
Description	Triggered when a client fails authentication too many times in a row. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	Ensure that the client has proper authentication credentials.

## rückusZDEventAPResetTrap

**TABLE 9** ruckusZDEventAPResetTrap

Name	rückusZDEventAPResetTrap
OID	1.3.6.1.4.1.25053.2.2.1.8
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType

**TABLE 9** ruckusZDEventAPResetTrap (continued)

Name	ruckusZDEventAPResetTrap
	ruckusZDEventTime
	ruckusZDEventStatus
	ruckusZDEventTitle
	ruckusZDEventContent
	ruckusZDEventAPMacAddr
Description	Trigger when AP reboots. The AP's MAC address is enclosed.
Recommended Actions	None.

## ruckusZDEventIPChangeTrap

**TABLE 10** ruckusZDEventIPChangeTrap

Name	ruckusZDEventIPChangeTrap
OID	1.3.6.1.4.1.25053.2.2.1.9
Severity	Medium
Status	current
Objects	ruckusZDEventSerial
	ruckusZDEventNEID
	ruckusZDEventSeverity
	ruckusZDEventType
	ruckusZDEventTime
	ruckusZDEventStatus
	ruckusZDEventTitle
	ruckusZDEventContent
Description	Trigger when IP changes.
Recommended Actions	None.

## ruckusZDEventSystemColdStartTrap

**TABLE 11** ruckusZDEventSystemColdStartTrap

Name	ruckusZDEventSystemColdStartTrap
OID	1.3.6.1.4.1.25053.2.2.1.10
Severity	Major
Status	current
Objects	ruckusZDEventSerial
	ruckusZDEventNEID
	ruckusZDEventSeverity
	ruckusZDEventType
	ruckusZDEventTime
	ruckusZDEventStatus
	ruckusZDEventTitle
	ruckusZDEventContent

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 11** ruckusZDEventSystemColdStartTrap (continued)

Name	rückusZDEventSystemColdStartTrap
Description	Trigger when system performs cold start.
Recommended Actions	None.

## ruckusZDEventAPChannelChangeTrap

**TABLE 12** ruckusZDEventAPChannelChangeTrap

Name	rückusZDEventAPChannelChangeTrap
OID	1.3.6.1.4.1.25053.2.2.1.11
Severity	Minor
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent, rückusZEventAPMacAddr
Description	Trigger when AP channel changes.
Recommended Actions	None.

## ruckusZDEventRadiusAuthUnavailableTrap

**TABLE 13** ruckusZDEventRadiusAuthUnavailableTrap

Name	rückusZDEventRadiusAuthUnavailableTrap
OID	1.3.6.1.4.1.25053.2.2.1.12
Severity	Major
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when RADIUS authentication server unavailable.
Recommended Actions	Check the connectivity between ZoneDirector and the RADIUS server.

## ruckusZDEventRadiusAcctUnavailableTrap

**TABLE 14** ruckusZDEventRadiusAcctUnavailableTrap

Name	rickusZDEventRadiusAcctUnavailableTrap
OID	1.3.6.1.4.1.25053.2.2.1.13
Severity	Major
Status	current
Objects	rickusZDEventSerial
	rickusZDEventNEID
	rickusZDEventSeverity
	rickusZDEventType
	rickusZDEventTime
	rickusZDEventStatus
	rickusZDEventTitle
	rickusZDEventContent
Description	Trigger when RADIUS accounting server unavailable.
Recommended Actions	Check the connectivity between ZoneDirector and the RADIUS server.

## ruckusZDEventClientJoinFailAPBusyTrap

**TABLE 15** ruckusZDEventClientJoinFailAPBusyTrap

Name	rickusZDEventClientJoinFailAPBusyTrap
OID	1.3.6.1.4.1.25053.2.2.1.14
Severity	Medium
Status	current
Objects	rickusZDEventSerial
	rickusZDEventNEID
	rickusZDEventSeverity
	rickusZDEventType
	rickusZDEventTime
	rickusZDEventStatus
	rickusZDEventTitle
	rickusZDEventContent
Description	Trigger when client fails to join because AP is busy.
Recommended Actions	None.

## ruckusZDEventInterferenceADHoc

**TABLE 16** ruckusZDEventInterferenceADHoc

Name	rickusZDEventInterferenceADHoc
OID	1.3.6.1.4.1.25053.2.2.1.15
Severity	Medium
Status	current

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 16** ruckusZDEventInterferenceADHoc (continued)

Name	rückusZDEventInterferenceADHoc
Objects	rückusZDEventSerial
	rückusZDEventNEID
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventContent
Description	Trigger when an interference AD hoc is detected.
Recommended Actions	Locate the origin of the ad hoc network and disconnect it.

## rückusZDEventImageUpgradeFailTrap

**TABLE 17** ruckusZDEventImageUpgradeFailTrap

Name	rückusZDEventImageUpgradeFailTrap
OID	1.3.6.1.4.1.25053.2.2.1.16
Severity	Medium
Status	current
Objects	rückusZDEventSerial
	rückusZDEventNEID
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventContent
Description	Trigger when AP image upgrade fails.
Recommended Actions	Delete the AP from ZoneDirector, factory reset the AP, then let it rejoin and attempt upgrade again.

## rückusZDEventHeartbeatTrap

**TABLE 18** ruckusZDEventHeartbeatTrap

Name	rückusZDEventHeartbeatTrap
OID	1.3.6.1.4.1.25053.2.2.1.22
Severity	Medium
Status	current
Objects	rückusZDEventSerial
	rückusZDEventNEID
	rückusZDEventSeverity
	rückusZDEventType

**TABLE 18** ruckusZDEventHeartbeatTrap (continued)

Name	rückusZDEventHeartbeatTrap
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventContent
Description	Trigger with trap heartbeat sent.
Recommended Actions	None.

## rückusZDEventAttackedTrap

**TABLE 19** rückusZDEventAttackedTrap

Name	rückusZDEventAttackedTrap
OID	1.3.6.1.4.1.25053.2.2.1.24
Severity	Major
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when a malicious attack is detected.
Recommended Actions	Enable Wireless Intrusion Prevention System from the <b>Configure &gt; WIPS</b> page.

## rückusZDEventSystemWarmStartTrap

**TABLE 20** rückusZDEventSystemWarmStartTrap

Name	rückusZDEventSystemWarmStartTrap
OID	1.3.6.1.4.1.25053.2.2.1.25
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when system performs warm start.

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 20** ruckusZDEventSystemWarmStartTrap (continued)

Name	rückusZDEventSystemWarmStartTrap
Recommended Actions	None.

## ruckusZDEventInterfereAPTrap

**TABLE 21** ruckusZDEventInterfereAPTrap

Name	rückusZDEventInterfereAPTrap
OID	1.3.6.1.4.1.25053.2.2.1.26
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZEventTitle rückusZEventContent
Description	Trigger when a rogue AP used same channel with current AP is detected.
Recommended Actions	Locate the rogue AP and disconnect it from the network.

## ruckusZDEventAPSystemColdStartTrap

**TABLE 22** ruckusZDEventAPSystemColdStartTrap

Name	rückusZDEventAPSystemColdStartTrap
OID	1.3.6.1.4.1.25053.2.2.1.31
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZEventTitle rückusZEventContent
Description	Trigger when an AP performs cold start.
Recommended Actions	None.

## ruckusZDEventAPSystemWarmStartTrap

**TABLE 23** ruckusZDEventAPSystemWarmStartTrap

Name	rickusZDEventAPSystemWarmStartTrap
OID	1.3.6.1.4.1.25053.2.2.1.32
Severity	Medium
Status	current
Objects	rickusZDEventSerial
	rickusZDEventNEID
	rickusZDEventSeverity
	rickusZDEventType
	rickusZDEventTime
	rickusZDEventStatus
	rickusZDEventTitle
	rickusZDEventContent
Description	Trigger when an AP performs warm start.
Recommended Actions	None.

## ruckusZDEventAPSSIDChangedTrap

**TABLE 24** ruckusZDEventAPSSIDChangedTrap

Name	rickusZDEventAPSSIDChangedTrap
OID	1.3.6.1.4.1.25053.2.2.1.33
Severity	Medium
Status	current
Objects	rickusZDEventSerial
	rickusZDEventNEID
	rickusZDEventSeverity
	rickusZDEventType
	rickusZDEventTime
	rickusZDEventStatus
	rickusZDEventTitle
	rickusZDEventContent
Description	Trigger when an AP SSID changed.
Recommended Actions	None.

## ruckusZDEventAPClientExceedValve

**TABLE 25** ruckusZDEventAPClientExceedValve

Name	rickusZDEventAPClientExceedValve
OID	1.3.6.1.4.1.25053.2.2.1.34
Severity	Medium
Status	current

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 25** ruckusZDEventAPClientExceedValve (continued)

Name	rückusZDEventAPClientExceedValve
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent rückusZDEventAPMacAddr
Description	Trigger when online client from AP is exceed valve.
Recommended Actions	Reduce clients per AP.

## rückusZDEventAPAvailableStatusTrap

**TABLE 26** ruckusZDEventAPAvailableStatusTrap

Name	rückusZDEventAPAvailableStatusTrap
OID	1.3.6.1.4.1.25053.2.2.1.35
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when AP is available.
Recommended Actions	None.

## rückusZDEventAPWirelessInterfaceFaultTrap

**TABLE 27** ruckusZDEventAPWirelessInterfaceFaultTrap

Name	rückusZDEventAPWirelessInterfaceFaultTrap
OID	1.3.6.1.4.1.25053.2.2.1.36
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType

**TABLE 27** ruckusZDEventAPWirelessInterfaceFaultTrap (continued)

Name	rückusZDEventAPWirelessInterfaceFaultTrap
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventContent
Description	Trigger when AP wireless interface fault occurs.
Recommended Actions	Reboot the AP.

## rückusZDEventSystemCpuUtilExceedValue

**TABLE 28** rückusZDEventSystemCpuUtilExceedValue

Name	rückusZDEventSystemCpuUtilExceedValue
OID	1.3.6.1.4.1.25053.2.2.1.37
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZEventNEID rückusZEventSeverity rückusZEventType rückusZEventTime rückusZEventStatus rückusZEventTitle rückusZEventContent
Description	Trigger when System CPU utilization exceeds specified value.
Recommended Actions	Identify the source of high CPU utilization (clear log files, disable debugging processes, disable Real Time Monitoring, etc.).

## rückusZDEventSystemMemUtilExceedValue

**TABLE 29** rückusZDEventSystemMemUtilExceedValue

Name	rückusZDEventSystemMemUtilExceedValue
OID	1.3.6.1.4.1.25053.2.2.1.38
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZEventNEID rückusZEventSeverity rückusZEventType rückusZEventTime rückusZEventStatus rückusZEventTitle rückusZEventContent

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 29** ruckusZDEventSystemMemUtilExceedValve (continued)

Name	rückusZDEventSystemMemUtilExceedValve
Description	Trigger when system memory utilization exceeds specified value.
Recommended Actions	Identify the source of high memory utilization (clear log files, disable debugging processes, disable Real Time Monitoring, etc.).

## rückusZDEventSystemBandwidthUtilExceedValve

**TABLE 30** ruckusZDEventSystemBandwidthUtilExceedValve

Name	rückusZDEventSystemBandwidthUtilExceedValve
OID	1.3.6.1.4.1.25053.2.2.1.39
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when system bandwidth utilization is exceed valve.
Recommended Actions	Reduce bandwidth utilization or increase bandwidth capacity.

## rückusZDEventSystemDropPacketRateExceedValve

**TABLE 31** ruckusZDEventSystemDropPacketRateExceedValve

Name	rückusZDEventSystemDropPacketRateExceedValve
OID	1.3.6.1.4.1.25053.2.2.1.40
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when system drop packet rate exceeds specified value.
Recommended Actions	None.

## ruckusZDEventAPSyncTimeFail

**TABLE 32** ruckusZDEventAPSyncTimeFail

Name	ruckusZDEventAPSyncTimeFail
OID	1.3.6.1.4.1.25053.2.2.1.41
Severity	Medium
Status	current
Objects	ruckusZDEventSerial
	ruckusZDEventNEID
	ruckusZDEventSeverity
	ruckusZDEventType
	ruckusZDEventTime
	ruckusZDEventStatus
	ruckusZDEventTitle
	ruckusZDEventContent
Description	Trigger when AP clock synchronization with controller fails.
Recommended Actions	None.

## ruckusZDEventSystemCpuUtilClrWarn

**TABLE 33** ruckusZDEventSystemCpuUtilClrWarn

Name	ruckusZDEventSystemCpuUtilClrWarn
OID	1.3.6.1.4.1.25053.2.2.1.42
Severit	Medium
Status	current
Objects	ruckusZDEventSerial
	ruckusZDEventNEID
	ruckusZDEventSeverity
	ruckusZDEventType
	ruckusZDEventTime
	ruckusZDEventStatus
	ruckusZDEventTitle
	ruckusZDEventContent
Description	Trigger when system CPU utilization is under the specifiedvalue.
Recommended Actions	None.

## ruckusZDEventSystemMemUtilClrwarn

**TABLE 34** ruckusZDEventSystemMemUtilClrwarn

Name	ruckusZDEventSystemMemUtilClrwarn
OID	1.3.6.1.4.1.25053.2.2.1.43
Severity	Medium
Status	current

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 34** ruckusZDEventSystemMemUtilCirwarn (continued)

Name	rückusZDEventSystemMemUtilCirwarn
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when system memory utilization is under the specified value.
Recommended Actions	None.

## rückusZDEventClientJoin

**TABLE 35** ruckusZDEventClientJoin

Name	rückusZDEventClientJoin
OID	1.3.6.1.4.1.25053.2.2.1.60
Severity	Minor
Status	current
Objects	rückusZDEventSerial, rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventClientMacAddr, rückusZDEventAPMacAddr, rückusZDEventSSID
Description	Triggered when a client joins an AP successfully. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	None

## rückusZDEventClientJoinFailed

**TABLE 36** ruckusZDEventClientJoinFailed

Name	rückusZDEventClientJoinFailed
OID	1.3.6.1.4.1.25053.2.2.1.61
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID

**TABLE 36** ruckusZDEventClientJoinFailed (continued)

Name	rückusZDEventClientJoinFailed
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventClientMacAddr
	rückusZDEventAPMacAddr
	rückusZDEventSSID
	rückusZDEventReason
Description	Triggered when a client attempt to join an AP fails. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	Examine trap contents to determine cause of client join failure.

## rückusZDEventClientJoinFailedAPBusy

**TABLE 37** ruckusZDEventClientJoinFailedAPBusy

Name	rückusZDEventClientJoinFailedAPBusy
OID	1.3.6.1.4.1.25053.2.2.1.62
Severity	Medium
Status	current
Objects	rückusZDEventSerial
	rückusZDEventNEID
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventClientMacAddr
	rückusZDEventAPMacAddr
	rückusZDEventSSID
Description	Trigger when a client attempt to join an AP fails because AP is too busy. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	None

## rückusZDEventClientDisconnect

**TABLE 38** ruckusZDEventClientDisconnect

Name	rückusZDEventClientDisconnect
OID	1.3.6.1.4.1.25053.2.2.1.63
Severity	Medium
Status	current

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 38** ruckusZDEventClientDisconnect (continued)

Name	rückusZDEventClientDisconnect
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventClientMacAddr rückusZDEventAPMacAddr rückusZDEventSSID
Description	Triggered when a client disconnect from AP. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	None

## rückusZDEventClientRoamOut

**TABLE 39** ruckusZDEventClientRoamOut

Name	rückusZDEventClientRoamOut
OID	1.3.6.1.4.1.25053.2.2.1.64
Severity	Minor
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventClientMacAddr, rückusZDEventAPMacAddr rückusZDEventSSID
Description	Triggered when a client roams out from AP. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	None

## rückusZDEventClientRoamIn

**TABLE 40** ruckusZDEventClientRoamIn

Name	rückusZDEventClientRoamIn
OID	1.3.6.1.4.1.25053.2.2.1.65
Status	current

**TABLE 40** ruckusZDEventClientRoamIn (continued)

Name	rückusZDEventClientRoamIn
Severity	Minor
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventClientMacAddr rückusZDEventAPMacAddr rückusZDEventSSID
Description	Triggered when a client roams in from AP. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	None

## rückusZDEventClientAuthFailed

**TABLE 41** rückusZDEventClientAuthFailed

Name	rückusZDEventClientAuthFailed
OID	1.3.6.1.4.1.25053.2.2.1.66
Severity	Medium
Status	current
Objects	rückusZDEventSerial rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventClientMacAddr rückusZDEventAPMacAddr rückusZDEventSSID rückusZDEventReason
Description	Triggered when a client authentication failure occurs. The failure reason, client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	Check the client authentication credentials.

## Events and Traps

ZoneDirector Event MIB Group

## ruckusZEventClientAuthorizationFailed

**TABLE 42** ruckusZEventClientAuthorizationFailed

Name	rickusZEventClientAuthorizationFailed
OID	1.3.6.1.4.1.25053.2.2.1.67
Severity	Medium
Status	current
Objects	rickusZEventSerial rickusZEventNEID rickusZEventSeverity rickusZEventType rickusZEventTime rickusZEventStatus rickusZEventTitle rickusZEventClientMacAddr rickusZEventAPMacAddr rickusZEventSSID
Description	Triggered when a client has no authorization to join an AP. The client's MAC address, AP's MAC address and SSID are enclosed.
Recommended Actions	None

## ruckusZEventAPCPUvalve

**TABLE 43** ruckusZEventAPCPUvalve

Name	rickusZEventAPCPUvalve
OID	1.3.6.1.4.1.25053.2.2.1.83
Severity	Medium
Status	current
Objects	rickusZEventSerial rickusZEventNEID rickusZEventSeverity rickusZEventType rickusZEventTime rickusZEventStatus rickusZEventTitle rickusZEventContent rickusZEventAPMacAddr
Description	Triggered when AP CPU utilization exceeds value.
Recommended Actions	None

## ruckusZEventAPMEMvalve

**TABLE 44** ruckusZEventAPMEMvalve

Name	ruckusZEventAPMEMvalve
OID	1.3.6.1.4.1.25053.2.2.1.84
Severity	Medium
Status	current
Objects	ruckusZEventSerial
	ruckusZEventNEID
	ruckusZEventSeverity
	ruckusZEventType
	ruckusZEventTime
	ruckusZEventStatus
	ruckusZEventTitle
	ruckusZEventContent
	ruckusZEventAPMacAddr
Description	Triggered when AP memory utilization exceeds value.
Recommended Actions	None

## ruckusZEventAPCPUvalveClrwarn

**TABLE 45** ruckusZEventAPCPUvalveClrwarn

Name	ruckusZEventAPCPUvalveClrwarn
OID	1.3.6.1.4.1.25053.2.2.1.85
Severity	Minor
Status	current
Objects	ruckusZEventSerial
	ruckusZEventNEID
	ruckusZEventSeverity
	ruckusZEventType
	ruckusZEventTime
	ruckusZEventStatus
	ruckusZEventTitle
	ruckusZEventContent
	ruckusZEventAPMacAddr
Description	Trigger when AP CPU utilization is under the value.
Recommended Actions	None

## ruckusZEventAPMEMvalveClrwarn

**TABLE 46** ruckusZEventAPMEMvalveClrwarn

Name	ruckusZEventAPMEMvalveClrwarn
OID	1.3.6.1.4.1.25053.2.2.1.86

## Events and Traps

ZoneDirector Event MIB Group

**TABLE 46** ruckusZDEventAPMEMvalveClrwarn (continued)

Name	rückusZDEventAPMEMvalveClrwarn
Severity	Minor
Status	current
Objects	rückusZDEventSerial
	rückusZDEventNEID
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventContent
	rückusZDEventAPMacAddr
Description	Trigger when AP CPU memory is under the value.
Recommended Actions	None

## rückusZDEventAPNumStaExceedValveClrwarn

**TABLE 47** ruckusZDEventAPNumStaExceedValveClrwarn

Name	rückusZDEventAPNumStaExceedValveClrwarn
OID	1.3.6.1.4.1.25053.2.2.1.87
Severity	Minor
Status	current
Objects	rückusZDEventSerial
	rückusZDEventNEID
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventContent
	rückusZDEventAPMacAddr
Description	Trigger when online client warning is cleared.
Recommended Actions	None

## rückusZDEventDhcpPoolFull

**TABLE 48** ruckusZDEventDhcpPoolFull

Name	rückusZDEventDhcpPoolFull
OID	1.3.6.1.4.1.25053.2.2.1.88
Severity	Medium
Status	current
Objects	rückusZDEventSerial

**TABLE 48** ruckusZDEventDhcpPoolFull (continued)

Name	rückusZDEventDhcpPoolFull
	rückusZDEventNEID
	rückusZDEventSeverity
	rückusZDEventType
	rückusZDEventTime
	rückusZDEventStatus
	rückusZDEventTitle
	rückusZDEventContent
Description	Trigger when DHCP pool is full.
Recommended Actions	None

## rückusZDEventDhcpPoolAbun

**TABLE 49** ruckusZDEventDhcpPoolAbun

Name	rückusZDEventDhcpPoolAbun
OID	1.3.6.1.4.1.25053.2.2.1.89
Severity	Minor
Status	current
Objects	rückusZDEventSerial, rückusZDEventNEID rückusZDEventSeverity rückusZDEventType rückusZDEventTime rückusZDEventStatus rückusZDEventTitle rückusZDEventContent
Description	Trigger when DHCP pool is abundant.
Recommended Actions	None

## rückusZDEventSmartRedundancyChangetoActive

**TABLE 50** ruckusZDEventSmartRedundancyChangetoActive

Name	rückusZDEventSmartRedundancyChangetoActive
OID	1.3.6.1.4.1.25053.2.2.1.100
Severity	Medium
Status	current
Objects	rückusZDEventIPAddr
Description	[Smart Redundancy] Peer ZoneDirector peer IP not found, system changed to active state.
Recommended Actions	None

## Events and Traps

ZoneDirector Event MIB Group

## ruckusZDEventSmartRedundancyActiveConnected

**TABLE 51** ruckusZDEventSmartRedundancyActiveConnected

Name	rickusZDEventSmartRedundancyActiveConnected
OID	1.3.6.1.4.1.25053.2.2.1.101
Severity	Minor
Status	current
Objects	rickusZDEventIPAddr
Description	[Smart Redundancy] connected, system is in active state.
Recommended Actions	None

## ruckusZDEventSmartRedundancyActiveDisconnected

**TABLE 52** ruckusZDEventSmartRedundancyActiveDisconnected

Name	rickusZDEventSmartRedundancyActiveDisconnected
OID	1.3.6.1.4.1.25053.2.2.1.102
Severity	Medium
Status	current
Objects	rickusZDEventIPAddr
Description	[Smart Redundancy] disconnected, system is in active state.
Recommended Actions	None

## ruckusZDEventSmartRedundancyStandbyConnected

**TABLE 53** ruckusZDEventSmartRedundancyStandbyConnected

Name	rickusZDEventSmartRedundancyStandbyConnected
OID	1.3.6.1.4.1.25053.2.2.1.103
Severity	Medium
Status	current
Objects	rickusZDEventIPAddr
Description	[Smart Redundancy] connected, system is in standby state.
Recommended Actions	None

## ruckusZDEventSmartRedundancyStandbyDisconnected

**TABLE 54** ruckusZDEventSmartRedundancyStandbyDisconnected

Name	rickusZDEventSmartRedundancyStandbyDisconnected
OID	1.3.6.1.4.1.25053.2.2.1.104
Severity	Medium
Status	current
Objects	rickusZDEventIPAddr
Description	[Smart Redundancy] disconnected, system is in standby state.

**TABLE 54** ruckusZDEventSmartRedundancyStandbyDisconnected (continued)

Name	rückusZDEventSmartRedundancyStandbyDisconnected
Recommended Actions	None

## rückusZDEventLBSAdminEnabled

**TABLE 55** rückusZDEventLBSAdminEnabled

Name	rückusZDEventLBSAdminEnabled
OID	1.3.6.1.4.1.25053.2.2.1.120
Severity	Medium
Status	current
Objects	rückusZDEventIPAddr
Description	[LBS] Admin enables location database server.
Recommended Actions	None

## rückusZDEventLBSAdminDisabled

**TABLE 56** rückusZDEventLBSAdminDisabled

Name	rückusZDEventLBSAdminDisabled
OID	1.3.6.1.4.1.25053.2.2.1.121
Severity	Medium
Status	current
Objects	rückusZDEventIPAddr
Description	[LBS] Admin disables location database server.
Recommended Actions	None

## rückusZDEventLBSZDLSConnectionUp

**TABLE 57** rückusZDEventLBSZDLSConnectionUp

Name	rückusZDEventLBSZDLSConnectionUp
OID	1.3.6.1.4.1.25053.2.2.1.122
Severity	Medium
Status	current
Objects	rückusZDEventIPAddr
Description	[LBS] Connection between ZD and LS server up
Recommended Actions	None

## rückusZDEventLBSZDLSConnectionDown

**TABLE 58** rückusZDEventLBSZDLSConnectionDown

Name	rückusZDEventLBSZDLSConnectionDown
OID	1.3.6.1.4.1.25053.2.2.1.123

## Events and Traps

### Ruckus ZD Event Objects

**TABLE 58** ruckusZDEventLBSZDLSConnectionDown (continued)

Name	rückusZDEventLBSZDLSConnectionDown
Severity	Medium
Status	current
Objects	rückusZDEventIPAddr
Description	[LBS] Connection between ZD and LS server down
Recommended Actions	None

## rückusZDEventLBSReceiveCMDFootfall

**TABLE 59** ruckusZDEventLBSReceiveCMDFootfall

Name	rückusZDEventLBSReceiveCMDFootfall
OID	1.3.6.1.4.1.25053.2.2.1.124
Severity	Medium
Status	current
Objects	rückusZDEventIPAddr
Description	[LBS] ZD receives passive tracking footfall command from LS.
Recommended Actions	None

## rückusZDEventLBSReceiveCMDCalibration

**TABLE 60** ruckusZDEventLBSReceiveCMDCalibration

Name	rückusZDEventLBSReceiveCMDCalibration
OID	1.3.6.1.4.1.25053.2.2.1.125
Severity	Medium
Status	current
Objects	rückusZDEventIPAddr
Description	[LBS] ZD receives passive tracking calibration command from LS.
Recommended Actions	None

## Ruckus ZD Event Objects

The objects in the following section are contained in the ruckusZDEventObjects tree and are used in traps to specify details for the trap.

## rückusZDEventSerial

**TABLE 61** ruckusZDEventSerial

Name	rückusZDEventSerial
OID	1.3.6.1.4.1.25053.2.2.2.1
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify

**TABLE 61** ruckusZDEventSerial (continued)

Name	rückusZDEventSerial
Description	Trap serial number.

## rückusZDEventNEID

**TABLE 62** rückusZDEventNEID

Name	rückusZDEventNEID
OID	1.3.6.1.4.1.25053.2.2.2.2
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	Network element ID.

## rückusZDEventSeverity

**TABLE 63** rückusZDEventSeverity

Name	rückusZDEventSeverity
OID	1.3.6.1.4.1.25053.2.2.2.3
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	Severity level of the trap.

## rückusZDEventType

**TABLE 64** rückusZDEventType

Name	rückusZDEventType
OID	1.3.6.1.4.1.25053.2.2.2.4
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	Trap type.

## rückusZDEventTime

**TABLE 65** rückusZDEventTime

Name	rückusZDEventTime
OID	1.3.6.1.4.1.25053.2.2.2.5
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify

## Events and Traps

### Ruckus ZD Event Objects

**TABLE 65** ruckusZDEventTime (continued)

Name	rückusZDEventTime
Description	Time when trap occurred.

## rückusZDEventStatus

**TABLE 66** ruckusZDEventStatus

Name	rückusZDEventStatus
OID	1.3.6.1.4.1.25053.2.2.2.6
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	Trap status.

## rückusZDEventTitle

**TABLE 67** ruckusZDEventTitle

Name	rückusZDEventTitle
OID	1.3.6.1.4.1.25053.2.2.2.7
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	Trap title.

## rückusZDEventContent

**TABLE 68** ruckusZDEventContent

Name	rückusZDEventContent
OID	1.3.6.1.4.1.25053.2.2.2.8
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	Trap content.

## rückusZDEventClientMacAddr

**TABLE 69** ruckusZDEventClientMacAddr

Name	rückusZDEventClientMacAddr
OID	1.3.6.1.4.1.25053.2.2.2.15
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify

**TABLE 69** ruckusZEventClientMacAddr (continued)

Name	rückusZEventClientMacAddr
Description	The client's MAC address.

## rückusZEventAPMacAddr

**TABLE 70** rückusZEventAPMacAddr

Name	rückusZEventAPMacAddr
OID	1.3.6.1.4.1.25053.2.2.2.18
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	The AP's MAC address.

## rückusZEventRogueMacAddr

**TABLE 71** rückusZEventRogueMacAddr

Name	rückusZEventRogueMacAddr
OID	1.3.6.1.4.1.25053.2.2.2.20
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	The rogue AP's MAC address.

## rückusZEventSSID

**TABLE 72** rückusZEventSSID

Name	rückusZEventSSID
OID	1.3.6.1.4.1.25053.2.2.2.23
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	SSID.

## rückusZEventChannel

**TABLE 73** rückusZEventChannel

Name	rückusZEventChannel
OID	1.3.6.1.4.1.25053.2.2.2.25
Syntax	Unsigned32
Status	current
Max Access	accessible-for-notify

**TABLE 73** ruckusZDEventChannel (continued)

Name	rückusZDEventChannel
Description	Channel.

## rückusZDEventReason

**TABLE 74** rückusZDEventReason

Name	rückusZDEventReason
OID	1.3.6.1.4.1.25053.2.2.2.28
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	Failure reason.

## rückusZDEventIpAddr

**TABLE 75** rückusZDEventIpAddr

Name	rückusZDEventIpAddr
OID	1.3.6.1.4.1.25053.2.2.2.30
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	IP address (IPv4 and IPv6).

# AP and Client Event MIB Group

The following section contains SNMP traps and objects delivered for AP-related events.

- [AP/Client Event Traps](#) on page 46
- [AP/Client Event Objects](#) on page 48

## AP/Client Event Traps

### rückusEventAssocTrap

**TABLE 76** rückusEventAssocTrap

Name	rückusEventAssocTrap
OID	1.3.6.1.4.1.25053.2.1.1.1
Severity	Minor
Objects	1: rückusEventClientMacAddr
Description	Trigger when there is a client association event. The client's MAC address is enclosed.
Recommended Action	None

## **ruckusEventDiassocTrap**

**TABLE 77** ruckusEventDiassocTrap

Name	ruckusEventDiassocTrap
OID	1.3.6.1.4.1.25053.2.1.1.2
Severity	Minor
Status	current
Objects	1: ruckusEventClientMacAddr
Description	Trigger when there is a client disassociation event. The client's MAC address is enclosed.
Recommended Action	None.

## **ruckusEventSetErrorTrap**

**TABLE 78** ruckusEventSetErrorTrap

Name	ruckusEventSetErrorTrap
OID	1.3.6.1.4.1.25053.2.1.1.3
Severity	Minor
Status	current
Objects	1: ruckusSetErrorOID
Description	Trigger when there is an snmp-set error event. The OID of the snmp-set is enclosed.
Recommended Action	None.

## **ruckusEventConnectTrap**

**TABLE 79** ruckusEventConnectTrap

Name	ruckusEventConnectTrap
OID	1.3.6.1.4.1.25053.2.1.1.25
Severity	Minor
Status	current
Objects	1: ruckusEventClientMacAddr
Description	Trigger when there is an AP connect event. The AP's MAC address is enclosed.
Recommended Action	None.

## **ruckusEventDisconnectTrap**

**TABLE 80** ruckusEventDisconnectTrap

Name	ruckusEventDisconnectTrap
OID	1.3.6.1.4.1.25053.2.1.1.26
Severity	Minor
Status	current
Objects	1: ruckusEventClientMacAddr
Description	Trigger when there is an AP disconnect event. The AP's MAC address is enclosed.

## Events and Traps

ZD Event Trap Switch Commands

**TABLE 80** ruckusEventDisconnectTrap (continued)

Name	rückusEventDisconnectTrap
Recommended Action	None.

## AP/Client Event Objects

### *ruckusEventClientMacAddr*

**TABLE 81** ruckusEventClientMacAddr

Name	rückusEventClientMacAddr
OID	1.3.6.1.4.1.25053.2.1.2.15
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	The client's MAC address.

### *ruckusEventSetErrorOID*

**TABLE 82** ruckusEventSetErrorOID

Name	rückusEventSetErrorOID
OID	1.3.6.1.4.1.25053.2.1.2.20
Syntax	OCTET STRING
Status	current
Max Access	accessible-for-notify
Description	OID of the error snmp-set.

## ZD Event Trap Switch Commands

The objects in the following section are contained in the ruckusZDEventTrap-SwitchCmd tree and are used to enable/disable SNMP trap switch commands.

### *ruckusZDEventAPJoinTrapSwitchCmd*

**TABLE 83** ruckusZDEventAPJoinTrapSwitchCmd

Name	rückusZDEventAPJoinTrapSwitchCmd
OID	rückusZDEventTrapSwitchCmd 1
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSSIDSpoofTrapSwitchCmd

**TABLE 84** ruckusZDEventSSIDSpoofTrapSwitchCmd

Name	ruckusZDEventSSIDSpoofTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 2
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventMACSpoofTrapSwitchCmd

**TABLE 85** ruckusZDEventMACSpoofTrapSwitchCmd

Name	ruckusZDEventMACSpoofTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 3
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventRogueAPTrapSwitchCmd

**TABLE 86** ruckusZDEventRogueAPTrapSwitchCmd

Name	ruckusZDEventRogueAPTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 4
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPLostTrapSwitchCmd

**TABLE 87** ruckusZDEventAPLostTrapSwitchCmd

Name	ruckusZDEventAPLostTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 5
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## Events and Traps

### ZD Event Trap Switch Commands

## ruckusZDEventAPLostTrapSwitchCmd

**TABLE 88** ruckusZDEventAPLostTrapSwitchCmd

Name	rickusZDEventAPLostTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 5
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPLostHeartbeatTrapSwitchCmd

**TABLE 89** ruckusZDEventAPLostHeartbeatTrapSwitchCmd

Name	rickusZDEventAPLostHeartbeatTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 6
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientAuthFailBlockTrapSwitchCmd

**TABLE 90** ruckusZDEventClientAuthFailBlockTrapSwitchCmd

Name	rickusZDEventClientAuthFailBlockTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 7
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPResetTrapSwitchCmd

**TABLE 91** ruckusZDEventAPResetTrapSwitchCmd

Name	rickusZDEventAPResetTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 8
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventIPChangeSwitchCmd

**TABLE 92** ruckusZDEventIPChangeSwitchCmd

Name	ruckusZDEventIPChangeSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 9
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSystemColdStartTrapSwitchCmd

**TABLE 93** ruckusZDEventSystemColdStartTrapSwitchCmd

Name	ruckusZDEventSystemColdStartTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 10
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPChannelChangeTrapSwitchCmd

**TABLE 94** ruckusZDEventAPChannelChangeTrapSwitchCmd

Name	ruckusZDEventAPChannelChangeTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 11
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventRadiusAuthUnavailableTrapSwitchCmd

**TABLE 95** ruckusZDEventRadiusAuthUnavailableTrapSwitchCmd

Name	ruckusZDEventRadiusAuthUnavailableTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 12
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## Events and Traps

### ZD Event Switch Commands

## ruckusZDEventRadiusAcctUnavailableTrapSwitchCmd

**TABLE 96** ruckusZDEventRadiusAcctUnavailableTrapSwitchCmd

Name	rickusZDEventRadiusAcctUnavailableTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 13
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientJoinFailAPBusyTrapSwitchCmd

**TABLE 97** ruckusZDEventClientJoinFailAPBusyTrapSwitchCmd

Name	rickusZDEventClientJoinFailAPBusyTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 14
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventInterferenceAdHocTrapSwitchCmd

**TABLE 98** ruckusZDEventInterferenceAdHocTrapSwitchCmd

Name	rickusZDEventInterferenceAdHocTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 15
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventImageUpgradeFailTrapSwitchCmd

**TABLE 99** ruckusZDEventImageUpgradeFailTrapSwitchCmd

Name	rickusZDEventImageUpgradeFailTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 16
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventHeartbeatTrapSwitchCmd

**TABLE 100** ruckusZDEventHeartbeatTrapSwitchCmd

Name	rickusZDEventHeartbeatTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 22
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAttackedTrapSwitchCmd

**TABLE 101** ruckusZDEventAttackedTrapSwitchCmd

Name	rickusZDEventAttackedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 24
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSystemWarmStartTrapSwitchCmd

**TABLE 102** ruckusZDEventSystemWarmStartTrapSwitchCmd

Name	rickusZDEventSystemWarmStartTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 25
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventInterfereAPTrapSwitchCmd

**TABLE 103** ruckusZDEventInterfereAPTrapSwitchCmd

Name	rickusZDEventInterfereAPTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 26
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## Events and Traps

### ZD Event Trap Switch Commands

## ruckusZDEventAPSystemColdStartTrapSwitchCmd

**TABLE 104** ruckusZDEventAPSystemColdStartTrapSwitchCmd

Name	rickusZDEventAPSystemColdStartTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 31
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPSystemWarmStartTrapSwitchCmd

**TABLE 105** ruckusZDEventAPSystemWarmStartTrapSwitchCmd

Name	rickusZDEventAPSystemWarmStartTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 32
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPSSIDChangedTrapSwitchCmd

**TABLE 106** ruckusZDEventAPSSIDChangedTrapSwitchCmd

Name	rickusZDEventAPSSIDChangedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 33
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPClientExceedValveTrapSwitchCmd

**TABLE 107** ruckusZDEventAPClientExceedValveTrapSwitchCmd

Name	rickusZDEventAPClientExceedValveTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 34
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPWirelessInterfaceFaultTrapSwitchCmd

**TABLE 108** ruckusZDEventAPWirelessInterfaceFaultTrapSwitchCmd

Name	ruckusZDEventAPWirelessInterfaceFaultTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 36
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSystemCpuUtilExceedValveTrapSwitchCmd

**TABLE 109** ruckusZDEventSystemCpuUtilExceedValveTrapSwitchCmd

Name	ruckusZDEventSystemCpuUtilExceedValveTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 37
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSystemMemUtilExceedValveTrapSwitchCmd

**TABLE 110** ruckusZDEventSystemMemUtilExceedValveTrapSwitchCmd

Name	ruckusZDEventSystemMemUtilExceedValveTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 38
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSystemBandwidthUtilExceedValveTrapSwitchCmd

**TABLE 111** ruckusZDEventSystemBandwidthUtilExceedValveTrapSwitchCmd

Name	ruckusZDEventSystemBandwidthUtilExceedValveTrapSwitchCmd
OID	ruckusZDEventTrapSwitchCmd 39
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## Events and Traps

### ZD Event Trap Switch Commands

## ruckusZDEventSystemDropPacketRateExceedValveTrapSwitchCmd

**TABLE 112** ruckusZDEventSystemDropPacketRateExceedValveTrapSwitchCmd

Name	rickusZDEventSystemDropPacketRateExceedValveTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 40
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPSyncTimeFailTrapSwitchCmd

**TABLE 113** ruckusZDEventAPSyncTimeFailTrapSwitchCmd

Name	rickusZDEventAPSyncTimeFailTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 41
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSystemCpuUtilClrWarnTrapSwitchCmd

**TABLE 114** ruckusZDEventSystemCpuUtilClrWarnTrapSwitchCmd

Name	rickusZDEventSystemCpuUtilClrWarnTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 42
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSystemMemUtilClrwarnTrapSwitchCmd

**TABLE 115** ruckusZDEventSystemMemUtilClrwarnTrapSwitchCmd

Name	rickusZDEventSystemMemUtilClrwarnTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 43
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientJoinTrapSwitchCmd

**TABLE 116** ruckusZDEventClientJoinTrapSwitchCmd

Name	rickusZDEventClientJoinTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 60
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientJoinFailedTrapSwitchCmd

**TABLE 117** ruckusZDEventClientJoinFailedTrapSwitchCmd

Name	rickusZDEventClientJoinFailedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 61
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientJoinFailedAPBusyTrapSwitchCmd

**TABLE 118** ruckusZDEventClientJoinFailedAPBusyTrapSwitchCmd

Name	rickusZDEventClientJoinFailedAPBusyTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 62
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientDisconnectTrapSwitchCmd

**TABLE 119** ruckusZDEventClientDisconnectTrapSwitchCmd

Name	rickusZDEventClientDisconnectTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 63
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## Events and Traps

### ZD Event Trap Switch Commands

## ruckusZDEventClientRoamOutTrapSwitchCmd

**TABLE 120** ruckusZDEventClientRoamOutTrapSwitchCmd

Name	rickusZDEventClientRoamOutTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 64
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientRoamInTrapSwitchCmd

**TABLE 121** ruckusZDEventClientRoamInTrapSwitchCmd

Name	rickusZDEventClientRoamInTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 65
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientAuthFailedTrapSwitchCmd

**TABLE 122** ruckusZDEventClientAuthFailedTrapSwitchCmd

Name	rickusZDEventClientAuthFailedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 66
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventClientAuthorizationFailedTrapSwitchC

**TABLE 123** ruckusZDEventClientAuthorizationFailedTrapSwitchC

Name	rickusZDEventClientAuthorizationFailedTrapSwitchC
OID	rickusZDEventTrapSwitchCmd 67
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPCPUvalveTrapSwitchCmd

**TABLE 124** ruckusZDEventAPCPUvalveTrapSwitchCmd

Name	rickusZDEventAPCPUvalveTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 83
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPMEMvalveTrapSwitchCmd

**TABLE 125** ruckusZDEventAPMEMvalveTrapSwitchCmd

Name	rickusZDEventAPMEMvalveTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 84
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPCPUvalveClrwarnTrapSwitchCmd

**TABLE 126** ruckusZDEventAPCPUvalveClrwarnTrapSwitchCmd

Name	rickusZDEventAPCPUvalveClrwarnTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 85
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventAPMEMvalveClrwarnTrapSwitchCmd

**TABLE 127** ruckusZDEventAPMEMvalveClrwarnTrapSwitchCmd

Name	rickusZDEventAPMEMvalveClrwarnTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 86
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## Events and Traps

### ZD Event Trap Commands

## ruckusZDEventAPNumStaExceedValveClrwarnTrapSwitchCmd

**TABLE 128** ruckusZDEventAPNumStaExceedValveClrwarnTrapSwitchCmd

Name	rickusZDEventAPNumStaExceedValveClrwarnTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 87
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventDhcpPoolFullTrapSwitchCmd

**TABLE 129** ruckusZDEventDhcpPoolFullTrapSwitchCmd

Name	rickusZDEventDhcpPoolFullTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 88
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventDhcpPoolAbunTrapSwitchCmd

**TABLE 130** ruckusZDEventDhcpPoolAbunTrapSwitchCmd

Name	rickusZDEventDhcpPoolAbunTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 89
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSmartRedundancyChangetoActiveTrapSwitchCmd

**TABLE 131** ruckusZDEventSmartRedundancyChangetoActiveTrapSwitchCmd

Name	rickusZDEventSmartRedundancyChangetoActiveTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 100
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSmartRedundancyActiveConnectedTrapSwitchCmd

**TABLE 132** ruckusZDEventSmartRedundancyActiveConnectedTrapSwitchCmd

Name	rickusZDEventSmartRedundancyActiveConnectedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 101
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSmartRedundancyActiveDisconnectedTrapSwitchCmd

**TABLE 133** ruckusZDEventSmartRedundancyActiveDisconnectedTrapSwitchCmd

Name	rickusZDEventSmartRedundancyActiveDisconnectedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 102
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSmartRedundancyStandbyConnectedTrapSwitchCmd

**TABLE 134** ruckusZDEventSmartRedundancyStandbyConnectedTrapSwitchCmd

Name	rickusZDEventSmartRedundancyStandbyConnectedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 16
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventSmartRedundancyStandbyDisconnectedTrapSwitchCmd

**TABLE 135** ruckusZDEventSmartRedundancyStandbyDisconnectedTrapSwitchCmd

Name	rickusZDEventSmartRedundancyStandbyDisconnectedTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 104
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## Events and Traps

### ZD Event Trap Switch Commands

## ruckusZDEventLBSAdminEnabledTrapSwitchCmd

**TABLE 136** ruckusZDEventLBSAdminEnabledTrapSwitchCmd

Name	rickusZDEventLBSAdminEnabledTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 120
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventLBSAdminDisabledTrapSwitchCmd

**TABLE 137** ruckusZDEventLBSAdminDisabledTrapSwitchCmd

Name	rickusZDEventLBSAdminDisabledTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 121
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventLBSZDLSConnectionUpTrapSwitchCmd

**TABLE 138** ruckusZDEventLBSZDLSConnectionUpTrapSwitchCmd

Name	rickusZDEventLBSZDLSConnectionUpTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 122
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventLBSZDLSConnectionUpTrapSwitchCmd

**TABLE 139** ruckusZDEventLBSZDLSConnectionUpTrapSwitchCmd

Name	rickusZDEventLBSZDLSConnectionUpTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 123
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventLBSReceiveCMDFootfallTrapSwitchCmd

**TABLE 140** ruckusZDEventLBSReceiveCMDFootfallTrapSwitchCmd

Name	rickusZDEventLBSReceiveCMDFootfallTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 124
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventLBSReceiveCMDCalibrationTrapSwitchCmd

**TABLE 141** ruckusZDEventLBSReceiveCMDCalibrationTrapSwitchCmd

Name	rickusZDEventLBSReceiveCMDCalibrationTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 125
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.

## ruckusZDEventALLEventTrapSwitchCmd

**TABLE 142** ruckusZDEventALLEventTrapSwitchCmd

Name	rickusZDEventALLEventTrapSwitchCmd
OID	rickusZDEventTrapSwitchCmd 200
Syntax	INTEGER {enable(1), disable(0)}
Status	current
MAX-ACCESS	read-write
Description	trap switch command.



# ZoneDirector System MIBs

• ZoneDirector System MIBs Overview.....	65
• System Info MIBs.....	65
• Expanded System Info MIBs.....	65
• System IP Table MIBs.....	67
• System Services MIBs.....	67
• System Load Balancing Info MIBs.....	69
• System Statistics MIBs.....	69
• ZD Ethernet Info MIBs.....	70

## ZoneDirector System MIBs Overview

The objects contained in the RUCKUS-ZD-SYSTEM-MIB.txt group provide system information and statistics such as system name, software version, AP licenses, CPU and memory utilization, IP addressing, system services running and other system information.

The following tables list the objects within each top-level MIB tree in the RUCKUS-ZD-SYSTEM-MIB.txt file.

## System Info MIBs

Table 143 lists the node names, OIDs and descriptions of each object in the System Info MIB tree.

**TABLE 143** ZoneDirector System MIBs - System Info MIB tree

MIB Tree	Node Name	OID	Description
ruckusZDSysInfo	ruckusZDSysName	1.3.6.1.4.1.25053.1.2.1.1.1.1.1	System name
	ruckusZDSysIPAddr	1.3.6.1.4.1.25053.1.2.1.1.1.1.2	IP address
	ruckusZDSysMacAddr	1.3.6.1.4.1.25053.1.2.1.1.1.1.3	MAC address
	ruckusZDSysUptime	1.3.6.1.4.1.25053.1.2.1.1.1.1.8	Uptime
	ruckusZDSysModel	1.3.6.1.4.1.25053.1.2.1.1.1.1.9	Model
	ruckusZDSysLicensedAPs	1.3.6.1.4.1.25053.1.2.1.1.1.1.12	Licensed APs
	ruckusZDSysMaxSta	1.3.6.1.4.1.25053.1.2.1.1.1.1.13	Max stations
	ruckusZDSysSerialNumber	1.3.6.1.4.1.25053.1.2.1.1.1.1.15	Serial number
	ruckusZDSysVersion	1.3.6.1.4.1.25053.1.2.1.1.1.1.18	Version
	ruckusZDSysCountryCode	1.3.6.1.4.1.25053.1.2.1.1.1.1.20	Country code
	ruckusZDSysAdminName	1.3.6.1.4.1.25053.1.2.1.1.1.1.25	Admin name
	ruckusZDSysAdminPassword	1.3.6.1.4.1.25053.1.2.1.1.1.1.26	Admin password
	ruckusZDSysStatus	1.3.6.1.4.1.25053.1.2.1.1.1.1.30	System status
	ruckusZDSysPeerConnectedStatus	1.3.6.1.4.1.25053.1.2.1.1.1.1.31	Peer connection status

## Expanded System Info MIBs

Table 144 lists the node names, OIDs and descriptions of each object in the Expanded System Info MIB tree.

**TABLE 144** Expanded System Info MIB Tree

MIB Tree	Node Name	OID	Description
ruckusZDSystemExplInfo	ruckusZDSystemNEId	1.3.6.1.4.1.25053.1.2.1.1.1.5.50	NE ID
	ruckusZDSystemManufacturer	1.3.6.1.4.1.25053.1.2.1.1.1.5.51	Manufacturer
	ruckusZDSystemSoftwareName	1.3.6.1.4.1.25053.1.2.1.1.1.5.52	Software name
	ruckusZDSystemCPUUtil	1.3.6.1.4.1.25053.1.2.1.1.1.5.58	CPU utilization
	ruckusZDSystemMemoryUtil	1.3.6.1.4.1.25053.1.2.1.1.1.5.59	Memory utilization
	ruckusZDSystemMemorySize	1.3.6.1.4.1.25053.1.2.1.1.1.5.60	Memory size
	ruckusZDSystemFlashFreeSize	1.3.6.1.4.1.25053.1.2.1.1.1.5.65	Flash free size
	ruckusZDSystemMgmtVlanID	1.3.6.1.4.1.25053.1.2.1.1.1.5.67	Management VLAN ID
	ruckusZDSystemCPUModel	1.3.6.1.4.1.25053.1.2.1.1.1.5.70	CPU model
	ruckusZDSystemtCPUSpeed	1.3.6.1.4.1.25053.1.2.1.1.1.5.71	CPU speed
	ruckusZDSystemtFlashModel	1.3.6.1.4.1.25053.1.2.1.1.1.5.72	Flash model
	ruckusZDSystemtMemModel	1.3.6.1.4.1.25053.1.2.1.1.1.5.73	Memory model
	ruckusZDSystemStartTime	1.3.6.1.4.1.25053.1.2.1.1.1.5.74	System startup time
	ruckusZDSystemCurrentTime	1.3.6.1.4.1.25053.1.2.1.1.1.5.80	System current time
	ruckusZDSystemAPFirmwareServer	1.3.6.1.4.1.25053.1.2.1.1.1.5.81	AP firmware download server
	ruckusZDSystemAPConfigServer	1.3.6.1.4.1.25053.1.2.1.1.1.5.82	AP configuration server
	ruckusZDSystemIDSAllowedESSID	1.3.6.1.4.1.25053.1.2.1.1.1.5.85	Allowed ESSIDs
	ruckusZDSystemIDSAllowBSSID	1.3.6.1.4.1.25053.1.2.1.1.1.5.86	Allowed BSSIDs
	ruckusZDSystemIDSAllowOUI	1.3.6.1.4.1.25053.1.2.1.1.1.5.87	Allowed OUIs
	ruckusZDSystemBandwidthUtilValve	1.3.6.1.4.1.25053.1.2.1.1.1.5.90	Number of system bandwidth utilization percent.
	ruckusZDSystemDropPacketRateValve	1.3.6.1.4.1.25053.1.2.1.1.1.5.91	Number of system drop packets rate percent.
	ruckusZDSystemCPUUtilValve	1.3.6.1.4.1.25053.1.2.1.1.1.5.92	CPU utilization
	ruckusZDSystemMemUtilValve	1.3.6.1.4.1.25053.1.2.1.1.1.5.95	Memory utilization
	ruckusZDSystemOnlineStaValve	1.3.6.1.4.1.25053.1.2.1.1.1.5.96	Online stations
	ruckusZDSystemLocationLongitude	1.3.6.1.4.1.25053.1.2.1.1.1.5.97	AC longitude
	ruckusZDSystemLocationLatitude	1.3.6.1.4.1.25053.1.2.1.1.1.5.98	AC latitude
	ruckusZDSystemDHCPServer	1.3.6.1.4.1.25053.1.2.1.1.1.5.110	DHCP server enabled or disabled
	ruckusZDAPCPUvalve	1.3.6.1.4.1.25053.1.2.1.1.1.5.120	AP's CPU utilization value for sending trap
	ruckusZDAPMemoryvalve	1.3.6.1.4.1.25053.1.2.1.1.1.5.121	AP'S Memory utilization valve for sending trap
	ruckusZDHeartBeatStatus	1.3.6.1.4.1.25053.1.2.1.1.1.5.122	Current heartbeat on-off status
	ruckusZDHeartBeatPeriod	1.3.6.1.4.1.25053.1.2.1.1.1.5.123	Heartbeat interval between ZD and NMS (units:seconds)

## System IP Table MIBs

Table 145 lists the node names, OIDs and descriptions of each object in the System IP Table MIB tree.

**TABLE 145** System IP Table MIB tree

MIB Tree	Node Name	OID	Description
ruckusZDSysIPTable	ruckusZDSysIPIndex	1.3.6.1.4.1.25053.1.2.1.1.8.1.1	IP index
	ruckusZDSysIPVersion	1.3.6.1.4.1.25053.1.2.1.1.8.1.2	Current IP version
	ruckusZDSysIPAddrMode	1.3.6.1.4.1.25053.1.2.1.1.8.1.5	IP address mode (static IP or DHCP)
	ruckusZDSysIPAddress	1.3.6.1.4.1.25053.1.2.1.1.8.1.6	IP address
	ruckusZDSysIPAddrNetmask	1.3.6.1.4.1.25053.1.2.1.1.8.1.8	Netmask
	ruckusZDSysIPGateway	1.3.6.1.4.1.25053.1.2.1.1.8.1.10	Gateway
	ruckusZDSysIPPrimaryDNS	1.3.6.1.4.1.25053.1.2.1.1.8.1.12	Primary DNS
	ruckusZDSysIPSecondaryDNS	1.3.6.1.4.1.25053.1.2.1.1.8.1.13	Secondary DNS
	ruckusZDSysIPV6AddressModel	1.3.6.1.4.1.25053.1.2.1.1.8.1.20	Current IPv6 address model
	ruckusZDSysIPV6Address	1.3.6.1.4.1.25053.1.2.1.1.8.1.21	IPv6 address
	ruckusZDSysIPV6PrefixLen	1.3.6.1.4.1.25053.1.2.1.1.8.1.22	Specifies the ip v6 address prefix length if the ruckusZDSysIPV6AddressModel is set to static(2).
	ruckusZDSysIPV6Gateway	1.3.6.1.4.1.25053.1.2.1.1.8.1.25	Specifies the gateway ipv6 address if the ruckusZDSysIPV6AddressModel is set to static(2).
	ruckusZDSysIPV6PrimaryDNS	1.3.6.1.4.1.25053.1.2.1.1.8.1.28	Specifies primary DNS IPV6 address.
	ruckusZDSysIPV6SecondaryDNS	1.3.6.1.4.1.25053.1.2.1.1.8.1.29	Specifies secondary DNS IPV6 address.

## System Services MIBs

Table 146 lists the node names, OIDs and descriptions of each object in the System Services (ruckusZDSysServices) MIB tree.

**TABLE 146** System Services MIB tree

MIB Tree	Node Name	OID	Description
ruckusZDSysTime	ruckusZDSysTimeWithNTP	1.3.6.1.4.1.25053.1.2.1.1.12.3.1	Enable the Zone Director system to synchronize its system time with NTP
	ruckusZDSysTimeNTPServer	1.3.6.1.4.1.25053.1.2.1.1.12.3.2	The NTP Server (URL) the ZoneDirector synchronizes its system time with
ruckusZDSysSMTP	ruckusZDSysEmailTriggerEnable	1.3.6.1.4.1.25053.1.2.1.1.12.5.1	Send an email message when an alarm is triggered
	ruckusZDSysEmailAddress	1.3.6.1.4.1.25053.1.2.1.1.12.5.2	Email address

## ZoneDirector System MIBs

### System Services MIBs

**TABLE 146** System Services MIB tree (continued)

MIB Tree	Node Name	OID	Description
ruckusZDSystem	ruckusZDSystemSMTPServerName	1.3.6.1.4.1.25053.1.2.1.1.12.5.3	SMTP server
	ruckusZDSystemSMTPServerPort	1.3.6.1.4.1.25053.1.2.1.1.12.5.4	SMTP server port
	ruckusZDSystemSMTPAuthUsername	1.3.6.1.4.1.25053.1.2.1.1.12.5.5	SMTP auth user name
	ruckusZDSystemSMTPAuthPassword	1.3.6.1.4.1.25053.1.2.1.1.12.5.6	SMTP auth password
	ruckusZDSystemFromEmailAddress	1.3.6.1.4.1.25053.1.2.1.1.12.5.7	From email address
	ruckusZDSystemSMTPEncryptionOptions	1.3.6.1.4.1.25053.1.2.1.1.12.5.8	SMTP encryption
ruckusZDSystemSysLog	ruckusZDSystemSysLogServer	1.3.6.1.4.1.25053.1.2.1.1.12.8.1	The syslog server IP or IPV6 address that ZoneDirector reports its system events to
	ruckusZDSystemSysLogServer	1.3.6.1.4.1.25053.1.2.1.1.12.8.2	Syslog server
ruckusZDSystemFlexMaster	ruckusZDSystemFlexMasterEnable	1.3.6.1.4.1.25053.1.2.1.1.12.9.1	FlexMaster enabled/disabled status
	ruckusZDSystemFlexMasterServer	1.3.6.1.4.1.25053.1.2.1.1.12.9.2	FlexMaster server
	ruckusZDSystemFlexMasterInterval	1.3.6.1.4.1.25053.1.2.1.1.12.9.3	FlexMaster inform interval
ruckusZDSystemStp	ruckusZDSystemStpStatus	1.3.6.1.4.1.25053.1.2.1.1.12.12.1	STP status
ruckusZDSystemSNMPTrapInfo	ruckusZDSystemSNMPTrapEnable	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.1	SNMP traps enabled/disabled status
	ruckusZDSystemSNMPTrapVersion	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.2	SNMP trap version
ruckusZDSystemSNMPV2TrapSrvTable	ruckusZDSystemSNMPV2TrapSrvIndex	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.35.1.1	SNMPv2 trap server index
	ruckusZDSystemSNMPV2TrapServer	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.35.1.3	SNMPv2 trap server address (v4 or v6)
	ruckusZDSystemSNMPV2TrapSrvRowStatus	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.35.1.8	SNMPv2 trap server row status
ruckusZDSystemSNMPV3TrapSrvTable	ruckusZDSystemSNMPV3TrapSrvIndex	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.1	SNMPv3 Trap server index
	ruckusZDSystemSNMPV3TrapServer	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.5	SNMPv3 Trap server index
	ruckusZDSystemSNMPV3TrapUser	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.8	SNMPv3 trap user
	ruckusZDSystemSNMPV3TrapAuth	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.10	SNMPv3 trap auth
	ruckusZDSystemSNMPV3TrapAuthKey	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.11	SNMPv3 trap auth key
	ruckusZDSystemSNMPV3TrapPrivacy	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.15	SNMPv3 trap privacy
	ruckusZDSystemSNMPV3TrapPrivacyKey	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.16	SNMPv3 trap privacy key
	ruckusZDSystemSNMPV3TrapSrvRowStatus	1.3.6.1.4.1.25053.1.2.1.1.12.15.3.36.1.20	SNMPv3 trap server row status
ruckusZDSystemSNMPV2Table	ruckusZDSystemSNMPEnable	1.3.6.1.4.1.25053.1.2.1.1.12.15.5.1.2	SNMP enabled/disabled status
	ruckusZDSystemSNMPROCommunity	1.3.6.1.4.1.25053.1.2.1.1.12.15.5.1.5	SNMP RO community string
	ruckusZDSystemSNMPRWCommunity	1.3.6.1.4.1.25053.1.2.1.1.12.15.5.1.6	SNMP RW community string
	ruckusZDSystemSNMPSysContact	1.3.6.1.4.1.25053.1.2.1.1.12.15.5.1.7	SNMP system contact
	ruckusZDSystemSNMPSysLocation	1.3.6.1.4.1.25053.1.2.1.1.12.15.5.1.8	SNMP system location

**TABLE 146** System Services MIB tree (continued)

MIB Tree	Node Name	OID	Description
ruckusZDSystemSNMPV3Table	ruckusZDSystemSNMPV3Enable	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.2	SNMPv3 enabled/disabled status
	ruckusZDSystemSNMPV3RoUser	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.5	SNMPv3 RO user
	ruckusZDSystemSNMPV3RoAuth	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.6	SNMPv3 RO auth
	ruckusZDSystemSNMPV3RoAuthKey	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.7	SNMPv3 RO auth key
	ruckusZDSystemSNMPV3RoPirvacy	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.8	SNMPv3 RO privacy
	ruckusZDSystemSNMPV3RoPrivacyKey	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.9	SNMPv3 RO privacy key
	ruckusZDSystemSNMPV3RwUser	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.12	SNMPv3 RW user
	ruckusZDSystemSNMPV3RwAuth	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.13	SNMPv3 RW auth
	ruckusZDSystemSNMPV3RwAuthKey	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.14	SNMPv3 RW auth key
	ruckusZDSystemSNMPV3RwPirvacy	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.15	SNMPv3 RW privacy
	ruckusZDSystemSNMPV3RwPrivacyKey	1.3.6.1.4.1.25053.1.2.1.1.12.15.8.1.16	SNMPv3 RW privacy key

## System Load Balancing Info MIBs

Table 147 lists the node names, OIDs and descriptions of each object in the System Load Balancing Info MIB tree.

**TABLE 147** System Load Balancing Info MIB tree

MIB Tree	Node Name	OID	Description
ruckusZDSystemLoadBalanceInfo	ruckusZDSystemLoadBalance24GStatus	1.3.6.1.4.1.25053.1.2.1.1.12.20.1	Load balancing status 2.4 GHz
	ruckusZDSystemLoadBalance5GStatus	1.3.6.1.4.1.25053.1.2.1.1.12.20.2	Load balancing status 5 GHz
	ruckusZDSystemLoadBalanceAdjacent24GThreshold	1.3.6.1.4.1.25053.1.2.1.1.12.20.3	Load balancing user threshold 2.4 GHz
	ruckusZDSystemLoadBalanceAdjacent5GThreshold	1.3.6.1.4.1.25053.1.2.1.1.12.20.4	Load balancing user threshold 5 GHz

## System Statistics MIBs

Table 148 lists the MIBs in the ruckusZDSystemStats MIB tree.

**TABLE 148** System statistics MIBs

MIB Tree	Node Name	OID	Description
ruckusZDSystemStats	ruckusZDSystemStatsNumAP	1.3.6.1.4.1.25053.1.2.1.1.15.1	Number of APs.
	ruckusZDSystemStatsNumSta	1.3.6.1.4.1.25053.1.2.1.1.15.2	Number of authorized client devices.
	ruckusZDSystemStatsNumRogue	1.3.6.1.4.1.25053.1.2.1.1.15.3	Number of rogue devices.
	ruckusZDSystemStatsNumRogueKnown	1.3.6.1.4.1.25053.1.2.1.1.15.4	Number of known rogue devices.
	ruckusZDSystemStatsWLANTotalRxPkts	1.3.6.1.4.1.25053.1.2.1.1.15.5	Total received packets of wireless interfaces.

## ZoneDirector System MIBs

ZD Ethernet Info MIBs

**TABLE 148** System statistics MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDSysTemStatsWLANTotalRxBytes	1.3.6.1.4.1.25053.1.2.1.1.1.15.6	Total received bytes of wireless interfaces.
	ruckusZDSysTemStatsWLANTotalRxMulticast	1.3.6.1.4.1.25053.1.2.1.1.1.15.7	Total received multicast packets of wireless interfaces.
	ruckusZDSysTemStatsWLANTotalTxPkts	1.3.6.1.4.1.25053.1.2.1.1.1.15.8	Total transmitted packets of wireless interfaces.
	ruckusZDSysTemStatsWLANTotalTxBytes	1.3.6.1.4.1.25053.1.2.1.1.1.15.9	Total transmitted bytes of wireless interfaces.
	ruckusZDSysTemStatsWLANTotalTxMulticast	1.3.6.1.4.1.25053.1.2.1.1.1.15.10	Total transmitted multicast packets of wireless interfaces.
	ruckusZDSysTemStatsWLANTotalTxFail	1.3.6.1.4.1.25053.1.2.1.1.1.15.11	Total transmitted fail packets of wireless interfaces.
	ruckusZDSysTemStatsWLANTotalTxRetry	1.3.6.1.4.1.25053.1.2.1.1.1.15.12	Total transmitted retry packets of wireless interfaces.
	ruckusZDSysTemStatsCPUUtil	1.3.6.1.4.1.25053.1.2.1.1.1.15.13	CPU utilization.
	ruckusZDSysTemStatsMemoryUtil	1.3.6.1.4.1.25053.1.2.1.1.1.15.14	Memory utilization.
	ruckusZDSysTemStatsNumRegisteredAP	1.3.6.1.4.1.25053.1.2.1.1.1.15.15	Number of registered AP.
	ruckusZDSysTemStatsWLANTotalAssocFail	1.3.6.1.4.1.25053.1.2.1.1.1.15.16	Total number of failed station associations.
	ruckusZDSysTemStatsWLANTotalRxErrFrm	1.3.6.1.4.1.25053.1.2.1.1.1.15.17	Total number of erroneous downlink frames.
	ruckusZDSysTemStatsNumRegAP	1.3.6.1.4.1.25053.1.2.1.1.1.15.18	Number of registered APs.
	ruckusZDSysTemStatsWLANTotalTxDroppedPkt	1.3.6.1.4.1.25053.1.2.1.1.1.15.19	Total number of dropped downlink packets.
	ruckusZDSysTemStatsWLANTotalTxErrFrm	1.3.6.1.4.1.25053.1.2.1.1.1.15.20	Total number of erroneous downlink frames.
	ruckusZDSysTemStatsWLANTotalTxDroppedFrm	1.3.6.1.4.1.25053.1.2.1.1.1.15.21	Total number of dropped downlink frames.
	ruckusZDSysTemStatsMonitorPeriod	1.3.6.1.4.1.25053.1.2.1.1.1.15.22	System stats monitoring period.
	ruckusZDSysTemStatsLanTxRate	1.3.6.1.4.1.25053.1.2.1.1.1.15.23	Lan transmit rate kbyte/s in last 5 minutes .
	ruckusZDSysTemStatsLanRxRate	1.3.6.1.4.1.25053.1.2.1.1.1.15.24	Lan received rate kbyte/s in last 5 minutes .
	ruckusZDSysTemStatsAllNumSta	1.3.6.1.4.1.25053.1.2.1.1.1.15.30	Number of All client devices.

## ZD Ethernet Info MIBs

Table 149 lists the MIBs in the ruckusZDEthInfo MIB tree.

**TABLE 149** Ethernet Info MIBs

MIB Tree	Node Name	OID	Description
ruckusZDEthTable	ruckusZDEthNum	1.3.6.1.4.1.25053.1.2.1.1.1.18.1	Number of ethernet devices.
	ruckusZDEthIfIndex	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.1	Ethernet device interface index.
	ruckusZDEthName	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.2	Ethernet device name.
	ruckusZDEthDesc	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.3	Ethernet device description.
	ruckusZDEthType	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.4	Ethernet device type.
	ruckusZDEthStatus	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.5	Ethernet device status.
	ruckusZDEthPhysAddr	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.6	Ethernet device MAC address.
	ruckusZDEthMtu	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.7	Ethernet device mtu size.
	ruckusZDEthIfSpeed	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.8	Ethernet device interface speed.
	ruckusZDEthUtil	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.9	Ethernet device utilization.
	ruckusZDEthTxBcastPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.10	Ethernet device transmitted broadcast packets number.
	ruckusZDEthTxMcastPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.11	Ethernet device transmitted multicast packets number.
	ruckusZDEthRxBcastPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.12	Ethernet device received broadcast packets number.
	ruckusZDEthRxMcastPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.13	Ethernet device received multicast packets number.
	ruckusZDEthTxUniPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.14	Ethernet device transmitted unicast packets number.
	ruckusZDEthRxUniPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.15	Ethernet device received unicast packets number.
	ruckusZDEthTxPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.16	Ethernet device transmitted packets number.
	ruckusZDEthRxPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.17	Ethernet device received packets number.
	ruckusZDEthDropTxPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.18	Ethernet device transmitted drop packets number.
	ruckusZDEthDropRxPkts	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.19	Ethernet device received drop packets number.
	ruckusZDEthTxBytes	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.20	Ethernet device transmitted bytes number.
	ruckusZDEthRxBytes	1.3.6.1.4.1.25053.1.2.1.1.1.18.2.1.21	Ethernet device received bytes number.



# Ruckus Product MIBs

• Ruckus Product MIBs Overview.....	73
• Ruckus Wireless Router Product MIBs.....	73
• Ruckus Wireless Adapter Product MIBs.....	73
• Ruckus Wireless Metro Product MIBs.....	73
• Ruckus Wireless Hotzone Product MIBs.....	74
• Ruckus Controller Product MIBs.....	79

## Ruckus Product MIBs Overview

The Ruckus Product MIBs define OIDs for supported Ruckus products. The Product MIBs are contained in the RUCKUS-PRODUCTS-MIB.txt MIB file.

## Ruckus Wireless Router Product MIBs

The following table lists the node names, OIDs and descriptions of each object in the ruckusWirelessRouterProducts MIB tree.

**TABLE 150** Ruckus Wireless Router Products MIB Tree

MIB Tree	Node Name	OID	Description
ruckusWirelessRouterProducts	ruckusVF2825	1.3.6.1.4.1.25053.3.1.4.1	VF 2825
	ruckusVF2811	1.3.6.1.4.1.25053.3.1.1.2	VF 2811
	ruckusVF2821	1.3.6.1.4.1.25053.3.1.1.3	VF 2821
	ruckusVF2835	1.3.6.1.4.1.25053.3.1.1.4	VF 2835
	ruckusVF7811	1.3.6.1.4.1.25053.3.1.1.5	VF 7811

## Ruckus Wireless Adapter Product MIBs

The following table lists the node names, OIDs and descriptions of each object in the ruckusWirelessAdapterProducts MIB tree.

**TABLE 151** Ruckus Wireless Adapter Products MIBs

MIB Tree	Node Name	OID	Description
ruckusWirelessAdapterProducts	ruckusVF2111	1.3.6.1.4.1.25053.3.1.2.1	VF 2111
	ruckusVF2121	1.3.6.1.4.1.25053.3.1.2.2	VF 2121
	ruckusVF7111	1.3.6.1.4.1.25053.3.1.2.3	VF 7111

## Ruckus Wireless Metro Product MIBs

The following table lists the node names, OIDs and descriptions of each object in the ruckusWirelessMetroProducts MIB tree.

## Ruckus Product MIBs

Ruckus Wireless Hotzone Product MIBs

**TABLE 152** Ruckus Wireless Metro Products MIBs

MIB Tree	Node Name	OID	Description
ruckusWirelessMetroProducts	ruckusMM2225	1.3.6.1.4.1.25053.3.1.3.1	MM 2225
	ruckusMM2211	1.3.6.1.4.1.25053.3.1.3.2	MM 2211
	ruckusMM2221	1.3.6.1.4.1.25053.3.1.3.3	MM 2221

## Ruckus Wireless Hotzone Product MIBs

The following table lists the node names, OIDs and descriptions of each object in the ruckusWirelessHotzoneProducts MIB tree.

**TABLE 153** Ruckus Wireless Hotzone Products MIBs

MIB Tree	Node Name	OID	Description
ruckusWirelessHotzoneProducts	ruckusZF2925	1.3.6.1.4.1.25053.3.1.4.1	ZF 2925
	ruckusZF2942	1.3.6.1.4.1.25053.3.1.4.2	ZF 2942
	ruckusZF7942	1.3.6.1.4.1.25053.3.1.4.3	ZF 7942
	ruckusZF7962	1.3.6.1.4.1.25053.3.1.4.4	ZF 7962
	ruckusZF2741	1.3.6.1.4.1.25053.3.1.4.5	ZF 2741
	ruckusZF7762	1.3.6.1.4.1.25053.3.1.4.6	ZF 7762
	ruckusZF7762S	1.3.6.1.4.1.25053.3.1.4.8	ZF 7762-S
	ruckusZF7762T	1.3.6.1.4.1.25053.3.1.4.9	ZF 7762-T
	ruckusZF7762N	1.3.6.1.4.1.25053.3.1.4.10	ZF 7762-N
	ruckusZF7343	1.3.6.1.4.1.25053.3.1.4.12	ZF 7343
	ruckusZF7363	1.3.6.1.4.1.25053.3.1.4.13	ZF 7363
	ruckusZF7341	1.3.6.1.4.1.25053.3.1.4.14	ZF 7341
	ruckusZF7211	1.3.6.1.4.1.25053.3.1.4.15	ZF 7211
	ruckusZF7731	1.3.6.1.4.1.25053.3.1.4.16	ZF 7731
	ruckusZF7025	1.3.6.1.4.1.25053.3.1.4.20	ZF 7025
	ruckusZF7321	1.3.6.1.4.1.25053.3.1.4.22	ZF 7321
	ruckusZF7321U	1.3.6.1.4.1.25053.3.1.4.23	ZF 7321-U
	ruckusZF2741EXT	1.3.6.1.4.1.25053.3.1.4.24	ZF 2471-EXT
	ruckusZF7982	1.3.6.1.4.1.25053.3.1.4.25	ZF 7982
	ruckusZF7782	1.3.6.1.4.1.25053.3.1.4.28	ZF 7782
	ruckusZF7782S	1.3.6.1.4.1.25053.3.1.4.29	ZF 7782-S
	ruckusZF7782N	1.3.6.1.4.1.25053.3.1.4.30	ZF 7782-N
	ruckusZF7782E	1.3.6.1.4.1.25053.3.1.4.31	ZF 7782-E
	ruckusZF8800SAC	1.3.6.1.4.1.25053.3.1.4.32	ZF 8800-S-AC
	ruckusZF7762AC	1.3.6.1.4.1.25053.3.1.4.35	ZF 7762-AC
	ruckusZF7762SAC	1.3.6.1.4.1.25053.3.1.4.36	ZF 7762-S-AC
	ruckusZF7762TAC	1.3.6.1.4.1.25053.3.1.4.37	ZF 7762-T-AC
	ruckusZF7372	1.3.6.1.4.1.25053.3.1.4.40	ZF 7372
	ruckusZF7372E	1.3.6.1.4.1.25053.3.1.4.41	ZF 7372-E
	ruckusZF7352	1.3.6.1.4.1.25053.3.1.4.45	ZF 7352

**TABLE 153** Ruckus Wireless Hotzone Products MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZF7351	1.3.6.1.4.1.25053.3.1.4.48	ZF 7351
	ruckusZF7742	1.3.6.1.4.1.25053.3.1.4.50	ZF 7742
	ruckusZF7055	1.3.6.1.4.1.25053.3.1.4.52	ZF 7055
	ruckusZF7781M	1.3.6.1.4.1.25053.3.1.4.55	ZF 7781-M
	ruckusZF7781CM	1.3.6.1.4.1.25053.3.1.4.56	ZF 7781CM
	ruckusZF7781CME	1.3.6.1.4.1.25053.3.1.4.57	ZF 7781CM-E
	ruckusZF7781CMS	1.3.6.1.4.1.25053.3.1.4.58	ZF 7781CM-S
	ruckusZF7781FN	1.3.6.1.4.1.25053.3.1.4.60	ZF 7781-FN
	ruckusZF7781FNE	1.3.6.1.4.1.25053.3.1.4.61	ZF 7781-FN-E
	ruckusZF7781FNS	1.3.6.1.4.1.25053.3.1.4.62	ZF 7781-FN-S
	ruckusSC8800SAC	1.3.6.1.4.1.25053.3.1.4.65	SC8800-S-AC
	ruckusSC8800S	1.3.6.1.4.1.25053.3.1.4.66	SC8800-S
	ruckusR300	1.3.6.1.4.1.25053.3.1.4.67	R300
	ruckusR700	1.3.6.1.4.1.25053.3.1.4.68	R700
	ruckusR710	1.3.6.1.4.1.25053.3.1.4.69	R710
	ruckusR500E	1.3.6.1.4.1.25053.3.1.4.70	R500e
	ruckusR500	1.3.6.1.4.1.25053.3.1.4.71	R500
	ruckusr600	1.3.6.1.4.1.25053.3.1.4.72	R600
	ruckusT300	1.3.6.1.4.1.25053.3.1.4.74	T300
	ruckusT300E	1.3.6.1.4.1.25053.3.1.4.75	T300e
	ruckusT301N	1.3.6.1.4.1.25053.3.1.4.76	T301n
	ruckusT301S	1.3.6.1.4.1.25053.3.1.4.77	T301s
	ruckusH500	1.3.6.1.4.1.25053.3.1.4.78	H500
	ruckusC500	1.3.6.1.4.1.25053.3.1.4.79	C500
	ruckusP300	1.3.6.1.4.1.25053.3.1.4.81	P300
	ruckusFZM300	1.3.6.1.4.1.25053.3.1.4.85	FZM300
	ruckusFZP300	1.3.6.1.4.1.25053.3.1.4.86	FZP300
	ruckusR310	1.3.6.1.4.1.25053.3.1.4.88	R310
	ruckusR320	1.3.6.1.4.1.25053.3.1.4.89	R320
	ruckusT710	1.3.6.1.4.1.25053.3.1.4.90	T710
	ruckusR510	1.3.6.1.4.1.25053.3.1.4.91	R510
	RuckusH510	1.3.6.1.4.1.25053.3.1.4.92	H510
	ruckusH320	1.3.6.1.4.1.25053.3.1.4.93	H320
	ruckusE510	1.3.6.1.4.1.25053.3.1.4.94	E510
	ruckusC110	1.3.6.1.4.1.25053.3.1.4.95	C110
	ruckusCMM310	1.3.6.1.4.1.25053.3.1.4.96	CMM310
	ruckusT811CM	1.3.6.1.4.1.25053.3.1.4.97	T811CM
	ruckusT610S	1.3.6.1.4.1.25053.3.1.4.99	T610s
	ruckusR610	1.3.6.1.4.1.25053.3.1.4.100	R610
	ruckusT610	1.3.6.1.4.1.25053.3.1.4.101	T610
	ruckusR720	1.3.6.1.4.1.25053.3.1.4.102	R720

## Ruckus Product MIBs

Ruckus Wireless Hotzone Product MIBs

**TABLE 153** Ruckus Wireless Hotzone Products MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusT310C	1.3.6.1.4.1.25053.3.1.4.103	T310c
	ruckusT310D	1.3.6.1.4.1.25053.3.1.4.104	T310d
	ruckusT310N	1.3.6.1.4.1.25053.3.1.4.105	T310n
	ruckusT310S	1.3.6.1.4.1.25053.3.1.4.106	T310s
	ruckusM510	1.3.6.1.4.1.25053.3.1.4.107	M510
	ruckusR730	1.3.6.1.4.1.25053.3.1.4.108	R730
	ruckusR750	1.3.6.1.4.1.25053.3.1.4.109	R750
	ruckusT305I	1.3.6.1.4.1.25053.3.1.4.110	T305i
	ruckusT305E	1.3.6.1.4.1.25053.3.1.4.111	T305e
	ruckusT750	1.3.6.1.4.1.25053.3.1.4.112	T750
	ruckusR650	1.3.6.1.4.1.25053.3.1.4.113	R650
	ruckusR550	1.3.6.1.4.1.25053.3.1.4.114	R550
	ruckusR850	1.3.6.1.4.1.25053.3.1.4.115	R850
	ruckusT750SE	1.3.6.1.4.1.25053.3.1.4.116	T750-SE
	ruckusC110ControlLED	1.3.6.1.4.1.25053.3.1.4.95.3	Reboot/reset AP or CM: (10): soft reset AP (12): factory reset AP (13): soft reset CM (15): factory reset CM
	ruckusC110WanIPAddr	1.3.6.1.4.1.25053.3.1.4.95.4	Specifies the IP address of the Cable Modem WAN interface.
	ruckusC110Customization	1.3.6.1.4.1.25053.3.1.4.95.1	C110 customization
	ruckusC110HTTPService	1.3.6.1.4.1.25053.3.1.4.95.1.1	Enable/disable HTTP service.
	ruckusC110TelnetService	1.3.6.1.4.1.25053.3.1.4.95.1.2	Enable/disable Telnet service.
	ruckusC110SSHSService	1.3.6.1.4.1.25053.3.1.4.95.1.3	Enable/disable SSH service.
	ruckusC110Username	1.3.6.1.4.1.25053.3.1.4.95.1.4	Specifies username of cable modem.
	ruckusC110Password	1.3.6.1.4.1.25053.3.1.4.95.1.5	Specifies password of cable modem.
	ruckusC110CpeAgingOutTimer	1.3.6.1.4.1.25053.3.1.4.95.9	While CM is adding the CPE in the learning table, if it reaches the number of MAX CPE it will remove the existing CPE which has no upstream traffic for N seconds. Where N is the value of this MIB. N=0 means to follow original implementation. That is no CPE will be removed for any new comers.

**TABLE 153** Ruckus Wireless Hotzone Products MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusC110WanIPV6Addr	1.3.6.1.4.1.25053.3.1.4.95.9	Specifies the IPV6 address of the Cable Modem WAN interface.
	ruckusT811CMControlLED	1.3.6.1.4.1.25053.3.1.4.97.3	softResetAP(10): Soft reset of Access Point, factoryResetAP(12): Reset Access Point to factory defaults, softResetCM(13): Soft reset of Cable Modem, factoryResetCM(15): Reset Cable Modem to factory defaults"
	ruckusCMM310WanIPAddr	1.3.6.1.4.1.25053.3.1.4.97.4	Specifies the IP address of the Cable Modem WAN interface.
	ruckusCMM310WanIPV6Addr	1.3.6.1.4.1.25053.3.1.4.97.10	Specifies the IPV6 address of the Cable Modem WAN interface.
	ruckusCMM310ControlLED	1.3.6.1.4.1.25053.3.1.4.96.3	softResetAP(10): Soft reset of Access Point, factoryResetAP(12): Reset Access Point to factory defaults, softResetCM(13): Soft reset of Cable Modem, factoryResetCM(15): Reset Cable Modem to factory defaults
	ruckusCMM310WanIPAddr	1.3.6.1.4.1.25053.3.1.4.96.4	Specifies the IP address of the Cable Modem WAN interface.
	ruckusCMM310Customization	1.3.6.1.4.1.25053.3.1.4.96.5	Cable Modem customization.
	ruckusCMM310HTTPService	1.3.6.1.4.1.25053.3.1.4.96.5.1	Enable/disable HTTP service.
	ruckusCMM310TelnetService	1.3.6.1.4.1.25053.3.1.4.96.5.2	Enable/disable Telnet service.
	ruckusCMM310SSHSERVICE	1.3.6.1.4.1.25053.3.1.4.96.5.3	Cable Modem SSH service.
	ruckusCMM310SSHlanService	1.3.6.1.4.1.25053.3.1.4.96.5.3.1	Enable/disable SSH service for Lan.
	ruckusCMM310SSHwanService	1.3.6.1.4.1.25053.3.1.4.96.5.3.2	Enable/disable SSH service for Wan.
	ruckusCMM310Username	1.3.6.1.4.1.25053.3.1.4.96.5.4	Specifies username of cable modem.
	ruckusCMM310Password	1.3.6.1.4.1.25053.3.1.4.96.5.5	Specifies password of cable modem.
	ruckusCMM310SKUInformation	1.3.6.1.4.1.25053.3.1.4.96.5.6	Cable Modem SKU information.

## Ruckus Product MIBs

Ruckus Wireless Hotzone Product MIBs

**TABLE 153** Ruckus Wireless Hotzone Products MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusCMM310SKUID	1.3.6.1.4.1.25053.3.1.4.96.5.6.1	Specifies the cable modem SKU SKU ID RF CAPABILITY DEFAULT SPLIT ruckusCMM310-001(1):Base (NA) DOCSIS 3.1 SKU (5-42, 108-1218), (5-85, 108-1218) (5-85, 108-1218) ruckusCMM310-002(2):Charter (NA) DOCSIS 3.1 SKU (5-46, 258-1218), (5-204, 258-1218) (5-204, 258-1218) ruckusCMM310-003(3):Base (Euro) DOCSIS 3.1 SKU (5-65, 258-1218), (5-204, 258-1218) (5-204, 258-1218) ruckusCMM310-004(4):Base (NA) DOCSIS 3.0 SKU (5-42, 54-1002) (5-42, 54-1002) ruckusCMM310-005(5):Base (Euro) DOCSIS 3.0 SKU (5-65, 87.5-1002) (5-65, 87.5-1002).
	ruckusCMM310SKUCurrentRFSplit	1.3.6.1.4.1.25053.3.1.4.96.5.6.2	Specifies the RF Split for the given SKU.
	ruckusCMM310EthernetMonitorService	1.3.6.1.4.1.25053.3.1.4.96.5.6.7	Enable/disable Ethernet Monitor Service. For Ruckus Internal use only.
	ruckusCMM310CpeAgingOutTimer	1.3.6.1.4.1.25053.3.1.4.96.9	While CM is adding the CPE in the learning table, if it reaches the number of MAX CPE it will remove the existing CPE which has no upstream traffic for N seconds. Where N is the value of this MIB. N=0 means to follow original implementation. That is no CPE will be removed for any newcomer.
	ruckusCMM310WanIPv6Addr	1.3.6.1.4.1.25053.3.1.4.96.10	Specifies the IPv6 address of the Cable Modem WAN interface.
	ruckusZF7761CM	1.3.6.1.4.1.25053.3.1.4.7	ZF 7761-CM
	ruckusZF7761CMResetCM	1.3.6.1.4.1.25053.3.1.4.7.1	ZF 7761-CM
	ruckusZF7761CMResetAP	1.3.6.1.4.1.25053.3.1.4.7.2	ZF 7761-CM
	ruckusZF7761CMControlLED	1.3.6.1.4.1.25053.3.1.4.7.3	ZF 7761-CM LED controls.
	ruckusZF7761CMWanIPAddr	1.3.6.1.4.1.25053.3.1.4.7.4	Specifies the IP address of the Cable Modem WAN interface.

**TABLE 153** Ruckus Wireless Hotzone Products MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZF7761CMCustomization	1.3.6.1.4.1.25053.3.1.4.7.5	ZF 7761-CM
	ruckusZF7761CMHTTPService	1.3.6.1.4.1.25053.3.1.4.7.5.1	Enable/disable HTTP service.
	ruckusZF7761CMTelnetService	1.3.6.1.4.1.25053.3.1.4.7.5.2	Enable/disable Telnet service.
	ruckusZF7761CMSSHSERVICE	1.3.6.1.4.1.25053.3.1.4.7.5.3	Enable/disable SSH service.
	ruckusZF7761CMUsername	1.3.6.1.4.1.25053.3.1.4.7.5.4	Specifies username of cable modem.
	ruckusZF7761CMPassword	1.3.6.1.4.1.25053.3.1.4.7.5.5	Specifies password of cable modem.
	ruckusZF7761CMLEDMode	1.3.6.1.4.1.25053.3.1.4.7.6	ledAllOff(0): All LEDs disabled after 3 second delay, blueActive(1): Blue Active Surge Protection Indicator, blueActiveCMOnlineLed(2): Blue Active Surge Protection Indicator and Cable Modem online Green LED enabled.
	ruckusZF7761CMHeartbeatMonitorCM	1.3.6.1.4.1.25053.3.1.4.7.7	Enable/disable Cable Modem heartbeat monitoring.
	ruckusZF7761CMHeartbeatMonitorAP	1.3.6.1.4.1.25053.3.1.4.7.8	Enable/disable Access Point heartbeat monitoring.

## Ruckus Controller Product MIBs

The following table lists the node names, OIDs and descriptions of each object in the ruckusWirelessControllerProducts MIB tree.

**TABLE 154** Ruckus Wireless Controller Products MIBs

MIB Tree	Node Name	OID	Description
ruckusWirelessControllerProducts	ruckusZD1000	1.3.6.1.4.1.25053.3.1.5.1	ZD 1000
	ruckusZD1000SystemName	1.3.6.1.4.1.25053.3.1.5.1.1	System name
	ruckusZD1000SystemIPAddr	1.3.6.1.4.1.25053.3.1.5.1.2	IP address
	ruckusZD1000SystemMacAddr	1.3.6.1.4.1.25053.3.1.5.1.3	MAC address
	ruckusZD1000SystemUptime	1.3.6.1.4.1.25053.3.1.5.1.4	Up time
	ruckusZD1000SystemModel	1.3.6.1.4.1.25053.3.1.5.1.5	Model
	ruckusZD1000SystemLicensedAPs	1.3.6.1.4.1.25053.3.1.5.1.6	Licensed APs
	ruckusZD1000SystemSerialNumber	1.3.6.1.4.1.25053.3.1.5.1.7	Serial number
	ruckusZD1000SystemVersion	1.3.6.1.4.1.25053.3.1.5.1.8	Software version
	ruckusZD1000CountryCode	1.3.6.1.4.1.25053.3.1.5.1.9	Country code
	ruckusZD1100	1.3.6.1.4.1.25053.3.1.5.2	ZD 1100
	ruckusZD1100SystemName	1.3.6.1.4.1.25053.3.1.5.21	System name

## Ruckus Product MIBs

Ruckus Controller Product MIBs

**TABLE 154** Ruckus Wireless Controller Products MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZD1100SystemIPAddr	1.3.6.1.4.1.25053.3.1.5.2.2	IP address
	ruckusZD1100SystemMacAddr	1.3.6.1.4.1.25053.3.1.5.2.3	MAC address
	ruckusZD1100SystemUptime	1.3.6.1.4.1.25053.3.1.5.2.4	Up time
	ruckusZD1100SystemModel	1.3.6.1.4.1.25053.3.1.5.2.5	Model
	ruckusZD1100SystemLicensedAPs	1.3.6.1.4.1.25053.3.1.5.2.6	Licensed APs
	ruckusZD1100SystemSerialNumber	1.3.6.1.4.1.25053.3.1.5.2.7	Serial number
	ruckusZD1100SystemVersion	1.3.6.1.4.1.25053.3.1.5.2.8	Software version
	ruckusZD1100CountryCode	1.3.6.1.4.1.25053.3.1.5.2.9	Country code
	ruckusZD3000	1.3.6.1.4.1.25053.3.1.5.3	ZD 3000
	ruckusZD3000SystemName	1.3.6.1.4.1.25053.3.1.5.3.1	System name
	ruckusZD3000SystemIPAddr	1.3.6.1.4.1.25053.3.1.5.3.2	IP address
	ruckusZD3000SystemMacAddr	1.3.6.1.4.1.25053.3.1.5.3.3	MAC address
	ruckusZD3000SystemUptime	1.3.6.1.4.1.25053.3.1.5.3.4	Up time
	ruckusZD3000SystemModel	1.3.6.1.4.1.25053.3.1.5.3.5	Model
	ruckusZD3000SystemLicensedAPs	1.3.6.1.4.1.25053.3.1.5.3.6	Licensed APs
	ruckusZD3000SystemSerialNumber	1.3.6.1.4.1.25053.3.1.5.3.7	Serial number
	ruckusZD3000SystemVersion	1.3.6.1.4.1.25053.3.1.5.3.8	Software version
	ruckusZD3000CountryCode	1.3.6.1.4.1.25053.3.1.5.3.9	Country code
	ruckusZD5000	1.3.6.1.4.1.25053.3.1.5.8	ZD 5000
	ruckusZD5000SystemName	1.3.6.1.4.1.25053.3.1.5.8.1	System name
	ruckusZD5000SystemIPAddr	1.3.6.1.4.1.25053.3.1.5.8.2	IP address
	ruckusZD5000SystemMacAddr	1.3.6.1.4.1.25053.3.1.5.8.3	MAC address
	ruckusZD5000SystemUptime	1.3.6.1.4.1.25053.3.1.5.8.4	Up time
	ruckusZD5000SystemModel	1.3.6.1.4.1.25053.3.1.5.8.5	Model
	ruckusZD5000SystemLicensedAPs	1.3.6.1.4.1.25053.3.1.5.8.6	Licensed APs
	ruckusZD5000SystemSerialNumber	1.3.6.1.4.1.25053.3.1.5.8.7	Serial number
	ruckusZD5000SystemVersion	1.3.6.1.4.1.25053.3.1.5.8.8	Software version
	ruckusZD5000CountryCode	1.3.6.1.4.1.25053.3.1.5.8.9	Country code
	ruckusZD1200	1.3.6.1.4.1.25053.3.1.5.15	ZD 1200
	ruckusZD1200SystemName	1.3.6.1.4.1.25053.3.1.5.15.1	System name
	ruckusZD1200SystemIPAddr	1.3.6.1.4.1.25053.3.1.5.15.2	IP address
	ruckusZD1200SystemMacAddr	1.3.6.1.4.1.25053.3.1.5.15.3	MAC address
	ruckusZD1200SystemUptime	1.3.6.1.4.1.25053.3.1.5.15.4	Uptime
	ruckusZD1200SystemModel	1.3.6.1.4.1.25053.3.1.5.15.5	Model
	ruckusZD1200SystemLicensedAPs	1.3.6.1.4.1.25053.3.1.5.15.6	Licensed APs
	ruckusZD1200SystemSerialNumber	1.3.6.1.4.1.25053.3.1.5.15.7	Serial number
	ruckusZD1200SystemVersion	1.3.6.1.4.1.25053.3.1.5.15.8	Software version
	ruckusZD1200CountryCode	1.3.6.1.4.1.25053.3.1.5.15.9	Country code

# ZoneDirector WLAN MIBs

• ZoneDirector WLAN MIBs Overview.....	81
• WLAN Info MIBs.....	81
• WLAN AP Info MIBs.....	83
• WLAN AP Radio Stats MIBs.....	86
• WLAN VAP Table MIBs.....	87
• WLAN Interface Table MIBs.....	88
• WLAN AP Ethernet Status Table MIBs.....	90
• WLAN Station Info MIBs.....	90
• WLAN Rogue Info MIBs.....	92

## ZoneDirector WLAN MIBs Overview

The objects contained in the RUCKUS-ZD-WLAN-MIB.txt file provide WLAN information including SSID, encryption settings, transmission statistics, WLAN APs, radio stats, stations and rogue information.

The following tables list the objects within each top-level MIB tree in the RUCKUS-ZD-WLAN-MIB.txt file.

## WLAN Info MIBs

Use the ZoneDirector WLAN Info MIBs to view WLAN settings information. [Table 155](#) lists the node names, OIDs and descriptions of each object in the ruckusZDWLANInfo MIB tree.

**TABLE 155** WLAN Info MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANTable	ruckusZDWLANSSID	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1	SSID.
	ruckusZDWLANDescription	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.2 1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.3	WLAN Description.
	ruckusZDWLANAuthentication	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.3	Authentication method.
	ruckusZDWLANEncryption	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.4	Encryption method.
	ruckusZDWLANIsGuest	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.5	This WLAN is for guest access.
	ruckusZDWLANSSIDBroadcastDisable	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.6	Hide SSID.
	ruckusZDWLANVlanID	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.7	Specifies the VLAN ID of the WLAN. If VLAN ID is 1, packets from this WLAN will be untagged.
	ruckusZDWLANRateLimitingUp	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.8	Rate limiting of uplink.
	ruckusZDWLANRateLimitingDown	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.9	Rate limiting of downlink.
	ruckusZDWLANTunnelWLAN	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.10	Tunnel WLAN.
	ruckusZDWLANNumVAP	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.11	Number of APs.
	ruckusZDWLANNumSta	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.12	Number of client devices.

**TABLE 155** WLAN Info MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANRxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.13	Received packets.
	ruckusZDWLANRxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.14	Received bytes.
	ruckusZDWLANTxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.15	Transmitted packets.
	ruckusZDWLANTxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.16	Transmitted bytes.
	ruckusZDWLANAssocNumSta	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.20	Number of associated client devices, includes authorized and unauthorized.
	ruckusZDWLANAuthTotal	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.26	Accumulated total number of attempt to authenticate by wireless terminals on this WLAN, or Authentication request.
	ruckusZDWLANAuthResp	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.27	Authentication response.
	ruckusZDWLANAuthSuccess	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.28	Accumulated total number of success out of Wireless authentication attempts.
	ruckusZDWLANAuthFail	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.29	Authentication fail.
	ruckusZDWLANAssocTotal	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.30	Accumulated total number of access of wireless terminal on this WLAN, or Association request.
	ruckusZDWLANAssocResp	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.31	Association response.
	ruckusZDWLANReassocReq	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.32	Reassociation request.
	ruckusZDWLANReassocResp	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.33	Reassociation response.
	ruckusZDWLANAssocSuccess	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.34	Association success.
	ruckusZDWLANAssocFail	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.3	Association fail.
	ruckusZDWLANAssocDenied	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.36	Association denied.
	ruckusZDWLANDiassocAbnormal	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.37	Disassociation request due to abnormal causes.
	ruckusZDWLANDiassocCapacity	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.38	Disassociation request due to device capacity.
	ruckusZDWLANDiassocLeave	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.39	Disassociation request due to client leave.
	ruckusZDWLANDiassocMisc	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.40	Disassociation request due to other reasons.
	ruckusZDWLANRxByteRate	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.41	Received rate Kbyte/s in last 90 seconds.
	ruckusZDWLANTxByteRate	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.42	Transmitted rate Kbyte/s in last 90 seconds.
	ruckusZDWLANRxDataFrameOnLan	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.43	Received Data Frame Number on Lan interface.
	ruckusZDWLANRxByteOnLan	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.1.44	Received Data Bytes on Lan interface.

**TABLE 155** WLAN Info MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANTxByteOnLan	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.45	Transmitted Data Bytes on Lan interface.
	ruckusZDWLANDownDropFrame	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.46	Drop Frame Number on Downlink of Wireless.
	ruckusZDWLANDownRetxFrame	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.47	Retransmitted Frame Number on Downlink of Wireless.
	ruckusZDWLANDownTotalFrame	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.48	Total Frame Number on Downlink of Wireless.
	ruckusZDWLANDownTotalErrFrame	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.49	Total Error Frame Number on Downlink of Wireless.
	ruckusZDWLANUpTotalFrame	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.50	Total Frame Number on Uplink of Wireless.
	ruckusZDWLANUpDropFrame	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.51	Drop Frame Number on Uplink of Wireless.
	ruckusZDWLANUpRetxFrame	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.52	Retransmitted Frame Number on Uplink of Wireless.
	ruckusZDWLANNAME	1.3.6.1.4.1.25053.1.2.2.1.1.1.1.108	WLAN NAME.

## WLAN AP Info MIBs

Use the ZoneDirector WLAN AP Info MIBs to view WLAN AP settings information. [Table 156](#) lists the node names, OIDs and descriptions of each object in the ruckusZDWLANAPInfo MIB tree.

**TABLE 156** WLAN AP Info MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANAPTable	ruckusZDWLANAPMacAddr	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.1	MAC address.
	ruckusZDWLANAPDescription	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.2	Description.
	ruckusZDWLANAPStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.3	The connection status with ZD.
	ruckusZDWLANAPModel	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.4	Model name.
	ruckusZDWLANAPSerialNumber	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.5	Serial number.
	ruckusZDWLANAPUptime	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.6	Up time.
	ruckusZDWLANAPSWversion	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.7	Software version.
	ruckusZDWLANAPHWversion	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.8	Hardware version.
	ruckusZDWLANAPIPAddrMode	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.9	IP mode.
	ruckusZDWLANAPIPAddr	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.10	IP address.
	ruckusZDWLANAPNumRadios	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.13	Number of radios.
	ruckusZDWLANAPNumVAP	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.14	Number of APs.
	ruckusZDWLANAPNumSta	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.15	Total number of authenticated terminal which is using currently on this AP.

## ZoneDirector WLAN MIBs

### WLAN AP Info MIBs

**TABLE 156 WLAN AP Info MIBs (continued)**

MIB Tree	Node Name	OID	Description
	ruckusZDWLANAPNumRogues	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.16	Number of rogue devices.
	ruckusZDWLANAPConnectionMode	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.17	The connection mode with ZD.
	ruckusZDWLANAPMeshEnable	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.18	Mesh enable.
	ruckusZDWLANAPMeshHops	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.19	Number of mesh hops.
	ruckusZDWLANAPMeshType	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.20	Mesh type.
	ruckusZDWLANAPLANStatsRXByte	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.21	Bytes received on LAN port.
	ruckusZDWLANAPLANStatsRXPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.22	Packets received on LAN port.
	ruckusZDWLANAPLANStatsRXPktErr	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.23	Packets received erroneously on LAN port.
	ruckusZDWLANAPLANStatsRXPKTsSucc	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.24	Packets received successfully on LAN port.
	ruckusZDWLANAPPLANStatsTXByte	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.25	Bytes transmitted on LAN port.
	ruckusZDWLANAPPLANStatsTXPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.26	Packets transmitted on LAN port.
	ruckusZDWLANAPMemUtil	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.27	Memory utilization in KB.
	ruckusZDWLANAPMemTotal	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.28	Total memory in KB.
	ruckusZDWLANAPCPUUtil	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.29	CPU utilization percentage.
	ruckusZDWLANAPFWSize	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.30	Firmware partition size in byte.
	ruckusZDWLANAPFWAvail	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.31	Firmware partition available size in byte.
	ruckusZDWLANAPMultipleVlanCapability	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.32	AP support multiple vlan capability.
	ruckusZDWLANAP11bCapable	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.36	Support 802.11b.
	ruckusZDWLANAP11gCapable	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.37	Support 802.11g.
	ruckusZDWLANAPMultiModeAccessStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.38	Support simultaneously connections from 11a/b/g clients.
	ruckusZDWLANAPEthStateChange	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.39	Ethernet port up/down count.
	ruckusZDWLANAPSyncConf	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.41	Manually push configuration to this AP.
	ruckusZDWLANAPUpgrade	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.42	Upgrade this AP.
	ruckusZDWLANAPFirstJoinTime	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.43	Time of first join.
	ruckusZDWLANAPLastBootTime	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.44	Time of last boot.
	ruckusZDWLANAPLastUpgradeTime	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.45	Time of last firmware upgrade.
	ruckusZDWLANAPLastConfSyncTime	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.46	Time of last configuration synchronization.

**TABLE 156 WLAN AP Info MIBs (continued)**

MIB Tree	Node Name	OID	Description
	ruckusZDWLANAPLANStatsRXPKTBcast	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.47	Broadcast packets received successfully on LAN port.
	ruckusZDWLANAPLANStatsRXPKTMcast	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.48	Multicast packets received successfully on LAN port.
	ruckusZDWLANAPLANStatsRXPKTUcast	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.49	Unicast packets received successfully on LAN port.
	ruckusZDWLANAPLANStatsTXPKTBcast	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.50	Broadcast packets transmitted successfully on LAN port.
	ruckusZDWLANAPLANStatsTXPKTMcast	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.51	Multicast packets transmitted successfully on LAN port.
	ruckusZDWLANAPLANStatsTXPKTUcast	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.52	Unicast packets transmitted successfully on LAN port.
	ruckusZDWLANAPLANStatsDropped	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.53	Number of packets dropped on LAN port.
	ruckusZDWLANAPMeshUpPortCntUpdown	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.54	/updown count of AP as a up port node in mesh mode.
	ruckusZDWLANAPMeshDownPortCntUpdown	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.55	/updown count of AP as a down port node in mesh mode.
	ruckusZDWLANAPTxFrameDropped	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.57	Dropped Frame count of AP wireless transmitted.
	ruckusZDWLANAPTxFrameError	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.58	Error Frame count of AP wireless transmitted.
	ruckusZDWLANAPCoverageTech	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.59	AP's coverage technology.
	ruckusZDWLANAPStaTxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.61	Client send data to this AP.(kbytes)
	ruckusZDWLANAPStaRxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.62	Client receive data from this AP.(kbytes)
	ruckusZDWLANAPNetmask	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.100	Netmask address.
	ruckusZDWLANAPGateway	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.101	Gateway address.
	ruckusZDWLANAPIpv4DNSSvr1	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.105	Primary DNS address.
	ruckusZDWLANAPIpv4DNSSvr2	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.106	Second DNS address.
	ruckusZDWLANAPTotalUser	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.110	Total number of client AP can support.
	ruckusZDWLANAPLANStatsRXByteRate	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.111	Bytes rate received on LAN port each 90s.
	ruckusZDWLANAPLANStatsTXByteRate	1.3.6.1.4.1.25053.1.2.2.1.1.2.1.1.112	Bytes rate transmitted on LAN port each 90s.

## WLAN AP Radio Stats MIBs

Use the ZoneDirector WLAN AP Info MIBs to view WLAN AP settings information. [Table 157](#) lists the node names, OIDs and descriptions of each object in the ruckusZDWLANAPRadioStatsTable MIB tree.

**TABLE 157** ZD WLAN AP Radio Stats Table MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANAPRadioStatsTable	ruckusZDWLANAPRadioStatsAPMacAddr	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.1	AP MAC address.
	ruckusZDWLANAPRadioStatsRadioIndex	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.2	Radio index of the AP.
	ruckusZDWLANAPRadioStatsRadioType	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.3	Radio type: {radio11bg (0), radio11a (1), radio11ng(2), radio11na(3), radio11ac(4), radio11axg(6), radio11axa(7)}
	ruckusZDWLANAPRadioStatsChannel	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.4	Radio channel.
	ruckusZDWLANAPRadioStatsTxPower	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.5	Transmit power of radio.
	ruckusZDWLANAPRadioStatsMeshEnable	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.6	Mesh enable.
	ruckusZDWLANAPRadioStatsNumVAP	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.7	Number of APs.
	ruckusZDWLANAPRadioStatsNumSta	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.8	Number of stations.
	ruckusZDWLANAPRadioStatsAvgStaRSSI	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.9	Average client RSSI.
	ruckusZDWLANAPRadioStatsRxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.10	Received packets.
	ruckusZDWLANAPRadioStatsRxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.11	Received bytes.
	ruckusZDWLANAPRadioStatsRxMulticast	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.12	Received multicast packets.
	ruckusZDWLANAPRadioStatsTxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.13	Transmitted packets.
	ruckusZDWLANAPRadioStatsTxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.14	Transmitted bytes.
	ruckusZDWLANAPRadioStatsTxMulticast	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.15	Transmitted multicast packets.
	ruckusZDWLANAPRadioStatsTxFail	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.16	Transmitted fail packets.
	ruckusZDWLANAPRadioStatsTxRetries	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.17	Transmitted retry packets.
	ruckusZDWLANAPRadioStatsPowerMgmt	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.18	Power management enable.
	ruckusZDWLANAPRadioStatsMaxSta	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.19	Number of max stations allowed.
	ruckusZDWLANAPRadioStatsFrameErrorRate	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.20	Frame error rate.
	ruckusZDWLANAPRadioStatsFrameRetryRate	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.21	Frame retry rate.
	ruckusZDWLANAPRadioStatsMonitoredTime	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.22	Monitored time.
	ruckusZDWLANAPRadioStatsTotalAssocTime	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.24	Client total association time.
	ruckusZDWLANAPRadioStatsAuthReq	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.25	Authentication request.
	ruckusZDWLANAPRadioStatsAuthResp	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.26	Authentication response.
	ruckusZDWLANAPRadioStatsAuthSuccess	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.27	Authentication success.
	ruckusZDWLANAPRadioStatsAuthFail	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.28	Authentication fail.

**TABLE 157** ZD WLAN AP Radio Stats Table MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANAPRadioStatsAssocReq	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.29	Association request.
	ruckusZDWLANAPRadioStatsAssocResp	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.30	Association response.
	ruckusZDWLANAPRadioStatsReassocReq	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.31	Reassociation request.
	ruckusZDWLANAPRadioStatsReassocResp	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.32	Reassociation response.
	ruckusZDWLANAPRadioStatsAssocSuccess	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.33	Association success.
	ruckusZDWLANAPRadioStatsAssocFail	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.34	Association fail.
	ruckusZDWLANAPRadioStatsAssocDenied	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.35	Association denied.
	ruckusZDWLANAPRadioStatsDiassocAbnormal	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.36	Disassociation request due to abnormal causes.
	ruckusZDWLANAPRadioStatsDiassocCapacity	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.37	Disassociation request due to device capacity.
	ruckusZDWLANAPRadioStatsDiassocLeave	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.38	Disassociation request due to client leave.
	ruckusZDWLANAPRadioStatsDiassocMisc	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.39	Disassociation request due to other reasons.
	ruckusZDWLANAPRadioStatsResourceUtil	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.40	Resource utilization.
	ruckusZDWLANAPRadioStatsRxSignalFrm	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.41	Received signal frames.
	ruckusZDWLANAPRadioStatsTxSignalFrm	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.42	Transmitted signal frames.
	ruckusZDWLANAPRadioStatsTotalSignalFrm	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.43	Total signal frames.
	ruckusZDWLANAPRadioStatsAntennaGain	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.44	Get antenna gain.
	ruckusZDWLANAPRadioStatsBeaconPeriod	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.45	Get beacon period.
	ruckusZDWLANAPRadioStatsRTSThreshold	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.46	Get RTS threshold.
	ruckusZDWLANAPRadioStatsFragThreshold	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.47	Get fragment threshold.

## WLAN VAP Table MIBs

Use the ZoneDirector WLAN VAP Info MIBs to view WLAN VAP settings information. [Table 158](#) lists the node names, OIDs and descriptions of each object in the ruckusZDWLANVapTable MIB tree.

**TABLE 158** ZD WLAN VAP Table MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANVapTable	ruckusZDWLANVapBSSID	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.1	The VAP's BSSID ,it is a MAC Address.
	ruckusZDWLANVapPAPAddr	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.2	The MAC address of the Parent's AP.
	ruckusZDWLANVapSSID	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.3	SSID of VAP.
	ruckusZDWLANVapLanRxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.6	Received bytes on LAN in VAP.
	ruckusZDWLANVapLanTxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.7	Transmitted bytes on LAN in VAP.
	ruckusZDWLANVapWlanRxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.8	Received bytes on WLAN in VAP.

**TABLE 158** ZD WLAN VAP Table MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANVapWlanTxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.9	Transmitted bytes on WLAN in VAP.
	ruckusZDWLANVapWlanRxErrorPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.11	Received error packet on WLAN in VAP.
	ruckusZDWLANVapWlanRxUnicastPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.12	Received unicast packet on WLAN in VAP.
	ruckusZDWLANVapWlanTxUnicastPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.13	Transmitted unicast packet on WLAN in VAP.
	ruckusZDWLANVapWlanRxPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.14	Received packet on WLAN in VAP.
	ruckusZDWLANVapWlanRxDropPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.15	Received dropped packet on WLAN in VAP.
	ruckusZDWLANVapWlanTxErrPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.16	Transmitted error packet on WLAN in VAP.
	ruckusZDWLANVapWlanTxPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.17	Transmitted packet on WLAN in VAP.
	ruckusZDWLANVapWlanTxDropPkt	1.3.6.1.4.1.25053.1.2.2.1.1.2.3.1.18	Transmitted dropped packet on WLAN in VAP.

## WLAN Interface Table MIBs

Use the ZoneDirector WLAN VAP Info MIBs to view WLAN IF settings information. [Table 159](#) lists the node names, OIDs and descriptions of each object in the ruckusZDWLANIfTable MIB tree.

**TABLE 159** WLAN Interface Table MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANIfTable	ruckusZDWLANAPMac	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.1	The AP's Mac Address.
	ruckusZDWLANAPIfIndex	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.2	The index of Interface in AP.
	ruckusZDWLANAPIfDescr	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.3	The Description information for this interface.
	ruckusZDWLANAPIfType	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.4	The type of interface.
	ruckusZDWLANAPIfMtu	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.5	The size of the largest packet which can be sent/received.
	ruckusZDWLANAPIfSpeed	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.6	An estimate of the interface's current bandwidth in bits.
	ruckusZDWLANAPIfPhysAddress	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.7	The interface's mac address.
	ruckusZDWLANAPIfAdminStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.8	The desired state of the interface: up(1), down(2) ,testing(3).

**TABLE 159** WLAN Interface Table MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANAPIfOperStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.9	The current operational state of the interface: up(1), down(2), testing(3), unknown(4), dormant(5), notPresent(6), lowerLayerDown(7).
	ruckusZDWLANAPIfInOctets	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.10	The total number of octets received on the interface.
	ruckusZDWLANAPIfInUcastPkts	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.11	The total number of unicast packets received on the interface.
	ruckusZDWLANAPIfInNUcastPkts	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.12	The total number of multicast and broadcast packets received on the interface.
	ruckusZDWLANAPIfInDiscards	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.13	The number of inbound packets which were chosen to be discarded even though no errors had been detected .
	ruckusZDWLANAPIfInErrors	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.14	The number of inbound packets that contained errors.
	ruckusZDWLANAPIfInUnknownProtos	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.15	The number of packets received via the interface which were discarded because of an unknown or unsupported protocol.
	ruckusZDWLANAPIfOutOctets	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.16	The total number of octets transmitted out of the interface.
	ruckusZDWLANAPIfOutUcastPkts	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.17	The total number of unicast packets transmitted out of the interface.
	ruckusZDWLANAPIfOutNUcastPkts	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.18	The total number of multicast and broadcast packets transmitted out of the interface.
	ruckusZDWLANAPIfOutDiscards	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.19	The number of outbound packets which were chosen to be discarded even though no errors had been detected.
	ruckusZDWLANAPIfOutErrors	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.20	The number of outbound packets that could not be transmitted because of errors.
	ruckusZDWLANAPIfName	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.21	The name of interface.
	ruckusZDWLANAPIfNameDefined	1.3.6.1.4.1.25053.1.2.2.1.1.2.4.1.22	The alias of interface.

## WLAN AP Ethernet Status Table MIBs

Use the ZoneDirector WLAN AP Ethernet Status MIBs to view WLAN AP Ethernet status information. [Table 160](#) lists the node names, OIDs and descriptions of each object in the ruckusZDWLANAPEthStatusTable MIB tree.

**TABLE 160** ZD WLAN AP Ethernet Status Table MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANAPEthStatusTable	ruckusZDWLANAPMacAddress	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.1	The AP's Mac Address.
	ruckusZDWLANAPEthPortId	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.2	The ap ethernet port id.
	ruckusZDWLANAPEthIfName	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.5	The name of interface.
	ruckusZDWLANAPEthDot1xStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.6	The ap ethernet port Dot1xStatus.
	ruckusZDWLANAPEthLogicalStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.7	The ap ethernet port logical status.
	ruckusZDWLANAPEthPhyStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.8	The ap ethernet port physical status.
	ruckusZDWLANAPEthPhyIfSpeed	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.9	The ap ethernet interface's current bandwidth in Mbits,.
	ruckusZDWLANAPEthPhyLinkStatus	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.10	The ap ethernet port physical link status.
	ruckusZDWLANAPEthLabel	1.3.6.1.4.1.25053.1.2.2.1.1.2.8.1.11	The ap ethernet port label.

## WLAN Station Info MIBs

Use the ZoneDirector WLAN Station Info MIBs to view WLAN station information. [Table 161](#) lists the node names, OIDs and descriptions of each object in the ruckusZDWLANStaInfo MIB tree.

**TABLE 161** ZD WLAN Station Table MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANStaTable	ruckusZDWLANStaMacAddr	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.1	The station's MAC Address.
	ruckusZDWLANStaAPMacAddr	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.2	The MAC address of the associated AP.
	ruckusZDWLANStaBSSID	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.3	BSSID of WLAN.
	ruckusZDWLANStaSSID	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.4	SSID.
	ruckusZDWLANStaUser	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.5	Login username of the client.
	ruckusZDWLANStaRadioType	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.6	Radio type: { radio11bg (0), radio11a (1), radio11ng(2), radio11na(3), radio11ac(4), radio11axg(6), radio11axa(7) }
	ruckusZDWLANStaChannel	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.7	Radio channel.
	ruckusZDWLANStaIPAddr	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.8	IP address.

**TABLE 161** ZD WLAN Station Table MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANStaAvgSNR	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.9	Averaged SNR.
	ruckusZDWLANStaRxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.10	Received packets.
	ruckusZDWLANStaRxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.11	Received bytes.
	ruckusZDWLANStaTxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.12	Transmitted packets.
	ruckusZDWLANStaTxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.13	Transmitted bytes.
	ruckusZDWLANStaRetries	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.14	Transmitted retries.
	ruckusZDWLANStaAssocTime	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.15	The time client has been associated.
	ruckusZDWLANStaRxError	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.16	Received error packets.
	ruckusZDWLANStaTxSuccess	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.17	Successful transmitted packets.
	ruckusZDWLANSta11bgReassoc	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.18	Reassociate count on B/G RF.
	ruckusZDWLANStaAssocTimestamp	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.19	The timestamp client associated.
	ruckusZDWLANStaRetryBytes	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.20	Transmitted retry bytes.
	ruckusZDWLANStaSNR	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.21	Station's Signal to Noise Ratio.
	ruckusZDWLANStaRxDrop	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.22	Drop transmitted packets.
	ruckusZDWLANStaTxDrop	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.23	Drop received packets.
	ruckusZDWLANStaTxError	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.24	Transmitted error packets.
	ruckusZDWLANStaVlanID	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.30	VLAN ID of the station. 1 for not specified.
	ruckusZDWLANStaAuthMode	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.80	Authentication mode of authenticated terminal.
	ruckusZDWLANStaSignalStrength	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.81	Signal strength.
rukusZDWiredStaTable			
	ruckusZDWiredStaMacAddr	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.1	The station's MAC Address.
	ruckusZDWiredStaAPMacAddr	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.3	The MAC address of the associated AP.
	ruckusZDWiredStaIPAddr	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.5	IP address.
	ruckusZDWiredStaIPv6Addr	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.6	IPV6 Address.
	ruckusZDWiredStaVlanID	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.8	VLAN ID of the station. 1 for not specified.
	ruckusZDWiredStaUserName	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.9	Login username of the client.
	ruckusZDWiredStaAuthState	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.10	Authentication state of authenticated terminal.
	ruckusZDWiredStaAssocTime	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.11	The time client has been associated.
	ruckusZDWiredStaRxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.15	Received packets.
	ruckusZDWiredStaRxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.16	Received bytes.
	ruckusZDWiredStaTxPkts	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.17	Transmitted packets.

**TABLE 161** ZD WLAN Station Table MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWiredStaTxBytes	1.3.6.1.4.1.25053.1.2.2.1.1.3.2.1.18	Transmitted bytes.

## WLAN Rogue Info MIBs

Use the ZoneDirector WLAN Rogue Info MIBs to view WLAN rogue information. [Table 161](#) on page 90 lists the node names, OIDs and descriptions of each object in the ruckusZDWLANRogueInfo MIB tree.

**TABLE 162** ZD WLAN Rogue Info MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANRogueTable	ruckusZDWLANRogueMacAddr	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.1	Rogue device's MAC Address.
	ruckusZDWLANRogueSSID	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.2	SSID.
	ruckusZDWLANRogueRadioType	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.3	Radio type.
	ruckusZDWLANRogueChannel	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.4	Radio channel.
	ruckusZDWLANRogueRSSI	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.5	RSSI.
	ruckusZDWLANRogueType	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.6	The type of the rogue device.
	ruckusZDWLANRogueEncrypted	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.7	Encryption mode.
	ruckusZDWLANRogueSignalStrength	1.3.6.1.4.1.25053.1.2.2.1.1.4.1.1.11	Signal strength.

# ZoneDirector WLAN Configuration MIBs

• ZoneDirector WLAN Configuration MIBs Overview.....	93
• WLAN Configuration MIBs.....	93

## ZoneDirector WLAN Configuration MIBs Overview

The objects contained in the RUCKUS-ZD-WLAN-CONFIGURATION-MIB.txt file provide WLAN configuration options including WLAN name, encryption settings, WLAN group settings, Hotspot settings and AAA server configuration settings.

The following tables list the objects within each top-level MIB tree in the RUCKUS-ZD-WLAN-CONFIGURATION-MIB.txt file.

## WLAN Configuration MIBs

Use the ZoneDirector WLAN Configuration MIBs to configure WLAN settings. The following table lists the node names, OIDs and descriptions of each object in the WLAN Configuration MIB tree.

**TABLE 163** WLAN Configuration MIBs

MIB Tree	Node Name	OID	Description
ruckusZDWLANConfigTable (SNMPv3 only)	ruckusZDWLANID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.1	WLAN ID for this Wireless LAN (WLAN). Max value: for zd1000 zd1100, 128; for zd3000,1024;for zd5000, 2048.
	ruckusZDWLANConfigSSID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.2	SSID for this Wireless LAN. It can't be modified after creating it.
	ruckusZDWLANConfigDescription	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.3	Description for this Wireless LAN.
	ruckusZDWLANConfigName	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.4	Name for this Wireless LAN.
	ruckusZDWLANConfigWLANSERVICEType	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.8	Select The the Service type for the Wireless LAN.for hotSpotService,only read-only.
	ruckusZDWLANConfigAuthentication	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.10	Authentication method chosen for this Wireless LAN.
	ruckusZDWLANConfigEncryption	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.12	Encryption method chosen for this Wireless LAN.
	ruckusZDWLANConfigWEPKeyIndex	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.15	Select the WEP key index for the WEP encryption.

## ZoneDirector WLAN Configuration MIBs

### WLAN Configuration MIBs

**TABLE 163** WLAN Configuration MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANConfigWEPKey	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.16	Enter the Pass-phrase for the WEP encryption method. Only 10 or 26 Hex character.such as: 1122334455.
	ruckusZDWLANConfigWPACipherType	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.20	Enter the encryption cipher method for the WPA encryption.
	ruckusZDWLANConfigWPAKey	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.21	Enter the Pass-phrase for the WPA encryption.Specifies the WPA PSK (Wi-Fi Protected Access Pre Shared key) If the key length is 64 then all 64 characters should be in hex,otherwise the key assumed to be ascii.
	ruckusZDWLANConfigAuthenticationServerID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.25	Select the Authentication Server by the registered Server ID.This server id must exist in table: ruckusZDAAAConfigTable(aaa-authentication) or local.
	ruckusZDWLANConfigWirelessClientIsolation	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.28	Set Wireless Client Isolation. Clients will be unable to communicate with each other or access restricted subnets.
	ruckusZDWLANConfigWirelessWhiteListID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.29	Make sure client isolation is enabled and then choose one id.
	ruckusZDWLANConfigZeroITActivation	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.30	Enable the Zero IT Activation Service of the Wireless LAN or not.
	ruckusZDWLANConfigWLANHotspotID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.31	Select the Hotspot Server for the Wireless LAN.
	ruckusZDWLANConfigWLANSERVICEPriority	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.32	Select the QOS service priority for the Wireless LAN.
	ruckusZDWLANConfigAccountingServerID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.35	Select the (RADIUS) Accounting Server by the registered Server ID. 0,disable;This server ID must exist in table: ruckusZDAAAConfigTable (AAA-accounting)
	ruckusZDWLANConfigAccountingUpdateInterval	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.36	Enter interval in minutes to update Accounting Server.

**TABLE 163** WLAN Configuration MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANConfigUplinkRate	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.40	Disable or Set the Speed/Rate limiting of uplink. Valid range 0.25mbps~20.00mbps in 0.25mbps steps. Examples: 'disable', '0.25mbps', '0.5mbps'...,'19.75mbps' , '20.00mbps'
	ruckusZDWLANConfigDownlinkRate	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.41	Disable or Set the Speed/Rate limiting of downlink. Valid range 0.25mbps~20.00mbps in 0.25mbps steps. Examples: 'disable', '0.25mbps', '0.5mbps'...,'19.75mbps' , '20.00mbps'
	ruckusZDWLANConfigIGMPSnooping	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.42	IGMP Snooping state of the WLAN.
	ruckusZDWLANConfigVlanID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.45	Specifies the VLAN ID of the WLAN. If VLAN ID is 1, packets from this WLAN will be untagged.
	ruckusZDWLANConfigDynamicVLAN	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.46	Enable the Service of the dynamic Wireless LAN or not. For 802.1x EAP + MAC Address model, 'set' is not supported.
	ruckusZDWLANConfig802dot11d	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.47	Enable 802.11d.
	ruckusZDWLANConfigOfdmonly	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.48	Enable OFDM-only.
	ruckusZDWLANConfigBSSMinrate	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.49	Set BSS-minrate. If OFDM-only is disabled, the value should be: 0, 1, 2, 5.5, 12, 24 (Mbps). if ODM-only is enabled, the value should be: 0, 12, 24 (Mbps), the default value is 0.
	ruckusZDWLANConfigHideSSID	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.50	Hide SSID; do not broadcast SSID.
	ruckusZDWLANConfigTunnelMode	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.52	Enable Tunnel support capability for the Wireless LAN.
	ruckusZDWLANConfigBackgroundScanning	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.53	Select Background Scanning support capability for the Wireless LAN.
	ruckusZDWLANConfigMaxClientsPerAP	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.55	Select the Number of client devices the AP can service for the Wireless LAN.
	ruckusZDWLANConfigWebAuthentication	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.60	Enable WEP Authentication or not.

## ZoneDirector WLAN Configuration MIBs

### WLAN Configuration MIBs

**TABLE 163** WLAN Configuration MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDWLANConfigRowStatus	1.3.6.1.4.1.25053.1.2.2.2.1.1.1.1.63	Create, Delete Administration control for this Wireless LAN. 1: ACTIVE state, only for read; 4: CREATEANDGO, create a new table; 6: DESTROY, delete an existing table.
ruckusZDWLANGroupConfigTable  (SNMPv3 only)	ruckusZDWLANGroupID	1.3.6.1.4.1.25053.1.2.2.2.1.1.2.1.1	WLAN Group ID. It can't be modified after creating it. Max value: for zd1000 and zd1100, 128; for zd3000, 1024; for zd5000, 2048
	ruckusZDWLANGroupConfigName	1.3.6.1.4.1.25053.1.2.2.2.1.1.2.1.5	Name for this Wireless LAN Group.
	ruckusZDWLANGroupConfigDescription	1.3.6.1.4.1.25053.1.2.2.2.1.1.2.1.6	Description for this Wireless LAN Group.
	ruckusZDWLANGroupVlanOverrideStatus	1.3.6.1.4.1.25053.1.2.2.2.1.1.2.1.8	Enable VLAN Override for the Wireless LAN Group.
	ruckusZDWLANGroupConfigRowStatus	1.3.6.1.4.1.25053.1.2.2.2.1.1.2.1.15	Create, Delete Administration control for this Wireless LAN Group. 1: ACTIVE state, only for read; 4: CREATEANDGO, create a new table; 6: DESTROY, delete an existing table.
ruckusZDWLANGroupCfgAttrTable  (SNMPv3 only)	ruckusZDWLANGroupCfgAttrOverrideType	1.3.6.1.4.1.25053.1.2.2.2.1.1.3.1.3	WLAN group VLAN Override Type.
	ruckusZDWLANGroupCfgAttrWGVlanTag	1.3.6.1.4.1.25053.1.2.2.2.1.1.3.1.4	WLAN group VLAN tag. For set, range is 1-4094. For get,, range is 0-4094. 1: If VLAN ID is 1, packets from this WLAN will be untagged; 0: for node ruckusZDWLANGroupCfgAttrOverrideType is nochange
	ruckusZDWLANGroupCfgAttrRowStatus	1.3.6.1.4.1.25053.1.2.2.2.1.1.3.1.10	Create, Delete Administration control for this Wireless LAN group attr. 1: ACTIVE state, only for read; 4: CREATEANDGO, create a new table; 6: DESTROY, delete an existing table.
ruckusZDHotspotConfigTable  (SNMPv3 only)	ruckusZDHotspotID	1.3.6.1.4.1.25053.1.2.2.2.1.1.8.1.1	Hotspot ID.

**TABLE 163** WLAN Configuration MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDHotspotName	1.3.6.1.4.1.25053.1.2.2.2.1.1.8.1.2	Name for this Hotspot. Can't be modified if created.
	ruckusZDHotspotRedirectLoginPage	1.3.6.1.4.1.25053.1.2.2.2.1.1.8.1.3	Redirect unauthenticated user to this for authentication. It is URL or IP address.
	ruckusZDHotspotRedirectStartURL	1.3.6.1.4.1.25053.1.2.2.2.1.1.8.1.4	After user is authenticated, redirect to this URL if the redirect type is URL.
	ruckusZDHotspotRedirectType	1.3.6.1.4.1.25053.1.2.2.2.1.1.8.1.6	To decide the redirect target. If it is user, redirect to the user intends to visit.
	ruckusZDHotspotRowStatus	1.3.6.1.4.1.25053.1.2.2.2.1.1.8.1.15	Create, Delete Administration control for this Hotspot.
ruckusZDClientIsolationWhiteListTable	ruckusZDClientIsolationWhiteListID	1.3.6.1.4.1.25053.1.2.2.2.1.1.15.1.1	Client Isolation White List ID. It can't be modified after creating it.
	ruckusZDClientIsolationWhiteListName	1.3.6.1.4.1.25053.1.2.2.2.1.1.15.1.5	Name for this Client Isolation White List.
	ruckusZDClientIsolationWhiteListDescription	1.3.6.1.4.1.25053.1.2.2.2.1.1.15.1.6	Description for this Client Isolation White List.
	ruckusZDClientIsolationWhiteListRowStatus	1.3.6.1.4.1.25053.1.2.2.2.1.1.15.1.6	Create, Delete Administration control for this Client Isolation White List.  1. ACTIVE state, only for read;  4. CREATEANDGO, create a new table;  6. DESTROY, delete an existing table.
ruckusZDClientIsolationWhiteListRuleTable	ruckusZDClientIsolationWhiteListRuleID	1.3.6.1.4.1.25053.1.2.2.2.1.1.16.1.1	WLAN Client Isolation White List Rule ID.
	ruckusZDClientIsolationWhiteListRuleDescription	1.3.6.1.4.1.25053.1.2.2.2.1.1.16.1.3	Description for this Client Isolation White List Rule.
	ruckusZDClientIsolationWhiteListRuleMac	1.3.6.1.4.1.25053.1.2.2.2.1.1.16.1.5	MAC address.
	ruckusZDClientIsolationWhiteListRuleDesAddr	1.3.6.1.4.1.25053.1.2.2.2.1.1.16.1.6	IP address.

**ZoneDirector WLAN Configuration MIBs**

## WLAN Configuration MIBs

**TABLE 163** WLAN Configuration MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDClientIsolationWhiteListRuleRowStatus	1.3.6.1.4.1.25053.1.2.2.2.1.1.16.1.10	Create, Delete Administration control for this Wireless LAN group attr.  1. ACTIVE state, only for read;  4. CREATEANDGOcreate a new table;  6. DESTROY, delete a existing table.

# ZoneDirector AAA Configuration MIBs

- ZoneDirector AAA Configuration MIBs Overview..... 99

## ZoneDirector AAA Configuration MIBs Overview

The ZoneDirector AAA Configuration module contains objects for configuration of AAA server objects.

Table 164 lists the node names, OIDs and descriptions of each object in the AAA Configuration MIB tree.

**TABLE 164** ZoneDirector AAA server configuration MIB Tree

MIB Tree	Node Name	OID	Description
ruckusZDAAAConfigTable	ruckusZDAAAConfigID	1.3.6.1.4.1.25053.1.2.2.3.1.1.1.1	AAA Directory Server ID.
	ruckusZDAAAConfigName	1.3.6.1.4.1.25053.1.2.2.3.1.1.1.2	Server name for this AAA or Directory Server. It can't be modified after creating.
	ruckusZDAAAConfigServiceType	1.3.6.1.4.1.25053.1.2.2.3.1.1.1.3	The Service type for this AAA or LDAP/Active Directory server. For current version, active-directory and ldap-directory are not supported (for set).
	ruckusZDAAAConfigRowStatus	1.3.6.1.4.1.25053.1.2.2.3.1.1.1.10	Row Status, Control of Add, Delete of the Directory Server. 1: ACTIVE state, only for read; 4: CREATEANDGO, create a new table; 6: DESTROY, delete an existing table.
ruckusZDAASrvTable	ruckusZDAAARadiusBackupControl	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.5	Enable Primary-Secondary Backup scheme for this RADIUS Server.
	ruckusZDAAARadiusPrimarySvrIpAddress	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.10	The IP(V4 or V6) Address chosen for this RADIUS or Directory Server.
	ruckusZDAAARadiusPrimarySvrPort	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.11	The port number chosen for this RADIUS Server. for auth, the value should be 1812; for account, the value should be 1813.
	ruckusZDAAARadiusPrimarySvrPasswd	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.12	The Password entered for this RADIUS Server.
	ruckusZDAAARadiusSecondarySvrIpAddress	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.15	The IP(V4 or V6) Address for the backup RADIUS Server.
	ruckusZDAAARadiusSecondarySvrPort	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.16	The port number for the backup RADIUS Server.

## ZoneDirector AAA Configuration MIBs

### ZoneDirector AAA Configuration MIBs Overview

**TABLE 164** ZoneDirector AAA server configuration MIB Tree (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDAAARadiusSecondarySrvPasswd	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.17	The Password for the backup RADIUS Server.
	ruckusZDAAARadiusFailoverTimeout	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.20	The timeout in seconds configured for RADIUS Server Failover for the Server.
	ruckusZDAAARadiusFailoverRetry	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.21	The number of reconnect retry configured for RADIUS Server Failover for the Server.
	ruckusZDAAARadiusFailoverReconnectPrimary	1.3.6.1.4.1.25053.1.2.2.3.1.1.2.1.22	The number of seconds configured for RADIUS Server to reconnect to the Primary Server

# ZoneDirector AP Configuration MIBs

• ZoneDirector AP Configuration MIBs Overview.....	101
• AP Configuration MIBs.....	101
• AP LBS Info MIBs.....	103

## ZoneDirector AP Configuration MIBs Overview

The objects contained in the RUCKUS-ZD-AP-MIB.txt file provide Access Point configuration options including AP name, IP address settings, radio settings and mesh settings.

The following tables list the objects within each top-level MIB tree in the RUCKUS-ZD-AP-MIB.txt file.

## AP Configuration MIBs

Table 165 lists the node names, OIDs and descriptions of each object in the AP Configuration MIB tree.

TABLE 165 AP Configuration MIBs

MIB Tree	Node Name	OID	Description
ruckusZDAPConfig (SNMPv3 only)	ruckusZDAPConfigID	1.3.6.1.4.1.25053.1.2.1.1.1.1.1	AP ID.Max value:for zd1000,50;for zd1100,100;for zd3000,500;zd5000,1000 .
	ruckusZDAPConfigMacAddress	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.2	AP MAC Address.
	ruckusZDAPConfigAPModel	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.4	AP Model.
	ruckusZDAPConfigDeviceName	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.5	AP Name.
	ruckusZDAPConfigDescription	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.6	AP Description.
	ruckusZDAPConfigLocation	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.7	AP Location.
	ruckusZDAPConfigGpsLatitude	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.10	The AP GPS location measured. the range is '-90,90'.
	ruckusZDAPConfigGpsLongitude	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.11	The AP GPS location measured. the range is '-180,180'.
	ruckusZDAPConfigIPVersion	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.14	The AP IP version.
	ruckusZDAPConfigIpAddressSettingMode	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.15	"The AP IP address configuration setting control.
	ruckusZDAPConfigIpAddress	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.16	The AP IP address.
	ruckusZDAPConfigIpAddressMask	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.17	The AP IP address mask.
	ruckusZDAPConfigGatewayIpAddress	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.20	The AP Gateway IP Address.
	ruckusZDAPConfigIpV6AddressSettingMode	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.21	"The AP IPV6 address configuration setting control.
	ruckusZDAPConfigIpV6Address	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.22	The AP IPV6 address.

## ZoneDirector AP Configuration MIBs

### AP Configuration MIBs

**TABLE 165** AP Configuration MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDAPConfigIpV6PrefixLen	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.23	The AP IPV6 prefix length.
	ruckusZDAPConfigGatewayIpV6Address	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.24	The AP Gateway IPV6 Address.
	ruckusZDAPConfigPrimaryDnsIpAddress	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.25	The AP Primary DNS IP Address.
	ruckusZDAPConfigSecondaryDnsIpAddress	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.26	The AP Secondary DNS IP Address.
	ruckusZDAPConfigPrimaryDnsIpv6Address	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.27	The AP Primary DNS IPV6 Address.
	ruckusZDAPConfigSecondaryDnsV6IpAddress	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.28	The AP Secondary DNS IPV6 Address.
	ruckusZDAPConfigRadioType	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.30	The AP Wireless type.
	ruckusZDAPConfigRadioChannel24	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.31	"The AP Channel selection on the 2.4 GHz radio.
	ruckusZDAPConfigRadioTxPowerLevel24	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.32	The AP Tx Power level selection on the 2.4 GHz radio.
	ruckusZDAPConfigRadioWlanGroup24	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.33	The AP WLAN group (name) selection on the 2.4 GHz radio.
	ruckusZDAPConfigRadioEnableWlanService24	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.34	The AP enable wlan service flag on the 2.4 GHz radio.
	ruckusZDAPConfigRadioChannel5	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.40	"The AP Channel selection on the 5 GHz radio.
	ruckusZDAPConfigRadioTxPowerLevel5	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.41	The AP Tx Power level selection on the 5 GHz radio.
	ruckusZDAPConfigRadioWlanGroup5	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.42	The AP WLAN group (name) selection on the 5 GHz radio.
	ruckusZDAPConfigRadioEnableWlanService5	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.43	The AP enable wlan service flag on the 5 GHz radio.
	ruckusZDAPConfigMeshConfigurationMode	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.50	The AP Mesh network configuration mode.
	ruckusZDAPConfigUplinkSelectionMode	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.51	The AP network uplink selection mode.For manual,now 'set' is not supported.
	ruckusZDAPConfigApproveMode	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.52	AP approval state. For not-approved,'set' is not supported.
	ruckusZDAPConfigManagementAdmin	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.60	Admin action to remove this AP from the ZD management.
	ruckusZDAPConfigAutoReboot	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.62	Enable AP auto reboot.
	ruckusZDAPConfigAutoRebootPeriod	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.63	AP auto reboot period.

**TABLE 165** AP Configuration MIBs (continued)

MIB Tree	Node Name	OID	Description
	ruckusZDAPConfigRebootNow	1.3.6.1.4.1.25053.1.2.2.4.1.1.1.1.64	AP reboot right now.

## AP LBS Info MIBs

Table 166 lists the node names, OIDs and descriptions of each object in the AP LBS Info MIB tree.

**TABLE 166** AP LBS Info MIBs

MIB Tree	Node Name	OID	Description
ruckusZDAPLBSVenueTable	ruckusZDAPLBSAPGroupID	1.3.6.1.4.1.25053.1.2.2.4.1.2.1.1.1	ID of the AP Group referenced to a venue. Max value:for zd1000,8;for zd1100,32;for zd3000,256; for zd5000,512.
	ruckusZDAPLBSVenueName	1.3.6.1.4.1.25053.1.2.2.4.1.2.1.1.2	Venue Name.
	ruckusZDAPLBSVenueAPGrpName	1.3.6.1.4.1.25053.1.2.2.4.1.2.1.1.3	AP group name referenced by this venue.
	ruckusZDAPLBSVenueLSConnection	1.3.6.1.4.1.25053.1.2.2.4.1.2.1.1.4	LS connection status.
	ruckusZDAPLBSVenue24GMode	1.3.6.1.4.1.25053.1.2.2.4.1.2.1.1.5	2.4 G band mode.
	ruckusZDAPLBSVenue5GMode	1.3.6.1.4.1.25053.1.2.2.4.1.2.1.1.6	5 G band mode.



# Appendix - Changes in This Version

- MIB Changes in 10.4.1..... 105
- ZoneDirector SNMP MIB Changes..... 105

## MIB Changes in 10.4.1

The following tables list the node name and OID changes in version 10.4.1.

For a list of changes between version 10.4 and earlier versions, see the *ZoneDirector 10.4 SNMP Reference Guide*, "Appendix - Changes in this Version" section.

## ZoneDirector SNMP MIB Changes

The following section lists the changes in ZoneDirector SNMP MIBs between version 10.4 and 10.4.1.

### ZD Products MIB Changes

The following table lists the changes in the RUCKUS-ZD-PRODUCTS-MIB.txt file in this version.

MIB Tree	OID	Node Name	Change
ruckusWirelessHotzoneProducts	1.3.6.1.4.1.25053.3.1.4.115	ruckusR850	New in 10.4.1
	1.3.6.1.4.1.25053.3.1.4.116	ruckusT750SE	New in 10.4.1

### ZD WLAN MIB Changes

The following table lists the changes in the RUCKUS-ZD-WLAN-MIB.txt file in this version.

MIB Tree	OID	Node Name	Change
RuckusZDWLANAPRadioStats	1.3.6.1.4.1.25053.1.2.2.1.1.2.2.1.3	ruckusZDWLANAPRadioStatsRadioType	Updated syntax to: SYNTAX INTEGER { radio11bg (0), radio11a (1), radio11ng(2), radio11na(3), radio11ac(4), radio11axg(6), radio11axa(7) }
ruckusZDWLANStaInfo	1.3.6.1.4.1.25053.1.2.2.1.1.3.1.1.6	ruckusZDWLANStaRadioType	Updated syntax to: SYNTAX INTEGER { radio11a (0), radio11b (1), radio11g(2), radio11ng(3), radio11na(4), radio11ac(5), radio11axg(6), radio11axa(7) }



© 2020 CommScope, Inc. All rights reserved.  
350 West Java Dr., Sunnyvale, CA 94089 USA  
<https://www.commscope.com>